User Guide





Contents

Getting Started with Your Phone	4
Phone Overview	4
Menu Overview	
Icon Reference	15
Feature Overview	19
The Battery	
Turning the Phone On and Off	
Making a call	
Answering a call	
Menu Access	
Using a Memory Card	
Connecting to the Headset Jack	34
Quick Access to Convenient Features	35
Vibrate Mode	35
Mute Function	
Volume Quick Adjustment	
Speakerphone	
Flashlight	
Operating Your Handset with the Flip Closed	37
Entering and Editing Information	39
Text Input with the Flip Open	
Text Input with the Flip Closed	
Text input with the Filp Glosed	
RECENT CALLS	44
Accessing the Recent Calls submenu	44
Making a Call from Recent Calls	45
Viewing Recent Call History	
View Timers	46
CONTACTS	47
Adding a new Contact from idle mode	
Adding a Phone Number to an Existing Contact	
Phone Numbers with Pauses	
Accessing the Contacts submenu	
New Contact	

Contents

Contact List	52
Favorites	54
Groups	55
New PTT Contact	56
PTT Contact List	57
PTT Groups	58
Temp PTT Group	59
Backup Assistant	60
Speed Dials	60
In Case of Emergency (ICE)	63
My Name Card	64
Push to Talk	65
About Push to Talk	65
Making a PTT Call	66
Incoming PTT Call	70
MEDIA CENTER	71
Music & Tones	71
Picture & Video	78
Games	94
Mobile Web	95
Browse & Download	97
Extras	98
My Documents	99
Info	100
MESSAGING	
Accessing the Messaging submenu	101
New Message Alert	101
New Message	102
Messages	107
Drafts	
Voicemail	
Visual Voice Mail	
Mobile IM	111
Email	112

Chat	112
Message Settings	112
Message Erase	114
SETTINGS & TOOLS	115
My Verizon	115
Tools	115
USB Mass Storage	124
Bluetooth	125
External Keyguard Settings	133
Sounds Settings	135
Display Settings	139
Phone Settings	147
Call Settings.	156
Memory	161
USB Mode	163
Phone Info	163
Set-up Wizard	166
	40-
Safety	
TIA Safety Information	
Safety Information for FCC RF Exposure	
FDA Information	
Emergency Calls	
Compliance with Other FCC Regulations	
General Safety	
Games	
Camera	
Accessibility	
RECYCLE YOUR CELL PHONE!	195
12 MONTH LIMITED WARRANTY	407
12 MONTH LIMITED WARRANTY	197
Index	201

Getting Started with Your Phone

Phone Overview









* For best performance, do not touch these areas when using your handset.

1. Internal Display

2. QWERTY Keypad

Press to enter numbers, letters, and characters using a full QWERTY keypad interface.

3. Left Soft Key

Press to display the Message menu, or to access the function listed above the key.

4. ☑ / ☑ Message Composer Key

Press to access the New TXT Message menu.

5. Speakerphone/Caps Key

From idle mode, press to turn the speakerphone on/off. When entering text, press to change between uppercase and lowercase letters.

6. Fn Function Key

From idle mode, press the Function Key [6] followed by the desired key with the symbol you would like to enter.

7. Right Soft Key

Press to display Contacts, or to access the function listed above the key.

8. Directional Key

Allows you to scroll through phone menu options and provides a shortcut to phone functions from idle mode.

9. O Center Select Key

Press to access the MENU in idle mode. It also allows you to accept choices when navigating through a menu.

10. ☐ AF Lock/Return Key

In Take Picture mode, press to automatically focus on and lock into your subject. In text entry mode, press to insert a carriage return.

11. CLR 1 / CLR 1 Clear/Voice Commands Key

From idle mode, press to access Voice Commands or press and hold to access the Sound Recorder function. When entering text or a phone number, press to delete a single space or character, or press and hold to delete an entire word. Within a menu, press to return to the previous menu.

12. END / END () End/Power Key

Press and hold to turn your handset on/off or press to end a call or browser session. Within a menu, press to return to idle mode.

13. Z Vibration Key

From idle mode, press and hold to activate/deactivate Vibrate Mode.

14. Camera Key

From idle mode, press and hold to access the built-in camera.

15. Video Key

From idle mode, press and hold to access the camcorder.

16. SPACE Space/PTT Key

In text entry mode, press to insert a space. It is also used as a substitute PTT when the handset is in PTT mode and the flip is open.

17. SEND / SEND Send Key

Press to place or answer a call, or from idle mode press to access the All Calls list.

18. Charging/Data Port

Plug in the Wall Charger or USB Cable (sold separately).

19. Red Side Key/PTT Key

In PTT Mode, press to access the PTT Contact List or press and hold to make a PTT Call. When not in PTT Mode, press to access the selected shortcut application.

20. **◄** ▶ Volume Keys

From idle mode, press to adjust the master volume. During a call, press to adjust voice volume.

21. Music Key

From idle mode, press for quick access to My Music. In Take Picture mode, press to capture an image. In Record Video mode, press to record a video.

22. Headset Jack

2.5mm connector port

23. Earpiece

24. Charge Indicator

Appears red when charging. When charging completes, the red indicator turns off.

25. External Display

26. Camera/Video Key

From idle mode, press to access the built-in camera. Press and hold to access the camcorder.

27. 1 P Voicemail Key

From idle mode, press and hold to connect to your voicemail.

28. Alphanumeric Keypad

Use to enter numbers, letters and symbols, and to select menu items.

29. * Shift Key

Press to enter an asterisk (*) character for calling features. When entering text, press to change the character input type. When making an international call, press and hold to enter a "+" sign for international dialing.

30. O Next Key

In T9 Word mode, press to display other matching words.

31. 🗷 Favorites Key

From idle mode, press for easy access to the Favorites List.

32. Speakerphone/Flashlight Key

From idle mode, press to turn the Speakerphone on or off. Press and hold to activate/dectivate the Flashlight.

33. # space Vibration Key

From idle mode, press and hold to activate/deactivate vibrate mode. Press to enter the (#) character for calling features. In text entry mode, press and hold to accept a word and add a space.

- 34. Speaker
- 35. Microphone
- 36. Internal Antenna Area
- 37. Camera Flash/Flashlight
- 38. Camera/Camcorder Indicator

Blinks green in the Take Picture mode and Record Video mode and turns red when taking a picture or while recording video.

- 39. Battery Cover Lock
- 40. Camera/Camcorder Lens
- 41. Secondary Microphone
- 42. Battery Cover
- 43. Memory Card Slot

Insert a microSD™ memory card (sold separately) under the battery to increase memory capacity.

44. Charging Terminals

NOTE

This guide gives navigation instructions according to the defaults, Main Menu Settings are set to Grid and Messaging, and Display Themes is set to Punching Metal. If other settings or themes are set, navigating the phone's menus may be different.

Menu Overview



Mobile IM



Messaging

- 1. New Message
 - 1. TXT Message
 - 2. Picture Message
 - Video Message
 - 4. Voice Message
- 2. Messages*
- 3. Drafts
- 4. Voicemail
- 5. Visual Voice Mail
- 6. Mobile IM
- 7. Email
- 8. Chat



Recent Calls

- 1. Missed
- 2. Received
- 3. Dialed
- 4. Blocked**
- 5. AII

6. View Timers



Contacts

- 1. New Contact
- 2. Contact List
- 3. Favorites
- 4. Groups
- 5. New PTT Contact***
- 6. PTT Contact List***
- 7. PTT Groups***
- 8. Backup Assistant
- 9. Speed Dials
- 0. In Case of Emergency
- Q. My Name Card



Media Center

- 1. Music & Tones
 - 1. V CAST Music I Rhapsody
 - 2. Get New Ringtones
 - 3. My Ringtones
 - 4. My Music
- * When By Time is selected for Messages View in Message Settings, the Inbox folder and Sent folder will appear in the Messaging submenu instead of the Messages folder.
- ** Blocked appears only when Contacts Only or Block All is selected for Calls under MENU > Settings & Tools > Phone Settings > Security > Restrictions > Calls > Incoming Calls.
- *** These options are available only when the PTT feature is turned on.

- 5. My Sounds
- 6. Sync Music

2. Picture & Video

- 1. V CAST Videos
- 2. Get New Pictures
- 3. My Pictures
- 4. My Videos
- 5. Take Picture
- 6. Record Video
- 7. Online Album

3. Games

- 1. Get New Applications
- 4. Mobile Web

5. Browse & Download

1. Get New Applications

6. Extras

- 1. Get New Applications
- 7. My Documents

@Email

- 1. Mobile Email
- 2. Corporate Email
- 3. Mobile Web Mail



VZ Navigator



My Verizon



Settings & Tools

- 1. My Verizon
- 2. Tools
 - 1. Voice Commands

- 2. Calculator
- 3. Calendar
- 4. Alarm Clock
- 5. Stop Watch
- 6. Countdown Timer
- 7. World Clock
- 8. Notepad
- 9. USB Mass Storage

3. Bluetooth

- 1. Add New Devices
- 4. External Keyguard Settings
 - 1. Keyguard Timer
 - 2. Unlock Options

5. Sounds Settings

- 1. Easy Set-Up
- 2. Call Sounds
 - 1. Call Ringtone
 - 2. Call Vibrate
 - 3. Caller ID Readout
- 3. Alert Sounds
 - 1. TXT Message
 - 2. Multimedia Message
 - 3. Voice Mail
 - 4. Emergency Tone
 - Missed Call
 - 6. PTT Alert
- 4. Keypad Volume
- 5. Digit Dial Readout
- Service Alerts
 - 1. ERI
 - 2. Minute Beep

- 3. Call Connect
- 7. Power On/Off
 - 1. Power On
 - 2. Power Off

6. Display Settings

- 1. Easy Set-Up
- 2. Banner
 - 1. Personal Banner
 - 2. ERI Banner
- 3. Backlight
 - 1. Display
 - 2. Keypad
- 4. Wallpaper
 - 1. My Pictures
 - 2. My Videos
 - 3. Fun Animations
- 5. Display Themes
- 6. Main Menu Settings
 - 1. Menu Layout
 - 2. Replace Menu Items
 - 3. Position Menu Items
 - 4. Reset Menu Settings
- 7. Dial Fonts
- 8 Menu Font Size
- 9. Clock Format
 - 1. Main Clock
 - 2 Front Clock

7. Phone Settings

- 1. Airplane Mode
- 2. Set Shortcuts

- 1. Set My Shortcuts
- Set Internal Directional Keys
- 3. Set Qwerty Shortcut
- 4. Set Red Side Key****
- Voice Commands Settings
- 4. Language
- 5. Location
- 6. Current Country
- 7. Security
 - 1. Edit Codes
 - 1. Phone Only
 - 2. Calls & Services
 - 2. Restrictions
 - 1. Location Setting
 - 2. Calls
 - 3. Messages
 - 4. Dial-Up Modem
 - 3. Phone Lock Setting
 - Lock Phone Now
 Restore Phone
- 8. System Select
- 9. NAM Selection

8. Call Settings

- 1. Answer Options
- 2. End Call Options
- 3. Auto Retry
- 4. TTY Mode
- 5. One Touch Dial

^{****} This option is available only when the PTT feature is turned off.

- 6. Voice Privacy
- 7. PC Connections
- 8. DTMF Tones
- 9. PTT Mode
- 0. Assisted Dialing

9. Memory

- 1. Save Options
 - 1. Pictures
 - 2. Videos
- 3. Sounds
- 2. Phone Memory
 - 1. Memory Usage
 - 2. My Pictures
 - 3. My Videos
 - 4. My Ringtones
 - 5. My Music
 - 6. My Sounds
 - 7. My Contacts
 - 8. My Documents
 - 9. Move All To Card
- 3. Card Memory****
 - 1. Memory Usage
 - 2. My Pictures
 - 3. My Videos
 - 4. My Ringtones
 - 5. My Music
 - 6. My Sounds
 - 7. My Contacts
 - 8. My Documents

- 9. Move All To Phone
- 0. USB Mode
- Q. Phone Info
 - 1. My Number
 - i. My Mullibei
 - 2. SW/HW Version
 - 3. Icon Glossary
 - 4. Software Update

W. Set-up Wizard

^{****} This option is available only when a memory card (sold separately) is inserted in the handset.

External Display Menu Displayed with the Flip Closed

1. Messaging

- 1. New TXT Msg
- 2. Messages*
- 3. Drafts

2. Contacts

- 1. New Contact
- 2. Contact List
- 3. Favorites
- 4. PTT Contact**

3. Recent Calls

- 1. Missed
 - 2. Received
- 3. Dialed
- 4. Blocked***
- 5. All

4. Bluetooth

- 1. Add New
- 2. Pair

- 3. BT Settings
 - 1. Turn On/Turn Off
 - Discovery On/ Discovery Off

5. Keyguard

- 1. Lock Now
- 2. Keyguard Timer
- 3. Unlock Option

6. Media

- 1. My Music
 - 1. Play All
 - 2. Shuffle
 - 3. Playlists
 - 4. Songs
- 2. Record New

- * When By Time is selected for Messages View in Message Settings, the Inbox folder and Sent folder will appear in the Messaging submenu instead of the Messages folder.
- ** These options are available only when the PTT feature is turned on.
- *** Blocked appears only when Contacts Only or Block All is selected for Calls under MENU > Settings & Tools > Phone Settings > Security > Restrictions > Calls > Incoming Calls.

NOTE

Icon Reference

Screen Icons

When the handset is turned on, the top line of the internal display displays icons indicating the status of the handset.

	-
DIIII	Digital indicator. Digital service is available.
3G	3G service indicator. 3G service is available.
1X	1x service indicator. 1x service is available.
® 0FF	Airplane Mode
•	Battery Strength indicator. Indicates battery level. The more bars, the stronger the charge.
Ō	In Call State. A call is in progress. * No icon shows when the handset is in idle mode.
	Data Session
⊕))	Location On Mode
⊕	E911 Only Mode
Ø	No Service indicator. Indicates the handset cannot receive a signal from the system.
Р	Voice Privacy
	Roaming indicator. The handset is outside of the home service area.
S	SSL (Secure Sockets Layer) is a protocol developed by Netscape Communications that uses encryption to secure data through the public Internet from client to server.
	TTY mode On
*	Indicates Bluetooth® mode is active.
∦ €	Indicates Bluetooth® is connected to another device.
*≠	Bluetooth® Discovery Mode
₽	Voice Commands (Active)

₽	Voice Commands (Listening)
1X	1x and PTT services are available.
3G	3G and PTT services are available.
	PTT in use. A PTT call is in progress.
Ø	Alarm Only
(=)	Vibrate Only
Ø	Sound Off
	Appears when an alarm is set.
	Appears when a Calendar event is set.
4	Indicates you have missed calls.
\vee	Indicates you have a new message.
2)	Indicates you have a new voicemail.
4)	Indicates Speakerphone mode is active.

Recent Call Icons

The following icons are displayed in the Recent Calls lists (Missed, Received, Dialed, and All):

	Indicates a dialed call.
	Indicates a received call.
×	Indicates a missed call.
1	Mobile 1
2	Mobile 2
	Home
RŽ.	Work
	Email 1
	Email 2

97	Group
ÖĪ	Picture
	Ringtone
P	IM Screen Name
AIM	AIM
Y !	Yahoo!
E	WL Messenger
= '	Address
+	In Case of Emergency

Message Icons

The following icons are displayed in the list of received messages:

\searrow	New/Unread Text or Web Messages
	Opened/Read Text or Web Messages
	New/Unread Picture/Video/Voice Notifications
	Opened/Read Picture/Video/Voice Notifications
□	Unread Downloaded Picture/Video/Voice Messages
	Opened/Read Downloaded Picture/Video/Voice Messages
•	Priority
த	Locked Messages

The following icons are displayed in the list of sent messages:

	Sent Messages
	Delivered Messages
×	Sent failed Messages
	Incomplete Delivery Messages
	Pending Messages

The following icons are displayed in the Drafts message list:

Æ	Draft Text
	Draft Pictures/Videos/Voices

PTT Screen Icons

The following icons are displayed on the incoming/outgoing PTT call screen or the PTT calls in the Recent Calls list:

O C	Received calls list - individual
Ť	Received calls list - group
a	Dialed calls list - individual
	Dialed calls list - group
0	[Number of] Missed calls
	Connecting to [individual name]
	Connected to [individual name]
	Connecting to [group name]
	Connected to [group name]
	Talking to [individual name]
	Talking to [group name]
(3)	Listening to [individual name]
3	Listening to [group name]
3 9	Alerting [individual name]
©	PTT Individual available
(3)	PTT Group available
X	PTT unavailable

Bluetooth® Icons

P	When an audio device is paired with your handset
	When a PC is paired with your handset
S	When a PDA is paired with your handset
= >	When another handset is paired with your handset

When successfully connected, the following icons may appear:

№ >	When a headset is connected with your handset
8	When a device is paired with your handset

Feature Overview

Water Resistance

The Brigade is water resistant. It provides reliable performance for outdoor activities, and in wet conditions such as driving rain or high humidity.

The tested device meets the requirements of the MIL-STD-810F (Rain & immersion 1m, 30min) standard.

Warning!

The Water Resistance feature does not guarantee protection against the usage of this device under the water. Do not use the handset in water.

NOTES

To maintain water resistance:

- Securely fasten the Charging/Data Port cover and the Headset Jack cover.
- Completely close the battery cover and slide the Battery Cover Lock to the LOCK position.

Shock Resistance

The rugged construction of the Brigade provides outstanding shock and vibration resistance. The tested device meets the requirements of the MIL-STD-810F (Drop 1.5m) standard.

Warning!

The shock and vibration resistance features do not guarantee protection against every type of shock and vibration. Your handset may be damaged or malfunction depending on the severity of received shock or vibration.

Dust Resistance

For additional peace of mind, the Brigade is also dust resistant. The device was tested using silica flour at a temperature of 95F and meets the MIL-STD-810F (Dust) standard.

NOTES

- Your handset can be rinsed with clean water when dirty. To ensure water resistance, make sure that all covers are securely closed before rinsing.
- Periodically, clean the Charging Terminals and the Battery
 Terminals with a dry cloth or cotton swab. Dust may cause some
 electrical connection problems. Avoid wiping with excessive
 force, which can damage the terminals.



Warning!

- Do not clean terminals inside the handset, or they may be damaged.
- If mud or sand has adhered to the handset, do not use it until wiping off completely.
- Do not place the handset directly on a sand beach. If sand gets into the Earpiece or Speaker, sounds may be difficult to hear.
 Sand getting into the handset's hinge can cause mechanical failures such as heat generation.

The Battery

The handset comes with a rechargeable battery.

Warning!

- Use only approved batteries for the Brigade. Wipe your handset before opening the battery cover to prevent moisture or dust from entering.
- Failure to follow the below directions for installing/removing the battery could result in product failure.
- Fully charge the battery before using the handset for the first time.

Installing the Battery

Warning!

- Do not install the battery where water or liquid may fall directly on the handset or battery or in a humid place such as a bathroom.
 Otherwise, the electrical circuits may short or erode and cause the handset to malfunction
- When removing the battery cover with a fingernail, the nail can be broken.

 Slide the Battery Cover Lock to the FREE position in the direction of the arrow shown in the figure to the right.



 Insert your fingertip into the recess ①, and then pull the battery cover up in the direction indicated in the figure to the right ②.



3. Slide the battery into the slot by aligning the contacts and tabs ① and press down ② until you hear the "click".



4. Place the battery cover properly on the handset, then press down firmly on the side of the battery cover at each arrow point, as shown to the right.



5. Slide the Battery Cover Lock to the LOCK position in the direction of the arrow shown in the figure to the right.



Warning!

If you are using a wrist strap (sold separately), be careful not to get it caught between the battery cover and the handset, in order to maintain waterproofing.

Removing the battery

 Slide the Battery Cover Lock to the FREE position in the direction of the arrow shown in the figure to the right.



 Insert your fingertip into the recess ①, and then pull the battery cover up in the direction indicated in the figure to the right ②.



3. Remove the battery by pulling up on the tab ①.



Warning!

- Do not leave the removed battery near heat sources such as a flame, stove, or in direct sunlight. Otherwise, it may burst, malfunction, or ignite -causing fire. Do not hit, or exert excessive shock on the battery, as it can ignite or break.
- When removing the battery cover with a fingernail, the nail can be broken.

Charging the Battery

To charge your battery:


 Connect the Wall Charger to the Handset Charging Cradle (included in box).

- 2. Plug the Wall Charger power plug into an electrical outlet.
- **3.** Insert the handset into the Handset Charging Cradle.



Warning!

- Hold the Wall Charger power plug horizontally and carefully insert it into the Handset Charging Cradle.
- Whenever placing the handset into or removing it from the Handset Charging Cradle, hold the cradle steady as shown in the figure to the right. Slide the handset along the guides on the charging cradle's back for support.



 Do not connect the Wall Charger to the Charging/Data Port when a handset is charging in the charging cradle. Damage or overheating may result.

Charging the battery by directly connecting the Wall Charger

You can also charge the battery by directly connecting the Wall Charger to the handset's Charging/Data Port and plugging the power plug into an electrical outlet.

 To open the Charging/Data Port cover, insert your finger tip into the notch and open the cover.



Plug the Wall Charger power plug into an electrical outlet and the Wall Charger connector into the Charging/ Data Port.



After the handset is completely charged, unplug the Wall Charger connector and close the Charging/Data Port cover.



Warning!

- Make sure the port cover is completely closed.
- Do not forcibly insert the Wall Charger power plug into the Charging/Data Port. Hold it horizontally and carefully insert it into the Charging/Data Port.
- Failure to completely reseal the Charging/Data Port cover after charging may allow liquids to enter the casing, and damage the handset.

Battery Level

The battery level icon appears at the top of the display. When the battery level becomes low, the low battery sensor alerts you in three ways: an audible tone will sound, the battery icon will begin to blink, and **BATTERY LOW** will appear on the display. If the battery level becomes too low, the phone automatically powers off and any function in progress will not be saved.



Fully Charged

Fully Depleted

NOTE

Charging time varies depending upon the battery level.

Turning the Phone On and Off

Turning the Phone On

 With the flip either open or closed, press and hold the End/Power Key until the display lights up.

NOTE

Avoid any unnecessary contact with the internal antenna area while your handset is on.

Turning the Phone Off

 With the flip either open or closed, press and hold the End/Power Key until the display turns off.

Making a call

- With the flip closed, to unlock the handset, press the Center Select Key, and then press (0,20) at the prompt.
- 2. Enter a phone number (include the area code if needed).
- 3. Press the Send Key to make the call.
- 4. Press the End/Power Key to end the call.

NOTE

When you place a call with the flip open, the phone automatically goes to Speaker On which enables speakerphone.

Correcting Dialing Mistakes

If you make a mistake while dialing a number, press the Clear Key $\underbrace{\text{cur \pm}}/\text{cur \pm} \text{ once to erase the last digit entered, or press and hold the Clear Key } \text{cur \pm}/\text{cur \pm} \text{ to delete all digits.}$

Redialing Call

- With the flip closed, to unlock the handset, press the Center Select Key, and then press at the prompt.
- 2. Press the Send Key twice to redial the last number.

Answering a call

NOTES

- The default answer option is set to Flip Open and Any Key so you can directly answer an incoming call by simply opening the handset or pressing any key. For information on how to select an answer option, see page 156.
- When you receive a call with the flip open, the phone automatically goes to Speaker On which enables speakerphone.
- Caller ID displays the number of the person calling when your phone rings. If the caller's identity is stored in Contacts, the name appears on the screen.
- When the phone rings or vibrates, with the flip closed, press the Send Key to answer the incoming call.
- 2. Press the End/Power Key to end the call.

NOTES

- When you ignore an incoming call by pressing the Center Select Key [Options] and (2 ABD) Ignore with the flip closed, you are prompted whether to send a text message to a caller. Selecting Yes and pressing the Center Select Key [OK] displays the Quick Text list. You can select an appropriate text phrase from the list and press the Center Select Key [OK] to create a text message to a caller.
- When you ignore an incoming call by pressing the Right Soft Key [Ignore] with the flip open, you are prompted whether to send a text message to a caller. Selecting Yes and pressing the Center Select Key [OK] displays the Quick Text list. You can select an appropriate text phrase from the list and press the Center Select Key [OK] to create a text message to a caller. For how to create a text message, see page 102.

Call Waiting

If you are on a call and you receive another incoming call, you will hear two beeps. With Call Waiting, you may put the active call on hold while you answer the incoming call. To use Call Waiting:

- With the flip either open or closed, to answer another call while on the phone, press the Send Key. This places the first call on hold.
- 2. To switch back to the first caller, press the Send Key again.

Menu Access

To display the Main Menu from idle mode with the flip open, press the Center Select Key [MENU].

To use the menu:

- Press the Directional Key up, down, left or right to select your desired menu item then press the Center Select Key [OK].
- Or enter the number or letter that corresponds to the menu or submenu item.

There are three Main Menu types: Tab, List, and Grid.

NOTES

- All directions in this manual assume that Main Menu Settings are set to Grid and Messaging, and Display Themes is set to Punching Metal, which are the default settings. If other settings or themes are set, navigating the phone's menus may be different.
- For information about how to switch between Main Menu types, see page 143.

Grid Menu

The Grid Menu has nine items.

- From idle mode with the flip open, press the Center Select Key [MENU].
- Press the Directional Key up, down, left or right to select your desired menu option then press the Center Select Key [OK].

NOTE

When navigating within menus and submenus or when configuring your handset's settings, you can return to the previous screen or step by pressing the Clear Key CLR **. To return to idle mode, press the End/Power Key.

Selecting Menu with the Flip Closed

When you press the Center Select Key from idle mode with the flip closed, the external display Menu will always appear in the list layout regardless of the menu layout selected in the Main Menu Settings.

- With the flip closed, to unlock the handset, press the Center Select Key, and then press (1.6) at the prompt.
- 2. Press the Center Select Key.
- **3.** Press the Directional Key 🗘 up or down to select one of the following menu options, and then the Center Select Key.

Messaging/Contacts/Recent Calls/Bluetooth/Keyguard/Media

Using a Memory Card

The Brigade supports the use of a microSD™ memory card as a source of external memory.

NOTE

The microSD™ memory card is sold separately.

Installing a Memory Card

Warning!

- Whenever installing or removing a memory card, make sure the handset is turned off and that the Wall Charger is not connected.
- When installing or removing a memory card, avoid touching the memory card contacts and avoid damaging the memory card.
 Either can cause malfunction or loss of data.
- The front and back of the memory card look different. When inserting the memory card, make sure the correct side is facing up. If not, the memory card may not fit in the memory card slot, or the memory card and/or memory card slot may be damaged.



Insert like this.

- Do not forcibly insert the memory card into the memory card slot. Hold it with the contacts facing down and carefully insert it.
- Failure to completely reseal the battery cover after installing may result in damage if the handset is exposed to water.
- When removing the battery cover with a fingernail, the nail can be broken.
- Slide the Battery Cover Lock to the FREE position in the direction of the arrow shown in the figure to the right.



 Insert your fingertip into the recess ①, and then pull the battery cover up in the direction indicated in the figure to the right ②.



3. Remove the battery by pulling up on the tab ①.



4. Carefully press the memory card into the memory card slot until it locks into place.



Install the battery and replace the battery cover ensuring that you slide the Battery Cover Lock to the LOCK position.

Removing a Memory Card

Warnina!

- Never remove a memory card from the handset while it is being accessed. Doing so can damage the memory card or the data stored on it
- The memory card is very small. Make sure you do not drop it.
- Failure to completely reseal the battery cover after removing may result in damage if the handset is exposed to water.
- When removing the battery cover with a fingernail, the nail can be broken.
- Slide the Battery Cover Lock to the FREE position in the direction of the arrow shown in the figure to the right.



 Insert your fingertip into the recess ①, and then pull the battery cover up in the direction indicated in the figure to the right ②.



3. Remove the battery by pulling up on the tab 1.



4. Gently press the memory card inward, until it pops out. Remove the memory card.





Install the battery and replace the battery cover ensuring that you slide the Battery Cover Lock to the LOCK position.

Connecting to the Headset Jack

You can connect a compatible device equipped with a standard 2.5mm plug to your handset for safe, convenient, hands-free conversations.

- To open the Headset Jack cover, insert your finger tip into the notch and open the cover.
- **2.** Plug the connector into the Headset Jack.



Warning!

- Do not forcibly insert/remove the connector into/from the Headset Jack. Carefully insert/remove it.
- Failure to completely reseal the Headset Jack cover after use may result in damage if the handset is exposed to water.

Quick Access to Convenient Features

Vibrate Mode

Vibrate Mode mutes key tones and activates an alert for an incoming call or message.

To activate and deactivate Vibrate Mode:

- From idle mode with the flip open, press and hold the Vibration Key
 to activate Vibrate Mode.
- To deactivate Vibrate Mode, press and hold the Vibration Key again.

NOTE

With the flip closed, to unlock the handset, press the Center Select Key, and then press **O** at the prompt. Next, press and hold the Vibration Key **#** spector of a gain, to deactivate Vibrate Mode.

Mute Function

If you activate the mute function during a call with the flip open, the person you are speaking with cannot hear you or any sounds from your handset. However, you are still able to hear them. To activate Mute:

- 1. During a call, press the Left Soft Key [Mute].
- 2. To unmute, press the Left Soft Key [Unmute].

NOTE

To activate Mute with the flip closed:

- During a call, press the Center Select Key [Options] on the front of the handset.
- 2. Select Mute, then press the Center Select Key.
- To unmute, press the Center Select Key [Options], select Unmute, then press the Center Select Key.

Volume Quick Adjustment

- With the flip closed, to unlock the handset, press the Center Select Key, and then press (1.6) at the prompt.
- Press the Volume Keys up or down to select from: All Sounds Off, Alarm Only, Vibrate Only, Low, Medium Low, Medium, Medium High and High.
- 3. Press the Center Select Key to save.

NOTES

- With the flip closed, to unlock the handset, press the Center Select Key, and then press () at the prompt. Next, press and hold the Volume Key Down to enable Sounds Off mode. Sounds Off mode turns off all phone sounds. Press and hold the Volume Key Up to revert to Normal Mode.
- With the flip open, you can also adjust the volume by pressing the Volume Keys ().
- The keypad volume is adjusted through the Menu. For more details, see page 138.

Speakerphone

To activate and deactivate the speakerphone with the flip open:

1. To activate, press the Speakerphone Key [to turn SPEAKER ON.

To deactivate, press the Speakerphone Key again to turn SPEAKER OFF.

NOTE

To activate and deactivate the speakerphone with the flip closed:

- With the flip closed, to unlock the handset, press the Center Select Key, and then press () at the prompt.
- 2. To activate, press the Speakerphone/Flashlight Key (3).
- 3. To deactivate, press the Speakerphone/Flashlight Key (3) again.

Flashlight

To activate and deactivate the flashlight with the flip closed:

- With the flip closed, to unlock the handset, press the Center Select Key, and then press at the prompt.
- Press and hold the Speakerphone/Flashlight Key (3) to turn FLASH ON.
- From idle mode with the flip closed and the keypad unlocked, press and hold the Speakerphone/Flashlight Key (3) again to turn FLASH OFF.

Operating Your Handset with the Flip Closed

With the flip closed, you can operate your handset using the Alphanumerical Keypad and side keys.

When you unlock the handset and then press the Center Select Key with the flip closed, the external display Menu will appear. The following functions are available:

Messaging: Send a text message or view the Messages and Drafts folders

Contacts: Register a new contact or view and use the Contact List, Favorites, and PTT Contact List for a phone call.

Recent Calls: Display a Recent Calls list such as Missed, Received, Dialed, or All and use it to make a phone call.

Bluetooth: Add and pair a Bluetooth®device with your handset, and also turn the Bluetooth® function On/Off and the Discovery Mode On/Off.

Keyguard Setting: Lock Now, set the Keyguard Timer and Unlock Option.

Media: Playback songs stored in My Music or Record New sounds.

The following functions are also available with the flip closed:

Call Feature: Make a phone call by entering a phone number or answer an incoming call.

Push to Talk: Use the Push to Talk feature by pressing the Red Side Key/PTT Key (2012).

Camera: Take a picture with the built-in camera which is activated by pressing the Camera/Video Key (2), or record video with camcorder which is activated by pressing and holding the Camera/Video Key (2), with the external display used as the Viewfider.

Voice Commands: Use Voice Commands by pressing the Clear/Voice Commands Key CLR.

Sound Recorder: Record sound with the Sound Recorder which is activated by pressing and holding the Clear/Voice Commands Key CLR .

Flashlight: Use the Flashlight which is activated/deactivated by pressing and holding Speakerphone/Flashlight Key .

NOTES

- When registering a contact with the flip closed, only Name/Mobile 1/Home/Work/Zip Code fields can be registered.
- Available functions are limited when the flip is closed. Use the handset with the flip open to access all available functions.

Entering and Editing Information

Text Input with the Flip Open

With the flip open, you can enter or edit Messages, Contacts, and Schedule using the QWERTY Keypad.

To perform the Text Input operation described in this section with your handset, open the text entry screen following the steps below to create the new Text Massage:

- 1. From idle mode with the flip open, press the Left Soft Key [Message], press [1] New Message.
- 2. Press [1] TXT Message.
- 3. Press the Center Select Key [OK] to go to the Text field.

Key Functions in the Text Entry Field

- Left Soft Key [Symbols]: Press to display the SYMBOLS popup box for the selection of a symbol.
- Shift/Caps: Press to change case.

 $\textbf{Abc} \rightarrow \textbf{ABC} \rightarrow \textbf{abc}$

- Function: Press to enter the right upper symbol on the key after pressing the Function Key ...
- Space: Press to insert a space.
- Return: Press to insert a carriage return.
- Clear: Press to delete a single space or character. Press and hold to delete entire words.

Entering Symbols using the SYMBOLS entry box

To insert symbols or punctuation:

- From the text entry screen with the flip open, press the Left Soft Key [Symbols].
- Press the Right Soft Key [Next] to view the next 12 symbols or Left Soft Key [Prev] to view the previous 12 symbols.

3. Select the symbol you want to insert, then press the Center Select Key [OK].

Text Input with the Flip Closed

With the flip closed, you can enter or edit Messages and Contacts using the front Alphanumeric Keypad.

To perform the Text Input operation described in this section with your handset, open the text entry screen following the steps below to create the new Text Massage:

- 1. With the flip closed, to unlock the handset, press the Center Select Key, and then press **O**NEXT at the prompt.
- 2. Press the Message Composer Key .
- 3. Press the Directional Key () down to go to the **Text** field.

NOTES

- With the flip closed, you can enter or edit a text message in any of the following entry modes: T9 Word, Abc, ABC, 123, or T9 Palabra
- Entry mode cannot be changed while entering or editing a contact.

Key Functions

* Shift: Press to change case.

T9 Word: T9 Word → T9 WORD → T9 word

Abc text: Abc → ABC → abc

T9 Palabra: T9 Palabra → T9 PALA. → T9 palabra

Next: When in T9 Word or T9 Palabra mode, press to display other words.

Space: Press to complete a word and insert a space.

CLR & Clear: Press to delete a single space or character. Press and hold to delete entire words.

Using Abc (Multi-tap) Text Input

To enter words in this mode, you need to press each key repeatedly until the desired letter appears. It can also be used to add words to the T9 database.

Example: From the text entry screen with the flip closed, in Abc mode, press (8 TuV) (8 TuV) (9 WXYZ] (9 WXYZ] (9 WXYZ] (9 WXYZ], wait one second, then press (9 WXYZ], "Vzw" is displayed.

NOTES

- Abc is the default text entry mode.
- Press and hold the alphanumeric key to enter the number in Abc mode

Using T9 Word Mode Text Input

T9 Word mode incorporates a built-in-dictionary to determine a word based on the entered characters. A word is entered more quickly because you only need to press each key once per character. To type the message "Call the office." follow these steps from the text entry screen:

- **1.** From the text entry screen with the flip closed, press the Center Select Key [Options].
- 2. Select Entry Mode, then press the Center Select Key [OK].
- 3. Select **T9 Word**, then press the Center Select Key.
- 4. Press 2 ABC 2 ABC 5 JKL 5 JKL.
- **5.** Press **#** space. to complete the word and add a space.
- 6. Press (8 TUY) (4 OH) (3 DEF) (# 500.5)
 (6 MNO) (3 DEF) (3 DEF) (4 OH) (2 ABC) (3 DEF) (1 0.5) (# 500.5)

[&]quot;Call the office." is displayed.

- After you have finished entering a word, if the word displayed is not the one you want, press the Next Key (to display additional word choices.
- Pressing (1) after pressing (1) to input a period displays other punctuation and symbols.

Adding Words to the T9 Database

If a word is not in the T9 database, add it by using Abc (Multi-tap) mode text entry. To add a new word, follow these steps from the text entry screen:

- From the text entry screen with the flip closed, in Abc mode, press
 JKL S JKL 6 MNO 6 MNO 6 MNO 7 PORS. "Kop" is displayed.
- 2. Press the Center Select Key [Options].
- 3. Select Entry Mode, then press the Center Select Key [OK].
- 4. Select **T9 Word**, then press the Center Select Key.
- **5.** Press and hold the Clear Key CLR to erase the existing word.
- 6. Press 5 JKL 6 MNO 7 PORS. "Kop" is displayed.
- 7. Press #spec to accept your choice and add a space.

Using 123 (Numbers) Text Input

To type numbers using one keystroke per number, follow these steps from the text entry screen:

- From the text entry screen with the flip closed, press the Center Select Key [Options].
- 2. Select Entry Mode, then press the Center Select Key [OK].
- **3.** Select **123**, then press the Center Select Key.
- **4.** Press **5** JKL **5** JKL **1** Press **1** Press **5** JKL **5** JKL **1** Press **2** ABC **1** Press **2** ABC **1** Press **2** ABC **3** ABC **3** ABC **3** ABC **4** ABC **5** ABC

Using Symbol Text Input

To insert symbols or punctuation, follow these steps from the text entry screen:


- From the text entry screen with the flip closed, press the Center Select Key [Options].
- 2. Select Entry Mode, then press the Center Select Key [OK].
- 3. Select **Symbols**, then press the Center Select Key.
- Press the Favorites Key (2) to view the next 12 symbols or the Message Composer Key (3) to view the previous 12 symbols.
- Select the symbol you want to insert, then press the Center Select Key to select it.

Using T9 Palabra Mode Text Input

The T9 Palabra mode is a T9 mode for Spanish input.

To type the message "Llame Ia oficina." follow these steps from the text entry screen:

- From the text entry screen with the flip closed, press the Center Select Key [Options].
- 2. Select Entry Mode, then press the Center Select Key [OK].
- 3. Select **T9 Palabra**, then press the Center Select Key.
- 4. Press (5 JKL) (5 JKL) (2 ABC) (6 MNO) (3 DEF).
- 5. Press (#space) to complete the word and add a space.
- 6. Press 5 JKL 2 ABC # SPACE



[&]quot;Llame la oficina." is displayed.

RECENT CALLS

The Recent Calls menu is a list of the last phone numbers or Contact entries for calls (including PTT calls) you placed, accepted, missed, or blocked. It is continually updated as new numbers are added to the beginning of the list and the oldest entries are removed from the bottom of the list.

Accessing the Recent Calls submenu

- From idle mode with the flip open, press the Center Select Key [MENU], select Recent Calls, then press the Center Select Key [OK].
- 2. Select a submenu.

Missed: Displays a list of the 90 most recently missed calls.

Received: Displays a list of the 90 most recently received calls.

Dialed: Displays a list of the 90 most recently dialed calls.

Blocked*: Displays a list of the 90 most recently blocked calls.

All**: Displays a list of the 270 most recent calls.

View Timers: Displays the duration of selected calls.

- If you select Blocked, enter the four-digit Lock Code, then press the Center Select Key [OK]. The default Lock Code is the last 4 digits of your phone number.
- * Blocked appears only when Contacts Only or Block All is selected for Calls under MENU > Settings & Tools > Phone Settings > Security > Restrictions > Calls > Incoming Calls. For information about how to configure this setting, see page 153.
- ** Blocked calls are not displayed in the All Calls list.

- When in idle mode with the flip open, pressing the Send Key takes you to the All Calls list.
- When in idle mode with the flip closed and the keypad unlocked, pressing the Send Key takes you to the All Calls list.

Making a Call from Recent Calls

 From the Recent Calls submenu, select one of the following call lists:

Missed/Received/Dialed/Blocked/All

2. Scroll to an entry, then press the Send Key to make a call.

Viewing Recent Call History

 From the Recent Calls submenu, select one of the following call lists:

Missed/Received/Dialed/Blocked/All

- **2.** Scroll to a call entry, then:
 - Press the Center Select Key [OPEN] to view the entry.
 - If you selected a non-PTT Contact, press the Right Soft Key
 [Options] to select:

Save To Contacts: Stores the phone number in your Contacts. **Save To PTT Contacts:** Stores the phone number in your PTT Contacts

Details: Displays the detail of the call. **Erase:** Erases the entry from the call list.

Lock/Unlock: Locks or unlocks the entry in the call list. Erase All: Erases all the entries in the selected call list.

 $\label{lem:view} \textbf{View Timers:} \ \mathsf{Displays} \ \mathsf{the} \ \mathsf{duration} \ \mathsf{of} \ \mathsf{the} \ \mathsf{call}.$

• Press the Left Soft Key [Message] to select:

New TXT Message/New Picture Message/New Video Message/New Voice Message • If you selected a PTT Contact, press the Right Soft Key [Options] to select:

New TXT Message/New Picture Message/New Video Message/New Voice Message/Save To Contacts/Save To PTT Contacts/Erase/Lock (Unlock)/Erase All/View Timers

 If you selected a PTT Group or Temp PTT Group from the Missed or Received Calls list, press the Right Soft Key [Options] to select:

New TXT Message/New Picture Message/New Video
Message/New Voice Message/Save To Contacts/Save To
PTT Contacts/Erase/Lock (Unlock)/Erase All/View Timers

 If you selected a PTT Group or Temp PTT Group from the Dialed Calls list, press the Right Soft Key [Options] to select: Erase/Lock (Unlock)/Erase All/View Timers

View Timers

To view the duration of selected calls:

- From the Recent Calls submenu, select View Timers, then press the Center Select Key [OK].
- 2. Scroll to a call list. Call timers include:

Last Call/All Calls/Received Calls/Dialed Calls/Roaming Calls/Transmit Data/Received Data/Total Data/Last Reset/Lifetime Calls/Lifetime Data Counter

- Press the Left Soft Key [Reset] to reset the highlighted timer.
- Press the Right Soft Key [Reset All] to reset all timers.

CONTACTS

The Contacts menu allows you to store names, phone numbers and other information in your handset's memory. You may store up to 500 entries.

Adding a new Contact from idle mode

- From idle mode with the flip open, enter the phone number (up to 48 characters) you want to register.
- 2. Press the Left Soft Key [Save].

NOTE

Pressing the Right Soft Key **[Options]** allows you to access the following options:

Add 2-Sec Pause: Inserts a 2-sec Pause into the number.

Add Wait: Inserts a Wait pause into the number.

Add From Contacts: Adds a phone number which is stored in the Contact List

Add From Recent Calls: Adds a phone number which is stored in the Recent Calls list.

New TXT Message: Sends a text message to the entered phone number.

New Picture Message: Sends a picture message to the entered phone number.

New Video Message: Sends a video message to the entered phone number.

New Voice Message: Sends a voice message to the entered phone number.

Assisted Dialing: Sets the Assisted Dialing setting. For more detail, see page 160.

- 3. Press [1] Add New Contact.
- Select the type of phone number you want to save, then press the Center Select Key [OK].

Mobile 1/Mobile 2/Home/Work

Scroll to the information field you want to enter. These fields include:

Name/Mobile 1/Home/Work/Email 1/Group/Picture/Ringtone/ Mobile 2/IM Screen Name/Email 2/Street/City/State/Zip Code/ Country

- To add the name, scroll to the Name field, then enter a name for the contact (up to 32 characters).
- To add the phone number, scroll to the Mobile 1, Home, Work, or Mobile 2 field, then enter the phone number (up to 48 characters).
- To add an e-mail address, scroll to the Email 1 or Email 2 field, then enter an e-mail address (up to 48 characters).
- To add the Contact entry into a group, scroll to the Group field, then press the Left Soft Key [Set]. Select the Group, press the Center Select Key [MARK], then press the Left Soft Key [Done].
- To assign the Picture ID, scroll to the Picture field, then press the Left Soft Key [Set]. Select a picture, then press the Center Select Key [OK].
- To assign the call ringtone, scroll to the **Ringtone** field, then
 press the Left Soft Key [Set]. Select a ringtone, then press the
 Center Select Key [OK].
- To add the IM Screen Name, scroll to the IM Screen Name field, then press the Left Soft Key [Set]. Select a service provider, then press the Center Select Key [OK]. Enter the IM Screen Name, then press the Center Select Key [OK].
- To add a street address, scroll to the Street, City, State, Zip Code, or Country field then enter the street, city, state, zip code, or country.

6. Select the entered phone number field and press the Right Soft Key [Options] to select one of the following options:

Set Speed Dial/Set As Default/Add 2-Sec Pause/Add Wait

- To add the Contact entry to the Speed Dial list, press Set
 Speed Dial. Select the desired Speed Dial digit by using the keypad or by scrolling to highlight it, then press the Center Select Key [SET]. Press the Center Select Key [OK] to select Yes.
- To set the phone number as the Default Number, press Set
 As Default, then press the Center Select Key [OK] to select Yes.
- To add a pause to an existing number, press 3 Add 2-Sec Pause or 3 Add Wait.

NOTE

The initial phone number entered when the new Contact is created becomes the Default Number. If more than one number is entered for the Contact entry, another number can be selected as the Default Number.

- After entering the information as necessary, press the Center Select Key [SAVE] to save.
- 8. CONTACT SAVED appears on the display. The phone number reappears on screen. Press the End/Power Key to exit, or press the Send Key to make a call to the displayed phone number.

Adding a Phone Number to an Existing Contact

- From idle mode with the flip open, enter the phone number (up to 48 characters) you want to register.
- 2. Press the Left Soft Key [Save], then press 2 Update Existing.
- Scroll to the existing Contact entry you want to update, then press the Center Select Key [OK].
- **4.** Select the phone number type, then press the Center Select Key **[OK]**.

Mobile 1/Mobile 2/Home/Work

If a phone number is already assigned to the field you selected, **Entry is already assigned. Overwrite?** appears on the display. Select **Yes** to overwrite, then press the Center Select Key **[OK]**.

5. Complete any additional fields and press the Center Select Key [SAVE] to update the contact entry. CONTACT UPDATED appears on the display. The phone number reappears on screen. Press the End/Power Key to exit, or press the Send Key to make a call to the displayed phone number.

Phone Numbers with Pauses

Pauses are used for automated systems (e.g. voicemail or calling cards). Insert a pause after a set of numbers then enter another set. The second set of numbers is dialed after the pause. This feature is useful for dialing into systems that require a code. There are two different types of pauses you can use when registering a phone number:

- Wait (W): The handset stops dialing until you press the Left Soft Key [Release] to advance to the next number.
- 2-Sec Pause (P): The handset waits 2 seconds before automatically dialing the next set of numbers.

Registering a Phone Number with Pauses

- **1.** From idle mode with the flip open, enter the phone number.
- 2. Press the Right Soft Key [Options], then press [1] Add 2-Sec Pause or [2] Add Wait.
- Enter the additional number(s) (e.g. PIN number or credit card number).
- **4.** Press the Left Soft Key [Save], then press [1] Add New Contact.
- Complete any additional fields and press the Center Select Key [SAVE].

Accessing the Contacts submenu

- From idle mode with the flip open, press the Center Select Key [MENU], select Contacts, then press the Center Select Key [OK].
- 2. Select a submenu:

New Contact/Contact List/Favorites/Groups/New PTT Contact/PTT Contact List/PTT Groups/Backup Assistant/ Speed Dials/In Case of Emergency/My Name Card

NOTES

- When in idle mode with the flip open, pressing the Right Soft Key [Contacts] functions as a hot key to access the Contact List.
- When in idle mode with the flip closed and the keypad unlocked, pressing the Directional Key right functions as a hot key to access the Contact List.

New Contact

To add a new number to your Contact List:

From idle mode with the flip open, press the Center Select Key
 [MENU], select Contacts, then press the Center Select Key [OK].
 Press New Contact.

Complete all the desired fields and press the Center Select Key [SAVE] to create the contact entry.

NOTE

Using this submenu, the number is saved as a new Contact. To save the number into an existing Contact, edit the Contact entry.

Contact List

To view your Contact List:

NOTE

Your handset is able to perform a dynamic search of the contents in your handset's memory. A dynamic search compares entered letters or numbers against the entries in your Contact List, and displays matches in alphabetical order. You can then select a number from the list to call or edit. You may locate a contact by:

- Searching by Letter
- Scrolling Alphabetically
- From idle mode with the flip open, press the Center Select Key [MENU], select Contacts, then press the Center Select Key [OK]. Press [Contact List.
 - Or, press the Right Soft Key [Contacts] from idle mode. The list of names in your contacts is displayed alphabetically.
- Searching by Letter: Enter a name or beginning letters of a name in the Go To Field at the bottom of the screen.
 - Scrolling Alphabetically: Press the Directional Key 🗘 up or down to scroll through your Contact List. You can select one of the following options:
 - To view the contact information, press the Center Select Key [VIEW].

- To edit the entry, press the Left Soft Key [Edit].
- Press the Right Soft Key [Options] to select one of the following options:

New Contact/Erase/New TXT Message/New Picture
Message/New Video Message/New Voice Message/Send
IM/Set As Favorite (Unassign Favorite)/Set As ICE Contact
(Unassigned ICE contact)/Call/Manage Contacts/Send
Name Card/Save To PTT Contacts

Making a Call from Your Contacts

Once you have registered phone numbers into your Contact List, you can make calls to those numbers quickly and easily.

- 2. Select the Contact entry, then press the Center Select Key [VIEW].
- 3. Select the phone number, then press the Send Key to make the call.

NOTES

- Selecting the Contact entry and then pressing the Send Key
 will dial the Default Number of the Contact entry automatically.
 If multiple numbers are saved in the Contact entry, select the
 number you want to dial, then press the Send Key.
- Selecting the Contact entry and then pressing the Message
 Composer Key will create a text message to be sent to the
 Default Number of the Contact entry as destination. If multiple
 phone numbers and/or e-mail addresses are saved in the
 Contact entry, select the phone number or e-mail address as
 the destination to which you want to send, and then press the
 Message Composer Key to create a text message to send to
 the selected phone number or e-mail address.

Editing a Contact Entry

- From idle mode with the flip open, press the Center Select Key [MENU], select Contacts, then press the Center Select Key [OK]. Press [3] Contact List.
- 2. Select the Contact entry, then press the Left Soft Key [Edit].
- Edit the contact information as necessary, then press the Center Select Key [SAVE] to update the contact entry.

Erasing a Contact Entry

- From idle mode with the flip open, press the Center Select Key
 [MENU], select Contacts, then press the Center Select Key [OK].
 Press Contact List.
- 2. Select the Contact entry, then press the Center Select Key [VIEW].
- Press Left Soft Key [Erase], then press the Center Select Key [OK] to select Yes.

Favorites

Assigning Contacts to Favorites

Up to 10 contacts can be assigned to Favorites.

- From idle mode with the flip open, press the Center Select Key [MENU], select Contacts, then press the Center Select Key [OK]. Press 3 Favorites.
- Select an unassigned position, then press the Center Select Key [Assign].
- Select the Contact you want to assign to the Favorites, then press the Center Select Key [OK]. A confirmation message appears.

Using Favorites

 From idle mode with the flip open, press the Center Select Key [MENU], select Contacts, then press the Center Select Key [OK]. Press [3] Favorites.

- **2.** Select the Contact entry. You can perform the following operations:
 - To view the contact information, press the Center Select Key [VIEW].
 - To unassign the entry, press the Left Soft Key [Unassign].
 - Press the Right Soft Key [Options] to select one of the following options:

Call/New TXT Message/New Picture Message/New Video Message/New Voice Message

- Press the Send Key to dial the Default Number of the Contact entry. If multiple numbers are saved in the Contact entry, select the phone number you want to dial by pressing the Directional Key → left or right, then press the Send Key.
- Press the Message Composer Key to create a text message to be sent to the Default Number of the Contact entry as the destination. If multiple phone numbers and/or e-mail addresses are saved in the Contact entry, select the phone number or e-mail address as the destination to which you want to send, and then press the Message Composer Key to create a text message to send to the selected phone number or e-mail address.

Groups

Groups allow you to classify phone entries into groups with up to 10 numbers in each group.

To view your grouped Contacts, add a new group, change the name of a group, delete a group, or send a message to everyone in the selected group:

- **2.** You can select one of the following options:
 - To add a new group to the Groups list, press the Left Soft Key [New], enter the group name, then press the Center Select Key [SAVE].
 - To view your grouped Contacts, select a group, then press the Center Select Key [VIEW].
 - To access the options menu, select a group, then press the Right Soft Key [Options]. These options include:

New TXT Message/New Picture Message/New Video Message/New Voice Message/Rename/Erase Group/Add

- To add Contacts to the group, select the existing group where you want to add the contact, then press the Right Soft Key [Options]. Press [7]* Add, then your contact entries will be displayed in alphabetical order. Select the contact you want to add then press the Center Select Key [MARK]. When you have added the desired contact(s), press the Left Soft Key [Done].
- To change the group name, select the existing group name that you want to change, then press the Right Soft Key [Options]. Press Rename, edit the group name, then press the Center Select Key [SAVE].

New PTT Contact

NOTE

You must first enable the PTT feature in order to see the PTT Contact List (see page 66).

To add a new Push To Talk (PTT) Contact:

- From idle mode with the flip open, press the Center Select Key
 [MENU], select Contacts, then press the Center Select Key [OK].
 Press [3] New PTT Contact.
- 2. Enter the name, then press the Directional Key Q down.
- **3.** Enter the 10-digit phone number of the Verizon Wireless PTT subscriber, then press the Directional Key 🕟 down.
- 4. To add the new PTT Contact as a member of an existing PTT Group, press the Left Soft Key [Add], select the PTT Group, press the Center Select Key [MARK], then press the Left Soft Key [Done].
- 5. Press the Center Select Key [SAVE].

PTT Contact List

To view your PTT Contact entries:

- Select the PTT Contact entry. You can select one of the following options:
 - To place a barge PTT call to the selected individual, press and hold the Red Side Key/PTT Key (2008).
 - To place an alert PTT call to the selected individual, press the Left Soft Key [Alert]. Then press and release the Red Side Key/PTT Key (2008).
 - Press the Right Soft Key [Options] to select one of the following options:

New PTT Contact/Copy To Contacts/Temp PTT Group/ Erase/Edit/Call/New TXT Message/New Picture Message/ New Video Message/New Voice Message/Sort

- When in idle mode with the flip open, pressing the Red Side Key/PTT Key functions as a hot key to access the PTT Contact List.
- When in idle mode with the flip closed and the keypad unlocked, pressing the Red Side Key/PTT Key functions as a hot key to access the PTT Contact List.

PTT Groups

- From idle mode with the flip open, press the Center Select Key [MENU], select Contacts, then press the Center Select Key [OK]. Press 7 PTT Groups.
- 2. You can select one of the following options:
 - To add a new PTT Group to the PTT Groups list, press the Left Soft Key [New], enter the PTT group name, then press the Center Select Key [SAVE].
 - To view the PTT contacts included in the group, select a PTT Group, then press the Center Select Key [VIEW].
 - To access the options menu, select a PTT Group, then press the Right Soft Key [Options]. These options include:

Rename/Erase/Add/Sort

- To change the PTT Group name, select the existing PTT Group that you want to change, then press the Right Soft Key [Options]. Press [1] Rename, edit the PTT Group name, then press the Center Select Key [SAVE].
- To erase the PTT Group, select the existing group that you want to erase, then press the Right Soft Key [Options]. Press [9]
 Erase, then press the Center Select Key [OK] to select Yes.
- To add PTT Contacts to the PTT Group, select the existing PTT Group where you want to add the PTT Contact, and then press the Right Soft Key [Options]. Press [3] Add, then your PTT

Contact entries will be displayed in alphabetical order. Select the PTT Contact you want to add, then press the Center Select Key **[MARK]**. Press the Left Soft Key **[Done]**.

Temp PTT Group

A Temp PTT Group allows you to quickly communicate with multiple contacts on a single PTT call. Temp PTT Groups can be created directly on your phone and are not permanently saved to your PTT Group list (unless you choose to save it).

The following operation temporarily assigns a PTT Contact to the Temp PTT Group. When assigned, displaying the Temp PTT Group and holding down the Red Side Key/PTT Key will initiate a Barge Call.

Adding PTT Contacts

- From idle mode with the flip open, press the Center Select Key
 [MENU], select Contacts, then press the Center Select Key [OK].
 Press PTT Contact List.
- Press the Right Soft Key [Options], then press ^a Temp PTT Group.
- Press the Center Select Key [ADD], select a PTT Contact entry, press the Center Select Key [MARK], then press the Left Soft Key [Done].

Viewing Temp PTT Group Members

- 2. Press the Right Soft Key [Options], then press Temp PTT Group.
- Select the PTT Contact entry. You can select one of the following options:

- Press the Left Soft Key [Remove] to remove the entry.
- Press the Right Soft Key [Options] to select one of the following options:

Remove All/New TXT Message/New Picture Message/New Video Message/New Voice Message/Save As PTT Group

Backup Assistant

Backup Assistant safeguards your handset's contacts and automatically saves a copy of the names, phone numbers, and email addresses stored in your handset. You can view, print, add, delete, or edit your contacts online.

To set Backup Assistant on your handset:

- From idle mode with the flip open, press the Center Select Key
 [MENU], select Contacts, then press the Center Select Key [OK].
 Press
 *Backup Assistant.
 - Backup Assistant launches, and the Welcome screen appears.
- **2.** Follow the on-screen prompts.

Speed Dials

Speed Dialing is a convenient feature that allows you to make phone calls quickly and easily. Assign your Contacts to Speed Dial numbers to use this calling feature.

NOTE

You will need to activate One-Touch Dialing to use Speed Dialing. See page 158.

Setting a Speed Dial

To view the Speed Dials list and assign a phone number entered in your Contacts to a Speed Dial number:

From idle mode with the flip open, press the Center Select Key
 [MENU], select Contacts, then press the Center Select Key [OK].

- Press 9 Speed Dials.
- Select or enter the Speed Dial number, then press the Center Select Key [SET].
- **3.** Select the Contact, then press the Center Select Key **[OK]**.
- 4. Select the phone number you want to assign to the selected Speed Dial number, then press the Center Select Key [OK]. "Set Speed Dial to Contact?" appears on screen.
- Press the Center Select Key [OK] to select Yes.A confirmation message appears.

NOTE

"Speed Dial is already assigned. Overwrite?" will appear on screen if you are selecting a speed dial location that is already assigned. Select **Yes** or **No** and press the Center Select Key **[OK]**.

Resetting a Speed Dial

- From idle mode with the flip open, press the Center Select Key
 [MENU], select Contacts, then press the Center Select Key [OK].
 Press Speed Dials.
- Select or enter the Speed Dial number, then press the Right Soft Key [Remove].
- Press the Center Select Key [OK] to select Yes.A confirmation message appears.

Single-Digit Speed Dialing

- 1. With the flip closed, to unlock the handset, press the Center Select Key, and then press (0,20) at the prompt.
- 2. Press and hold the Speed Dial digit.
- Your handset recalls the phone number from your Contacts, displays it briefly, and then dials it.

- From idle mode with the flip open, you can also make a phone call by pressing and holding the Speed Dial digit.
- 1: Speed Dial entry 1 (Voicemail), is already assigned.

Double-Digit Speed Dialing

- With the flip closed, to unlock the handset, press the Center Select Key, and then press (1.6) at the prompt.
- 2. Press the first Speed Dial digit, then press and hold the key of the last Speed Dial digit.
- Your handset recalls the phone number from your Contacts, displays it briefly, and then dials it.

NOTES

- From idle mode with the flip open, you can also make a phone call by pressing the first Speed Dial digit, then pressing and holding the last digit.
- 95, 96, 97, 98 and 99: Speed Dial entries 95(#Warranty Center), 96(#DATA), 97(#BAL), 98(#MIN) and 99(#PMT) are already assigned to Verizon Wireless Account Information.

Triple-Digit Speed Dialing

- With the flip closed, to unlock the handset, press the Center Select Key, and then press (1.6) at the prompt.
- Press the first and second Speed Dial digits, then press and hold the key of the last Speed Dial digit.
- Your handset recalls the phone number from your Contacts, displays it briefly, and then dials it.

- From idle mode with the flip open, you can also make a phone call by pressing the first and second Speed Dial digits, then pressing and holding the last Speed Dial digit.
- 411: Speed Dial entry 411 (Directory Assistance) is already assigned.
- If the three digits you input are not registered for Speed Dial, your handset dials the number you input.

In Case of Emergency (ICE)

Follow the procedure below to register a Contact to be contacted in case of emergency, or to register a medical record number or other personal info. Up to three different Contacts can be registered to ICE.

NOTE

Even when the handset is locked, the Contact or personal info registered as ICE can be viewed without unlocking the handset by pressing the Left Soft Key [ICE].

Adding a Contact to ICE

To register to ICE:

- Select Contact 1, Contact 2, or Contact 3, then press the Center Select Key [ADD].
- 3. To select from the Contact List, press [] From Contacts, select the Contact entry, then press the Center Select Key [OK].

 To add a new Contact, press [2] New Contact, enter the contact information, then press the Center Select Key [SAVE].

- For details about adding a new Contact, see page 47.
- The contact name assigned as the ICE contact is displayed in red font in the Contact List.

Entering Personal Info

To register a Medical Record Number or other information that may be used in case of an emergency:

- 2. Select Personal Info, then press the Center Select Key [VIEW].
- 3. Select Note 1, Note 2, or Note 3, then press the Center Select Key [ADD].
- 4. Enter the information, then press the Center Select Key [SAVE].
- The information you entered now appears in place of Note 1, Note 2, or Note 3.

My Name Card

To register a name, telephone number, and e-mail address to My Name Card:

- From idle mode with the flip open, press the Center Select Key
 [MENU], select Contacts, then press the Center Select Key [OK].
 Press My Name Card.
- Enter the name, then scroll to the information field you want to enter. Information fields include:

Mobile 1/Home/Work/Email 1/Mobile 2/IM Screen Name/Email 2

After entering the necessary information, press the Center Select Key [SAVE].

NOTE

My Name Card can be added to a message. See page 105.

Push to Talk

The Push to Talk (PTT) feature on your phone allows you to use your phone like a walkie-talkie to communicate with an individual or group of individuals who are also Verizon Wireless Push to Talk subscribers.

NOTES

- PTT Mode is Off by default, which means you are not able to send or receive PTT calls and alerts. See page 160 for instructions on how to turn on PTT Mode.
- When PTT mode is ON, from idle mode with the flip open, or the flip closed and the keypad unlocked, pressing the Red Side Key/ PTT Key displays the PTT contact list.
- When PTT mode is ON, from idle mode with the flip open, or the flip closed and the keypad unlocked, pressing and holding the Red Side Key/PTT Key initiates a barge call to the last number from which you sent/received the last call.

About Push to Talk

Push to Talk calls may only be made with other Verizon Wireless Push to Talk subscribers and only from the National Enhanced Services Rate and Coverage Area. The Push to Talk feature can be added to calling plans with a monthly access fee of \$34.99 or higher (or to Family SharePlan secondary lines). For optimal Push to Talk performance, all callers on a Push to Talk session must have an EV-DO Rev. A-capable device and be receiving EV-DO service. A Push to Talk call is terminated by pressing or will automatically time out after ten (10) seconds of inactivity. While you are on a Push to Talk call, voice calls received will go directly to Voice Mail. When you are on a voice call, you cannot receive a Push to Talk call. You cannot prevent others who have your wireless phone number from entering

you into their Push to Talk contact list. Only one person can speak at a time during Push to Talk calls. When using your phone keypad to make a Push to Talk call, you must enter the ten-digit phone number of the called party. Presence information may not be available for all Push to Talk contacts. The timeliness of presence information may be impacted by the network registration status of a Push to Talk contact. Your Push to Talk service cannot be used for any applications that tether your phone to computers or other devices for any purpose. If you add the Push to Talk feature, coverage for your data services will be limited to the National Enhanced Services Rate and Coverage Area.

Making a PTT Call

You can make two types of PTT calls:

- A barge call automatically connects to the other party. The called party does not have the option to ignore the call.
- An alert call is a call to notify a called party that the calling party wants to talk using a tone. The called party has the option to answer or ignore the call.

NOTE

You must first enable the PTT feature in order to see the PTT icons and menus.

PTT Mode

You can use the following procedure to turn the PTT feature On or Off. When PTT is turned on, you will be able to send and receive PTT calls or alerts.

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [8] Call Settings, [9] PTT Mode.
- 2. Select On or Off, then press the Center Select Key [OK].

NOTE

The 3G or 1x service indicator icon on the top line of the main display is highlighted to indicate that the PTT service is available.

Calling from PTT Contact List (Barge)

- 1. With the flip closed, to unlock the handset, press the Center Select Key, and then press (2002) at the prompt.
- 2. Press the Red Side Key/PTT Key (to access your PTT Contact List
- 3. Scroll to the PTT Contact entry you wish to call.
- **4.** Press and hold the Red Side Key/PTT Key (Wait until the "OK to Talk" tone sounds and the message "Talking to" appears on the display. Speak while holding the Red Side Key/PTT Key (RES).
- 5. Release the Red Side Key/PTT Key (ESSE) to let the other party talk.
- **6.** Press the End/Power Key to end the call.

NOTE

With the flip open, you can also perform the same operation by pressing the Red Side Key/PTT Key (2012).

Calling from PTT Contact List (Alert)

You can send an alert to any user with Verizon Wireless PTT service. The user may answer or ignore the alert.

- 1. From idle mode with the flip open, press the Red Side Key/PTT Key

 (ESSE) to access your PTT Contact List.
- 2. Scroll to the PTT Contact entry you wish to call.
- Press the Left Soft Key [Alert]. The message "Press Red Side Key/PTT Key to Alert" will appear on the display.
- Press and release the Red Side Key/PTT Key (See) to alert the selected individual.

The "PTT Outgoing Alert" tone will sound, and "Alerting" will appear on the display.

- 5. If the called party answers the alert, "Listening to" appears on the display and you will hear the called party speaking.
 If the called party chooses to ignore the alert, or if the phone is unavailable to accept a PTT call, an "Unavailable" message will appear on your display.
- 6. When the called party finishes speaking, you will hear the "Floor Available" tone and the "Connected to" screen will appear on your display.
- 7. Press and hold the Red Side Key/PTT Key (to talk.
- 8. Release the Red Side Key/PTT Key (to let the other party talk.
- **9.** Press the End/Power Key to end the call.

Calling from Temp PTT Group (Barge)

- From idle mode with the flip open, press the Red Side Key/PTT Key to access your PTT Contact List.
- 2. Press the Right Soft Key [Options], then press [1] Temp PTT Group.
- 3. Press and hold the Red Side Key/PTT Key . Wait until the "OK to Talk" tone sounds and the message "Talking to" appears on the display. Speak while holding the Red Side Key/PTT Key .
- Release the Red Side Key/PTT Key (to let the other party talk.
- 5. Press the End/Power Key to end the call.

Calling from Keypad (Barge)

- 1. With the flip closed, to unlock the handset, press the Center Select Key, and then press () at the prompt.
- Enter the 10-digit phone number of the Verizon Wireless PTT subscriber you wish to contact.
- **3.** Press and hold the Red Side Key/PTT Key (ESE). Wait until the "OK to Talk" tone sounds and the message "Talking to" appears on the display. Speak while holding the Red Side Key/PTT Key (ESE).

If the phone number you entered has already been registered in your PTT Contact List, the contact name will replace the phone number entered on the display when you initiate the call by pressing the Red Side Key/PTT Key

- **4.** Release the Red Side Key/PTT Key to let the other party talk.
- 5. Press the End/Power Key to end the call.

NOTE

With the flip open, you can also perform the same operation by pressing the Red Side Key/PTT Key (2008).

Calling from Keypad (Alert)

- From idle mode with the flip open, enter the 10-digit phone number of the Verizon Wireless PTT subscriber you wish to alert.
- 2. Press the Left Soft Key [Alert].
- Press and release the Red Side Key/PTT Key (EEEE) to alert the individual.
 - The "PTT Outgoing Alert" tone will sound, and "Alerting" will appear on the display.
 - If the phone number you entered has already been registered in your PTT Contact List, the contact name will replace the phone number entered on the display when the alert is initiated.
- 4. If the called party answers the alert, "Listening to" appears on the display and you will hear the called party speaking.
 If the called party chooses to ignore the alert, or if the phone is unavailable to accept a PTT call, an "Unavailable" message will appear on your display.
- **5.** When the called party finishes speaking, you will hear the "Floor Available" tone and the "Connected to" screen will appear on your display.
- **6.** Press and hold the Red Side Key/PTT Key (ESSE) to talk.

- Release the Red Side Key/PTT Key (to let the other party talk.
- 8. Press the End/Power Key to end the call.

Incoming PTT Call Incoming PTT (Barge)

- 1. When you receive a barge call, you will hear the calling party speaking through the speakerphone. The calling party's phone number will appear on your display. If the calling party's number has already been registered in your PTT Contact List, the contact name will replace the phone number on the display.
- 2. Press and hold the Red Side Key/PTT Key (3252) to talk.
- 3. Release the Red Side Key/PTT Key (to let the other party talk.
- 4. Press the End/Power Key to end the call.

Incoming PTT (Alert)

- 1. When you receive an alert, you will hear the "PTT Alert" tone. The message "Incoming Alert" will be displayed with the phone number or contact name of the calling party. The PTT Alert tone repeats every 1 second until you answer or ignore the call. If you do not answer an incoming alert within 10 seconds, the PTT call will be automatically disconnected.
- 2. Answer or ignore the alert:
 - To answer the alert, press and hold the Red Side Key/PTT Key and begin talking.
 - To ignore the alert, press the Right Soft Key [Ignore].
- 3. Release the Red Side Key/PTT Key (to let the other party talk.
- 4. Press the End/Power Key to end the call.

MEDIA CENTER

Media Center provides you customizable service right on your handset that lets you access ringtones, play games, surf the web, get up-to-the-minute information and more.

You can use Media Center and download applications anywhere on the Verizon Wireless network, as long as you have a digital signal available for your handset.

Music & Tones

You can personalize your phone's ringtones and download music. You can select from a wide variety of genres.

Accessing the Music & Tones submenu

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK].
- 2. Press Music & Tones.
- 3. Select a submenu.

library all in one place.

V CAST Music | Rhapsody/Get New Ringtones/My Ringtones/ My Music/My Sounds/Sync Music

V CAST Music with Rhapsody®

V CAST Music with Rhapsody® is a digital music service that lets you listen to millions of songs from thousands of artists. Discover new and old favorites in an extensive music catalog. Download V CAST Music with Rhapsody® to sync tracks, albums, and playlists to your new compatible phone, while managing your existing PC music

■ Purchase songs on your V CAST Music with Rhapsody® capable device*

When you purchase music from your V CAST Music with Rhapsody® capable device, you also get a second copy that can be downloaded to your PC from the V CAST Music with Rhapsody® software.

- * Per-song charges apply.
- From idle mode with the flip open, press the Center Select Key
 [MENU], select Media Center, then press the Center Select Key
 [OK]. Press Music & Tones, V CAST Music I Rhapsody.
- Browse and search the V CAST Music catalog, and select the song you want.
- **3.** To purchase the selected song, press the Center Select Key [Buy].
- 4. The CONFIRM PURCHASE screen appears with the price and the title of the song being purchased. To agree to the purchase, press the Center Select Key [Buy].
- 5. Press the Center Select Key [OK] at the Download now? screen. Choose to either save the song to phone memory or the memory card, then press the Center Select Key [OK]. You will be able to play the saved song from My Music by pressing the Left Soft Key [My Music] or by pressing the Right Soft Key [Play].

NOTE

You may be charged for each track you download. You must be within the Coverage Area to use V CAST. V CAST may not be available in all areas.

Get New Ringtones

To connect to MEDIA CENTER and download various ringtones:

1. From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press [1] Music & Tones, [2] Get New Ringtones, [1] Get New Applications.

2. Follow the on screen prompts to download.

My Ringtones

To select a desired ringtone, or download a new ringtone:

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press [1] Music & Tones, [3] My Ringtones.
- **2.** Scroll to a ringtone. You can select the following options:
 - Press the Center Select Key [PLAY] to play the ringtone and press the Center Select Key [STOP] again to stop playing the ringtone.
 - Press the Left Soft Key [Set As] to access the following options:
 Ringtone: A confirmation message appears.

Contact ID: The SET AS CONTACT ID screen appears. Select the Contact you want to assign the ringtone to, then press the Center Select Key **[OK]**.

Alert Sounds: Press the corresponding number key to set the ringtone for one of the following:

All Messages/TXT Message/Media Message/Voicemail/ PTT Alert

 Press the Right Soft Key [Options] to access the following options (These options are only available for a downloaded ringtone.):

Erase: Erases the current ringtone from your phone.

Rename: Allows you to rename the ringtone's title.

Lock/Unlock: Locks or unlocks the current ringtone in your phone.

Erase All: Erases all the ringtones in your phone.

File Info: Displays information on the selected ringtone.

My Music

To play back and manage music stored in your phone's memory or on a memory card (purchased separately):

NOTES

- When in idle mode with the flip open, pressing the Music Key
 Music functions as a hot key to access My Music.
- When in idle mode with the flip closed and the keypad unlocked, pressing the Music Key (MUSIC) functions as a hot key to access My Music.

■ Playing Music with the Flip Closed

- With the flip closed, to unlock the handset, press the Center Select Key, and then press (1 in the prompt.)
- Press the Center Select Key, select Media, then press the Center Select Key.
- 3. Select My Music, then press the Center Select Key.
- Select one of the following menu options, then press the Center Select Key.

Play All/Shuffle/Playlists/Songs

■ Playing Music with the Flip Open

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press [1] Music & Tones, [4] My Music.
- 2. A Music Library screen will appear with all of the music stored in your phone's memory or on the memory card. Select one of the following menu options:

Play All/Shuffle/Songs/Playlists/Albums/Artists/Genres/

My Sounds

To select a desired sound:

- From idle mode with the flip open, press the Center Select Key
 [MENU], select Media Center, then press the Center Select Key
 [OK]. Press Music & Tones, My Sounds.
- Scroll to a sound, then press the Center Select Key [PLAY] to hear the sound. Press the Center Select Key [STOP] to stop playing the sound.
- ${\bf 3.}$ Press the Right Soft Key ${\bf [Options]}$ to access the following options:

For **DOWNLOADED** or **RECORDED SOUNDS**:

Send: Sends the selected sound via Picture Message.

To Online Album: Uploads the selected sound to Online Album storage.

Rename: Allows you to rename the sound's title.

Move: Moves the selected sound to the memory card. (Only when a memory card is loaded in the phone)

Lock/Unlock: Locks or unlocks the selected sound in your phone.

Erase: Erases the selected sound.

Erase All: Erases all the sounds in your phone.

File Info: Displays information about the selected sound.

For **PRELOADED SOUNDS**:

Send: Sends the selected sound via Picture Message.

To Online Album: Uploads the selected sound to Online Album

storage.

File Info: Displays information about the selected sound.

■ Recording New Sounds

To record a new sound:

1. From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press [1] Music & Tones, [5] My Sounds, [1] Record New.

- Press the Center Select Key [OK] to begin recording. When done, press the Center Select Key [STOP] to finish recording. The recording is automatically saved to your My Sounds list.
- Your recording is saved with a number. To rename your recording, scroll to it with the Directional Key, then press the Right Soft Key [Options].
- **4.** Press **3** Rename.
- **5.** Press and hold the Clear Key clr to erase the number.
- **6.** Enter the new name for your recording, then press the Center Select Key [OK].

NOTES

- When in idle mode with the flip open, you can directly access the Sound Recorder function by pressing and holding the Clear Key
- When in idle mode with the flip closed and the keypad unlocked, you can directly access the Sound Recorder function by pressing and holding the Clear Key CULE \$\Delta\$.

■ Erase Sound

To erase a sound:

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press [1] Music & Tones, [5] My Sounds.
- Select the sound you want to erase, then press the Right Soft Key [Options].
- Select Erase, then press the Center Select Key [OK]. "Erase Sound?" will appear on your display.
- Press the Center Select Key [OK] to select Yes. A confirmation message appears.

NOTE

Your handset comes with 5 preloaded sounds: clapping, crowd roar, happy birthday, rainforest, and train. These cannot be erased.

Sync your music from your PC to your V CAST Music with Rhapsody® wireless device

This option allows you to transfer music files from your PC. In order to use this option, you must install V CAST Music with Rhapsody® on your PC.

- Open V CAST Music with Rhapsody®. Don't have V CAST MUSIC with Rhapsody®? Download it for free at www.verizonwireless.com/music.
- Plug in the USB cable (purchased separately) to your handset and connect it to a USB port on your PC.
- From idle mode with the flip open, the SYNC MUSIC V CAST MOBILE PHONE display appears. Your phone should display the message: Connected.
- Drag and drop the song(s) you want to sync from My Library, to your V CAST Music with Rhapsody® handset, listed under the Sources tab.

Once synchronization is complete, press the End/Power Key and disconnect the USB cable.

NOTE

A compatible USB cable (sold separately) is required for synchronizing.

Picture & Video

You can view, take and trade your digital pictures and video right from your wireless phone.

Accessing the Picture & Video submenu

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK].
- 2. Press [2] Picture & Video.
- 3. Select a submenu.

V CAST Videos/Get New Pictures/My Pictures/My Videos/Take Picture/Record Video/Online Album

V CAST Videos

Get news and entertainment on your wireless device with streaming video clips.

NOTE

Application fees may apply. You must be within the Coverage Area to use V CAST. V CAST may not be available in all areas.

■ Browsing, Selecting, and Playing Video Clips

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press Picture & Video, V CAST Videos.
- 2. Select one of the video clip categories.
- Select the content provider then press the Center Select Key [OK] to open the selected category.
- If subcategory selection is allowed, select a subcategory then press the Center Select Key [OK].
- After reading the description of the video clip, press the Center Select Key [SAVE].

- Select Yes then press the Center Select Key [OK] to start transferring the video clip.
- "Download Complete Play Video Now?" may appear. Select Yes and press the Center Select Key [OK]. The video clip is played back in streaming video.

■ Downloading a Video Clip

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press [2] Picture & Video, [1] V CAST Videos.
- Browse and search the V CAST Video catalog, and select the video you want.
- After reading the description of the video clip, press the Right Soft Key [Options].
- 4. Press [28] Save Video.
- Select Yes then press the Center Select Key [OK] to start downloading the video clip.
- **6.** After download is complete, the message "Download Complete Play Video Now?" will appear on your phone's display.
- 7. Select **Yes** to play the video clip.
- 8. The video clip is automatically stored in the My Videos folder.

NOTE

There is no guarantee you will be able to download any particular video clip to your phone.

■ Deleting Video Clips

From idle mode with the flip open, press the Center Select Key
 [MENU], select Media Center, then press the Center Select Key
 [OK]. Press Picture & Video, 4 My Videos.

- Select the video you want to delete, then press the Left Soft Key [Erase].
- 3. Press the Center Select Key [OK] to select Yes.

■ Configuring Alerts for New Video Clips

To configure alerts that will be sent whenever new clips matching a preference become available:

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press [2] Picture & Video, [1] V CAST Videos.
- 2. Browse and search the V CAST Video catalog, and select the video you want.
- After reading the description of the video clip, press the Right Soft Key [Options].
- 4. Select Alerts and then press the Center Select Key [OK].
- Select Configure Alerts and then press the Center Select Key [OK].
- Select the type of alert you want and then press the Center Select Key [OK].
- Using the Directional Key, highlight Save and press the Center Select Key [OK] to sign up for the selected alert.

NOTE

Alerts are displayed as incoming TXT Messages.

Get New Pictures

To connect to MEDIA CENTER and download a variety of Pictures (images):

1. From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press Picture & Video, PG Get New Pictures, Get New Applications.

Media Center will launch and take you to the download menu.

2. Follow the on-screen prompts.

NOTE

The downloaded application will be included in the list displayed when you access: MENU > Media Center > Picture & Video > Get New Pictures.

My Pictures

In My Pictures you can view all the pictures you have taken, store selected images in your phone, send pictures to the Online Album, delete images and access additional picture options.

- From idle mode with the flip open, press the Center Select Key
 [MENU], select Media Center, then press the Center Select Key
 [OK]. Press [2] Picture & Video, [3] My Pictures.
- 2. Select your desired picture, then press the Right Soft Key [Options].
- **3.** Select one of the following options:

Send: Sends the selected picture. (Picture Message/To Online Album/Via Bluetooth)

Set As: Assigns the selected picture to display for specific tasks. (Wallpaper/Picture ID)

Take Picture: Takes a new picture.

Get New Pictures: Downloads various pictures.

Manage Pictures: Allows you to manage the pictures stored in the My Pictures folder. (Erase/Lock/Unlock/Move To Card/Move To Phone).

Rename: Allows you to rename the selected picture.

Print Via Bluetooth: Prints the selected picture via Bluetooth®. File Info: Displays information about the selected picture. (File

Name/Date/Time/Resolution/Size)

■ Rotate

You can rotate the pictures stored in the My Pictures folder.

NOTES

- The rotated picture is stored in the My Pictures folder as a separate file.
- Some images cannot be rotated due to copyright protection, image size, or other reasons.
- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press Picture Video, My Pictures.
- Select your desired picture, then press the Center Select Key [VIEW].
- **3.** Press the Right Soft Key [Options], then press 4 Rotate.
- 4. Press the Right Soft Key [Rotate(R)] or the Left Soft Key [Rotate(L)], then press the Center Select Key [SAVE]. The rotated picture is stored in the My Pictures folder.

Zoom

You can zoom into the pictures stored in the My Pictures folder.

NOTE

Only pictures taken with your handset can be zoomed.

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press [2] Picture & Video, [3] My Pictures.
- Select your desired picture, then press the Center Select Key [VIEW].
- 3. Press the Right Soft Key [Options], then press [Zoom.

4. Press the Right Soft Key [Zoom+] or the Left Soft Key [Zoom-]. Press the Directional Key up, down, left or right while zooming to scroll the display.

■ Resize

You can resize the pictures stored in the My Pictures folder.

NOTES

- The resized picture is stored in the My Pictures folder as a separate file.
- Only pictures taken with your handset can be resized.
- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press [2] Picture & Video, [3] My Pictures.
- Select your desired picture, then press the Center Select Key [VIEW].
- 3. Press the Right Soft Key [Options], then press 6 Resize.
- Select one of the following sizes, then press the Center Select Key IOK1.

160 × 120 / 320 × 240 / 640 × 480 / 1280 × 960* / 1600 × 1200

* The selectable size depends on the size of the image you are editing.

The resized picture is stored in the My Pictures folder.

■ Crop

You can crop the pictures stored in the My Pictures folder.

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press Picture Video, My Pictures.
- Select your desired picture, then press the Center Select Key [VIEW].

- **3.** Press the Right Soft Key [Options], then press ? Crop.
- Select one of the following sizes, then press the Center Select Key [OK].

160 × 120 / 120 × 160 / 320 × 240 / 240 × 320 / 400 × 240 / 240 × 400 / 640 × 480 / 480 × 640 / 1280 × 960 / 960 × 1280 / 1600 × 1200*

- * The selectable size depends on the size of the image you are editing.
- 5. Select the area to crop by pressing the Directional Key
 up, down, left or right and press the Center Select Key [SAVE]. The cropped picture is stored in the My Pictures folder.

NOTES

- The cropped picture is stored in the My Pictures folder as a separate file.
- Only pictures taken with your handset can be cropped.

■ Perspective Adjustment

If you need to adjust the perspective of a picture after shooting a timetable or poster, you can select and cut the outline of the picture and adjust it to appear as a rectangular image taken straight from the front.

NOTES

- Up to 16 blue frames and one red frame appear on the picture.
 The blue frames are the selectable outlines of the subject and the red frame is the currently selected outline.
- If there is no selectable outline around the subject, Perspective Adjustment cannot be performed.
- The picture adjusted with Perspective Adjustment is stored in the My Pictures folder as a separate file.
- Only pictures taken with your handset can be adjusted by Perspective Adjustment.

- From idle mode with the flip open, press the Center Select Key
 [MENU], select Media Center, then press the Center Select Key
 [OK]. Press [2] Picture & Video, [3] My Pictures.
- Select your desired picture, then press the Center Select Key [VIEW].
- 3. Press the Right Soft Key [Options], then press * Perspective Adjustment.
- Select the outline of the subject with the Directional Key
 up or down and press the Center Select Key [OK].
- Press the Center Select Key [SAVE]. The adjusted picture is stored in the My Pictures folder.

■ Erase Picture

- From idle mode with the flip open, press the Center Select Key
 [MENU], select Media Center, then press the Center Select Key
 [OK]. Press [2] Picture & Video, [3] My Pictures.
- Select the picture you want to erase, then press the Left Soft Key [Erase]. "Erase Picture from My Pictures and Settings?" will appear on your display.
- Press the Center Select Key [OK] to select Yes. A confirmation message appears.

■ Erase All Pictures

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press Picture & Video, My Pictures.
- **2.** Press the Right Soft Key [Options].
- 3. Press Manage Pictures, La Erase.
- Press the Right Soft Key [Mark All], then press the Left Soft Key [Done]. "Erase pictures?" will appear on your display.
- **5.** Press the Center Select Key **[OK]** to select **Yes**. A confirmation message appears.

My Videos

In My Videos, you can view all the videos you have taken, store the selected videos in your phone, send a video to the Online Album, delete videos, and access additional video options.

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press 2 Picture & Video, 4 My Videos.
- 2. Select your desired video, then press the Center Select Key [PLAY] to play. While the video is playing, use the following keys to control the video:

 - Left Soft Key [Mute/Unmute] : Mute/Unmute
 - Right Soft Key [File Info/Options] : File Info or Options
 - Center Select Key : Pause/Play
 - Directional Key 🔿 up: Show full screen view/normal screen view
 - Directional Key 🔾 down: Stop
 - Directional Key → right: Fast Forward (while held down)

NOTE

When you press the Right Soft Key **[Options]** after selecting a video in My Videos, you can select the following options:

Send: Sends the selected video. (Video Message/To Online

Album/Via Bluetooth)

Record Video: Records a new video.

V CAST Videos: Accesses V CAST Videos.

Set As Wallpaper: Sets the selected video as wallpaper.

Set As wailpaper: Sets the selected video as wailpaper.

Manage Videos: Allows you to manage the videos stored in the My Videos folder. (Erase/Lock/Unlock/Move To Card/Move To Phone)

Rename: Allows you to rename the selected video.

File Info: Displays information about the selected video. (Name/

Date/Time/Duration/Size)

View: Switches the view of the video list. (Thumbnail View/List

View)

■ Erase Video

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press [®] Picture & Video, ³ My Videos.
- Select the video you want to erase, then press the Left Soft Key [Erase]. "Erase video from My Videos?" will appear on your display.
- Press the Center Select Key [OK] to select Yes. A confirmation message appears.

■ Erase All Videos

- From idle mode with the flip open, press the Center Select Key
 [MENU], select Media Center, then press the Center Select Key
 [OK]. Press Picture & Video, 4 My Videos.
- **2.** Press the Right Soft Key [Options].
- 3. Press Manage Videos, TErase.

- 4. Press the Right Soft Key [Mark All], then press the Left Soft Key [Done]. "Erase videos?" will appear on your display.
- Press the Center Select Key [OK] to select Yes. A confirmation message appears.

Take Picture

In Take Picture mode, you can take pictures with a picture size up to 2048×1536 pixels.

- From idle mode with the flip open, press the Center Select Key
 [MENU], select Media Center, then press the Center Select Key
 [OK]. Press Picture & Video, Take Picture.
- Press the Right Soft Key [Options] to change the following settings:

Best Shot: Select the scene mode that best matches the subject type to be taken. (Off/Person/Scenery/Night View/Sepia/Black & White/Negative)

Resolution: Select a picture size. (2048 \times 1536, 2048 \times 1232, 1600 \times 1200, 1280 \times 960, 640 \times 480, 400 \times 240, 320 \times 240, 160 \times 120)

Flash: Select a flash setting. (Auto Flash/Off/On/Only This Shot)

Macro: Allows you to focus on a close object. (Off/On)

White Balance: Select a white balance setting. (Auto/Sunny/

Shade/Tungsten/Fluorescent)

Self Timer: Select the camera's timer interval. (Off / 3 Seconds / 5 Seconds / 10 Seconds)

Multishot: Select whether or not to take four consecutive pictures with a single shot with a picture size of 640 × 480. (On/Off)

Auto Focus: Select a focus setting. (Off/Single Point AF/9 Point AF/Face Focus)

Brightness: Adjust the brightness level. (-5 to +5)

Guide: Displays the Key Guide.

Display Setting: Select the icon display method. (Timeout/Always)

Shutter Sound: Select a shutter sound. (Shutter/Silent)

Memory: Select the location to save the picture. (Phone/Card)

Video: Changes to Record Video mode.

Viewfinder: Select the internal (main) display or external (front) display to use as the viewfinder. (Main Display/Front Display)

- 3. Use the following keys to change the Take Picture mode settings:
 - Directional Key 🗘 up or down: Brightness Up/Down
 - Directional Key → left or right: Zoom Out/Zoom In
 - AF Lock/Return Key [3]: Auto Focus Lock (When Auto Focus is set to Single Point AF, 9 Point AF, or Face Focus.)
 - Left Soft Key [My Pics]: Displays My Pictures.
 - : Changes the Best Shot setting.
 - 2 : Changes the Resolution setting.
 - 3#: Changes the Flash setting.
 - 43: Changes the Macro setting.
 - [5"]: Changes the White Balance setting.
 - 6: Changes the Self Timer setting.
 - 78: Changes the Shot Mode.
 - * Changes the Auto Focus setting.
 - 0: Displays the Key Guide.
 - V: Changes to Record Video mode.
 - Space/PTT Key [SPACE*]: Changes the Viewfinder setting.
- **4.** To take the picture, press the Center Select Key [].
- **5.** Perform one of the following operations:
 - Press the Left Soft Key [Save] to save the picture in the My Pictures folder.
 - Press the Center Select Key [SEND] to save the picture in the My Pictures folder and create a Picture Message.
 - Press the Right Soft Key [Erase] to shoot again without saving the picture.

NOTES

- The Music Key (Music) or Camera Key (2) can also be used to take a picture.
- Best Shot provides you with a collection of scene modes that show a variety of different types of shooting conditions. When you need to change the setup of the camera, simply select the scene mode that matches the subject type to be taken, and the camera automatically optimizes settings for that subject type.
 - When the Shot Mode setting is set to Multishot, you cannot select Night View.
- When using the flash, take a picture within about 4" to 20" from the subject.
- Press the AF Lock/Return Key 🚡 to adjust and lock the focus without activating the shutter. When AF is locked, the focus point changes from white to green and the lock clicks. If AF cannot be locked, the focus point turns red. You can readjust and lock the focus by pressing the AF Lock/Return Key 🖀 again.
- When the Auto Focus setting is set to 9 Point AF, nine focus points appear. When the focus is locked, three focus points change from white to green and the lock clicks. If the focus cannot be locked, the focus point turns red.
- When the Auto Focus setting is set to Face Focus, the camera
 automatically detects and focuses on the face of the subject.
 When the camera detects several faces, it automatically selects
 and focuses on the face closest to the center. When no face can
 be detected, the center of the display is automatically measured
 and focused, this is the same as when the Single Point AF is
 selected.
- Something other than a person may be detected as a human face with the Face Focus function.

- A face may not be detected with the Face Focus function in the following cases:
 - A face that appears very large or small relative to the screen.
 - A face partly covered by hair, hat or glasses.
 - A face partly shadowed.
 - A face looking up or down, right or left, or tilted.
- When the external display is used as a Viewfinder, only part of the actual shooting image can be seen.
- When you turn off the camera, the Best Shot and Macro settings return to Off.
- When in idle mode with the flip open, you can directly access

 Take Picture mode by pressing and holding the Camera Key [2].
- When in idle mode with the flip closed and the keypad unlocked, pressing the Camera/Video Key (2) functions as a hot key to Take Picture.
- With the flip closed, you can change from Take Picture mode to Record Video mode by pressing the Camera/Video Key (2).

Record Video

In Record Video mode you can record video at 320×240 pixels with sound.

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press Picture & Video, Record Video.
- Press the Right Soft Key [Options] to change the following settings:

Color Effects: Select a color effect to apply. (Normal/Black & White/Negative/Sepia)

Recording Resolution: Select a video size. $(176 \times 144 / 320 \times 240)$

Recording Light: Select a lighting setting. (Auto/Off/On/Only This Shot)

Macro: Allows you to focus on a close object (Off/On)

White Balance: Select a white balance setting. (Auto/Sunny/

Shade/Tungsten/Fluorescent)

Self Timer: Select the camera's timer interval. (Off / $3 \sec / 5 \sec /$

10 sec)

Call Interruption: Select to block or allow interruption by an incoming call, alert, etc. while recording. (Block/Allow).

Brightness: Adjust the brightness level. (-5 to +5)

Display Setting: Select the icon display method. (Timeout/Always)

Guide: Displays the Key Guide.

Shutter Sound: Adjust the shutter sound setting. (On/Off) **Recording Time:** Set the duration limit to 60 Seconds for Video

Message or 60 Minutes for Save. (Limit for Video Message/Limit for Save)

Memory: Select the location to save the video. (Phone/ Card)

Camera: Changes to Take Picture mode.

Viewfinder: Select the internal (main) display or external (front) display to use as the viewfinder. (Main Display/Front Display)

- **3.** Use the following keys to change the Record Video mode settings:
 - Directional Key () up or down: Brightness Up/Down
 - Directional Key → left or right: Zoom Out/Zoom In
 - Left Soft Key [My Videos]: Displays My Videos.
 - 1: Changes the Color Effects setting.
 - [2]: Changes the Recording Resolution setting.
 - 3*: Changes the Recording Light setting.
 - 43: Changes the Macro setting.
 - 5": Changes the White Balance setting.
 - Changes the Self Timer setting.
 - 78: Changes the Call Interruption setting.
 - [a]: Displays the Key Guide.
 - Changes to Take Picture mode.
 - Space/PTT Key [SPACE*]: Changes the Viewfinder setting.

- **4.** To begin recording, press the Center Select Key [REC]. To finish recording, press the Center Select Key [STOP].
- **5.** Perform one of the following operations:
 - Press the Left Soft Key [Save] to save the video in the My Videos folder.
 - Press the Center Select Key [SEND] to save the video in the My Videos folder and create a Video Message.
 - Press the Right Soft Key [Erase] to record again without saving the video.

NOTES

- The Music Key (Music) or Video Key (P) can also be pressed to start or stop the recording of a video.
- When the external display is used as the Viewfinder, only part of the actual recording image can be seen.
- When you turn off the camcorder, the Macro setting returns to Off.
- When you turn off the camcorder, the Color Effects setting returns to Normal
- When you turn off the camcorder, the Call Interruption setting returns to Allow.
- When in idle mode with the flip open, you can directly access

 Record Video mode by pressing and holding the Video Key [7].
- When in idle mode with the flip closed and the keypad unlocked, you can directly access Record Video mode by pressing and holding the Camera/Video Key (2).
- With the flip closed, you can change from Record Video mode to Take Picture mode by pressing the Camera/Video Key (2).

Online Album

To access the Online Album:

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK]. Press [2] Picture & Video, [7] Online Album.
 The browser launches, and the Online Album sign-on screen appears.
- 2. Follow the on-screen prompts.

Games

To download games and applications from the MEDIA CENTER server:

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK].
- 2. Press [3" Games, [1] Get New Applications.
- Choose the software you want from the list displayed on the screen. Follow the on-screen prompts to download.

Playing Downloaded Games

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK].
- 2. Press [3"] Games.
- 3. Select the application, then press the Center Select Key [PLAY].
- 4. Follow the on-screen prompts.

Removing a Downloaded Game

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK].
- 2. Press [3" Games.

- Select the application you want to delete, then press the Right Soft Key [Options].
- 4. Press [3" Erase.
- 5. Select Yes, then press the Center Select Key [OK] to delete.

Mobile Web

Find the news you want or let it come to you. Now, a few seconds is all it takes to get up-to-the-minute information.

Starting the Mobile Web

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK].
- 2. Press 4 Mobile Web.
 The browser launches

NOTE

When in idle mode with the flip open, you can directly access the Mobile Web feature by pressing the Directional Key (*) up.

Ending a Browser Session

End a Browser session by pressing the End/Power Key.

Initiating a Phone Call from the Browser

You can make a phone call from the Browser if the site you are using supports the feature (You can make a call by pressing the Center Select Key when the phone number is highlighted). The browser connection is terminated when you initiate the call. After you end the call, your phone immediately returns to the screen from which you initiated the call

Launching Document Viewer

You can view a document file with the Document Viewer by selecting a link to Word (.doc, .docx), Excel (.xls, .xlsx), or PowerPoint (.ppt, .pptx), and pressing the Center Select Key. For how to operate the Document Viewer, see page 99.

Navigate Menu

The following options are available when you press the Left Soft Key [Navigate] while browsing the Mobile Web:

WWW/Back/Forward/Home/View Favorites/Add Favorite/Find On Page/Search/Refresh/History

Main Menu

The following options are available when you press the Right Soft Key [Menu] while browsing:

Full Screen View(Normal Screen View)/Zoom/Optimized View/ Display Mode/Page Overview/Settings/Information

Changing Display Mode

The available Display Modes are Standard and Fixed Width. When switched to Standard, the horizontal scroll bar appears and you can scroll horizontally. When switched to Fixed Width, the contents are displayed across the width of the display. Therefore, no horizontal scroll is necessary.

- 1. Press the Right Soft Key [Menu] while browsing.
- 2. Select **Display Mode**, then press the Center Select Key [OK].
- Select Standard or Fixed Width, then press the Center Select Key [OK].

NOTE

When you check the **Text Only** checkbox in step 3, only text information will be displayed, no images will be downloaded while browsing.

Settings

Allows you to set the Mobile Web settings.

- 1. Press the Right Soft Key [Menu] while browsing.
- 2. Select **Settings**, then press the Center Select Key [OK].
- **3.** Select one of the following options:

Home Page: Use Current/Assign New/Reset to Default **JavaScript:** Whether to enable JavaScript. (On/Off)

Security: Cookies/Send Referrer/Enable Authentication Caching/ Enable SSL 3.0/Enable SSL 2.0/Enable TLS 1.0/Certificates

Manage Memory: Clear All/Clear Cache/Clear Cookies/Clear

History/Clear Auto Complete

Restore Defaults: Home Page/Display Mode/Security/Restore All

Browse & Download

To download tools that can help you navigate to entertainment spots, restaurants, and provide you with up-to-date weather information:

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK].
- 2. Press 5 Browse & Download.
- 3. Press [1] Get New Applications. Follow the on-screen prompts.

VZ NavigatorSM

Now you can find the address of a great restaurant or the nearest ATM. Check movie times. Discover the latest hot spots. And know exactly how to get where you're going. VZ Navigator puts all the advanced features of the latest GPS devices and systems on your wireless device — at a fraction of the price.

- From idle mode with the flip open, press the Center Select Key [MENU], select VZ Navigator, then and press the Center Select Key [OK].
- **2.** Follow the on-screen prompts.

NOTES

- To use VZ Navigator, you must set Location to Location On. See page 151.
- Download, subscription, and airtime required for use; only in National Enhanced Services Coverage Area; accuracy and completeness of information is not guaranteed; information about the location of the device will be used to deliver service.

Extras

To download applications:

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK].
- 2. Press 6 Extras.
- **3.** Press [] Get New Applications. Follow the on-screen prompts.

My Documents

You can view Word (.doc, .docx), Excel (.xls, .xlsx), PowerPoint (.ppt, .pptx), PDF (.pdf), or Text (.txt) file stored in My Documents, by using the Document Viewer.

NOTES

- The My Documents list includes files stored in the Phone Memory and those in the "my_doc" folder on a memory card (sold separately) inserted in the handset.
- With your handset connected to a PC using the USB Mass Storage feature, you can copy files from a PC to the "my_doc" folder on a memory card. For details of USB Mass Storage, see page 124.
- You can also copy files from a PC to the "my_doc" folder with a memory card directly inserted into a PC memory card slot.
- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK].
- 2. Press 78 My Documents.
- 3. Select your desired file, then press the Center Select Key [OK] to view. The Document Viewer launches and the file opens. Press the Directional Key (*) up or down to scroll through the document or display the previous or next page.
 - To access the menu, press the Right Soft Key [Menu]. These options include:

Go to: Moves to the First page, Last page, Next page, Previous page, or Specify Page.

Zoom: Changes the display magnification allowing you to Zoom in. Zoom out. or Zoom to.

Rotate: Rotates a page clockwise by 90 degrees.

Search: Searches in the file for Whole Words Only, Case

Sensitive, or Start Position: Current Page or First Page.

Shortcut: Displays the list of short cut keys.

About: Displays version information, etc.

Thumbnail on/off: Select whether to display the thumbnail of pages. (on/off)

 Pressing the Left Soft Key [Exit] closes the file and returns to the list of files in My Documents.

NOTES

 When you press the Right Soft Key [Options] after selecting a file in My Documents, you can select the following options:

Rename: Allows you to rename the file.

Lock (Unlock): Allows you to lock or unlock the selected file which is stored in the Phone Memory. Locked files cannot be deleted by the Erase All function.

Erase All: Erase all the documents in your handset. (From Card/From Phone)

File Info: Displays information on the selected file.

• Some files may not be displayed with the Document Viewer.

Info

To view App. Memory, Phone Memory, View Log, and Help information:

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK].
- 2. Press the Right Soft Key [Info].
- Select one of the following settings, then press the Center Select Key [OK].

App. Memory/Phone Memory/View Log/Help

MESSAGING

Accessing the Messaging submenu

- From idle mode with the flip open, press the Center Select Key [MENU], select Messaging, then press the Center Select Key [OK].
- Select a submenu.

New Message/Messages/Drafts/Voicemail/Visual Voice Mail/ Mobile IM/Email/Chat

NOTES

- When in idle mode with the flip open, pressing the Left Soft Key [Message] functions as a hot key to access the Messaging submenu.
- When in idle mode with the flip closed and the keypad unlocked, pressing the Directional Key own functions as a hot key to access the Messaging submenu.
- You can make a call to the callback number by pressing the Send Key during a message check.
- When By Time is selected for Messages View in Message
 Settings, the Inbox folder and the Sent folder will appear in the
 Messaging submenu instead of the Messages folder.
 By Contacts is the default setting. If By Time is selected,
 navigating the phone's Messaging menu will be different.

New Message Alert

There are two ways your handset alerts you to new messages:

- 1. The handset displays a message on the screen.
- The message icon (M) appears on the idle screen. In the case of an urgent message, the icon will flash.

New Message

Allows you to send messages (Text, Picture, Video, and Voice). Each message has a destination (Address) and information (Message). These are dependent upon the type of message you want to send.

Sending a Text Message

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Messaging, then press the Center Select Key [OK]. Press [1] New Message, [1] TXT Message.
- 2. Enter the phone number or e-mail address of the recipient. By pressing the Right Soft Key [Add] in the To field you can choose from the following:

From Contacts: Search for a phone number or e-mail address which is stored in the Contact List.

From Favorites: Allows you to select a Contact from Favorites to add a phone number or e-mail address as a destination.

Recent Calls: Search for a phone number stored in Recent Calls. **Groups:** Search for a group which is stored in your Contacts.

To Online Album: Send pictures to Online Album storage. (This option only appears for a Picture/Video/Voice Message)

To Contacts: Stores the phone number in the Contact List.

To PTT Contacts: Stores the phone number in the PTT Contact List.

- **3.** Press the Center Select Key **[OK]**.
- **4.** Type your message.
- Press the Center Select Key [SEND]. A sending screen appears.

NOTES

- If you send a Text message to a phone without Text capabilities, you will still be notified that the message was sent, however the message will not be received.
- When in idle mode with the flip open, you can create a new text message by pressing the Message Composer Key
- If the Set Qwerty Shortcut is set to TXT Message, when in idle mode with flip open, you can create a new text message by pressing any alphabetical key on the QWERTY keypad. For information about the Set Qwerty Shortcut, see page 149.

Sending a Picture Message

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Messaging, then press the Center Select Key [OK]. Press [1] New Message, [2] Picture Message.
- 2. Enter the phone number or e-mail address of the recipient.
- 3. Press the Center Select Key [OK].
- **4.** Type your message in the **Text**: field.
- 5. Scroll to the **Picture** field, then press the Left Soft Key [My Pics].
- Select the picture you want to include in your message, then press the Center Select Key [OK].
- 7. Scroll to and edit any additional fields as desired.
- Press the Center Select Key [SEND]. A sending screen appears.

Sending a Video Message

1. From idle mode with the flip open, press the Center Select Key [MENU], select Messaging, then press the Center Select Key [OK]. Press [1] New Message, [3] Video Message.

- 2. Enter the phone number or e-mail address of the recipient.
- 3. Press the Center Select Key [OK].
- **4.** Type your message in the **Text**: field.
- 5. Scroll to the Video field and press the Left Soft Key [MyVideos].
- **6.** Select the video you want to attach to your message, then press the Center Select Key **[OK]**.
- 7. Scroll to and edit any additional fields as desired.
- Press the Center Select Key [SEND]. A sending screen appears.

Sending a Voice Message

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Messaging, then press the Center Select Key [OK]. Press [] New Message, [4] Voice Message.
- The RECORD NEW screen appears. Press the Center Select Key [OK] to record a voice message. Press the Center Select Key [STOP] to finish recording.
- **3.** Enter the phone number or e-mail address of the recipient.
- 4. Press the Center Select Key [OK].
- **5.** Type your message in the **Text**: field.
- 6. Scroll to and edit any additional fields as desired.
- Press the Center Select Key [SEND]. A sending screen appears.

Customizing the Message Using Options

You can customize a new Text Message, Picture Message, Video Message or Voice Message, by pressing the Right Soft Key [Options] to access the following features.

NOTE

These options vary depending on the type of message you are sending.

Insert Quick Text: Inserts Quick Text into a message.

Add: Allows you to add a Graphic, Animation, Sound, Signature,

Name Card or Contact.

(The Add option only appears for a Text Message. The Signature option appears only when Signature is set to Custom in Message Settings and "No" is selected for the confirmation message "Insert Signature for all Messages?".)

Preview: Displays the Picture/Video message as it would appear at the recipient. (This option only appears for a Picture/Video Message) **Review:** Plays back the recorded sound to hear the Voice message

Review: Plays back the recorded sound to hear the Voice message as it would be heard by the recipient. (This option only appears for a Voice Message)

Save Quick Text: Saves the text to the Quick Text list. Quick Text can save up to 100 characters per phrase.

Format Text: Allows you to change the look of the text. (Alignment/

Font Size/Font Style/Text Color/Background) (This option only appears for a Text Message)

Save As Draft: Saves the message into the Drafts folder.

Add Slide: Inserts multiple pictures into a message. (This option only appears for a Picture Message)

appears for a riotate incosage)

Add Signature: Inserts the signature text into a message.

(This option only appears for a Picture/Video/Voice Message, and only when Signature is set to Custom in Message Settings and "No" is selected for the confirmation message "Insert Signature for all Messages?".)

Priority Level: Assigns a priority to the message. (High/Normal) **Callback #:** Inserts a pre-programmed callback number in your message. (Off/On/Edit)

(This option only appears for a Text Message)

Remove Picture: Removes the picture from the message.

(This option only appears for a Picture Message)

Remove Sound: Removes the sound from the message.

(This option only appears for a Picture Message)

Remove Slide: Removes the slide from the message.

(This option only appears for a Picture Message)

Remove Video: Removes the video from the message.

(This option only appears for a Video Message)

Remove Recording: Removes the recorded voice message. (This option only appears for a Voice Message)

Cancel Message: The handset will prompt you whether to save a message to the Drafts folder. Select **Yes** and press the Center Select Key **[OK]** to save the message to the Drafts folder. Select **No** and

press the Center Select Key [OK] to cancel the message.

Using Contacts to Send a Message

To select an entry saved in your Contacts as the recipient instead of manually entering the address:

- From idle mode with the flip open, press the Center Select Key [MENU], select Messaging, then press the Center Select Key [OK]. Press 1 New Message.
- 2. Press 1 TXT Message or 2 Picture Message or 1 Video Message or 4 Voice Message.
- 3. Press the Right Soft Key [Add].
- 4. Press [1] From Contacts.
- Scroll to the Contact entry containing the destination, then press the Center Select Key [MARK].
- **6.** Press the Left Soft Key [Done] then press the Center Select Key [OK] to go to the Text field.

NOTE

You can send a message to up to ten people at a time.

7. Scroll to and edit any additional fields as desired.

8. Press the Center Select Key [SEND]. A sending screen appears.

Messages

Your handset alerts you in the following 3 ways when you receive a new Text, Picture, Video, or Voice message:

- By displaying a message notification on the screen.
- By sounding a beep or vibrating (if Vibrate Mode is set).

The Messages menu displays all messages sent and received from a contact together.

- From idle mode with the flip open, press the Center Select Key [MENU], select Messaging, then press the Center Select Key [OK]. Press [3] Messages.
- 2. Select a contact. You can select one of the following options:
 - To view a list sorted by time of messages received from or sent to the selected contact, press the Center Select Key [OPEN].
 A new text message can be sent to the selected contact, by entering text in the text box "To reply, just type" above the message list and then press the Center Select Key [SEND].
 - To view contents of a message received from or sent to the selected contact, press the Center Select Key [OPEN], select a message, then press the Center Select Key [OPEN].

 When you press [a] while displaying a message, the handset reads out the message with a synthetic voice.
 - To erase all messages sent to and received from the selected contact, press the Left Soft Key [Erase].
 - Press the Right Soft Key [Options] to select one of the following options:

Reply: Replies to the selected contact. (TXT Message/Picture Message/Video Message/Voice Message)

Add To Contacts: Stores the callback number, e-mail address, and numbers from the address of the sender/recipient into your Contacts. (This option is available only if the sender/recipient is not in your Contacts.)

Add To PTT Contacts: Stores the callback number and numbers from the address of the sender/recipient into your PTT Contacts.

Compose New: Create a new message. (TXT Message/Picture Message/Video Message/Voice Message).

Erase: Erases the message selected from all messages sent to and received from the selected contact.

Sort by Alphabetically: Temporarily sorts the list of contacts in alphabetical order by sender/recipient name. When the list of contacts is sorted alphabetically, you can search the contact by entering a name or beginning letters of a name in the Go To Field at the bottom of the screen. (This option does not appear when the list of contacts in the Messages folder is displayed in alphabetical order.)

Sort by Time: Sorts the list of contacts by sent/received time. (This option does not appear when the list of contacts in the Messages folder is displayed by time.)

Sort by Size: Temporarily sorts the list of contacts by size (cumulative size of all the messages sent to/received from the same contact) in descending order. (This option does not appear when the list of contacts in the Messages folder is displayed by size.)

NOTES

- Locked messages cannot be deleted using Erase Messages and Erase All functions.
- If the memory is full, no more messages can be received until enough memory space becomes available.

If the memory is over 80% full, one of the following warning messages will appear.

Text MEMORY FULL

TEXT MSG xx% FULL

Pictures/Videos MEMORY FULL

MEDIA MSG xx% FULL

Pictures/Videos Notification MEMORY FULL

MEDIA NOTI xx% FULL

 Storage space may be affected by the combined size and content of all messages.

Drafts

To display draft messages:

- From idle mode with the flip open, press the Center Select Key [MENU], select Messaging, then press the Center Select Key [OK]. Select Drafts and then press the Center Select Key [OK].
- 2. Select a draft message. You can select one of the following options:
 - To edit the selected message, press the Center Select Key [EDIT].
 - To erase the selected message, press the Left Soft Key [Erase].
 - Press the Right Soft Key [Options] to select one of the following options:

Send: Allows you to send the selected message.

Lock (Unlock): Locks or unlocks the selected message. Locked messages cannot be deleted by the Erase Drafts and Erase All functions.

Add To Contacts: Stores the callback number, e-mail address, or numbers from the draft message into your Contacts.

Add To PTT Contacts: Stores the callback number from the draft message into the PTT Contact List.

Erase Drafts: Deletes all messages except locked messages.

Voicemail

Your handset will alert you when you receive new voicemail.

- From idle mode with the flip open, press the Center Select Key [MENU], select Messaging, then press the Center Select Key [OK]. Select Voicemail and then press the Center Select Key [OK].
- 2. Perform either of the following operations:
 - Press the Left Soft Key [Clear] to clear the voicemail counter.
 Select Yes, then press the Center Select Key [OK].
 - Press the Send Key or the Center Select Key [CALL] to listen to the message(s).
 - If you have no messages, press the Center Select Key [OK] to return to the Messaging menu.

NOTES

- Voicemail is pre-assigned to the Speed Dial entry 1. When in idle mode with the flip open, you can make a call to Voicemail by pressing and holding [1]. When in idle mode with the flip closed and the keypad unlocked, you can make a call to Voicemail by pressing and holding [1].
- You will need to activate One-Touch Dialing to use Speed Dialing.
 See page 158.

Visual Voice Mail

Visual Voice Mail allows the management of voice mail directly from the device rather than accessing voice mail via traditional methods. Visual Voice Mail displays a list of messages and allows the user to choose which message to listen to or erase, without having to dial into their mailbox, listen to voice instructions, or prior messages.

To access Visual Voice Mail:

- From idle mode with the flip open, press the Center Select Key
 [MENU], select Messaging, then press the Center Select Key
 [OK]. Select Visual Voice Mail and then press the Center Select
 Key [OK] to access the Visual Voice Mail application for download,
 and future use
- 2. Follow the on-screen prompts.

Mobile IM

Instant message with AIM, WL Messenger or Yahoo!

To send and receive an Instant Message:

From idle mode with the flip open, press the Center Select Key
 [MENU], select Messaging, then press the Center Select Key
 [OK]. Select Mobile IM and then press the Center Select Key
 [OK].

Mobile IM launches.

- 2. Press the Left Soft Key [Accept] to accept the terms & conditions.
- To send and receive an instant message, follow the on-screen prompts and functions.

Email

To read and send e-mail from your e-mail accounts:

- From idle mode with the flip open, press the Center Select Key [MENU], select Messaging, then press the Center Select Key [OK]. Select Email and then press the Center Select Key [OK].
- Select one of the following options, then press the Center Select Key [OK].
 - Mobile Email/Corporate Email/Mobile Web Mail
- **3.** To send an e-mail, follow the on-screen prompts and functions.

Chat

To chat with Internet Messenger users:

- From idle mode with the flip open, press the Center Select Key [MENU], select Messaging, then press the Center Select Key [OK]. Select Chat and then press the Center Select Key [OK]. The browser launches.
- Select one of the displayed chat rooms, then press the Center Select Key [OK].
- To chat with Internet Messenger users, follow the on-screen prompts and functions.

Message Settings

To configure message settings:

- From idle mode with the flip open, press the Center Select Key [MENU], select Messaging, then press the Center Select Key [OK]. Press the Left Soft Key [Settings].
- 2. You can select one of the following settings:
 - **Messages View:** Select By Time or By Contacts. Selecting the By Time option will display all messages in the Inbox sorted by message reception time. Selecting the By Contacts option will group together all messages sent to and received by Contacts. By Contacts is the default setting.

Entry Mode: Select the default input method when creating a message with the flip open. (Abc/ABC)

Auto Save Sent: Selecting On automatically saves the sent text messages in the Sent folder. (On/Off/Prompt)

Auto Erase Inbox: Selecting On automatically erases the read/ unlocked messages in the Inbox when the storage capacity reaches the limit. (On/Off)

Messaging Font Size: Select the font size used to display a message in the internal or external display. Select from Small/Normal/Large for the internal display, and from Small/Normal for the external display.

TXT Auto View: Selecting On will automatically display the message content in the idle screen upon receiving a message. (On/Off)

Multimedia Auto Receive: Selecting the On option will automatically download the content upon receiving a Picture/ Video/Voice message. (On/Off)

Quick Text: You can use these registered text phrases frequently to facilitate message creation.

Voicemail #: Allows you to manually enter the access number for Voicemail Service (VMS). This feature should only be used when a VMS access number is not provided by your network.

Callback #: Automatically sends a designated callback number when you send a text message. (Off/On)

Signature: Allows you to make/edit a signature to automatically send with your Text messages. (None/Custom)

Delivery Receipt: Requests to receive a Delivery

Acknowledgement or Delivery Report for all sent messages. (On/Off)

Message Erase

To erase all messages stored in your Messages or Drafts folders:

- From idle mode with the flip open, press the Center Select Key [MENU], select Messaging, then press the Center Select Key [OK]. Press Right Soft Key [Options], to access the following options:

 - Press a Erase All to erase all messages stored in the Messages and Drafts folders. Then select All Messages Including Unread or All Except Unread Messages, and press the Center Select Key [OK].
- 2. A confirmation message appears.

NOTE

Locked, Unread and MMS notification messages cannot be erased.

SETTINGS & TOOLS

The Settings & Tools menu has options to customize your handset.

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].
- 2. Select a submenu.

My Verizon/Tools/Bluetooth/External Keyguard Settings/ Sounds Settings/Display Settings/Phone Settings/Call Settings/Memory/USB Mode/Phone Info/Set-up Wizard

My Verizon

Allows you to access your account information.

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].
- 2. Press My Verizon.

The browser will launch.

To exit the browser at any time and return to the idle screen, press the End/Power Key.

NOTES

- When in idle mode with the flip open, you can directly access the My Verizon feature by pressing the Directional Key € left.
- Airtime is free when accessing My Verizon.

Tools

Accessing the Tools submenu

 From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].

- 2. Press 2 Tools.
- 3. Select a submenu:

Voice Commands/Calculator/Calendar/Alarm Clock/Stop Watch/Countdown Timer/World Clock/Notepad/USB Mass Storage

Voice Commands

The Voice Commands tool allows you to make a phone call quickly and easily by verbal command. Your handset recalls the number from your Contacts, displays it briefly, and then dials it.

NOTES

- When in idle mode with the flip open, you can directly access the Voice Commands function by pressing the Voice Commands Key
- When in idle mode with the flip closed and the keypad unlocked, you can directly access the Voice Commands function by pressing the Voice Commands Key CLR ★.
- Press the Left Soft Key [Info] or say the word "Information" and a
 detailed explanation about the currently selected voice command
 displays and is read out (when Readout is selected as the
 Prompts mode).
- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [Tools, Voice Commands.
- Follow the prompts to use voice command(s).The following is a list of functions that you can perform using the Voice Commands tool

Call <Name or Number>: To make a call, say "Call," and the command system will prompt you for the name or number. If the contact has more than one number, the system will prompt you for

the number type. You can state the name and number type of the contact (for example, "Call John Work") to access the contact's phone number directly.

Send <Message Type>: To create a message, say "Send," and the command system will prompt you for the type of message you want to send: Text, Picture, Video or Voice. You can state the name and number of the contact, the message type, and the contact name, number, or group (for example, "Send text message to Bob") and the message will automatically start.

Go To <Menu>: The "Go To" command allows you to access a menu within the handset (for example, "Go to Contacts"). If no menu option is stated, a list of options will be provided. Choose from the following: Alarm Clock, Bluetooth Menu, Calculator, Calendar, Call Settings, Contacts, Display Settings, Media Center, Games, Messaging, Missed Calls, Mobile Web, Music & Tones, My Music, My Verizon, My Pictures, My Ringtones, My Sounds, My Videos, New Contact, New Picture Message, New TXT Message, New Video Message, Phone Settings, Recent Calls, Settings & Tools, Sound Settings, Tools, and V CAST Videos.

Check < Item>: The "Check" command allows you to access device information including the Status, Voicemail, Messages, Missed Calls, Time, Signal Strength, Battery Level, Volume, and Minutes (for example, "Check Battery"). If no menu option is stated, a list of options will be provided.

Contact <Name>: The "Contact" command allows you to access information for a contact. For example, saying, "Contact Bob Smith," will provide all entered information for that contact.

Redial: The "Redial" command allows you to make a call to the last number that you called.

Play <All Songs/Playlist name>: The "Play" command allows you to play all your songs by stating "Play All Songs," or play individual playlists by saying "Play" followed by the playlist name.

My Verizon: The "My Verizon" command allows you to access information about your Verizon Wireless account (for example, balance, minutes, usage, and payment information).

Help: Help displays general information about how to use Voice Commands.

■ Voice Commands Settings

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [2] Tools, [1] Voice Commands.
- 2. Press the Right Soft Key [Settings].
- 3. Select one of the following options:

Confirm Choices: Automatic/Always Confirm/Never Confirm Sensitivity: More Sensitive/Automatic/Less Sensitive

Adapt Voice: Adapts digit dialing and name dialing to your voice.

Prompts: Mode/Audio Playback/Timeout

For Mode, set Prompts/Readout + Alerts/Readout/Tones Only.

For Audio Playback, set Speakerphone/Earpiece.

Info: Displays version information, etc.

Calculator

The Calculator allows you to perform simple mathematical calculations. You can enter numbers with up to six decimal places. You can input a calculation that is up to two display lines long.

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press 2 Tools, 2 Calculator.
- 2. You can input arithmetic operators using the following keys.
 - Directional Key 🔿 up: +
 - Directional Key → right: ×
 - Directional Key € left: ÷
 - Directional Key Q down: -

- Center Select Key : =
- 6 : Changes the number from positive to negative
- u⁺: Changes the number from negative to positive
- Press the Left Soft Key [Clear] to delete the equation or the Right Soft Key [Operator] to insert (,), or Power.

NOTE

To insert a decimal, press . To insert -, press . For example:

- 1. Press , the Directional Key (up, , then press the Directional Key (down,), (10+5-(-5)" is displayed.
- Press the Center Select Key [=], the answer "20" will be displayed.

Calendar

The Calendar tool provides easy and convenient access to your schedule.

Simply store your events and your handset will alert you to them.

NOTE

When in idle mode with the flip open, you can directly access the Calendar feature by pressing the Directional Key \bigcirc down.

■ Adding a New Event

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [Tools,] Calendar.
- 2. Scroll to the scheduled day.
- 3. Press the Left Soft Key [Add].
- 4. Scroll to the information field you want to enter. These fields include:
 - Event: Use the keypad to enter an appointment in your schedule.

- Start Date & Time: Press the Left Soft Key [Set], then use the keypad to enter the start date & time and press the Directional Key (2) up or down for am/pm. Then press the Center Select Key [SET].
- End Date & Time: Press the Left Soft Key [Set], then use the keypad to enter the start date & time and press the Directional Key (2) up or down for am/pm. Then press the Center Select Key [SET].
- Time Zones: Press the Left Soft Key [Set], then select from the following: GMT/UTC, EST, EDT, CST, CDT, MST, MDT, PST, PDT, AKST, AKDT, HAST, or HADT. Then press the Center Select Key [SET].
- Recurrence: Press the Left Soft Key [Set], then select from the following: Once, Daily, Weekly, Monthly, Yearly. Then press the Center Select Key [SET].
- Alert Tone: Press the Left Soft Key [Set], then select the desired ringtone and press the Center Select Key [SET].
- Alert Vibrate: Press the Left Soft Key [Set], then select On or Off and press the Center Select Key [SET].
- Reminder: Press the Left Soft Key [Set], then select Once,
 Every 2 Minutes, Every 15 Minutes, or Off and press the
 Center Select Key [SET].
- Alert Time: Press the Left Soft Key [Set], then select from the following: None/On Time / 5 minutes before / 10 minutes before / 15 minutes before / 30 minutes before / 1 hour before /
 - 3 hours before /5 hours before /1 Day Before, then press the Center Select Key [SET].
- Press the Center Select Key [SAVE] after setting all of the applicable Event Fields.

■ Viewing and Editing Event Details

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press Tools, Calendar.
- Scroll to the day on which an event is registered, then press the Center Select Key [VIEW].
- 3. Scroll to an event, then press the Center Select Key [VIEW].
- 4. If you need to edit event details, press the Center Select Key [EDIT]. To erase an event, press the Left Soft Key [Erase]. With Yes highlighted, press the Center Select Key [OK] to erase the calendar event.

Alarm Clock

The Alarm Clock tool allows you to set up to three alarms.

When you set an alarm, the current time is displayed. When the alarm goes off, Alarm 1 (or 2 or 3, as applicable) will be displayed on the screen and the alarm will sound.

NOTE

When in idle mode with the flip open, you can directly access the Alarm Clock feature by pressing the Directional Key \bigcirc right and pressing \bigcirc Alarm Clock.

■ Setting an Alarm

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press Tools, Alarm Clock.
- 2. Select an Alarm (1, 2, or 3), then press the Center Select Key [OK].
- Scroll to the information field you want to enter. These fields include:

On/Off: Press the Left Soft Key [Set], select **On** or **Off**, and press the Center Select Key [SET].

Time: Press the Left Soft Key [Set], then use the keypad to enter the time and press the Directional Key 🗘 up or down for am/pm. Then press the Center Select Key [SET].

Frequency: Press the Left Soft Key [Set], then select from the following: Once, Daily, Mon - Fri, or Weekends. Then press the Center Select Key [SET].

Ringer: Press the Left Soft Key [Set] then select the desired ringtone and press the Center Select Key [SET].

Press the Center Select Key [SAVE] after setting all of the applicable Alarm Fields.

■ Disabling an alarm before it sounds

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press 2 Tools, 4 Alarm Clock.
- 2. Select an alarm, then press the Right Soft Key [Options].
- Select one of the following options, then press the Center Select Key [OK].

Turn Off: Turns off the highlighted alarm. **Reset Alarm:** Resets the highlighted alarm.

Reset All: Resets all of the alarms.

Stop Watch

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [Tools, 5 Stop Watch.
- 2. Press the Center Select Key [START] to start the stop watch.
 - Press the Center Select Key [STOP] to stop the watch.
 - Press the Right Soft Key [Lap] to record the lap time.
 - Press the Left Soft Key [Reset] to reset the time.

Countdown Timer

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [2] Tools, [6] Countdown Timer.
- 2. Select a countdown timer, then press the Right Soft Key [Edit].
- **3.** Edit the countdown time, then press the Center Select Key [SET].
- 4. Press the Center Select Key [START] to start the countdown timer.
 - Press the Center Select Key [STOP] to stop the countdown timer.
 - Press the Left Soft Key [Reset] to reset the countdown timer.

World Clock

To determine the current time in another time zone or country:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press 2 Tools, 7 World Clock.
- 2. Press the Directional Key ⊕ left or right to view the time in different cities. To view a list of the cities, press the Right Soft Key [Cities], select the desired City and press the Center Select Key [OK]. The world map appears with the city, its date and time.

NOTE

Press the Left Soft Key [Set DST], to apply Daylight Savings Time.

Notepad

Your handset includes an internal notepad that can be used to compose and store reminders and notes.

■ Adding a New Note

From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [®] Tools, [8*] Notepad.

Press the Left Soft Key [Add] to write a new note. When you are done, press the Center Select Key [SAVE].

■ Viewing and Editing a Note

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [Tools, Notepad.
- 2. Select a note, then press the Center Select Key [VIEW].
- 3. If you need to edit the note, press the Center Select Key [EDIT].
- Edit the note. When you are done, press the Center Select Key [SAVE].

NOTE

You can erase the note by pressing the Left Soft Key [Erase] in step 3. Select Yes, then press the Center Select Key [OK].

USB Mass Storage

Allows you to transfer data from your handset to your PC or vice versa when your handset is connected to your PC with a compatible USB cable (purchased separately).

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press Tools, USB Mass Storage.
- Plug in the USB cable connector to the Charging/Data port of your handset and the other side of the connector to a USB port on your PC.

Follow the on-screen prompts.

NOTES

- Mac OS operating systems are not supported.
- You can select this menu only when a memory card (sold separately) is inserted in the handset.
- When using USB Mass Storage with the USB cable connected to a PC, you will not be able to answer or make a phone call. Unplug the USB cable connector from your handset to enable calls.

Bluetooth

Your handset supports the following Bluetooth® profile services and protocols: Headset, Handsfree, Dial Up Networking, Stereo, Phonebook Access, Basic Printing, Object Push for vCard & vCalendar, and File Transfer.* You can create and store 20 pairings within the handset but connect to only one device at a time. The approximate communication range for Bluetooth® wireless technology is up to 25 feet.

Your handset is based on the Bluetooth® specification, but it is not guaranteed to work with all devices enabled with Bluetooth® wireless technology. This handset does not support all Bluetooth® OBEX Profiles. For vehicle/accessory (sold separately) compatibility go to www.verizonwireless.com/bluetoothchart.

NOTES

- Read the user guide of each Bluetooth® accessory that you are trying to pair with your handset because the instructions may differ.
- When in idle mode with the flip closed and the keypad unlocked, you can directly access the Bluetooth Menu by pressing the Directional Key (*) up.

Power

To toggle Bluetooth® power On/Off:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].
- 2. Press 3 Bluetooth.
- 3. Press the Left Soft Key [Turn On].

NOTES

- By default, your handset's Bluetooth® functionality is turned off.
- When in idle mode with the flip open, you can toggle Bluetooth® power on or off by pressing the Directional Key → right and pressing
 Bluetooth on/off.

Add New Devices

"Pairing" is the process that allows the handset to locate, establish, and register a 1-to-1 connection with the target device.

To pair the handset with a new Bluetooth® device:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].
- 2. Press [3#] Bluetooth.
- 3. Press [1] Add New Devices.

NOTE

If the Bluetooth® power is switched off, the following message will appear on the internal display: **Turn Bluetooth power on?**Press the Center Select Key **[OK]** to select **Yes. BLUETOOTH POWER ON** will appear on the display.

- 4. The handset will prompt you with the following message on the internal display: PLACE DEVICE YOU ARE CONNECTING TO IN DISCOVERABLE MODE. Press the Center Select Key [OK].
- 5. The device will appear in the ADD NEW DEVICE menu. Select the device you wish to pair with, then press the Center Select Key [PAIR].
- **6.** The handset may prompt you for the passkey. Consult the Bluetooth® accessory instructions for the appropriate passkey (typically "0000"—4 zeroes). Enter the passkey, then press the Center Select Key **[OK]**.

NOTE

You do not need to input the passkey for pairing when the passkey of the Bluetooth® Headset or hands-free kit is 0000.

- 7. The handset will prompt you with the following message on the internal display: Before Connecting To [Device Name]. If you would like to always confirm before connecting to the Bluetooth® device, select Always Ask, then press the Center Select Key [OK]. The handset will prompt you with the message Connect to [Device Name]. Select Yes, then press the Center Select Key [OK]. If you do not wish to confirm every time before connecting to the Bluetooth® device, select Always Connect, then press the Center Select Key [OK].
- 8. Once connected, you will see the device listed in the Bluetooth Menu and the Bluetooth® device connected icon ★ will appear at the top of the internal display.

NOTES

- In the Bluetooth Menu, you can disconnect the connected device with an icon by pressing the Center Select Key [DROP].
 Conversely, you can reconnect by pressing the Center Select Key [OK] again.
- When an audio device is connected, you can select another device and the connection is automatically transferred from the one to the other.
- If multiple devices are displayed, select the device to which you want to connect.

Bluetooth Settings

■ Settings for Your Handset

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].
- 2. Press [3" Bluetooth.
- Press the Right Soft Key [Options] to select one of the following options:
 - To edit the Bluetooth® name of your phone, press My Phone Name. Enter a new custom name and then press the Center Select Key [OK] to save and exit.
 - To set whether your handset is able to be searched for by other Bluetooth® devices in the area, press Discovery Mode.
 Select On or Off, then press the Center Select Key [OK].
 - To view brief descriptions of the profiles supported by the phone, press [3] Supported Profiles. Select one of the profiles, then press the Center Select Key [VIEW].

■ Settings for Paired Device

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].
- 2. Press 3 Bluetooth.
- 3. Select the paired device, then press the Right Soft Key [Options].
- **4.** Select one of the following options:

Remove Device: Removes a device from the pairing list.

Rename Device: Allows you to rename the paired device.

Incoming Security: Set whether or not to confirm (Always Ask/

Always Connect) before connecting to the paired device upon receiving an incoming connection request from it.

Service Discovery: Searches for services supported by the selected device.

Device Info: Displays the paired device information.

Sending and Receiving Name Cards

Use the following procedures to send and receive a Name Card via Bluetooth®.

■ Sending a Name Card

To send a name card to the paired device via Bluetooth®:

- - Or, press the Right Soft Key [Contacts] from idle mode.
- 2. Select the Contact then press the Right Soft Key [Options].
- 3. Select Send Name Card, then press the Center Select Key [OK].
- 4. Your contact entries will be displayed in alphabetical order. Select the contact you want to send, then press the Center Select Key [MARK].
- **5.** Press the Left Soft Key [Done].

- Select the receiving device and then press the Center Select Key [OK].
- Select the device you wish to pair to in the ADD NEW DEVICE screen and press the Center Select Key [PAIR].
- 8. "Do the device codes match? #" will appear, select Yes or No and press the Center Select Key [OK].
- [Device Name] Before connecting: will appear on screen. Select Always Ask or Always Connect and press the Center Select Key [OK].

■ Sending My Name Card

To send My Name Card to the paired device via Bluetooth®:

NOTE

Register My Name Card before performing the following steps. For information about how to register My Name Card, see page 64.

- From idle mode with the flip open, press the Center Select Key [MENU], select Contacts, then press the Center Select Key [OK].
- 2. Press
 My Name Card.
- 3. Press the Right Soft Key [Options] then [*] Exchange Name Card
- 4. Select the receiving device then press the Center Select Key [OK].

■ Pulling a Name Card

You can use the following procedure to request a name card from another Bluetooth® device and add the received name card to your Contact List.

NOTE

Register My Name Card before performing the following steps. For information about how to register My Name Card, see page 64.

- From idle mode with the flip open, press the Center Select Key
 [MENU], select Contacts, then press the Center Select Key [OK].
- 2. Press a My Name Card.
- 3. Press the Right Soft Key [Options] then 6 Pull Name Card.
- 4. Select the device and then press the Center Select Key [OK].

■ Receiving a Name Card

To save a Name Card received via Bluetooth® to your Contact List:

- The message "Want to Receive files?" will appear on your handset's display when another Bluetooth[®] device sends your handset a name card.
- 2. Select Yes, then press the Center Select Key [OK].

Sending and Receiving Images

To send and receive an image via Bluetooth®:

■ Sending an Image

To send an image saved on your handset to the paired device via Bluetooth®:

- From idle mode with the flip open, press the Center Select Key [MENU], select Media Center, then press the Center Select Key [OK].
- 2. Press Picture & Video, My Pictures.
- Select the image you want to send, then press the Right Soft Key [Options].
- **4.** Press [1] **Send** and then [3] **Via Bluetooth**.
- Select the picture you want to send, press the Center Select Key [MARK], then press the Left Soft Key [Done].
- Select the device you wish to pair to in the ADD NEW DEVICE screen and press the Center Select Key [PAIR].
- "Do the device codes match? #" will appear, select Yes or No and press the Center Select Key [OK].

8. [Device Name] Before connecting: will appear on screen. Select Always Ask or Always Connect and press the Center Select Key [OK].

■ Receiving an Image

To receive and save an image sent from the paired device via Bluetooth®:

- The message "Receive Image?" will appear on your handset's display when another Bluetooth® device sends an image to your handset.
- 2. Select Yes, then press the Center Select Key [OK].

Downloading Files

If the paired device supports the File Transfer Profile (FTP), you can download files from the paired device.

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].
- 2. Press [3"] Bluetooth.
- Select the paired device, then press the Center Select Key [OK].
- 4. Press the Center Select Key [OK] to select Yes.
- 5. Select a folder and then press the Center Select Key [GET].
- Select the file you want to download and then press the Center Select Key [GET].
- 7. When the file is downloaded successfully, select one of the following options:

View downloaded: Displays the downloaded files.

Get more files: Returns to the file list to allow you to download other files

NOTES

• When you press the Right Soft Key [Options] in step 5, you can select one of the following options:

Sort By Folders: Displays folders at the top of the list. (This option does not appear when the list is displayed by folders.)

Sort Alphabetically: Displays folders and files alphabetically without separating them. (This option does not appear when the list is displayed by alphabetically.)

Save Options: Select where the downloaded file will be saved

- Phone Memory or Card Memory. (Phone/Card)

Goto Root Folder: Displays the root folder in the paired device.

- The downloaded files will be stored in either My Pictures, My Videos, My Sounds, or My Documents, depending on their file type.
- When the connection request is sent from the paired device supporting the File Transfer Profile (FTP), you can download files stored in My Pictures, My Videos, My Sounds, and My Documents on your handset to the paired device, by pressing the Center Select Key [OK] and selecting Yes.

External Keyguard Settings

NOTE

When in idle mode with the flip closed and the keypad unlocked, you can directly access the External Keyguard Settings by pressing the Directional Key \bigcirc left.

Keyguard Timer

The Keyguard Timer feature locks the side keys and touch keys to prevent them from being pressed accidentally in your bag or pocket. Set the period of time since the last key operation is made with the flip closed until this feature locks the external keys.

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].
- 2. Press 4 External Keyguard Settings, 1 Keyguard Timer.
- Select one of the following settings, then press the Center Select Key [SET].

Always Off / 7 seconds / 15 seconds / 30 seconds

NOTES

- When you open the flip, the side keys will unlock.
- When a function is active with the flip closed, the external keys will not lock.
- Even when locked, the external keys are valid in the following cases:
 - When the handset receives an incoming call.
 - During a call.
 - When the handset receives a PTT incoming call.
 - During a PTT call.

Unlock Options

Select how to temporarily unlock the external keys with the flip closed.

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].
- 2. Press [45] External Keyguard Settings, [20] Unlock Options.

Select one of the following settings, then press the Center Select Key [SET].

Press Once: Temporarily release the lock by pressing the Center Select Key with the flip closed.

Press Twice: Temporarily release the lock by pressing the Center Select Key then $\sqrt{0.161}$ with the flip closed.

Sounds Settings

Provides options to customize the handset's sounds.

Accessing the Sounds Settings submenu

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].
- 2. Press Sounds Settings.
- 3. Select a submenu:

Easy Set-Up / Call Sounds / Alert Sounds / Keypad Volume / Digit Dial Readout / Service Alerts / Power On/Off

Easy Set-Up

You can set the Call Sounds, Keypad Volume, Text Message Alert, Multimedia Message Alert, and Voicemail Message Alert all at once using the Wizard.

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press S Sounds Settings, L Easy Set-Up.
- 2. Follow the on screen prompts to set sounds settings.
 - CALL SOUNDS: Select Ring Only, Vibrate Only, Ring and Vibrate or Be Silent then press the Center Select Key [SET] to save the setting or press the Right Soft Key [Skip] to go to the next setting.

- KEYPAD VOLUME: Adjust the volume by pressing the
 Directional Key up or down, then press the Center Select Key
 [SET] to save the setting or press the Right Soft Key [Skip] to go
 to the next setting.
- TEXT MESSAGE ALERT: Select Ring Only, Vibrate Only, Ring and Vibrate or Be Silent then press the Center Select Key [SET] to save the setting or press the Right Soft Key [Skip] to go to the next setting.
- MULTIMEDIA MESSAGE ALERT: Select Ring Only, Vibrate
 Only, Ring and Vibrate or Be Silent then press the Center
 Select Key [SET] to save the setting or press the Right Soft Key
 [Skip] to go to the next setting.
- VOICEMAIL MESSAGE ALERT: Select Ring Only, Vibrate
 Only, Ring and Vibrate or Be Silent then press the Center
 Select Key [SET] to save the setting or press the Right Soft Key
 [Skip] to complete set-up.

Call Sounds

To set ringtones for types of incoming calls:

■ Call Ringtone

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press Sounds Settings, Call Sounds, Call Ringtone.
- Select a ringtone, then press the Center Select Key [SET] to save the sound. To play the ringtone, press the Left Soft Key [Play].

■ Call Vibrate

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press Sounds Settings, Call Sounds, Call Vibrate.
- 2. Select On or Off, then press the Center Select Key [SET].

■ Caller ID Readout

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [3] Sounds Settings, [2] Call Sounds, [3] Caller ID Readout.
- Select one of the following settings, then press the Center Select Key [SET].

Ring Only/Caller ID + Ring/Name Repeat

Alert Sounds

To select the alert type for a new message:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [3] Sounds Settings, [3] Alert Sounds.
- Select TXT Message/Multimedia Message/Voice Mail/ Emergency Tone/Missed Call/PTT Alert, then press the Center Select Key [OK].
- Select Tone/Vibrate/Reminder, then press the Center Select Key [OK].

Tone: Select a ringer, then press the Center Select Key **[SET]**. To play the alert tone, press the Left Soft Key **[Play]**.

Vibrate: Select On or Off, then press the Center Select Key [SET].

Reminder: Select Once/Every 2 Minutes/Every 15 Minutes/Off, then press the Center Select Key [SET].

NOTES

- Emergency Tone has the following settings: Alert/Vibrate/Off.
- PTT Alert has only two settings: Tone/Vibrate.

Keypad Volume

To set the keypad volume:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press 5 Sounds Settings, 4 Keypad Volume.
- Adjust the volume by pressing the Directional Key (3) up or down, then press the Center Select Key [SET] to save the setting.

Digit Dial Readout

To set whether to read out the numbers being entered when dialing a phone number:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press S Sounds Settings, Digit Dial Readout.
- 2. Select On or Off, then press the Center Select Key [SET].

Service Alerts

To set any of the three Alert options to either On or Off:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press S Sounds Settings, A Service Alerts.
- Select one of the following options, then press the Center Select Key [OK].

ERI: Alerts you to the status of cellular service.

Minute Beep: Alerts you every minute during a call in progress. **Call Connect:** Alerts you when the call is connected.

3. Select On or Off, then press the Center Select Key [SET].

Power On/Off

To set the handset to sound a tone when the handset is powered on/off:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press S Sounds Settings, P Power On/Off.
- 2. Press [1] Power On or [2] Power Off.
- 3. Select On or Off, then press the Center Select Key [SET].

Display Settings

Provides options to customize the handset's display screen.

Accessing the Display Settings submenu

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].
- 2. Press 6 Display Settings.
- 3. Select a submenu:

Easy Set-Up/Banner/Backlight/Wallpaper/Display Themes/ Main Menu Settings/Dial Fonts/Menu Font Size/Clock Format

Easy Set-Up

You can set the Personal Banner, Internal Display Backlight, Internal Keypad Backlight, Main Wallpaper, Display Theme, Main Menu Settings, Dial Fonts, Main Clock Format, and Front Clock Format all at once using the Wizard.

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press Display Settings, Lasy Set-Up.
- 2. Follow the on screen prompts to set display settings.
 - PERSONAL BANNER: Enter in the desired banner text, then
 press the Center Select Key [SET] to save the setting or press

- the Right Soft Key [Skip] to go to the next setting.
- INTERNAL DISPLAY BACKLIGHT: Select 7 seconds, 15 seconds, 30 seconds, or Always Off, then press the Center Select Key [SET] to save the setting or press the Right Soft Key [Skip] to go to the next setting.
- INTERNAL KEYPAD BACKLIGHT: Select 7 seconds, 15 seconds, 30 seconds, Always On, or Always Off, then press the Center Select Key [SET] to save the setting or press the Right Soft Key [Skip] to go to the next setting.
- MAIN WALLPAPER: Select the desired picture, then press the Center Select Key [SET] to save the setting or press the Right Soft Key [Skip] to go to the next setting.
- DISPLAY THEMES: Select White, Punching Metal, Paint, or Checker Plate, then press the Center Select Key [SET] to save the setting or press the Right Soft Key [Skip] to go to the next setting.
- MENU LAYOUT: Select Tab, List, or Grid, then press the Center Select Key [SET] to save the setting or press the Right Soft Key [Skip] to go to the next setting.
- MENU TYPE: Select Communicator or Messaging, then press
 the Center Select Key [SET] to save the setting or press the
 Right Soft Key [Skip] to go to the next setting.
- DIAL FONTS: Select Normal or Large, then press the Center Select Key [SET] to save the setting or press the Right Soft Key [Skip] to go to the next setting.
- MAIN CLOCK FORMAT: Select Analog, Large Analog, Digital 12, Large Digital 12, Digital 24, Large Digital 24 or Off, then press the Center Select Key [SET] to save the setting or press the Right Soft Key [Skip] to go to the next setting.
- FRONT CLOCK FORMAT: Select Digital, Analog or Off, then press the Center Select Key [SET] to save the setting or press the Right Soft Key [Skip] to complete set-up.

Banner

To set your Personal or ERI banner:

■ Personal Banner

The Personal Banner can be up to 16 characters and is displayed on the idle screen.

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press Display Settings, Banner, Personal Banner.
- Enter your banner text (up to 16 characters) then press the Directional Key down to advance to the **Text Color** field.
- Press the Directional Key ⊕ left or right to choose the desired color, then press the Center Select Key [SET].

ERI Banner

If you use ERI Service, ERI Text is shown on the sub banner.

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press A Display Settings, Banner, E ERI Banner.
- 2. Select On or Off, then press the Center Select Key [SET].

Backlight

■ Setting the Internal Display Backlight

To set the duration and brightness of backlight illumination for the internal display:

1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press Display Settings, Backlight, Display, Internal.

Select one of the following settings, then press the Center Select Key [OK].

Duration: Select **7 seconds**, **15 seconds**, **30 seconds**, or **Always Off**, then press the Center Select Key [SET].

Brightness: Press the Directional Key ⊕ left or right to set the brightness to Low, Medium Low, Medium, Medium High, or High, then press the Center Select Key [SET].

■ Setting the External Display Backlight

To set the duration of backlight illumination for the external display:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press Display Settings, Backlight, Display, Backlight, Display,
- Select one of the following settings, then press the Center Select Key [SET].

7 seconds / 15 seconds / 30 seconds

■ Setting the Keypad Backlight

To set the duration of backlight illumination for the QWERTY Keypad (Internal) or the Alphanumeric Keypad (External):

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press A Display Settings, Backlight, Reypad.
- 2. Press [1] Internal or [2] External.
- Select one of the following settings, then press the Center Select Key [SET].

7 seconds / 15 seconds / 30 seconds / Always On / Always Off

NOTE

If Always On or High are selected for the Backlight setting, the battery life may be reduced.

Wallpaper

To choose the background to be displayed on the handset:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [A] Display Settings, [4] Wallpaper.
- Select one of the following options, then press the Center Select Key [OK].

My Pictures/My Videos/Fun Animations

Select from the available screens, then press the Center Select Key [SET].

NOTE

Files larger than 5MB can not be set as Wallpaper.

Display Themes

To choose the color of the background screen:

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [6] Display Settings, [5] Display Themes.
- Select one of the following settings, then press the Center Select Key [SET].

White/Punching Metal/Paint/Checker Plate

Main Menu Settings

■ Menu Layout

To change Main Menu layout and type:

1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press (a) Display Settings, (a) Main Menu Settings, (1) Menu Layout.

Select one of the following layouts, then press the Center Select Key [SET].

Tab/List/Grid

If you selected List or Grid, select one of the following types, then press the Center Select Key [SET].

Communicator/Messaging

NOTE

All directions in this manual assume that Main Menu Settings are set to Grid and Messaging, and the Display Themes option is set to Punching Metal, which are the default settings.

■ Replace Menu Items

Main Menu items can be replaced only when Menu Layout is set to List or Grid

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press (A) Display Settings, (A) Main Menu Settings, (B) Replace Menu Items.
- Select the item you want to replace, then press the Center Select Key [EDIT].
- Select the item you want to replace it with, then press the Center Select Key [SET].
- 4. Press the Left Soft Key [Done].

■ Position Menu Items

The Position of Main Menu items can be changed only when Menu Layout is set to List or Grid.

1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press (a) Display Settings, (a) Main Menu Settings, (a) Position Menu Items.

- Select the item you want to move, then press the Center Select Key [MOVE].

If the current Main Menu Layout is Grid, press the Directional Key up, down, left or right to highlight desired position, then press the Center Select Key [SWAP].

4. Press the Left Soft Key [Done].

■ Reset Menu Settings

Main Menu Settings can be reset when Menu Layout is set to List or Grid by using the following procedure.

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press Display Settings, Main Menu Settings,
 Reset Menu Settings.
- Select one of the following options, then press the Center Select Key [OK].

Menu Layout: Reactivates the initial Main Menu Layout (Grid and Messaging).

Menu Items: Reactivates the initial content of the Menu.

Item Positions: Reorders Main Menu Items to their initial positions.

All: Reactivates all your initial Main Menu settings.

NOTE

When Menu Layout is set to Tab, Menu Layout settings can be defaulted to Grid and Messaging by pressing Main Menu Settings, Reset Menu Layout from the Display Settings submenu.

Dial Fonts

To set the font size:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press Display Settings, Dial Fonts.
- 2. Select Normal or Large, then press the Center Select Key [SET].

Menu Font Size

To set the menu font size:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press A Display Settings, * Menu Font Size.
- 2. Select Normal or Large, then press the Center Select Key [SET].

Clock Format

To choose the kind of clock to be displayed on the internal display and the external display:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press Display Settings, Clock Format.
- 2. Press Main Clock or Front Clock.
- Select one of the following settings, then press the Center Select Key [SET].

Main Clock: Analog/Large Analog/Digital 12/Large Digital 12/

Digital 24/Large Digital 24/Off

Front Clock: Digital/Analog/Off

Phone Settings

The Phone Settings menu allows you to set your handset's system.

Accessing the Phone Settings submenu

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].
- 2. Press [78] Phone Settings.
- 3. Select a submenu:

Airplane Mode/Set Shortcuts/Voice Commands Settings/ Language/Location/Current Country/Security/System Select/ NAM Selection

Airplane Mode

In Airplane Mode, all menu functions can be accessed except making calls, receiving calls, data connection and Bluetooth®.

Activating Airplane Mode will disable all wireless communications. In Airplane Mode, services that support Location On functions are temporarily disabled.

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press 7 Phone Settings, 1 Airplane Mode.
- 2. Select On or Off, then press the Center Select Key [SET].

Set Shortcuts

■ Set My Shortcuts

Your handset offers you the option of assigning four shortcuts for favorite or often-used functions.

From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [2] Phone Settings, [2] Set Shortcuts, [1] Set My Shortcuts.

- Select Shortcut 1, Shortcut 2, Shortcut 3, or Shortcut 4, then press the Center Select Key [SET].
- 3. Select a function, then press the Center Select Key [SET].

NOTES

- When in idle mode with the flip open, you can display the MY SHORTCUTS screen by pressing the Directional Key Oright.
- On the MY SHORTCUTS screen, you can select a function and then press the Center Select Key [OK] to access the function.
- On the MY SHORTCUTS screen, you can relocate a function by pressing the Right Soft Key [Move], pressing the Directional Key
 up or down, then pressing the Center Select Key [SAVE].

■ Resetting My Shortcuts

To return My Shortcuts to their original defaults:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [2] Phone Settings, [2] Set Shortcuts, [1] Set My Shortcuts.
- Select Shortcut 1, Shortcut 2, Shortcut 3, or Shortcut 4, then press the Right Soft Key [Options].
- 3. Press : Reset Shortcut ([1], [2], [3], or [4]), or Reset My Shortcuts.
- 4. Select Yes, then press the Center Select Key [OK].

Set Internal Directional Keys

You can specify the function that is accessed when you press the Directional Key 🔾 up, down or left from idle mode with the flip open.

1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [2] Phone Settings, [2] Set Shortcuts, [2] Set Internal Directional Keys.

- Select UP Directional Key, LEFT Directional Key, or DOWN Directional Key, then press the Center Select Key [SET].
- 3. Select a function, then press the Center Select Key [SET].

■ Resetting the Internal Directional Key Settings

Use the following procedure to specify the default Internal Directional Key settings.

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [2] Phone Settings, [2] Set Shortcuts, [2] Set Internal Directional Keys.
- Select UP Directional Key, LEFT Directional Key, or DOWN Directional Key, then press the Right Soft Key [Options].
- 3. Press 1 Reset ([UP], [LEFT] or [DOWN]) Key, or 2 Reset Directional Keys.
- 4. Select Yes, then press the Center Select Key [OK].

■ Set Qwerty Shortcut

You can assign a function to be launched when any alphabetical key on the QWERTY Keypad is pressed from idle mode with the flip open.

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [3] Phone Settings, [3] Set Shortcuts, [3] Set Qwerty Shortcut.
- Select one of the following options, then press the Center Select Key [SET]:
 - Off/TXT Message/Notepad/Contact List

■ Set Red Side Key

You can specify the function that is accessed when you press the Red Side Key/PTT Key (from idle mode with the flip open.

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [2] Phone Settings, [2] Set Shortcuts, [4] Set Red Side Key.
- 2. Select a function, then press the Center Select Key [SET].

NOTE

When PTT mode is ON, the Set Red Side Key submenu does not appear, and nothing can be changed.

Voice Commands Settings

To configure prompts and call alert for voice commands:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press Phone Settings, Voice Commands Settings.
- Select one of the following options and then press the Center Select Key [OK]:

Confirm Choices/Sensitivity/Adapt Voice/Prompts/Info

Language

To set the bilingual feature for either English or Spanish:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [-] Phone Settings, [-] Language.
- 2. Select English or Español, then press the Center Select Key [SET].

Location

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press 7 Phone Settings, 5 Location.
- Select one of the following settings, then press the Center Select Key [SET].

Location On: Your location is now available to the network. **E911 Only:** Your location will be hidden from the network and applications, except for 911.

NOTE

In Airplane Mode, services that support Location On functions are temporarily disabled.

Current Country

To change the handset settings to reflect the Country where you are currently located:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press 7 Phone Settings, 6 Current Country.
- Select the country where you are currently located, then press the Center Select Key [SET].

NOTE

To assure that your handset works properly while you travel, please verify the country of your current location, so the correct country code can be applied.

Security

The Security menu allows you to electronically secure the handset.

■ Edit Codes

To set a new Lock Code:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press Phone Settings, Security.
- Enter the four-digit Lock Code, then press the Center Select Key [OK].
- 3. Press [1] Edit Codes.
- **4.** Select one of the following settings, then press the Center Select Key **[OK]**.

Phone Only: Allows you to edit the Lock Code for the handset only.

Calls & Services: Allows you to edit the Lock Code for all Calls & Services.

- 5. Enter the new four-digit code in the Enter New Code field.
 If you selected Calls & Services in step 4, you would also need to enter the current code before entering the new code.
- Press the Directional Key Q down to advance to the Re-enter New Code field.
- 7. Enter the new four-digit code again as confirmation.
- 8. Press the Center Select Key [SET].

NOTES

- The default Lock Code is the last 4 digits of your phone number.
- There are two Lock Codes: Phone Only and Calls & Services.

■ Restrictions

Use the following procedure to configure Location Setting, Calls, Messages, and Dial-Up Modem restrictions.

- Enter the four-digit Lock Code, then press the Center Select Key [OK]. The default Lock Code is the last 4 digits of your mobile telephone number.
- 3. Press 2 Restrictions.
- Enter the four-digit Lock Code, then press the Center Select Key [OK].
- 5. Select one of the following settings and then press the Center Select Key [OK]:

Location Setting: Unlock Setting/Lock Setting

Calls: Incoming Calls/Outgoing Calls

For Incoming Calls, set Allow All/Contacts Only/Block All. For Outgoing Calls, set Allow All/Contacts Only/Block All.

Messages: Incoming Messages/Outgoing Messages

For Incoming Messages, set **Allow All/Block All**.

For Outgoing Messages, set Allow All/Block All.

Dial-Up Modem: Allow/Block

To set any of the submenus, press the Center Select Key [SET].

■ Phone Lock Setting

This setting specifies whether the handset should be locked whenever it is turned on.

Lock Mode prevents the unauthorized use of your handset. Once the handset is locked, it is in restricted mode until the Lock Code is entered. When in Lock Mode, you can only receive a phone call, make a 911 call, or call an (In Case of Emergency) ICE contact. You can change the Lock Code using the Security menu.

From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [7] Phone Settings, [7] Security.

- Enter the four-digit Lock Code, then press the Center Select Key [OK]. The default Lock Code is the last 4 digits of your phone number.
- 3. Press ³ Phone Lock Setting.
- Select one of the following settings, then press the Center Select Key [SET].

Unlocked: Your handset is unlocked.

On Power Up: Your handset will be locked when it is turned on.

■ Lock Phone Now

- Enter the four-digit Lock Code, then press the Center Select Key [OK]. The default Lock Code is the last 4 digits of your phone number.
- 3. Press [45] Lock Phone Now.

NOTES

- With the flip open, to unlock the handset, press the Right Soft
 Key [Unlock] from idle mode, enter the four-digit Lock Code then
 press the Center Select Key [OK].
- With the flip closed, to unlock the handset, press the Center Select Key from idle mode, and then enter at the prompt.
 Next, enter the four-digit Lock Code and press the Center Select Key.

■ Restore Phone

To delete all User Data and restore all settings to their initial defaults:

From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press ? Phone Settings, ? Security.

- Enter the four-digit Lock Code, then press the Center Select Key [OK].
- 3. Press [5th] Restore Phone.
- After reading the warning message that appears, select Yes and press the Center Select Key [OK].
- After reading the message that appears, press the Center Select Key [OK].
- 6. Enter the four-digit Lock Code, then press the Center Select Key [OK]. The handset will turn off and then back on again automatically.

System Select

You can set your handset to search or roam for another network when you are not in your home area.

Leave this setting as default unless you want to alter the system selection as instructed by your service provider.

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [7] Phone Settings. [8] System Select.
- Select one of the following settings, then press the Center Select Key [SET].

Home Only: Only within your home area or home affiliated area. **Automatic:** Scan radio channels based on the Automatic setting.

NOTES

- After you purchase your handset but before you activate it by obtaining a phone number, the available settings will be Home Only, Automatic A, and Automatic B.
 - After the handset is activated by obtaining a phone number, Home Only and Automatic settings will be available.
- When PTT mode is on, you cannot change this setting.

NAM Selection

To select the handset's NAM (Number Assignment Module) if the handset is registered with multiple service providers:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press Phone Settings, NAM Selection.
- 2. Select NAM 1 or NAM 2, then press the Center Select Key [SET].

NOTE

When PTT mode is on, you cannot change this setting.

Call Settings

The Call Setup menu allows you to designate how the handset handles both incoming and outgoing calls.

Accessing the Call Settings submenu

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].
- 2. Press * Call Settings.
- 3. Select a submenu:

Answer Options/End Call Options/Auto Retry/TTY Mode/One Touch Dial/Voice Privacy/PC Connections/DTMF Tones/PTT Mode/Assisted Dialing

Answer Options

To set how to answer an incoming call:

From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press * Call Settings, * Answer Options.

 Select Flip Open, Any Key, or Auto with Handsfree, press the Center Select Key [MARK] then the Left Soft Key [Done].
 "ANSWER OPTIONS SET" will appear on the display.

NOTES

- The Auto with Handsfree Mode will function after about five seconds.
- When the handset is closed, the Auto with Handsfree Mode will not function, except when connected to a headset.
 When the handset is open, the Auto w/Handsfree Mode will only function when the Speakerphone is on.
- Flip Open and Any Key are the default settings.

End Call Options

To set whether to end a call by closing the flip:

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press * Call Settings, * End Call Options.
- Select Flip Close or End Key Only, then press the Center Select Key [SET].

NOTE

Even if End Call Options is set to Flip Close, closing the flip does not end a call when the Speakerphone is on.

Auto Retry

To set the length of time the handset waits before automatically redialing a number when the attempted call fails:

From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [s] Call Settings, [s] Auto Retry.

Select one of the following settings, then press the Center Select Key [SET].

10 seconds / 30 seconds / 60 seconds / Off

TTY Mode

You can attach a TTY device to your handset enabling you to communicate with other parties using a TTY device.

A phone with TTY support is able to translate typed characters to voice. Voice can also be translated into characters and then displayed on the TTY.

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press at Call Settings, 4 TTY Mode.
- A warning message "Enabling TTY will disable headset audio." appears on the display. Press the Center Select Key [OK].
- Select one of the following settings, then press the Center Select Key [SET].

TTY Full/TTY+Talk/TTY+Hear/TTY Off

One Touch Dial

To initiate a speed dial call by holding down the speed dial digit:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press (a)* Call Settings, (s)* One Touch Dial.
- **2.** Select **On** or **Off**, then press the Center Select Key **[SET]**.

NOTE

If One Touch Dial is disabled, Speed Dial numbers designated in your Contacts will not function.

Voice Privacy

To turn the voice privacy feature On or Off:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [s*] Call Settings, [6*] Voice Privacy.
- 2. Select On or Off, then press the Center Select Key [SET].

PC Connections

Allows you to use wireless data communication services, which use subscriber terminals for access to the internet with personal computers or laptops. The connection speed depends on your carrier's network and other variables. Contact communication information specifications must match the network.

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press * Call Settings, * PC Connections.
- Select one of the following settings, then press the Center Select Key [SET].

USB/Bluetooth/Close

NOTE

If you select Bluetooth, you cannot change PTT mode.

DTMF Tones

To set the Key Tone length and touch tone playback speed:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [s*] Call Settings, [s*] DTMF Tones.
- Select one of the following settings, then press the Center Select Key [SET].

Normal: Sends out a tone for a fixed period of time even if you continue to press the key.

Long: Sends out a continuous tone for the duration the key is pressed and held.

PTT Mode

You can use the following procedure to turn the PTT feature On or Off. When PTT is turned on, you will be able to send and receive PTT calls or alerts.

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press at Call Settings, PTT Mode.
- 2. Select On or Off, then press the Center Select Key [OK].

NOTE

The 3G or 1x service indicator icon on the top line of the main display is highlighted to indicate that the PTT service is available.

Assisted Dialing

Assisted Dialing allows easy dialing of international calls while roaming in another country. First, set Reference Country to your home location.

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press (a) Call Settings, (a) Assisted Dialing.
- **2.** Press the Directional Key \odot left or right to select **On** or **Off**.
- Select the Reference Country field, then press Left Soft Key [Set] to select country.
- **4.** Select the desired country, then press the Center Select Key **[OK]**. If you want to edit details, press Left Soft Key **[Details]** to edit and save the Country Code, International Dialing Digits (IDD) Prefix, the National Dialing Digits (NDD) Prefix, Area/City Code, and the National Number Length, then press the Center Select Key **[SAVE]**.

5. Press the Center Select Key [OK].

Memory

You can view details about the information stored in your handset's internal memory and on a memory card inserted in the handset.

Accessing the Memory submenu

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].
- 2. Press of Memory.
- 3. Select a submenu:

Save Options/Phone Memory/Card Memory

Save Options

To select whether to save to Phone Memory or to Card Memory when saving a file:

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press [7] Memory. [7] Save Options.
- Select one of the following settings, then press the Center Select Key [OK].

Pictures/Videos/Sounds

Select Phone Memory or Card Memory, then press the Center Select Key [SET].

Phone Memory and Card Memory

Select this option to display Phone or Card Memory information, and to delete or move files saved in Phone or Card Memory.

- 1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press Memory, Phone Memory or Card Memory
- Select one of the following settings, then press the Center Select Key [OK].

Memory Usage/My Pictures/My Videos/My Ringtones/My Music/My Sounds/My Contacts/My Documents/Move All to Card(Move All to Phone)

- Press the Right Soft Key [Options].
- 4. Select Erase if you want to delete a file or Move if you want to move a file to Card or Phone Memory, then press the Center Select Key [OK].
- Select a file or a contact, press the Center Select Key [MARK] or the Right Soft Key [Mark All], then press the Left Soft Key [Done].
- **6.** Select **Yes**, then press the Center Select Key **[OK]**.

NOTES

- Selecting Memory Usage in step 2 displays the available memory capacity, used capacity, and total capacity.
- Selecting Move All To Card in step 2 moves all the files stored in Phone Memory to Card Memory.
- Selecting Move All To Phone in step 2 moves all the files stored in Card Memory to Phone Memory.
- Do not remove the memory card from the handset while files are being transferred.
- To view Card Memory, a memory card (sold separately) must be inserted in your handset.

USB Mode

Your handset has the ability to automatically detect connection of a USB cable (purchased separately) from the handset to your PC.

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].
- 2. Press o' USB Mode.
- Select one of the following settings, then press the Center Select Key [SET].

Media Sync Mode/Modem Mode/Ask On Plug

NOTES

- Before connecting the handset to your PC with a USB cable, check that your handset is not locked.
- While a USB cable is connected to your handset, if you select
 Media Sync Mode or Modem Mode, all calls and Bluetooth®
 functions will be temporarily disabled. Unplug the USB cable from your handset to be able to make or receive calls, and to enable Bluetooth® function.

Phone Info

Accessing the Phone Info submenu

To display information about your handset:

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].
- 2. Press a Phone Info.
- Select a submenu and press the Center Select Key [OK]:
 My Number/SW/HW Version/Icon Glossary/Software Update

My Number

To view your handset's Mobile Device Number (MDN), Mobile Identifications Number (MIN), and other device information:

 From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press a Phone Info, My Number.

SW/HW Version

To view the Software, PRL, ERI, Browser, Media Center, MSUI and HW versions, and MEID, Software Update Client, BT Mac Address, Warranty Date Code:

1. From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press • Phone Info, SW/HW Version.

Icon Glossary

To view all the icons and their meanings:

 From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press
Phone Info,
Place Icon Glossary.

NOTE

For more information on the icons, see page 15.

Software Update

■ Status

To check the status of a Software Update:

From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK]. Press Phone Info, (4) Software Update, (1) Status.

■ Check new

To check for and execute a Software Update:

- From idle mode with the flip open, press the Center Select Key
 [MENU], select Settings & Tools, then press the Center Select
 Key [OK]. Press Phone Info, Software Update, Check
 New
- 2. If there is a new Software Update, it will be downloaded.
- After download is complete, press the Center Select Key [OK] or wait for three minutes to execute the Software Update.

Warning!

You cannot make phone calls including 911 emergency calls, nor answer calls while a Software Update is in progress.

NOTES

- After the software download is complete, you can press the Left Soft Key [Info] to check the content of the downloaded Software Update.
- After the software download is complete, you can press the Right Soft Key [Options] and then [] Defer to set a time when Software Update should start.
- After the software download is complete, you can press the Right Soft Key [Options], then Reject to reject the Software Update.

Set-up Wizard

You can set the Call Sounds, Display Themes, Main Menu Settings, Main Clock Format, and Front Clock Format all at once using the Wizard.

- From idle mode with the flip open, press the Center Select Key [MENU], select Settings & Tools, then press the Center Select Key [OK].
- 2. Press w Set-up Wizard.
- **3.** Follow the on screen prompts to the above settings.
 - CALL SOUNDS: Select Ring Only, Vibrate Only, Ring&Vibrate
 or Be Silent then press the Center Select Key [SET] to save
 the setting or press the Right Soft Key [Skip] to go to the next
 setting.
 - DISPLAY THEMES: Select White, Punching Metal, Paint, or Checker Plate, then press the Center Select Key [SET] to save the setting or press the Right Soft Key [Skip] to go to the next setting.
 - MENU LAYOUT: Select Tab, List, or Grid, then press the Center Select Key [SET] to save the setting or press the Right Soft Key [Skip] to go to the next setting.
 - MENU TYPE: Select Communicator or Messaging, then press the Center Select Key [SET] to save the setting or press the Right Soft Key [Skip] to go to the next setting.
 - MAIN CLOCK FORMAT: Select Analog, Large Analog, Digital 12, Large Digital 12, Digital 24, Large Digital 24 or Off, then press the Center Select Key [SET] to save the setting or press the Right Soft Key [Skip] to go to the next setting.
 - FRONT CLOCK FORMAT: Select Digital, Analog or Off, then
 press the Center Select Key [SET] to save the setting or press
 the Right Soft Key [Skip] to complete set-up.

Safety

TIA Safety Information

The following is the complete TIA Safety Information for wireless handheld phones.

■ Tips on Efficient Operation

Do not touch the antenna unnecessarily when the phone is in use. Contact with the antenna affects call quality and may cause the phone to consume more power than otherwise needed.

Driving

Talking on the phone while driving is extremely dangerous and is illegal in some states. Remember, safety comes first. Check the laws and regulations on the use of phones in the areas where you drive. Always obey them.

If you must use your phone while driving, please:

- Give full attention to driving. Driving safely is your first responsibility.
- Use hands-free operation and/or one-touch, speed dialing, and auto answer modes.
- Pull off the road and park before making or answering a call.

An air bag inflates with great force. DO NOT place objects, including either installed or portable wireless equipment, in the area over the air bag or in the air bag deployment area.

If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

Warning!

Failure to follow these instructions could lead to serious personal injury and possible property damage.

■ Electronic Devices

Your wireless handheld portable telephone is a low power radio transmitter and receiver. When it is ON, it receives and also sends out radio frequency (RF) signals.

Most modern electronic equipment is shielded from RF energy.

However, certain electronic equipment may not be shielded against the RF signals from your wireless phone. Therefore, use of your phone must be restricted in certain situations.

Pacemakers

The Health Industry Manufacturers Association recommends that a minimum separation of six (6) inches be maintained between a handheld wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research.

Never come closer than six (6) inches to a person with a heart pacemaker implant when using your phone. Doing so could result in interference with the function of the pacemaker.

Persons with pacemakers:

- ALWAYS keep the phone more than six (6) inches from your pacemaker when the phone is turned on.
- Do not carry the phone in a breast pocket.
- Use the ear opposite the pacemaker to minimize the potential for interference.
- If you have any reason to suspect that interference is taking place, turn your phone OFF immediately.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your service provider (or call the customer service line to discuss alternatives).

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if they are adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information.

Hospitals and Health Care Facilities

Turn your phone OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

■ Posted Facilities

Turn your phone OFF where posted notices so require.

■ Aircraft

FCC regulations prohibit using your phone while in the air. Turn your phone OFF before boarding an aircraft.

Always request and obtain prior consent and approval of an authorized airline representative before using your phone aboard an aircraft. Always follow the instructions of the airline representative whenever using your phone aboard an aircraft, to prevent any possible interference with airborne electronic equipment.

■ Blasting Areas

To avoid interfering with blasting operations, turn your phone OFF when in a "blasting area" or in areas posted "Turn off two-way radio". Obey all signs and instructions.

■ Potentially Explosive Atmospheres

Turn your phone OFF when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include fueling areas such as gas stations; below deck on boats; fuel or chemical transfer or storage facilities; vehicles using liquefied petroleum gas (such as propane or butane); areas where the air contains chemicals or articles, such as grain, dust, or metal powders; and any other area where you would normally be advised to turn off your vehicle's engine.

Safety Information for FCC RF Exposure

Warning!

Read this information before using.

In August 1996 the Federal Communications Commission (FCC) of the United States with its action in Report and Order FCC 96-326 adopted an updated safety standard for human exposure to radio frequency electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies. The design of this phone complies with the FCC guidelines and these international standards.

■ Body-Worn Operation

This device was tested for typical body-worn operations with the back of the phone kept 2.0 cm from the body. To maintain compliance with FCC RF exposure requirements, use only belt-clips, holsters or similar accessories that maintain a 2.0 cm separation distance between the user's body and the back of the phone, including the antenna. The use of belt-clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

■ SAR information

THIS MODEL PHONE MEETS THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg.* Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to

use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when tested for use at the ear is 0.813 W/Kg and when worn on the body, as described in this guide, is 0.752 W/Kg. (Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements). While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of

http://www.fcc.gov/oet/ea/fccid after searching on TYKNX9290. Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications & Internet Association (CTIA) web-site at http://www.ctia.org.

* In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against

harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. if this equipment does cause harmful interference to television reception, which can be determined by turning the equipment off and on the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

FDA Information



U.S. Food and Drug Administration
Cell Phone Facts
Consumer Information on Wireless Phones

What kinds of phones are the subject of this update?

The term "wireless phone" refers here to hand-held wireless phones with built-in antennas, often called "cell," "mobile," or "PCS" phones. These types of wireless phones can expose the user to measurable radiofrequency energy (RF) because of the short distance between the phone and the user's head. These RF exposures are limited by Federal Communications Commission safety guidelines that were developed with the advice of FDA and other federal health and safety agencies. When the phone is located at greater distances from the user, the exposure to RF is drastically lower because a person's RF exposure decreases rapidly with increasing distance from the source.

The so-called "cordless phones," which have a base unit connected to the telephone wiring in a house, typically operate at far lower power levels, and thus produce RF exposures well within the FCC's compliance limits.

■ Do wireless phones pose a health hazard?

The available scientific evidence does not show that any health problems are associated with using wireless phones. There is no proof, however, that wireless phones are absolutely safe. Wireless phones emit low levels of radiofrequency energy (RF) in the microwave range while being used. They also emit very low levels of RF when in the stand-by mode. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low level RF that does not produce heating effects causes no known adverse health effects. Many studies of low

level RF exposures have not found any biological effects. Some studies have suggested that some biological effects may occur, but such findings have not been confirmed by additional research. In some cases, other researchers have had difficulty in reproducing those studies, or in determining the reasons for inconsistent results.

What is FDA's role concerning the safety of wireless phones?

Under the law, FDA does not review the safety of radiation-emitting consumer products such as wireless phones before they can be sold, as it does with new drugs or medical devices. However, the agency has authority to take action if wireless phones are shown to emit radiofrequency energy (RF) at a level that is hazardous to the user. In such a case, FDA could require the manufacturers of wireless phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory

actions, FDA has urged the wireless phone industry to take a number of steps, including the following:

- Support needed research into possible biological effects of RF of the type emitted by wireless phones;
- Design wireless phones in a way that minimizes any RF exposure to the user that is not necessary for device function; and
- Cooperate in providing users of wireless phones with the best possible information on possible effects of wireless phone use on human health

FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of RF safety to ensure coordinated efforts at the federal level. The following agencies belong to this working group:

- National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Federal Communications Commission
- Occupational Safety and Health Administration
- National Telecommunications and Information Administration
 The National Institutes of Health participates in some interagency working group activities, as well.

FDA shares regulatory responsibilities for wireless phones with the Federal Communications Commission (FCC). All phones that are sold in the United States must comply with FCC safety guidelines that limit RF exposure. FCC relies on FDA and other health agencies for safety questions about wireless phones.

FCC also regulates the base stations that the wireless phone networks rely upon. While these base stations operate at higher power than do the wireless phones themselves, the RF exposures that people get from these base stations are typically thousands of times lower than those they can get from wireless phones. Base stations are

thus not the primary subject of the safety questions discussed in this document.

■ What are the results of the research done already?

The research done thus far has produced conflicting results, and many studies have suffered from flaws in their research methods. Animal experiments investigating the effects of radiofrequency energy (RF) exposures characteristic of wireless phones have yielded conflicting results that often cannot be repeated in other laboratories. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. However, many of the studies that showed increased tumor development used animals that had been genetically engineered or treated with cancer-causing chemicals so as to be pre-disposed to develop cancer in the absence of RF exposure. Other studies exposed the animals to RF for up to 22 hours per day. These conditions are not similar to the conditions under which people use wireless phones, so we don't know with certainty what the results of such studies mean for human health.

Three large epidemiology studies have been published since December 2000. Between them, the studies investigated any possible association between the use of wireless phones and primary brain cancer, glioma, meningioma, or acoustic neuroma, tumors of the brain or salivary gland, leukemia, or

other cancers. None of the studies demonstrated the existence of any harmful health effects from wireless phone RF exposures. However, none of the studies can answer questions about long-term exposures, since the average period of phone use in these studies was around three years.

What research is needed to decide whether RF exposure from wireless phones poses a health risk?

A combination of laboratory studies and epidemiological studies of people actually using wireless phones would provide some of the data that are needed. Lifetime animal exposure studies could be completed in a few years. However, very large numbers of animals would be needed to provide reliable proof of a cancer promoting effect if one exists. Epidemiological studies can provide data that is directly applicable to human populations, but 10 or more years' follow-up may be needed to provide answers about some health effects, such as cancer. This is because the interval between the time of exposure to a cancer-causing agent and the time tumors develop—if they do—may be many, many years. The interpretation of epidemiological studies is hampered by difficulties in measuring actual RF exposure during day-to-day use of wireless phones. Many factors affect this measurement, such as the angle at which the phone is held, or which model of phone is used.

What is FDA doing to find out more about the possible health effects of wireless phone RF?

FDA is working with the U.S. National Toxicology Program and with groups of investigators around the world to ensure that high priority animal studies are conducted to address important questions about the effects of exposure to radiofrequency energy (RF).

FDA has been a leading participant in the World Health Organization International Electromagnetic Fields (EMF) Project since its inception in 1996. An influential result of this work has been the development of a detailed agenda of research needs that has driven the establishment of new research programs around the world. The Project has also helped develop a series of public information documents on EMF issues

FDA and the Cellular Telecommunications & Internet Association (CTIA) have a formal Cooperative Research and Development Agreement (CRADA) to do research on wireless phone safety. FDA provides the scientific oversight, obtaining input from experts in government, industry, and academic organizations. CTIA-funded research is conducted through contracts to independent investigators. The initial research will include both laboratory studies and studies of wireless phone users.

The CRADA will also include a broad assessment of additional research needs in the context of the latest research developments around the world.

What steps can I take to reduce my exposure to radiofrequency energy from my wireless phone?

If there is a risk from these products—and at this point we do not know that there is—it is probably very small.

But if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your exposure to radiofrequency energy (RF). Since time is a key factor in how much exposure a person receives, reducing the amount of time spent using a wireless phone will reduce RF exposure.

If you must conduct extended conversations by wireless phone
every day, you could place more distance between your body and
the source of the RF, since the exposure level drops off dramatically
with distance. For example, you could use a headset and carry
the wireless phone away from your body or use a wireless phone
connected to a remote antenna.

Again, the scientific data do not demonstrate that wireless phones are harmful. But if you are concerned about the RF exposure from these products, you can use measures like those described above to reduce your RF exposure from wireless phone use.

■ What about children using wireless phones?

The scientific evidence does not show a danger to users of wireless phones, including children and teenagers. If you want to take steps to lower exposure to radiofrequency energy (RF), the measures described above would apply to children and teenagers using wireless phones. Reducing the time of wireless phone use and increasing the distance between the user and the RF source will reduce RF exposure.

Some groups sponsored by other national governments have advised that children be discouraged from using wireless phones at all. For example, the government in the United Kingdom distributed leaflets containing such a recommendation in December 2000. They noted that no evidence exists that using a wireless phone causes brain tumors or other ill effects. Their recommendation to limit wireless phone use by children was strictly precautionary; it was not based on scientific evidence that any health hazard exists.

■ Do hands-free kits for wireless phones reduce risks from exposure to RF emissions?

Since there are no known risks from exposure to RF emissions from wireless phones, there is no reason to believe that hands-free kits reduce risks. Hands-free kits can be used with wireless phones for convenience and comfort. These systems reduce the absorption of RF energy in the head because the phone, which is the source of the RF emissions, will not be placed against the head.

On the other hand, if the phone is mounted against the waist or other part of the body during use, then that part of the body will absorb more RF energy. Wireless phones marketed in the U.S. are required to meet safety requirements regardless of whether they are used against the head or against the body. Either configuration should result in compliance with the safety limit.

■ Do wireless phone accessories that claim to shield the head from RF radiation work?

Since there are no known risks from exposure to RF emissions from wireless phones, there is no reason to believe that accessories that claim to shield the head from those emissions reduce risks. Some products that claim to shield the user from RF absorption use special phone cases, while others involve nothing more than a metallic accessory attached to the phone. Studies have shown that these products generally do not work as advertised. Unlike "hands-free" kits, these so-called "shields" may interfere with proper operation of the phone. The phone may be forced to boost its power to compensate, leading to an increase in RF absorption. In February 2002, the Federal Trade Commission (FTC) charged two companies that sold devices that claimed to protect wireless phone users from radiation with making false and unsubstantiated claims. According to FTC, these defendants lacked a reasonable basis to substantiate their claim.

What about wireless phone interference with medical equipment?

Radiofrequency energy (RF) from wireless phones can interact with some electronic devices. For this reason, FDA helped develop a detailed test method to measure electromagnetic interference (EMI) of implanted cardiac pacemakers and defibrillators from wireless telephones.

This test method is now part of a standard sponsored by the Association for the Advancement of Medical Instrumentation (AAMI). The final draft, a joint effort by FDA, medical device manufacturers, and many other groups, was completed in late 2000. This standard will allow manufacturers to ensure that cardiac pacemakers and defibrillators are safe from wireless phone EMI.

FDA has tested hearing aids for interference from handheld wireless

phones and helped develop a voluntary standard sponsored by the Institute of Electrical and Electronic Engineers (IEEE). This standard specifies test methods and performance requirements for hearing aids and wireless phones so that no interference occurs when a person uses a "compatible" phone and a "compatible" hearing aid at the same time. This standard was approved by the IEEE in 2000. FDA continues to monitor the use of wireless phones for possible interactions with other medical devices. Should harmful interference be found to occur, FDA will conduct testing to assess the interference and work to resolve the problem.

For more information, please visit the FDA website at http://www.fda.gov/cellphones.

Emergency Calls

Never rely solely upon your wireless phone for essential communications (e.g., medical emergencies), if it can be avoided, since a wireless phone requires a complex combination of radio signals, relay stations and landline networks for its operation. Consequently, emergency calls may not always be possible under all conditions on all wireless phone systems. Your wireless phone, however, may sometimes be the only available means of communication at the scene of an accident. When making an emergency call, always give the recipient all necessary information as accurately as possible. Never terminate an emergency call until you have received clearance to do so.

■ FCC Enhanced 911 (E911) Rules Background

The Federal Communications Commission (FCC) requires wireless carriers to transmit specific latitude and longitude location (Automatic Location Identification = ALI) information as well as "911" calls to Public Safety Answering Points (PSAPs) to identify the location of

the caller in case of emergency. Generally, the rules require that carriers identify an E911 caller's location within 50 meters of the actual location for 67 percent of calls and within 150 meters of the actual location for 95 percent of calls.

■ Casio G'zOne Brigade's ALI Capability

The Brigade is an ALI-capable phone equipped with a GPS (Global Positioning System) receiver supporting a satellite-based GPS ALI-capable network to comply with the FCC's ALI requirements. The network compliance with the above FCC requirements is dependent on: (a) the use of digital technology by the wireless network; (b) GPS satellite signals being able to reach the handset (such transmissions do not always work indoors, for example); and (c) handset signals reaching wireless "base stations" (atmospheric and environmental conditions may cause variations in handset receiving signal strength).

Also the transmission of the ALI information is subject, in part, to system constraints within the wireless network to which the E911 signal is transmitted and over which PCD has no control. Finally, customers are advised that the Brigade's ALI capability is to be used for E911 purposes only.

911 in Lock Mode

The "911" call service is available even in the lock mode.

- **1.** Enter "911" then press the Send Key.
- 2. The call connects.
- 3. The phone exits the Lock Mode for 5 minutes.
- 4. To exit emergency mode, press the End/Power Key.

911 Using Any Available System

- 1. Enter "911" then press the Send Key.
- 2. The call connects.

- **3.** The phone remains in Emergency Mode for 5 minutes.
- 4. To exit emergency mode, press the End/Power Key.

Compliance with Other FCC Regulations ■ Operating Procedures

Never violate any of the following Rules and Regulations of the FCC when using your Cellular Phone. Such violations are punishable by fine, imprisonment or both.

- Never use obscene, indecent, or profane language.
- Never use your Cellular Phone to send false distress calls.
- Never wiretap or otherwise intercept a phone call, unless you have first obtained the consent of the parties participating in the call.
- Never make any anonymous calls to annoy, harass, or molest other people.
- Never charge another account without authorization, to avoid payment for service.
- Never willfully or maliciously interfere with any other radio communications
- Never refuse to yield the line when informed that it is needed for an Emergency Call. Also, never take over a line by stating falsely that it is needed for an emergency.

General Safety

■ Precautions

Your Handheld Portable Telephone is a high quality piece of equipment. Before operating, read all instructions and cautionary markings on the product, battery and adapter/charger.

Failure to follow the directions below could result in serious bodily injury and/or property damage due to battery liquid leakage, fire or rupture.

DO NOT use or store this equipment in a place where it will be exposed to high temperatures, such as near an open flame or heat-

emitting equipment.

DO NOT drop your device or subject it to severe shock. When not using, lay down the unit to avoid possible damage due to instability. DO NOT expose this equipment to rain or spilled beverages.

DO NOT use unauthorized accessories.

DO NOT disassemble the phone or its accessories. If service or repair is required, return unit to an authorized PCD cellular service center. If unit is disassembled, the risk of electric shock or fire may result. DO NOT place this equipment inside the microwave or pressurized container. It may cause the explosion, product failure and fire. DO NOT throw device into the fire or heat. It may cause the explosion or fire.

DO NOT short the terminal. Also, protect the terminal so that the conductive objects, such as metal piece and pencil lead, do not touch or get caught into the terminal. It may cause the fire or product failure.

When plugging the AC-Adapter, do not expose the metal strap or accessory to the electric plug. It may cause the fire, electric shock, injury or product failure.

To avoid the risk electric shock, do not use device while lightning outside.

The device is not water-proof. By placing it under faucet or shower and adding water-pressure, or submerging it inside water for a long time, the warranty will be invalid because the device will become non-repairable. If, by an accident, you spill the fluid, such as water, on device, turn off the power, remove the battery pack and wipe off the fluid with dry, clean cloth. By using device with fluid attached to it, it may cause heat generation, fire, product failure and electric shock. The device is not heat-resistant. Do not place it into hot bath or liquid soap. Never touch device's charging terminal with hand or finger. It may cause electric shock, injury or product failure. If device does not finish recharging within the specified timeframe, stop recharging. It

may cause leakage, heat generation, explosion or fire.

If device is damaged by dropping and the internal parts are exposed, do not touch the exposed parts. You might get electric shock or injured from damaged parts. Call the customer service for assistance.

Do not place device on unstable area, such as wobbly stool or slanted places. Device may drop and cause injury. Also watch for shocks, particularly during vibrator mode.

DO NOT place device around child. They may accidentally swallow device and suffocate.

Stop using device, if it starts to smoke, smell, make abnormal sound or generate heat. If abnormality starts to happen while recharging, remove AC-Adapter or DC-Adapter from the plug or cigar lighter adapter, check that device has cooled down, turn off the power, remove the battery pack and call the customer service for assistance. Also, if device has been damaged by dropping or getting wet, discontinue using device and call the customer service.

Never try to repair device yourself. It is highly dangerous.

Do not touch device, battery pack or battery charging device for a long time while it is being recharged. It may cause the low-temperature burn.

If you are using the metal strap, be sure that it does not touch the handset charging cradle or the charging terminal, especially the plug, while recharging. It may cause the electric shock, fire, injury or product failure.

To avoid falling or getting into a traffic accident, check for your safety and the safety around you while placing a call, messaging, taking picture or playing game using device.

To avoid injury, do not use device as the earpiece magnet picks up metal objects such as pins.

Never bring device near a floppy disk, magnetic card, magnetic tape, MOs, MDs, prepaid card, or other similar objects. It may destroy or

corrupt these data.

Never press or poke display with your finger or other object. It may cause damage to display.

Never twist device. It may cause product failure.

DO NOT put stickers on LCD screen or keypad. these stickers may touch and press keys when the Flip Top is closed. This may cause improper operating of the phone.

■ Antenna Safety

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could impair call quality, damage the phone, or result in violation of FCC regulations. Please contact your local dealer for replacement antenna. Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with the skin, a minor burn may result. Please contact your local dealer for replacement antenna.

■ Battery Safety

Your device uses a removable and rechargeable lithium ion battery. Please contact customer service for assistance should you need a replacement battery.

DOs

- Only use Casio branded batteries specific to your phone model.
- Use only the Wall charger provided with the phone. Using any charger other than the one included with the phone may damage your phone or battery.
- Only use the battery and charger approved by the manufacturer.
- Only use the battery for its original purpose.
- Try to keep batteries in a temperature between 41°F (5°C) and 95°F (35°C).

- If the battery is stored in temperatures above or below the recommended range, give it time to warm up or cool down before using.
- Completely drain the battery before recharging. It may take one to four days to completely drain.
- When the device is not used for long period, remove the battery from the device.
- Store the discharged battery in a cool, dark, and dry place.
- Purchase a new battery when its operating time gradually decreases after fully charging.
- Properly dispose of the battery according to local regulations.

DON'Ts

- Don't attempt to disassemble the battery—it is a sealed unit with no serviceable parts.
- Don't expose the battery terminals to any other metal object (e.g., by carrying it in your pocket or purse with other metallic objects such as coins, clips and pens).
 - This can short circuit and critically damage the battery, and may cause the fire or injury.
- Don't leave the battery in hot or cold temps.
 Otherwise, it could significantly reduce the capacity and lifetime of the battery.
- Don't dispose of the battery into a fire.
- Don't short the positive electrode and negative electrode on battery pack.
- Don't nail, hit with hammer, or step on battery pack.
 It may cause fire or damage.
- Don't use the battery pack with damage or leak.

Lithium ion batteries are recyclable. When you replace your built-in battery, please request the repair center to recycle the battery in accordance with RBRC standards. When disposing of the battery by

yourself, please call RBRC at (800) 822-8837 for proper disposal tips. Never touch any fluid that might leak from the built-in battery. Such liquid when in contact with the eyes or skin, could cause injury to the skin or eyes. Should the liquid come into contact with the eyes, irrigate the eyes thoroughly with clean water and immediately seek medical attention. In the event the liquid comes into contact with the skin or clothing, wash it away immediately with clean water.

■ Charger

The Wall Charger and Desktop Charger designed by PCD for this unit both require the use of a standard 120 V AC power source for their operation.

Never attempt to disassemble or repair a wall charger or desktop charger. Never use a wall charger or desktop charger if it has a damaged or worn power cord or plug. Always contact a PCD authorized service center, if repair or replacement is required. Never alter the AC cord or plug on your wall charger or desktop charger. If the plug will not fit into the available outlet, have a proper outlet installed by a qualified electrician.

Never allow any liquids or water to spill on the wall charger or desktop charger when it is connected to an AC power source.

Always use the authorized PCD wall charger or desktop charger to avoid any risk of bodily injury or damage to your cellular phone or battery.

Never attempt to connect or disconnect the wall charger or desktop charger with wet hands. Always unplug the wall charger or desktop charger from the power source before attempting any cleaning. Always use a dry, soft cloth dampened with water to clean the equipment, after it has been unplugged.

Handling the cord on this product or cords associated with accessories sold with this product, will expose you to lead, a chemical known to the State of California to cause birth defects or other

reproductive harm. Wash hands after handling.

Always disconnect the wall charger or desktop charger from the power source when it is not in use.

Move the charger away from fire if it starts to leak or smell. The leaked liquid may catch the fire, which causes fire or explosion. If the plug is not be inserted completely, it may cause electric shock, heat generation or fire. Do not use damaged AC-Adapter or loosened plug. Do not touch the charging terminal with your hand or finger while it is conducting electricity. It may cause electric shock, injury or product failure.

Do not touch the electric plug when starts lightning. It may cause the electric shock from thunderbolt.

Do not overload a power outlet with too many devices.

Do not connect another Wall Charger to the Charging/Data Port (either directly or through the Headset Adapter), when charging the phone inserted in the Handset Charging Cradle. Damage or overheat may result.

Games

■ Seizures/Blackouts

Warning

A very small percentage of individuals may experience epileptic seizures when exposed to certain light patterns or flashing lights. Exposure to certain patterns or backgrounds on a computer screen, or while playing video games, may induce an epileptic seizure in these individuals. Certain conditions may induce previously undetected epileptic symptoms even in persons who have no history of prior seizures or epilepsy.

If you, or anyone in your family, have an epileptic condition, consult your physician prior to playing. If you experience any of the following symptoms while playing a video or computer game—dizziness, altered vision, eye or muscle twitches, loss of awareness,

disorientation, any involuntary movement, or convulsions— IMMEDIATELY discontinue use and consult your physician before resuming play.

■ Repetitive Motion Injuries

When you play games on your phone, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow these instructions to avoid problems such as tendonitis, carpal tunnel syndrome, or other musculoskeletal disorders:

- Take a minimum 15-minute break every hour of game playing.
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after play, stop playing and see a doctor.

Camera

Do not aim your camera at the sun. The sunlight passing through the Camera/Camcorder Lens may cause damage to the camera. Do not use your camera's flash close to a person's eyes. This may cause the person to lose eyesight temporarily and result in an accident.

Do not expose the Camera/Camcorder Lens to the direct sunlight for a long period of time. It may cause explosion or fire from light-focus action.

Do not use flash toward the automobile driver. It may startle the driver and will not be able to drive, which may cause an accident.

Accessibility

Hearing Aid Compatibility (HAC) for Wireless Telecommunications Devices

PCD's Commitment

PCD believes that all of our customers should be able to enjoy the benefits of digital wireless technologies. We are committed to providing a selection of compatible devices for our customers who wear hearing aids.

THIS PHONE HAS HAC RATINGS OF M4/T4

What is Hearing Aid Compatibility?

The Federal Communications Commission has implemented rules and a rating system designed to enable people who wear hearing aids to more effectively use these wireless telecommunications devices. The standard for compatibility of digital wireless phones with hearing aids is set forth in American National Standard Institute (ANSI) standard C63.19. There are two sets of ANSI standards with ratings from one to four (four being the best rating): an "M" rating for reduced interference making it easier to hear conversations on the phone when using the hearing aid microphone, and a "T" rating that enables the phone to be used with hearing aids operating in the telecoil mode thus reducing unwanted background noise.

How will I know which wireless phones are Hearing Aid Compatible?

The Hearing Aid Compatibility rating is displayed on the wireless phone box.

A phone is considered Hearing Aid Compatible for acoustic coupling (microphone mode) if it has an "M3" or "M4" rating. A digital wireless phone is considered Hearing Aid Compatible for inductive coupling (telecoil mode) if it has a "T3" or "T4" rating.

How will I know if my hearing aid will work with a particular digital wireless phone?

You'll want to try a number of wireless phones so that you can decide which works the best with your hearing aids.

You may also want to talk with your hearing aid professional about the extent to which your hearing aids are immune to interference, if they have wireless phone shielding, and whether your hearing aid has a HAC rating.

For more information about hearing aids and digital wireless phones:

- FCC Hearing Aid Compatibility and Volume Control http://www.fcc.gov/cgb/dro/hearing.html
- Hearing Loss Association of America http://www.hearingloss.org/learn/cellphonetech.asp
- CTIA

http://www.accesswireless.org/hearingaid/

Gallaudet University, RERC

http://tap.gallaudet.edu/voice

■ Teletypewriter (TTY) Devices

You can use an optional teletypewriter (TTY) device with your phone to send and receive calls. You must plug the TTY device into the phone's headset connector and set the phone to operate in one of three TTY modes.

A TTY is a communication device used by people who are hard of hearing or have a speech impairment. TTY does not work from mobile phone to mobile phone. Use a TSB-121 compliant cable (provided by the TTY manufacturer) to connect the TTY device to your phone. Your phone has a 2.5mm jack. Set the phone to Medium volume level for proper operation. If you experience a high number of incorrect

characters, adjust the volume as needed to minimize the error rate. For optimal performance, your phone should be at least 12 inches (30 centimeters) from the TTY device. Placing the phone too close to the TTY device may cause high error rates.

Avoid potential hearing loss.

Prolonged exposure to loud sounds (including music) is the most common cause of preventable hearing loss. Some scientific research suggests that using portable audio devices, such as portable music players and cellular telephones, at high volume settings for long durations may lead to permanent noise-induced hearing loss. This includes the use of headphones (including headsets, earbuds and Bluetooth or other wireless devices). Exposure to very loud sound has also been associated in some studies with tinnitus (a ringing in the ear), hypersensitivity to sound and distorted hearing. Individual susceptibility to noise-induced hearing loss and other potential hearing problems varies.

The amount of sound produced by a portable audio device varies depending on the nature of the sound, the device, the device settings and the headphones. You should follow some common sense recommendations when using any portable audio device:

- Set the volume in a quiet environment and select the lowest volume at which you can hear adequately.
- When using headphones, turn the volume down if you cannot hear the people speaking near you or if the person sitting next to you can hear what you are listening to.
- Do not turn the volume up to block out noisy surroundings. If you choose to listen to your portable device in a noisy environment, use noise-cancelling headphones to block out background environmental noise.

- Limit the amount of time you listen. As the volume increases, less time is required before your hearing could be affected.
- Avoid using headphones after exposure to extremely loud noises, such as rock concerts, that might cause temporary hearing loss.
 Temporary hearing loss might cause unsafe volumes to sound normal.
- Do not listen at any volume that causes you discomfort. If you
 experience ringing in your ears, hear muffled speech or experience
 any temporary hearing difficulty after listening to your portable audio
 device, discontinue use and consult your doctor.

You can obtain additional information on this subject from the following sources:

American Academy of Audiology

11730 Plaza American Drive, Suite 300

Reston, VA 20190

Voice: (800) 222-2336 Email: info@audiology.org Internet: www.audiology.org

National Institute on Deafness and Other Communication Disorders

National Institutes of Health 31 Center Drive, MSC 2320 Bethesda, MD USA 20892-2320

Voice: (301) 496-7243 Email: nidcdinfo@nih.gov

Internet: http://www.nidcd.nih.gov/health/hearing

National Institute for Occupational Safety and Health

Hubert H. Humphrey Bldg. 200 Independence Ave., SW

Washington, DC 20201

Voice: 1-800-35-NIOSH (1-800-356-4674)

Internet: http://www.cdc.gov/niosh/topics/noise/default.html

RECYCLE YOUR CELL PHONE!

Carriers marketing this cell phone have an in-store phone take-back program. Consumers can drop off their used wireless devices to specified carrier retail outlets for recycling purposes. For a list of carrier members and collection sites, visit the cellular industry's recycling website

www.recyclewirelessphones.com.

To mail in your old wireless device to PCD Personal Communications for recycling purposes, simply package your old wireless device and any accessories (including discharged batteries) in appropriate shipping materials and mail to:

For Recycling PCD Personal Communications LLC 555 Wireless Blvd. Hauppauge, NY 11788

Wireless phones also can be donated to the Wireless Foundation's DONATE A PHONE® CALL TO PROTECT® campaign. This charitable cause collects wireless phones to benefit victims of domestic violence.

All donated phones are tax deductible. You may mail the phone to:

CALL TO PROTECT

2555 Bishop Circle

West Dexter, MI 48130

-OR-

Drop the phone off at a local collection center. For a list of collection centers, visit

www.wirelessfoundation.org/CalltoProtect/dropoff.cfm

Before returning any wireless device for recycling purposes, please remember to terminate your service on the device, clear the device of any stored information and remove the device's SIM card, if it has one (please contact your wireless provider to find out if your device contains a SIM card and for assistance on how to remove it).

12 MONTH LIMITED WARRANTY

Personal Communications Devices, LLC. (the "Company") warrants to the original retail purchaser of this handheld portable cellular telephone, that should this product or any part thereof during normal consumer usage and conditions, be proven defective in material or workmanship that results in product failure within the first twelve (12) month period from the date of purchase, such defect(s) will be repaired or replaced (with new or rebuilt parts) at the Company's option, without charge for parts or labor directly related to the defect(s).

The antenna, keypad, display, rechargeable battery and battery charger, if included, are similarly warranted for twelve (12) months from date of purchase.

This Warranty extends only to consumers who purchase the product in the United States or Canada and it is not transferable or assignable.

This Warranty does not apply to:

- (a) Product subjected to abnormal use or conditions, accident, mishandling, neglect, unauthorized alteration, misuse, improper installation or repair or improper storage;
- (b) Product whose mechanical serial number or electronic serial number has been removed, altered or defaced.
- (c) Damage from exposure to moisture, humidity, excessive temperatures or extreme environmental conditions;
- (d) Damage resulting from connection to, or use of any accessory or other product not approved or authorized by the Company;
- (e) Defects in appearance, cosmetic, decorative or structural items such as framing and non-operative parts;

(f) Product damaged from external causes such as fire, flooding, dirt, sand, weather conditions, battery leakage, blown fuse, theft or improper usage of any electrical source.

The Company disclaims liability for removal or reinstallation of the product, for geographic coverage, for inadequate signal reception by the antenna or for communications range or operation of the cellular system as a whole.

When sending your wireless device to Personal Communications Devices for repair or service, please note that any personal data or software stored on the device may be inadvertently erased or altered. Therefore, we strongly recommend you make a back up copy of all data and software contained on your device before submitting it for repair or service. This includes all contact lists, downloads (i.e. third-party software applications, ringtones, games and graphics) and any other data added to your device. In addition, if your wireless device utilizes a SIM or Multimedia card, please remove the card before submitting the device and store for later use when your device is returned, Personal Communications Devices is not responsible for and does not guarantee restoration of any third-party software, personal information or memory data contained in, stored on, or integrated with any wireless device, whether under warranty or not, returned to Personal Communications Devices for repair or service.

To obtain repairs or replacement within the terms of this Warranty, the product should be delivered with proof of Warranty coverage (e.g. dated bill of sale), the consumer's return address, daytime phone number and/or fax number and complete description of the problem, transportation prepaid, to the Company at the address shown below or to the place of purchase for repair or replacement processing. In addition, for reference to an authorized Warranty station in your

area, you may telephone in the United States (800) 229-1235, and in Canada (800) 465-9672 (in Ontario call 416-695-3060).

THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LAIBILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY MUST BE BROUGHT WITHIN A PERIOD OF 18 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR AN SPECIAL CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. THE COMPANY SHALL NOT BE LIABLE FOR THE DELAY IN RENDERING SERVICE UNDER THIS WARRANTY OR LOSS OF USE DURING THE TIME THE PRODUCT IS BEING REPAIRED OR REPLACED.

No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

Some states or provinces do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitation or exclusions may not apply to you. This Warranty gives you specific legal rights, and you may also have other rights, which vary from state to state or province to province.

IN USA: Personal Communications Devices, LLC.

555 Wireless Blvd. Hauppauge, NY 11788

(800) 229-1235

IN CANADA: PCD Communications Canada Ltd.

5535 Eglinton Avenue West

Suite# 234

Toronto, ON M9C 5K5

(800) 465-9672

Index

12 MONTH LIMITED	Call Ringtone	136
WARRANTY197	Call Settings	156
	Call Sounds	136
Α	Call Vibrate	137
Accessibility191	Call Waiting	29
Add New Devices126	Caller ID	28
Airplane Mode147	Caller ID Readout	137
Alarm Clock121	Card Memory	162
Alert Sounds137	Charging the Battery	23
All (RECENT CALLS) 44	Chat	112
Answer Options156	Clock Format	146
Answering a call28	Compliance with other	
Assisted Dialing160	FCC Regulations	183
Auto Retry157	Connecting to the Headset	
	Jack	34
В	Contact List	
Backlight141	CONTACTS	47
Backup Assistant 60	Countdown Timer	123
Banner141	Current Country	151
Battery21		
Battery Level26	D	
Blocked 44	Dial Fonts	146
Bluetooth Settings128	Dialed	44
Bluetooth®125	Digit Dial Readout	138
Bluetooth® Icons19	Display Settings	139
Browse & Download97	Display Themes	143
	Downloading Files	132
С	Drafts	109
Calculator118	DTMF Tones	159
Calendar119	Dust Resistance	20

E	Info	100
Easy Set-Up135, 139		
Edit Codes152	K	
Email112	Keypad Volume	138
Emergency Calls181		
End Call Options157	L	
ERI Banner141	Language	150
External Display Menu14	Location	
External Keyguard	Lock Phone Now	154
Settings133		
Extras98	M	
	Main Menu Settings	143
F	Making a call	27
Favorites54	Making a PTT Call	66
FCC Regulations183	MEDIA CENTER	71
FDA Information173	Memory	161
Flashlight37	Memory Card	30
	Menu Access	29
G	Menu Font Size	146
Games94	Menu Overview	10
General Safety183	Message Erase	114
Get New Pictures80	Message Icons	17
Get New Ringtones72	Message Settings	112
Groups55	Messages	107
	MESSAGING	101
l	Missed	44
Icon Glossary164	Mobile IM	111
Icon Reference15	Mobile Web	95
In Case of Emergency	Music & Tones	71
(ICE)63	Mute Function	35
Inbox101	My Documents	99
Incoming PTT Call70	My Music	74

My Name Card64	Power On/Off139
My Number164	PTT Contact List57
My Pictures81	PTT Groups58
My Ringtones73	PTT Mode 66, 160
My Sounds75	PTT Screen Icons18
My Verizon115	Push to Talk 65
My Videos86	
	R
N	Received 44
NAM Selection156	Recent Call Icons16
New Contact 47, 51	RECENT CALLS 44
New Message102	Record Video91
New Message Alert101	RECYCLE YOUR CELL
New PTT Contact56	PHONE!195
Notepad123	Redialing call27
	Restore Phone154
0	Restrictions152
One Touch Dial158	
Online Album94	S
	Safety167
P	Safety Information for FCC
Pauses50	RF Exposure170
PC Connections159	Save Options161
Personal Banner141	Screen Icons15
Perspective Adjustment84	Security151
Phone Info163	Sending and Receiving
Phone Lock Setting153	Images131
Phone Memory162	Sending and Receiving
Phone Overview4	Name Cards129
Phone Settings147	Sent101
Picture & Video78	Service Alerts138
Picture Message 103	

Set Internal Directional	U
Keys148	USB Mass Storage124
Set My Shortcuts147	USB Mode163
Set Qwerty Shortcut149	Using a Memory Card 30
Set Red Side Key150	
Set Shortcuts147	V
SETTINGS & TOOLS 115	V CAST Music with
Set-up Wizard166	Rhapsody71
Shock Resistance20	V CAST Videos78
Software Update164	Vibrate Mode35
Sounds Settings135	Video Message103
Speakerphone36	View Timers46
Speed Dials 60	Visual Voice Mail 111
Stop Watch122	Voice Commands116, 150
SW/HW Version164	Voice Message104
Sync music from PC77	Voice Privacy159
System Select155	Voicemail110
	Volume Quick Adjustment36
<u>T</u>	VZ Navigator sm 98
T9 Palabra Mode 43	
T9 Word Mode41	W
Take Picture88	Wallpaper143
Temp PTT Group59	Warranty197
Text Input39	Water Resistance19
TIA Safety Information167	World Clock123
Tools 115	
TTY Mode158	
Turning the Phone On and	
Off26	
TXT Message102	

Your wireless device can determine its (and your) physical, geographical location ("Location Information"). Certain software applications are capable of accessing, collecting and using Location Information and disclosing the information to the application provider and other people. You should use caution and discretion when determining whether or not Location Information should be made available to them. To limit potential unauthorized access to your Location Information, Verizon Wireless devices are preset to "E911 ONLY" which will only allow authorized emergency response personnel to locate you if you dial 9-1-1 from your wireless device. By changing the setting on the device to "LOCATION ON" you are enabling third party access to Location Information through software, widgets or peripheral components you choose to download, add or attach to your wireless device. Verizon Wireless encourages you to check your wireless device periodically and only use software, widgets and peripheral components that are obtained from reliable sources. When you use your mobile browser or other services and applications, you authorize Verizon Wireless to collect, use and disclose your Location Information as appropriate to provide you with any location services that you enabled. Verizon Wireless does not retain Location Information longer than necessary to provide the services to you. We will not knowingly disclose your Location Information to third parties without your consent. You should carefully review the privacy policies of application providers and third parties who you allow access to your Location Information, and you should know that significant risks can be associated with disclosing your Location Information to others

THIS PRODUCT IS LICENSED UNDER THE MPEG-4 VISUAL PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER FOR (i) ENCODING VIDEO IN COMPLIANCE WITH THE MPEG-4 VISUAL STANDARD

("MPEG4-VIDEO") AND/OR (ii) DECODING MPEG-4 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED BY MPEG LA TO PROVIDE MPEG-4 VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION INCLUDING THAT RELATING TO PROMOTIONAL, INTERNATIONAL AND COMMERCIAL USES AND LICENSING MAY BE OBTAINED FROM MPEG LA, LLC. SEE

HTTP://WWW.MPEGLA.COM.

This Product contains Adobe® Flash® Lite™ player software under license from Adobe Systems Incorporated, Adobe Flash Lite Copyright © 2003-2007 Adobe Systems Incorporated. All rights reserved.

Adobe, Flash and Flash Lite are trademarks of Adobe Systems Incorporated in the United States and other countries.

This Product contains WMDRM software to access WMDRM-protected content.

If the WMDRM software fails to protect the content, content owners may ask Microsoft Corporation to revoke the software's ability to use WMDRM to play or copy protected content.

T9 Text Input is covered by U.S. Pat. 5,818,437, U.S. Pat. 5,953,541, U.S. Pat. 6,011,554, 6,307,548, U.S. Pat. 6,286,064, U.S. Pat. 6,307,549 and other patents pending.

This Product incorporates technology from Nuance Communications, Inc.

The PTT of this Product incorporates technology from Core Mobility, Inc.

microSD is a registered trademark of the SD Card Association.

ACCESS and NetFront are trademarks or registered trademarks of ACCESS CO., LTD. in Japan and other countries.

Copyright © 1996 - 2006 ACCESS CO., LTD.



Purple Labs, the Purple Labs logo and the family of terms carrying the "Purple Labs" prefix are trademarks of Purple Labs SA. All other trademarks and registered trademarks are the properties of their respective owners.

Copyright@ 2001-2009 Purple Labs SA. All Rights Reserved.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Casio Computer Co.,Ltd. is under license. Other trademarks and trade names are those of their respective owners.

G'zOne is a trademark of Casio Computer Co., Ltd.