

(1) Depending on your network operator.



All received messages (read and unread) are stored in the same Inhox

Group by sender/Group by receiver(1)

sender","Options\Group by receiver"). And you are enabled to quick meun, you can set "Caller name/nb", "Call time" and "Ringtone". search the messages by pressing the key associated with the first letter of sender/receiver's name.

5.2 SMS Conversation (chat) (2)

Access to "Advanced" and select "Switch view mode" keep the conversation going in real time using SMS chat. You may separate chat for every contact with whom you exchange short text messages.



6.1 Consulting your directory

To access the **Directory** from the main screen, press the key and select the 🙀 icon.

6.2 Adding a contact

(2) Depending on your network operator.

Select the contacts list in which you wish to add a contact to, press the "Options" softkey, select "Add contact" then Save.

Fake Call......

Confirm an option (press the middle of the key)

Switch on/Switch off the telephone (long keypress)

Access to menu (short keypress)

Send a call

End call

Left softkey

Right softkey

In idle screer

In edit mode:

Input the "#" in Idle

Side key in idle screen

Short keypress: input space

Long keypress: switch language

En key + Space: switch input mode

Show/hide shortlist menu(long keypress)

Access call memory (short keypress)

Access to Fake call (long keypress)

Access your voicemail (long keypress)

Short Push : Show/hide shortlist menu

Long/short keypress: Lock/Unlock the keypad

Return to the idle screen

Messages can be grouped by sender/receiver ("Options\Group by Protect yourself from annoying situations with the "Fake Call". In this When the timer reaches, the phone will ring and display like receiving a real phone call. Press key, pretend answering a call, the screen will display just like have an ongoing call. Press & key, pretend to reject the call, the call will terminate automatically ICE (in case of emergency) are 3 numbers emergency services can call if



Your phone is equipped with a Radio (1) with RDS functionality. You can use the application as a traditional Radio with saved channels or with parallel visual information related to the radio program on the display, if you tune to stations that offer Visual Radio service. You can listen to it while running Your phones includes some games, Select "Game settings", it allows you Enter a number, select the type of operation to be performed using the other applications.



Your phone has an email client with the settings predefined for a few environments popular email services like - GoogleMail, Windows live, Yahoo, AOL, etc.

Access WAP options: Homepage, Bookmarks, Go to URL, Recent pages, Offline pages.

HTML email and image in email not supported.

Media album.....

You will have an access to all audio and visual files stored in phone or in Allows you to have settings of date and time, including 12/24h format. You will have an access to all audio and visual lines stored in My Medium Album. You can access a number of items with this option: My 15.5.3 World clock

10 The option of Group by receiver is available in Outbox, Sent, and Draft folders 10 The quality of the radio depends on the coverage of the radio station in that 10 Depending on your network operator. May cause additional network charge roaming states.

Alarm clock Level of network recention

Line switching (2): indicates the selected line

GPRS connection status (Blue - Activated)

Message list is full: your terminal cannot accept any new messages. You must access the message list and delete at least

Services.....

Others.....

You can create a note in text or voice format by accessing "Notes" from My numbers

WAP alerts

GPRS attached

Sending a message

except for the alarms.

Message receipt in progress

one message on your SIM card.

Missod calls

Press twice to lock top-half inputting mode, then press once to

Long keypress: access to Dictionary.

In edit mode: Short press: popup symbol page to select special character by Long press & Fn+SYM: popup smileys page to select special

smileys by navigation key Delete one by one (short keypress Delete one by one quickly (long keypress)

Switch the uppercase and minuscule (in edit screen)

Return a cursor to the next line

Main screen icons (1

In idle screen:

In edit mode:

Press to access shortcuts

En + P: access to Profiles

Fn + Q: access to Clock

Fn + S: access to Notes

Press once to input top-half character

unlock top-half inputting mode.

Vibrate alert: Your phone vibrates, but does not ring or been with the exception of the alarm.

Keypad locked

9.3 Weather

forecast of favorite cities.

are available: View, Add/Edit. Delete.

Call forwarding activated: your calls are forwarded.

Your phone is equipped with a weather function for consulting up to 3-day

you have an accident, you can also add useful information such as blood

type, allergy. Access to "ICE" menu from main menu and below options

ICE

Games.....

Profiles.....

The icons and illustrations in this guide are provided for informational purposes (i) Depending on your network operator Contact your network operator to check service availability.

Contact your network operator to check service availability.

Days with events entered will be marked in color.

priorities. All the tasks will be sorted by due date

Access this feature by selecting "Calculator" from the main menu.

Your mobile phone has a built-in alarm clock with a snooze feature.

to manage settings, in which you may set background audio and vibration navigation keys, and enter the second number, then press key or left Fn + Keys: you may define the combined Fn key function and to get

15 | Calendar

15.2 Calculator

softkey to display the result.

15.4 Tasks


15.5 Clock 15.5.1 Alarm

With this menu, you may personalise ringtones for different events and Enables you to easily manage and track the progress of an task with


Getting started

2.1 Set-up

Removing or installing the back cover



Installing or removing the battery Silence mode: your phone neither rings, beeps nor vibrates



15.5.4 Stopwatch

15.6 Converter.

Once you enter this menu from main menu, there is a monthly-view From the main menu, select the menu icon of

calendar for you to keep track of important meetings, appointments, etc. your choice in order to customise your telephone: Display, Languages,

Unit converter and Currency converter.

Connectivity, Restore default set, Call settings.

shortcuts with below options: Edit/Add/Delete.

Your telephone number is usually written on your SIM card.

16.2 Call settings

GPRS counter, Beep duration.

to register several results and suspend/resume measurement.


Settings.....

Headset mode, Input mode, Vocabulary, Keys, Security, Network,

Type in or modify your telephone number and confirm by pressing

You can access different items with this option: Amount, Duration,

Inserting or removing the SIM card



Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press destination and confirm with key. the bottom and slide it out. Please power off your phone before you remove the SIM card

2.2 Power on your phone

Hold down the key until the telephone powers on

Power off your phone

Hold down the key from the main screen.

Calls.....

Making a call

To hang up the call, press the Akey.

Making an emergency call

If your phone has network coverage, dial emergency number and press the key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.

You can access your call memory by pressing the key from the idle screen. Check "Outgoing calls", "Missed calls", "Answered calls"

Menu arrange.....

Main Menu is designed to vary according to your preference.

Change the order

3.2 Call memory

From main menu, press left softkey and select "Move" or long keypress key till tick " $\sqrt{}$ " is shown, then move the cursor to your favorite

Show/Hide

Access "Menu arrange", press key till tick ("√") show or off, it will

Messages

5.1 Messages: Text/Multimedia message

Create message

From the main menu select "Messages" to create text/multimedia

You can type a message and you can also modify a predefined message in Templates or customise your message by adding pictures, photos, sounds, Dial the desired number then press the key to place the call. If you titles, etc (only available while editing a MMS). While writing a message make a mistake, you can delete the incorrect digits by pressing the right select "Options" to access all the messaging options. You can save your messages that you send often to **Drafts** or **Templates** (MMS only).

To write messages, there are two writing methods:

- Normal: this mode allows you to type a text by choosing a letter or a sequence of characters associated with a key.

Press twice: lock top-half character inputting mode, then press once to unlock top-half character inputting mode. Long press: access to Dictionary

Long press: press to switch language Fn+Space: switch input mode

minuscule to uppercase

In eZiahc (Smartahc) input mode: Short press once: to eZi ABC

Latin input mode...... The stopwatch is a simple application for measuring time with the possibility

- Predictive with the Zi mode: This mode speeds up the writing of your text.

Press once: input top-half character.

Short keypress: access the Symbols table Long keypress & Fn + Sym: popup smileys page Short press: input space

In abc (Multitapabc) input mode (no Abc mode): Short press once: only switch one character from Short press twice: lock uppercase input mode Short press once: unlock the uppercase

Short press twice: to eZi Abc

Short keypress: delete one by one Long keypress: delete one by one quickly ALCATEL is a trademark of Alcatel-Lucent and is used under license by TCT Mobile Limited.

> All rights reserved © Copyright 2010 TCT Mobile Limited.

TCT Mobile Limited reserves the right to alter material or technical specification without prior notice.

13

Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only eadphones recommended by TCT Mobile Limited and its affiliates.

English - CJB21EAALAAB

2010-10-15 14:58:49

(1) Depending on your network operator

IP3041_255_QG_Eng_GB_24_101015.indd 1

The World clock shows current local time and the time zone in different



Safety and use

We recommend that you read this chapter carefully before using your phone. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein.

• TRAFFIC SAFETY:

Given that studies show that using a mobile phone while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit, headset...). drivers are requested to refrain from using their mobile when the vehicle is not Do not gaint it.

radio. Using a headphone can be dangerous and forbidden in some areas.

When switched on, your phone emits electromagnetic waves that can interfere with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To Remember to make back-up copies or keep a written record of all important. Observe the following precautions for battery use:

- do not place your phone on top of the dashboard or within an airbag deployment
- check with your car dealer or the car manufacturer to make sure that the dashboard is adequately shielded from mobile phone RF energy.

CONDITIONS OF USE

You are advised to switch off the telephone from time to time to optimise its

Switch the phone off before boarding an aircraft.

Switch the phone off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use, mobile relephones can interfere with other electrical or electronic devices, or equipment

Switch the phone off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, petrol station, or chemical plant, or in inv potentially explosive atmosphere

When the phone is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker, a hearing aid or insulin pump, etc. In particular when using the phone, you should hold it against the ear on the opposite side to the

To avoid hearing impairment, pick up the call before holding your phone to your because the amplified volume might cause hearing damage.

Do not let children use the phone and/or play with the telephone and accessories

When replacing the cover please note that your phone may contain substances that could create an allergic reaction.

Always handle your phone with care and keep it in a clean and dust-free place Do not allow your phone to be exposed to adverse weather or environmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc). The

manufacturer's recommended operating temperature range is -10°C to +55°C. At over 55°C the legibility of the phone's display may be impaired, though this is

Emergency call numbers may not be reachable on all cellular networks. You should never rely only on your phone for emergency calls.

Do not open, dismantle or attempt to repair your mobile phone yourself Do not drop, throw or hend your mobile phone.

Use only batteries, battery chargers, and accessories which are recommended by the improper use of the mobile phone. When driving, do not use your phone and headphone to listen to music or to the TCT Mobile Limited and its affiliates and are compatible with your phone model. • BATTERY:

information stored in your phone

Some people may suffer epilentic seizures or blackouts when exposed to flashing lights or when playing video games. These seizures or blackouts may occur even if a Do not hurn or dispose of a used battery in household rubbish or store it at a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please. Batteries must be disposed of in accordance with locally applicable environmental

Parents should monitor their children's use of video games or other features that its affiliates. ncorporate flashing lights on the phones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. To limit the likelihood of such symptoms, please take the following safety precautions:

Do not play or use a flashing-lights feature if you are tired or need sleep.

- Take a minimum of a 15-minute break hourly.
- Play in a room in which all lights are on.
- Play at the farthest distance possible from the screen
- If your hands, wrists, or arms become tired or sore while playing, stop and rest In European Union countries:
- for several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after playing, stop All products with this sign must be brought to these collection point: the game and see a doctor.

ear. Also move the handset away from your ear while using the "hands-free" mode in your hands, arms, shoulders, neck, or other parts of your body. Follow the your jurisdiction or your region has suitable recycling and collection facilities; instructions to avoid problems such as tendinitis, carpal tunnel syndrome, or other instead they are to be taken to collection points for them to be recycled. musculoskeletal disorders.

15

Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only INSTRUCTIONS headphones recommended by TCT Mobile Limited and its affiliates.

sdiction or other jurisdiction(s) where you will use your mobile phone regarding 40 °C. It is the user's sole responsibility to ensure that prior authorisation be obtained, if • RADIO WAVES:

TCT Mobile Limited and its affiliates disclaim any liability for damage caused by the Before removing the battery from your phone, please make sure that the phone is

- Do not attempt to open the battery (due to the risk of toxic fumes and burns).
- Do not puncture, disassemble or cause a short-circuit in a battery.
- temperatures above 60 °C.

use damaged batteries or those not recommended by TCT Mobile Limited and/or age or state of health.



- the end of their life: items of equipment
- Collection bins at points of sale.

These collection points are accessible free of charge In non European Union jurisdictions:

When you play games on your phone, you may experience occasional discomfort. Items of equipment with this symbol are not to be thrown into ordinary bins if

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE, DISPOSE OF USED BATTERIES ACCORDING TO THE

• CHARGERS

Please note that you must respect the laws and regulations in force in your Mains powered chargers will operate within the temperature range of 0 °C to compliance against the standard is 1.2 W/kg. While there may be differences

taking photographs and recording sounds with your mobile telephone. Pursuant to The chargers designed for your mobile phone meet with the standard for safety of the relevant International guidelines and EU requirements for RF (radio-waves) such laws and regulations, it may be strictly forbidden to take photographs and/or information technology equipment and office equipment use. Due to different exposure. record the voices of other people or any of their personal attributes, and applicable electrical specifications, a charger you purchased in one jurisdiction may. The World Health Organisation (WHO) considers that present scientific

> any other person is an essential requirement of these standards or this directive.
>
> On the following site: http://www.who.int/peh-emf. THIS MOBILE PHONE COMPLIES WITH INTERNATIONAL AND EUROPEAN Although no danger relating to the use of telephone was ever proved, the World REQUIREMENTS REGARDING EXPOSURE TO RADIO WAVES.

recommended by international requirements (ICNIRP) (1) and by the Council of the belly of pregnant women and from the lower abdomen for teenagers. European Union (Recommendation 1999/519/EC) (2)

These limits are part of a set of requirements and establish authorised, should avoid touching it or degrading it radiofrequency levels for the public. These limits were established by independent. As mobile devices of a range of functions, they can be used in positions other. This equipment is in compliance with the essential requirements and other or replacement may be carried out using reconditioned components.

This symbol on your telephone, the battery and the accessories known as the Specific Absorption Rate or "SAR". The SAR limit is set by • LICENCES means that these products must be taken to collection points at international requirements or by the Council of the European Union at 2 watts/ Obigo® kilogram (W/kg) averaged over 10 grams of body tissue. The tests used to - Municipal waste disposal centres with specific bins for these determine SAR levels were carried out on the basis of standard usage modes with the phones transmitting at their maximum power level over the entire range of ZICOTDOTATION Affiliates. frequency bands.

They will then be recycled, preventing substances being disposed of in the Although the SAR was established at the highest certified level, the actual SAR level for the mobile phone during use is generally much lower than the maximum values In fact, since mobile phones are designed to operate at many different power levels, they only use the minimum level of power required to provide a connection to the network. In theory, the closer you are to a base station antenna, the lower the power level required by the mobile phone.

> The ICNIRP requirements are applicable in the following regions: Central America (except Mexico), South America, North and South Africa, Pacific Asia (except Korea) Australia

ation (1999/519/EC) is applicable in the following regions: Europe, Israel.

You can adjust the volume during a call by means of the key.

I am unable to use the features described in the manual

Make sure this feature does not require an Alcatel accessory

My callers are unable to leave messages on my voicemail

Contact your network operator to check service availability

Make sure your operator's voicemail number is correctly entered in

I am unable to send and receive messages MMS, Vox MMS

Contact your network operator to check service availability and

Verify the server centre number or your MMS profile with your

You have saved too many short messages on your SIM card; delete

Check your phone memory available as it might be full

The server centre may be saturated; try again later

The icon is displayed on my standby screen

some of them or archive them in the product memory

Make sure that you have correctly recorded the number in your

The sound quality of the calls is not optimal

l am unable to create a file in my directory

Check the radio reception icon level

includes this service

personal directories)

"My numbers"

I cannot access my voicemail

Try later if the network is busy

check MMS parameters

not dialled

between the SAR levels on various phones and at various positions, they all meet

information does not indicate the need for any special precautions for use of mobile phones. If individuals are concerned, they might choose to limit their own necessary, in order to record private or confidential conversations or take a Proof of compliance with international standards (ICNIRP) or with European or their children's RF exposure by limiting the length of calls, or using "hands-free" photograph of another person; the manufacturer, the seller or vendor of your Directive 1999/5/EC (R&TTE) is required of all mobile phone models before they devices to keep mobile phones away from the head and body (fact sheet n° 193). mobile phone (including the operator) disclaim any liability which may result from can be put on the market. The protection of the health and safety for the user and. Additional information about electromagnetic fields and public health are available.

> Health Organisation advises as a precautionary measure to use your telephone Your mobile phone is a radio transmitter/receiver. It was designed and with a good level of network reception as indicated on the telephone display (4 to Your telephone is a transceiver that operates on GSM networks with 900 manufactured to comply with the radiofrequency (RF) exposure thresholds 5 bars). It is also advised to keep the telephone, during communications, away from and 1800 MHz bands.

Your telephone is equipped with a built-in antenna. For optimal operation, you

groups of experts on the basis of regular and detailed scientific assessments. They than against your ear, In such circumstances the device will be compliant with the relevant provisions of Directive 1999/5/EC. The entire copy of the offering equivalent functionality. consult your doctor before playing video games on your phone or enabling a regulations. Only use the battery for the purpose for which it was designed. Never include a significant safety margin intended to ensure the safety of all, regardless of guidelines when used with headset or usb data cable. If you are using another Declaration of Conformity for your telephone can be obtained through our This warranty covers the cost of parts and labor but excludes any accessory ensure that whatever product is used is free of any metal and that it website: www.alcatel-mobilephones.com. he exposure standard for mobile phones is determined by a measurement unit positions the phone at least 2cm away from the body.

is a registered trademark of Obigo AB.

Internet address: www.alcatel-mobilephones.com

Hot Line Number: see "TCT Mobile Services" leaflet or go to

On our Internet site, you will find our FAO (Frequently Asked Questions)

An electronic version of this user guide is available in English and other from the date of purchase as shown on your original invoice. languages according to availability on our server: www.alcatel- In case of any defect of your phone which prevents you from normal mobilephones com

Protection against theft (1)

Your phone is warranted against any defect which may occur in conditions of normal use during the warranty period of twelve (12) months (1) from the date of purchase as shown on your original

section. You can also contact us by e-mail to ask any questions you may Batteries (2) and accessories sold with your phone are also warranted against any defect which may occur during the first six (6) months (1)

> use thereof, you must immediately inform your vendor and present your phone with your proof of purchase

> If the defect is confirmed, your phone or part thereof will be either replaced or repaired as appropriate. Repaired Phone and accessories are entitled to a one (1) month warranty for the same defect. Repair

the packaging label and in the product's memory. We recommend that you note the number the first time you use your telephone by entering * # 0 6 # and keep it in a safe place. It may be requested by the police or your operator if your telephone is stolen. This number allows your mobile telephone to be blocked preventing a third person from using it, even with a different SIM card.

Disclaimer

There may be certain differences between the user manual description and the phone's operation, depending on the software release of your telephone or specific operator services.

() Contact your network operator for service availabilit

The warranty period may vary depending on your country

during the first six months after purchase and for approximately 200 more





- 1) Non-compliance with the instructions for use or installation, o area where your phone is used.
- 2) Connection to any equipment not supplied or not recommended You are advised to switch off the telephone from time to time to by TCT Mobile Limited
- TCT Mobile Limited or its affiliates or your vendor. 4) Inclement weather, lightning, fire, humidity, infiltration of liquids • Avoid storing large amounts of data in your telephone as this may or foods, chemical products, download of files, crash, high affect the performance of your telephone. voltage, corrosion, oxidation...

Your phone will not be repaired in case labels or serial numbers (IMEI) have been removed or altered.

There are no express warranties, whether written, oral or implied, other than this printed limited warranty or the mandatory warranty provided by your jurisdiction

In no event shall TCT Mobile Limited or any of its affiliates be liable • Remove the battery and re-insert it, then switch the phone back • Make sure your mobile phone is connected to a network, and that for incidental or consequential damages of any nature whatsoever, including but not limited commercial loss, to the full extent those damages can be disclaimed by law. Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

IP3041 255 QG Eng GB 24 101015.indd 2

with technical and safety standards applicable in the geographical Before contacting the aftersales department, you are advised to follow the

- optimise its performance.
- 3) Modification or repair performed by individuals not authorised by You are advised to fully charge (IIII) the battery for optimal

and carry out the following checks: My mobile phone will not switch on

Press until the screen comes on

- Check the battery charge level
- Check the battery contacts, remove and reinstall your battery, then

My phone has not responded for several minutes

- Press the A key

My screen is difficult to read

turn your telephone back on

- Use your mobile phone in accordance with the recommended conditions of use
- My mobile phone turns off by itself · Check that your keypad is locked when you are not using your mobile phone

Check the battery charge level My mobile phone will not charge properly

- Make sure that your battery is not completely discharged; the battery charge indicator can take several minutes and may be accompanied by a quiet whistling sound
- Make sure charging is carried out under normal conditions (0°C –

- Make sure your battery is inserted. It must be inserted before plugging in the charger
 - Make sure you are using an Alcatel battery and charger When abroad, check that the electrical current is compatible

My mobile phone will not connect to a network

- Try connecting in another location
- Verify the network coverage with your operator Check with your operator that your SIM card is valid
- Try selecting the available network(s) manually Try connecting at a later time if the network is overloaded.

SIM card error

- Make sure the SIM card has been correctly inserted
- Verify with your operator that your SIM card is 3V compatible; the old 5V SIM cards cannot be used
- Make sure the chip on your SIM card is not damaged or scratched

Unable to make outgoing calls Make sure you have dialled a valid number and press the key

- For international calls, check the country and area codes
- the network is not overloaded or unavailable Check your subscription status with your operator (credit, SIM card
- valid, etc.) Make sure you have not barred outgoing calls

Unable to receive incoming calls

- · Make sure your mobile phone is switched on and connected to a network (check for overloaded or unavailable network)
- Check your subscription status with your operator (credit, SIM card
- Make sure you have not forwarded incoming calls Make sure that you have not barred certain calls

The caller's name does not appear when a call is received Check that you have subscribed to this service with your operator

- Your caller has concealed his/her number
- "No service" is displayed · You are outside of the network coverage area

I have already entered 3 incorrect PIN codes

 Contact your network operator to obtain the PUK code (Personal Unblocking Key)

I am unable to download new files

· Check with your operator to make sure that your subscription · Check for free space

Make sure that you have selected the country prefix when calling a • Hold down # + power on/off key at same time to reset it.

25

Delete some files · Check your subscription status with your operator

When I select a number from my directory, the number is My mobile phone is dead, can't power on

- Make sure your battery is not completely used up or damaged
- Remove your battery, remove your SIM card then power it on

All User phone data: contacts photos messages and files downloade

- Make sure that your SIM card directory is not full; delete some files How to make your battery last longer or save the files in the product directory (i.e. your professional or • Make sure you follow the complete charge time (minimum 3
 - After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain an exact indication
 - Switch on the backlight upon request.
 - Extend email auto-check interval to as long as possible.
 - Update weather info. upon demand manually or set its auto-check interval longer.

20

The life of a rechargeable mobile phone battery in terms of constandby time, and total service life, will depend on the conditions of use and network configuration. Batteries being considered expendable supplies, the specifications state that you should obtain optimal performance for your phone





2010-10-15 14:58:50

