



**Aqua Star
GSM/GPRS Mobile Phone
User Guide**

User Guide

Aqua Star

Dear INTEX customer,

Congratulations on becoming a proud owner of INTEX product. You have now joined the fraternity of millions of satisfied INTEX customers spread across the globe.

Intex Technologies is one of the fastest growing IT Hardware, Mobile Phones and Electronics Company. A well established brand, INTEX has kept pace with the technology needs of millions of IT hardware & electronics consumers and has been serving them with more than 300 user friendly, high quality, state-of-the art yet simple products/solutions. The products have been in the market since 1996 and conform to global standards.

Brand INTEX covers a wide range of computer peripherals and accessories such as Computer Multimedia speakers, Cabinets, Keyboards, Mouse, UPS, Add-on cards, Webcams, Headphones, Laptop bags, etc. As a part of its diversification strategy, Intex also offers an interesting range of PCs, TFT-LCD Monitors, Consumer Electronics (DVD Players), Home UPS & Mobile Phones.

Every INTEX product goes through a rigorous process of sample evaluation and approval before commercial launch. Customers look upon the brand as a value-for-money & feature-rich offering, supported by efficient after sales service.

We look forward to your patronage.

It would be our pleasure to receive feedback and suggestions you may have for improvements in the product(s) you are using.

Intex Technologies (I) Ltd

info@intextechnologies.com

www.intextechnologies.com

Helpline No. 1800-103- 8822 (India)

Intex Way Gulf LLC

service@intexuae.com

www.intexuae.com

Toll Free No. 800-468- 39823 (Dubai)

Tel: 00971 04 3931991

SAFETY TIPS

- Use of wireless hands-free system (headphone, headset) with a low power Bluetooth emitter.
- Make sure the cell phone has a low SAR. The highest SAR value for this mobile phone is < 1.6 W/Kg, in accordance with the requirements of the ICNIRP, which recommended the limit for exposure to radio

User Guide

Aqua Star

waves is 1.6 watts/kilogram (W/kg) averaged over 1 gram of tissue. For more information, please visit (website) to query

- Keep your calls short or send a text message (SMS) (instead. This advice applies especially to children, adolescents and pregnant women.
- Use cell phone when the signal quality is good.
- People having active medical implants should preferably keep the cell phone at least 15 cm away from the implant.

You have now become the owner of the AQUA STAR This phone offers you the versatility of Android coupled with the trusted craftsmanship of Intex. It offers you the following features:

- Android 2.3.6
- 1 GHz Processor
- Dual SIM support
- 3.95 inch Capacitive Touch screen
- Bluetooth 2.1
- Pinch Zoom
- External memory (expandable up to 16 GB)
- USB support
- 3MP Back Camera/ 1.3 MP Front Camera
- FM Radio
- Sound Recorder

Phone Layout

The following figure shows the phone layout along with the keys and parts for your reference.

User Guide



Aqua Star



Getting Started

Insert SIM Card

1. Switch off the mobile phone and remove the rear cover and battery.
2. Insert the SIM card(s) correctly in the card slot(s) as shown below.

User Guide

Aqua Star



3. Finally, insert the battery and place back the rear cover of the mobile phone.

Insert Memory Card

1. Switch off the mobile phone and remove the rear cover and battery.
2. Insert the memory card into the slot as shown in the diagram:



Note: Use only compatible memory cards approved by Intex with this device. Incompatible cards may damage the card and the device and corrupt data stored on the card.

Please charge the battery for at least 4 hours continuously before you use the newly purchased phone for the first time.

Using the Touch Screen

Please refer to the preceding phone layout for a better understanding:

You can use the touch screen in the following ways:

Action	Effect
Touch	Acts on items on the screen, such as application and settings icons, to type letters and symbols using the onscreen keyboard, or to press onscreen buttons
Touch and hold	Touch and hold an item on the screen until an action occurs
Drag	Touch and hold an item and move your finger on the screen until you reach the target position
Swipe or slide	Quickly slide your finger across the surface of the screen, (without dragging an item). For example, slide the screen up or down to scroll a list

User Guide

Aqua Star

Double-tap	Tap quickly twice on a webpage, map, or other screen to zoom. For example, double-tap a section of a webpage in Browser to zoom that section to fit the width of the screen. You can also double-tap to control the zoom in Maps, and in other applications.
Pinch	In some applications you can zoom in and out by placing two fingers on the screen at once and pinching them together (to zoom out) or spreading them apart (to zoom in).
Rotate the screen	On most screens, the orientation of the screen changes as you rotate it. You can turn this feature on and off

Customize Home Screen

You can add applications, shortcuts, widgets, and other items to any part of the Home screen or change the wallpaper.

- Enter Menu screen, long press and hold an application till the screen vibrates, and then release your finger hold.
- Long press and hold the widget or icon you want to move. Once the device vibrates, don't release your hold on the icon. Drag the widget or icon to a new location on the screen.

Manage Notifications

Your notification icons inform you of new messages and events.

When you receive a notification, its icon appears in the status bar, along with a summary that appears only briefly. Drag the status bar down from the top of the screen as shown below.

User Guide



Aqua Star



The Notifications panel displays your network provider name and a list of your current notifications. Drag the tab at the bottom of the Notifications panel to the top of the screen. Or just press the back button. The panel also closes when you touch a notification to respond to it.

Toolkits

Open the Notifications panel. The icons displayed at the top constitute the toolkit.



Using Your Phone

Switch On/Off

- In standby mode, press and hold the Power key to open phone options. Then, press the **Power off** option that

User Guide

Aqua Star

appears on the display.




Lock/Unlock the Phone



You can lock the phone using Pattern lock, PIN or Password. Go to **Settings>Location and Security>Set up screen lock** to set your preference.

To unlock the phone, do one of the following:

- Press and hold the **Power** key. The LCD shows up with a lock icon.
- Slide the lock icon towards the right to unlock the phone.
- If the phone lock has been activated, you need to enter the unlock code.

Make a Call

- Touch the  icon to enter your desired number and press the  /  icon on the dialer pad that displays.

- Touch the  icon and press  icon to access the desired number. Tap on the number to make a call.

Answer/Reject a Call

- To answer a call, slide the green phone icon to the right.
- To reject a call, slide the red phone icon to the left.

Make an International Call


1. In dialing mode, press and hold the **0** key, until the **+** sign appears on the screen.
2. Enter the desired international code and then the complete phone number and make the call.

In Call Options

- Touch the **Add Call** icon to add another person to the call.
- Touch the Mute icon to mute your voice so that the phone's MIC will not transmit voice to the other end. You can resume transmitting your voice by pressing the Mute icon again.

User Guide

Aqua Star

- If Bluetooth device is connected, then tap the Bluetooth option to transmit voice to Bluetooth devices.
- Touch the Speaker icon to listen via the speaker.
- End the call by pressing the End  icon.

Listen to Music

Menu > Music

You will be presented with the list of available songs to play. You can listen to music by tapping the required icons.



Send Messages

Menu > Messaging

You can compose a new message or reply to existing messages in the list. You can also send receive multimedia messages.

Add Contacts to Phonebook

Menu > Dialpad

- Dial a number and tap on  button. Tap on  icon to add to contacts.
- You can either create a new contact or can add the number to existing contacts.

Browse the Internet

1. Go to **Browser**.
2. Enter the web address and click 'Go'.

Note: To browse the Internet, your Internet settings need to be configured first. You can refer to the Frequently Asked Questions section of the User Guide.

Transfer Data via USB

1. Connect the phone with the PC/laptop using the USB cable supplied with this device.
2. Drag the notification header downwards (on the top portion of the LCD, tap and drag down your finger).
3. Tap **USB Connected > Turn on USB Storage**.

The file dialog will open on your PC for file transfer between the PC and Phone.

Using my AQUA STAR as a Modem for Internet Connectivity

You can use your AQUA STAR as a modem and connect your PC or laptop to the Internet when required. You can

User Guide

Aqua Star

do this via:

- USB Tethering
- Wi-Fi Hotspot

Connectivity via USB Tethering

You need to insert an internet enabled SIM card in your phone.

1. Connect your AQUA STAR to your computer through the USB cable.
2. Go to **Settings> Wireless & networks>Tethering & portable hotspot > USB Tethering**.

The driver installation window will pop up on your PC or laptop.

3. Install the driver as suggested.

You can now start using the Internet service via your AQUA STAR.

Note: Your mobile operator will charge you based on your GPRS data usage.

Connectivity via Wi-Fi Hotspot

You need to insert a Data Service enabled SIM card on your phone to use your AQUA STAR as a router.

1. Go to **Settings> Wireless & networks>Tethering & Portable hotspot**.
2. Configure your Wi-Fi hotspot as suggested.

Make sure your computer has Wi-Fi. After connecting to the Wireless network, you can use the GPRS service from your AQUA STAR.

Note: Your mobile operator will charge you based on your GPRS data usage.

Other Notable Features

Capture Photos and Videos

Menu > Camera

Use the slider that displays to shift between camera and video mode.

Features:

- 3Megapixel back camera with 8x Zoom
- White Balance/Scene Mode/Picture quality(Camera Mode)
- White Balance/Video Quality (Video mode)

Use the Pinch Zoom Feature

You can open any image or web page and then use your thumb and index finger to zoom the display through the pinch gesture as illustrated below.



Synchronize Contacts List

Settings> Accounts & sync

You can use this feature to synchronize your contacts and calendar with your email account

1. You can add new account or can use existing account.
2. Enter your **Email ID** and **Password** and tap **Next**.
3. Enter/edit the domain/username and server if required for corporate account.
4. Choose the account options that display and tap **Next**.
5. Follow the suggested steps.

Your contacts synchronization will be complete in a few seconds.

To auto-sync an existing account:

1. Tap on an existing account.
2. Tap **Sync Contacts**. (All phone contacts will be copied to that email account with details).

For this feature to work, you need to have Internet connectivity via your SIM or Wi-Fi. If your Sync does not proceed as expected, check whether data option is set to ON.

Record Sound

Menu > Sound recorder

Tap  icon to start recording. Press the  icon to stop the recording.

Safety Precautions

Please read these simple guidelines. Not following them may be dangerous or illegal.

Safe Driving

User Guide

Aqua Star

- Do not use the phone while driving. When you have to use the phone, please use the personal hands-free kit.
- Please do not put the phone onto any passenger seat or any place from which it may fall down in case of vehicular collision or emergency braking.

During Flight

Flight is influenced by interference caused by the phone. It is illegal to use a phone on the airplane. Please turn off your phone during a flight.

In Hospitals

- Your Phone's radio waves may interfere with the functioning of inadequately shielded medical devices. Consult a physician or the manufacturer of the medical device to determine whether they are adequately shielded from external Radio Frequency. Switch off your device when regulations posted instruct you to do so.
- To avoid potential interference with implanted medical devices such as a pacemaker or cardioverter defibrillator:
- Always keep your phone at least 15.3 centimeters (6 inches) from the medical device.
- Do not carry the wireless device in a breast pocket.
- Turn off the phone if there is any reason to suspect that interference is taking place.
- Follow the manufacturer directions for the implanted medical device.
- If you have any questions about using your wireless device with an implanted medical device, consult your health care provider.

Unsafe Areas

Please turn off your phone when you are close to a gas station or in the vicinity of any place where fuel and chemical preparations, or any other dangerous goods are stored.

Taking Care of Your Device



Your device is a product of superior design and craftsmanship and should be handled with care: The following suggestions will help you protect your phone:

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will rust electronic circuits. If your device does get wet, remove the battery without turning on the device, wipe it with a dry cloth and take it the service center.
- Do not store the device in high or cold temperature. High temperatures can shorten the life of electronic devices

User Guide

Aqua Star

and damage batteries.

- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not attempt to open the device other than as instructed in this guide. Repairing this phone by yourself other than our authorized service agents/centers goes against the warranty rules.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not store your device near magnetic fields or allow your device to come in contact with magnetic fields for extended period of time.
- Location: The socket-outlet shall be installed near the equipment and shall be easily accessible.

Battery Recommendations

- Please put the battery in a cool and well-ventilated place out of direct sunlight. We recommend you to charge the battery at room temperature range.
- Batteries have life cycles. If the time that the battery powers equipment becomes much shorter than usual, the battery life is at an end. Replace the battery with a new battery of the same make and specification.
- Use manufacturer approved batteries, chargers, accessories and supplies. Intex will not be held responsible for user's safety when using unapproved accessories or supplies.
- Do not discard the battery with household trash. Please dispose of used battery according to your local environmental laws and guidelines.
- Warnings on Battery:
 - (a) Please use appointed battery in case of explosion risk.
 - (b) Please dispose of lifeless battery under guidance.

Technical Information

Model: Aqua Star

Weight: 114 gram (with battery)

Size Length: 121mmx67.3mmx11.8mm

Networks: GSM 900/1800 MHz

SAR Value: 0.836 W/kg-GSM 900MHz; 1.456W/kg-DCS 1800MHz;

User Guide

Aqua Star

Battery: 1400mAh

Lithium Battery

Nominal voltage: 3.7v

Nominal: 4.2v

Continuous standby time*: 200-300hrs

Continuous calling time: 3-5hrs

* Depending on the network

Operation Temperature: -10~+55 °C

The operation time of the battery depends on conditions such as:

- Transmitting power level
- Signal (distance between the phone and the base station)
- Network parameters defined by the operator
- Phone use (WAP, games, SMS)
- Charging procedure used

Exclusions:

Subject to the exclusions contained below:

1. Damage due to the improper use.
2. User does not follow the manual.

Explanation:

The company has the final right of the explanation for this document.

Software upgrades will not be announced.

All pictures are for reference only in the instruction book; please refer to the actual phone.

Disclaimer

© Intex. All rights reserved.

Features and specifications are subject to change without prior notice. Certain mobile phone features may not be activated by your service provider, and / or their network setting may limit the feature's functionality. Services and some features such as GPRS, email may be dependent on the network, SIM card, as well as on the compatibility of the devices used and content formats supported and may require network/service subscription/solutions. Data transfers speeds are

User Guide

Aqua Star

network dependent. Always contact your service provider for details or help. Talk and standby time is quoted in digital mode and are approximate; battery performance and the signal reception depend on network configuration, signal strength, type of SIM card, operating temperature, features selected as well as voice, data and other application usage pattern. The phones supports Bluetooth, A2DP, in order for Bluetooth devices to communicate with one another, they must utilize the same Bluetooth Profile. To determine the profiles supported by other Intex products, visit www.intextechnologies.com, for other devices, contact their respective manufacturers. Always demand for original Intex mobile phones to protect against buying tinkered and/or used, refurbished or tampered phones. The warranty is applicable only for Intex phones; the company is not responsible for any loss or theft. Always use Intex original Enhancements (including batteries) for safety. The use of any other type may invalidate and approval or warranty applying to the mobile phone and may be dangerous. The phone is designed to operate using Li-ion batteries approved by the phone manufactures. Using non approved batteries with the phone may result in poor performance and damage to the phone or its enhancements. The display and products visualization here are illustrative purposes only; Display / color of the phone may differ from that shown on the manual. All features, functionality and other product specifications are based on the latest available information and are correct at the time of printing; however such product specifications are subject to change without notice. Copyrights are reserved. Intex is the trademark of INTEX TECHNOLOGIES (INDIA) LTD. which is registered. The unauthorized copying of copyrighted material is not legalized is inimical to the provisions of the copyright laws of India and other countries.

INFORMATION UNDER E-WASTE (MANAGEMENT AND HANDLING) RULES, 2011

For disposal of e-waste, please call our helpline no. or visit our website.

E-waste Helpline no. 1800-103-8822

Weblink: http://intextechnologies.com/window_self/Waste%20Disposal.html

1.Do's for disposal of product

- a)Always drop your used electronic products, batteries, and packaging materials after the end of their life in nearest collection point or collection center
- b)Separate the packaging material according to responsible waste disposal options and sorting for recycling.
- c)The battery can easily be removed from the product for recycling.

2.Don't of disposal of equipment

User Guide

Aqua Star

- a) Never dump E-waste in garbage bins or municipal solid waste stream.
- b) Do not dispose of your product as unsorted municipal waste.
- c) Do not throw used batteries into household waste.
- d) Do not dispose damaged or leaking Lithium Ion (Li-Ion) battery with normal household waste.



3. Information on the consequences of improper handling, accidental breakage damage and improper recycling of the end of life product.
- a) If batteries are not properly disposed of, it can cause harm to human health or the environment.
 - b) Placing of batteries or devices on or in heating devices, such as microwave ovens, stoves, or radiators and improper disposal of batteries may lead to explosion.
 - c) If the battery terminals are in contact with metal objects, it may cause a fire.