lenovo

IdeaTab A1000

Quick Start Guide v1.0

Welcome



Please read this guide carefully before using your IdeaTab. The guide will help you learn tips on setting and using IdeaTab.

The information in this guide is based on default settings. Illustrations and screenshots used here may differ from the actual product appearance and screen displays.

Getting started



Screen lock/unlock

In standby mode, press the Power button to lock your IdeaTab.


To unlock the screen, press the Power button, and then drag the on-screen slider to enter the interface displayed before it locks.

If you do not touch the screen for a while, IdeaTab dims its screen to enter sleep mode for power saving.

Turning IdeaTab off


While in standby mode, press and hold the Power button and then follow the on-screen instructions to confirm shutdown.

Technical specifications



▲ *Based on actual measurements

Charging IdeaTab



When the battery level falls below the threshold, IdeaTab will alert you with a tone and the battery status icon will change into . We recommend you plug the AC power adapter into your IdeaTab in the direction of the grange arrow as shown above figure.

You can charge your IdeaTab whether it is on or off.

If your IdeaTab is being charged while it is on, the battery status icon (located on the status bar of the screen) will appear as 3 . After the battery has finished charging, the status bar will show the fully charged icon

Learn more

For more information about IdeaTab functions, Regulatory Notices and other useful manuals.

go to http://support.lenovo.com/. To read this manual on your IdeaTab, please access "User Guide" from the Browser favorites in your IdeaTab.

Getting support

For support on network service and billing, please contact your wireless network operator. For instructions on how to use your IdeaTab, go to http://support.lenovo.com/

European Union conformity



Radio and Telecommunications Terminal Equipment Directive

This product is in compliance with the essential requirements and other relevant provisions of the Radio and Telecommunications Terminal Equipment Directive, 1999/5/EC.

Legal notices

Lenovo, the Lenovo logo, and IdeaTab are trademarks of Lenovo in the United States, other countries, or both, Other company, product, or service names may be trademarks

or service marks of others

First Edition (April 2013)

© Copyright Lenovo 2013. LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant a General Services Administration "GSA" contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Reduce | Reuse | Recycle






For more information on battery safety, see the *Important Product* Information Guide.

Inserting SD card

Connecting IdeaTab to PC



IdeaTab supports SD card extension. To insert an SD card, do the following:

- 1. Open the SD card cover.
- 2. Insert the SD card as shown by the arrow.
- Close the SD card cover.

You can connect IdeaTab to the PC's USB port with the cable provided for battery charging or data transferring with the PC.

There are three connection methods available: USB storage, Media device (MTP) and Camera (PTP).

Transfer the APK setup file from the PC to IdeaTab, and then open it in the file manager on IdeaTab. The installer will run automatically.

Customizing the desktop

➤ Touch ::: > WIDGETS. You can drag your favorite applications and widgets onto the desktop.



Adding apps/widgets to the desktop Tap and hold the icon of your desired application or widget, until the desktop background pattern appears on the screen, and then place the icon wherever you wish.

Editing the desktop

Tap and hold any icon on the desktop and then drag it to your preferred location or delete it from the desktop.

Communication

Wi-Fi connection

You can connect your tablet to the Internet using Wi-Fi. When Wi-Fi is on, your IdeaTab will automatically scan for Wi-Fi hotspots within range. Select the Wi-Fi hotspot you want to connect to.



If your computer has an integrated Bluetooth adapter card, it can connect to and transfer data wirelessly with other Bluetooth enabled devices, such as notebook computers, PDAs and cell phones. You can transfer data between these devices without cables and up to 10 meters range in open space.

The actual maximum range may vary due to interference and transmission barriers.

Browsing the web

➤ Touch ::: > Browser. Now you can browse the Web and download applications.



Add a bookmark

O Search or type a URL

★ Bookmarks, history and saved pages

Camera

➤ Touch ::: > Camera. Now you can record the wonderful moments of your life with the camera.



There are two modes available for the camera; photo and video.

You can zoom in/out a photo by double-tapping or moving your two fingers



apart/together while touching the screen.

⚠ The above functions require your IdeaTab to connect to the Internet via Wireless network.