

# HTC Desire 620G dual sim

## User guide

# Contents

---

## Unboxing

---

HTC Desire 620G dual sim	8
Back cover	9
Dual micro SIM cards	11
Storage card	12
Battery	13
Switching the power on or off	14

---

## Setting up your phone

---

Setting up HTC Desire 620G dual sim for the first time	15
Transferring contacts from your old phone through Bluetooth	15
Installing an update	16
Checking for updates manually	16

---

## Your first week with your new phone

---

Basics	17
Working with text	24
Battery	29
HTC Dot View	31

---

## HTC BlinkFeed

---

Your dynamic Home screen	33
Turning HTC BlinkFeed on or off	33
Selecting feeds	34
Reading articles in HTC BlinkFeed	35
Deleting tiles on HTC BlinkFeed	35
Posting to your social networks	36

---

## Personalizing

---

Home wallpaper	37
Launch bar	37
Adding a widget to your Home screen	38
Adding Home screen shortcuts	38
Editing Home screen panels	39
Changing your main Home screen	40
Grouping apps on the widget panel and launch bar	41
Arranging apps	41
Adding a widget on the lock screen	42
Turning the lock screen off	43

---

## Phone calls

---

Making a call	44
Calling a speed dial number	44
Making an emergency call	45
Answering or rejecting a call	45
What can I do during a call?	45
Setting up a conference call	47
Checking calls in the Call History	47
Switching between silent, vibrate, and normal modes	48

---

## Messages

---

Sending a text or multimedia message via Android Messages	49
---	----

---

## Storage and files

---

Types of storage	50
Copying files to or from HTC Desire 620G dual sim	50
File Manager	50

---

## Backup and reset

---

Backup	52
Reset	53

---

## Search and web browser

---

Getting instant information with Google Now	55
Searching HTC Desire 620G dual sim and the Web	56
Browsing the Web	57
Bookmarking a webpage	58
Clearing your browsing history	58

---

## People

---

Your contacts list	59
Setting up your personal contact information	59
Adding a new contact	60
Editing a contact's information	60
Getting in touch with a contact	60
Importing contacts from your SIM card	60
Importing contacts from the storage	61
Sending contact information	61
Contact groups	61

---

## Email

---

Adding an email account	62
Checking your mail	63
Sending an email message	63
Reading and replying to an email message	64
Searching email messages	64
Viewing your Gmail Inbox	65
Sending an email message in Gmail	65

Replying to or forwarding email messages in Gmail	66
---	----

---

## Camera

---

Using Android Camera	67
----------------------	----

---

## Gallery and Video Highlights

---

Viewing photos and videos in Gallery	68
Editing photos	68
Viewing and editing Video Highlights	68

---

## Music

---

Listening to music	70
Creating music playlists	70
Adding a song to the queue	71

---

## Travel and maps

---

Turning location services on or off	72
About Google Maps	72
Getting around maps	72
Searching for a location	73
Getting directions	74

---

## Google Play and other apps

---

Getting apps from Google Play	75
Downloading apps from the web	76
Uninstalling an app	77
Using the Clock app	77
Viewing the Calendar	78
Watching videos on YouTube	79
Creating video playlists	79

---

## Internet connections

---

Turning the data connection on or off	80
Wi-Fi	80
Managing your data usage	81
Connecting to a virtual private network (VPN)	83
Using HTC Desire 620G dual sim as a Wi-Fi hotspot	84
Sharing your phone's Internet connection by USB tethering	85

---

## Bluetooth

---

Connecting a Bluetooth headset	86
Unpairing from a Bluetooth device	86

---

## Settings and security

---

Managing your micro SIM cards	87
Choosing which micro SIM card to connect to the 3G network	87
Assigning a PIN to a micro SIM card	87

Protecting HTC Desire 620G dual sim with a screen lock	88
Turning Airplane mode on or off	89
Adding and syncing an account	89
Removing an account	89
Turning automatic screen rotation off	89
Adjusting the time before the screen turns off	90
Adjusting the screen brightness manually	90
Changing the display language	90
Working with certificates	91

---

## Trademarks and copyrights

---

---

## Index

---

## About this guide

In this user guide, we use the following symbols to indicate useful and important information:



This is a note. A note often gives additional information, such as what happens when you choose to do or not to do a certain action. A note also provides information that may only be applicable to some situations.



This is a tip. A tip gives you an alternative way to do a particular step or procedure, or lets you know of an option that you may find helpful.



This indicates important information that you need in order to accomplish a certain task or to get a feature to work properly.



This provides safety precaution information, that is, information that you need to be careful about to prevent potential problems.


Some apps may not be available in all regions or with your mobile operator.

## Important note on recoverable data

Files and other data that have been deleted, cleared, removed, or erased from your device may still be recoverable by third-party data recovery software. Even a factory reset may not permanently erase all data from your phone, including personal information.

# Unboxing

## HTC Desire 620G dual sim



1. POWER
2. VOLUME
3. Receiver
4. 3.5mm headset jack
5. Front camera
6. Proximity sensor
7. Speaker
8. USB connector



You need a data plan to use your operator's network for data services. Check with your operator for details.



- If you want to use a case or screen protector, don't cover and block the proximity sensor. Purchase a case or screen protector designed for HTC Desire 620G dual sim.
- Avoid connecting third-party headsets or accessories with metallic charms that dangle near the headset jack. Using these may affect signal reception.


## Back cover

---

### Removing the back cover

---

1. With one hand, securely hold HTC Desire 620G dual sim with the bottom edge facing up and the back facing you.
2. With your other hand, press your thumb on the back cover. From the notch (where the USB port is located), use your finger to open a small gap along the bottom edge. Then continue to lift open from the bottom edge.




3. Slowly detach the cover from the phone to remove it.

---

## Replacing the back cover

---

1. Align the back cover onto the top part of HTC Desire 620G dual sim.
2. Press the sides and the bottom part of the back cover against HTC Desire 620G dual sim to lock the cover into place.



You will hear a click when the back cover is locked in place.

## Dual micro SIM cards

HTC Desire 620G dual sim has two micro SIM card slots.




Use a standard micro SIM card only. Do not cut a regular SIM and insert it into the micro SIM slot, since the card may get stuck in the slot. If you're using a nano SIM card with a card adapter, never insert the adapter when it's empty. This may damage the card slot.

---

### Inserting a micro SIM card

---

1. Take the back cover off.
2. Remove the battery.
3. Insert the micro SIM cards into the two micro SIM slots. When inserting, make sure the card's gold contacts are facing down and its cut-off corner facing in.



---

### Removing a micro SIM card

---



Make sure to switch off HTC Desire 620G dual sim before removing the card.

1. Take the back cover off.
2. Remove the battery.
3. Slide the card out from the card slot.

## Storage card

Use a storage card to store your photos, videos, and music. When you need to free up phone storage space, you can also move certain apps to the storage card, if the apps support this feature.



The storage card is optional and sold separately.




- Moving apps to the storage card doesn't back up the apps. If you do a factory reset, your phone loses the apps. You'll need to reinstall them.
- When you remove the storage card and insert it in another phone, the apps on the storage card won't be installed automatically to the other phone. You'll need to reinstall them.

---

### Inserting the storage card

---

1. Take the back cover off.
2. Make sure to remove the battery first before inserting the microSD™ card.
3. Insert the microSD card into the storage card slot with its gold contacts facing down and push it all the way in.



---

### Removing the storage card

---

1. Take the back cover off.
2. Make sure to remove the battery first before removing the microSD card.
3. Slide the microSD card out from its slot.

## Battery


### Charging the battery

Before you turn on and start using HTC Desire 620G dual sim, it is recommended that you charge the battery.



- If the battery has been discharged for several days, you may need to charge HTC Desire 620G dual sim for several minutes before powering it on.
- Use only the adapter and the USB cable that came with HTC Desire 620G dual sim to charge the battery. When the battery power is too low, make sure to use the power adapter to charge, not the USB cable connection with your computer.
- Do not remove the battery from HTC Desire 620G dual sim while you are charging it using the power or car adapter.

1. Insert the small end of the USB cable into the USB connector.



2. Insert the other end of the USB cable into the power adapter.
3. Plug in the power adapter to an electrical outlet to start charging the battery.



- As a safety precaution, the battery may stop charging to avoid overheating.
- We recommend you check the temperature of the battery while you're charging. Also, avoid charging the battery in hot environments.
- When you're using the Internet and charging the battery, HTC Desire 620G dual sim may become warmer. This is normal.
- To conserve energy, unplug the power adapter from the electrical outlet after you finish charging.

## Switching the power on or off

---

### Switching the power on

---

Press the POWER button until HTC Desire 620G dual sim vibrates.



When you turn on HTC Desire 620G dual sim for the first time, you'll need to set it up.

---

### Switching the power off

---

1. If the display is off, press the POWER button to turn it back on.
2. Press and hold the POWER button for a few seconds.
3. Tap **Power off** on the options menu.

# Setting up your phone

## Setting up HTC Desire 620G dual sim for the first time

When you switch on HTC Desire 620G dual sim for the first time, you'll be asked to set it up.

Walk through the on-device setup to choose your Internet connection and more. You can also sign in to your Google® account.



Some features that need to connect to the Internet such as location-based services and auto-sync of your online accounts may incur extra data fees. To avoid incurring these fees, disable these features under Settings.

## Transferring contacts from your old phone through Bluetooth

Use Bluetooth® to transfer contacts from another HTC phone, an iPhone, or other types of phones.

1. If you're setting up HTC Desire 620G dual sim for the first time, tap **Transfer my stuff**.  
Or go to Settings, and then tap **Get content from another phone**.
2. Choose whether to transfer from an Android™ phone, iPhone, or other phone types.
3. Follow the onscreen instructions on HTC Desire 620G dual sim to turn on Bluetooth on your old phone and pair the two phones.
4. On HTC Desire 620G dual sim, slide the Notifications panel open, and then tap **Pairing request**.
5. When you see the passkey, tap **Pair** on both phones.
6. After data has been transferred, tap **Done**.

## Installing an update

Updates to the system software are periodically available. When Internet connection is on and there's a new software update available, you will receive a notification.



If you don't want to download the update using your data connection, go to **Settings > About phone > System updates** and tap **Update over Wi-Fi only**.

1. Slide the Notifications panel open, and then tap the system update notification.
2. Tap **Download**.
3. When download is complete, choose to install the update now or install at a later time.

After updating, HTC Desire 620G dual sim will restart.

## Checking for updates manually

1. Go to Settings, and then tap **About phone**
2. Tap **System updates > Check now**. HTC Desire 620G dual sim checks if updates are available.



If you don't have Internet connection, you'll be prompted to turn on mobile data or connect to a Wi-Fi® network. Once connected, tap **Check now** to check for updates.

# Your first week with your new phone

## Basics

### Onscreen navigation buttons

HTC Desire 620G dual sim has onscreen navigation buttons at the bottom of the screen which rotate when you change the orientation.


	Goes to the previous screen.
	Goes to the home screen.
	Shows thumbnails of the most recently used apps.

Swipe up from any of the navigation buttons to access Google search.

### Touch gestures

Use touch gestures to get around the Home screen, open apps, scroll through lists, and more.

#### Tap




Tap the screen with your finger when you want to select onscreen items such as application and settings icons, or press onscreen buttons.

## Press and hold




To open the available options for an item (for example, a text message), just press and hold the item.

## Swipe or slide



Quickly swipe your finger vertically or horizontally across the screen to go to other Home screen, read the next e-mail, and more.

## Drag



Press and hold your finger with some pressure before you start to drag. While dragging, don't release your finger until you have reached the target position.

## Flick



Flicking the screen is similar to swiping, except that you need to swipe your finger in light, quicker strokes, such as when moving right and left on the Home screen, or flicking through a contacts or message list.

## Slide with two fingers



In some apps, like Gallery or the web browser, slide two fingers apart to zoom in when viewing a picture or text.



Slide two fingers together to zoom out of the picture or text.

---

## Sleep mode

---

Sleep mode saves battery power by putting HTC Desire 620G dual sim into a low power state while the display is off. It also stops accidental button presses when HTC Desire 620G dual sim is in your bag.

### Switching to Sleep mode

Briefly press the POWER button to turn off the display and switch to Sleep mode. HTC Desire 620G dual sim also automatically goes into Sleep mode when it's left idle for a while.

You can change the time before HTC Desire 620G dual sim sleeps in the **Settings > Display**.

### Waking up from Sleep mode

To wake HTC Desire 620G dual sim up manually, press the POWER button. You may need to unlock the screen.




HTC Desire 620G dual sim automatically wakes up when you have an incoming call.

---

## Unlocking the screen

---

- Swipe up to unlock the screen, swipe right to go directly to HTC BlinkFeed™, or swipe left to go to the Home widget panel.
- You can also press and hold the lock icon, and then drag it up, right, or left.



If you've set up a screen lock, you'll be asked to provide your credentials before HTC Desire 620G dual sim unlocks.



If you've set an event reminder or an alarm, you can snooze or dismiss the event or alarm right from the lock screen.

---

## Opening an app

---

- Tap an app on the launch bar at the bottom of the Home screen.
- To see the Apps screen, tap . Then tap the app you want to use.
- In the Apps screen, tap  and enter the name of the app you're looking for.

---

## Switching between recently opened apps

---

You can easily access apps you've just recently opened.

1. Tap the  button.
2. Slide your finger up or down to see recently-opened apps.




- To remove an app from the list, drag it left or right.
- To switch back to an app, just tap it.

## Notifications panel

Notification icons inform you of new messages, calendar events, alarms, and activities in progress such as files downloading. When you see notification icons, open the Notifications panel to check out details of the notifications that you've received.



1. To open the Notifications panel, slide down from the top of the screen.



If you have several notifications, scroll down the screen to see them all.



To quickly access the Notifications panel from Quick settings, tap .

2. On the Notifications panel:
  - You can expand certain notifications to see more information, such as email previews and calendar events. Slide two fingers apart to expand a notification. To collapse it, slide two fingers together.
  - You'll see icons in some notifications that allow you to take immediate actions. For example, when you have a missed call, tap the available icons to return the call or reply with a text message.
  - Tap the notification icon on the left to open the corresponding app.
  - To dismiss just one notification in the list, drag it left or right.
3. To close the Notifications panel, slide up from the bottom bar of the panel or press the  button.

You can also tap  to dismiss all notifications and close the Notifications panel.

---

## Using Quick Settings

---

In the Quick Settings panel, easily turn settings such as Wi-Fi and Bluetooth on or off. You'll also find a few shortcuts, such as for viewing your profile.

1. With two fingers, swipe down from the status bar to open Quick Settings.
2. To turn a setting on or off, just tap its tile.



When you're in the Notifications panel, you can tap  to switch to Quick Settings.

---

## Getting to know your settings

---

Want to change the ringtone, set up a Wi-Fi connection, or add your accounts? Do this and more in Settings.

1. Open Settings either from the Quick Settings panel or the Apps screen.
  - With two fingers, swipe down from the status bar to open Quick Settings, and then tap **Settings**.
  - From the Home screen, tap  to switch to the Apps screen, and then tap **Settings**.
2. Here are some of the basic settings you can change:
  - Tap the on/off switch next to an item such as Wi-Fi to turn it on or off. Tap the item itself to configure its settings.
  - Tap **Audio profiles** to choose a sound profile, set a ringtone, and configure notification sound settings.
  - Tap **Display** to choose your wallpaper, change the sleep timeout setting, and more.
  - Tap **Add account** to sign in to your different accounts, such as email, social network, and more.
  - Tap **Security** to help secure HTC Desire 620G dual sim, for example with a screen lock.

---

## Changing your ringtone and notification sound

---

1. Go to Settings.
2. Tap **Audio profiles**.
3. Tap  next to **General**.  
Or tap  to create your own audio profile, and then tap  next to your created profile.
4. Tap **Phone ringtone** to change the ringtone.
5. Tap **Default notification sound** to change the notification sound.

---

## Capturing the HTC Desire 620G dual sim screen

---

Want to show off your high game score, write a blog post about HTC Desire 620G dual sim features, or post a status update about a song you're playing? It's easy to take a picture of the screen and share it from Gallery.

Simultaneously press and hold POWER and VOLUME DOWN buttons. The screen is saved in the Screenshot album in Gallery.

## Working with text

---

### Selecting, copying, and pasting text

---

In apps such as the web browser and Mail, you can select and copy text, and then paste or share it.

1. Press and hold on a word.
2. Drag the start and end anchors to highlight the surrounding text you want to select.



3. After you have selected the text you want to copy, tap > Copy (or tap ).
- The selected text is then copied to the clipboard.
4. In a text entry field (for example while composing an email), press and hold at the point where you want to paste the text.
5. Tap Paste.



To copy the address of a linked webpage, press and hold the link, and then tap Copy link URL (or Copy link address).

---

### Sharing text

---

1. After you have selected the text you want to share, tap > Share (or tap ).
2. Choose where to paste and share the selected text, such as in an email message or social network status update.

---

## The HTC Sense keyboard

---

Typing is fast and accurate with the HTC Sense™ keyboard.

- Word prediction also saves typing time. As you type, you'll see word suggestions that you can choose from. You can even add words, phrases, and shortcuts to the word prediction dictionary. See [Entering text with word prediction](#) on page 26.
- You can type words by just speaking. See [Entering text by speaking](#) on page 28.
- Turn on the Trace keyboard so you can type words by just sliding your finger from one letter to another. See [Using the Trace keyboard](#) on page 28.
- Just swipe right to access the numeric and symbol keyboard. Or swipe left to switch between languages.
- The keys have secondary numbers, punctuation symbols, or other characters that you can insert without having to switch to the numeric and symbol keyboard.

For example, just press and hold a key on the first row to insert a number.

- Choose from a wide selection of emoji.
- Show or hide navigational arrow keys on the keyboard. If you enable the arrow keys in Settings, they'll only appear on the portrait keyboard.

---

## Entering text

---

The onscreen keyboard becomes available when you tap a text field in an app. Enter letters and numbers, change the keyboard layout or language, and more.

Tap the keys on the onscreen keyboard to enter letters and numbers, as well as punctuation marks and symbols.

- Tap  to enter an uppercase letter. Tap twice to turn on caps lock.
- Press and hold keys with gray characters at the top to enter numbers, symbols, or accented letters. Some keys have multiple characters or accents associated with them.
- Swipe right to show number and symbol keys. To return to the main keyboard, swipe left.
- Press  to close the onscreen keyboard.



To open the keyboard settings, press and hold the comma key if you see  above the key. Or go to **Settings > Language & input** and tap  beside **HTC Sense Input**.

### Selecting a keyboard layout

Choose a keyboard layout that suits your typing style.

1. Go to Settings, and then tap **Language & input**.
2. Tap  beside **HTC Sense Input**.

3. Tap **Keyboard selection** > **Keyboard types**.
4. Select the keyboard layout that you want to use.

### Choosing and switching between keyboard languages

If multiple keyboard languages are available on HTC Desire 620G dual sim, you can choose which languages to enable in the onscreen keyboard.

1. Go to Settings, and then tap **Language & input**.
2. Tap  beside **HTC Sense Input**.
3. Tap **Keyboard selection**, and then choose the languages you want.

To change the keyboard language, do any of the following:

- Swipe left on the onscreen keyboard (not available if you're using trace keyboard).
- Tap the language key (for example, **EN**) until you see the keyboard language you want to use.
- Press and hold the language key, and then drag your finger to the keyboard language you want to use.

---

### Entering text with word prediction

---

Ever started typing something you weren't sure how to spell? With word prediction, you'll see suggested words displayed just above the keyboard.



Word prediction and next word prediction are enabled by default.

To enter text in word prediction mode, do any of the following:

- Tap the space bar to insert a highlighted word in the suggestion list.
- Tap a word from the suggestion list.
- Tap the arrow next to the suggestion list to see more choices.



In some keyboard languages such as English and Spanish, if you've accidentally chosen a wrong word from the suggestion list, you can go back and change it by tapping the word and selecting another suggestion.

## Setting a second language for word prediction

You can set the word prediction to be bilingual. As you type, you'll get word suggestions in the languages that you've selected.



Bilingual prediction is available only when you're using a Latin-based keyboard.

1. Go to Settings, and then tap **Language & input**.
2. Tap  beside **HTC Sense Input**.
3. Tap **Keyboard selection > Bilingual prediction**, and then choose the language you want.

## Adding words and phrases to the word prediction dictionary

Add frequently-used names, acronyms, and even phrases to the word prediction dictionary to easily find them in the suggestion list.

Type even faster when you create text shortcuts to words and phrases. Instead of typing "Talk to you later", save a few keystrokes by adding the ttyl shortcut. In your message or email, just type "ttyl", and then tap the spacebar to enter the complete phrase.



This feature is available only for Latin-based languages.

1. Go to Settings, and then tap **Language & input**.
2. Tap  beside **HTC Sense Input**.
3. Tap **Personal dictionary**, choose which language you want to add a word for, and then tap .
4. Enter a word or phrase, and then enter its text shortcut.
5. Tap **Add to dictionary**.

## Editing or deleting words and phrases in the word prediction dictionary

1. Go to Settings, and then tap **Language & input**.
2. Tap  beside **HTC Sense Input**.
3. Tap **Personal dictionary**, and then choose the dictionary language that you want to make changes in.
  - To edit a word, phrase, or shortcut, tap the item in the list and make your changes.
  - To delete an item, tap it and then tap .

---

## Using the Trace keyboard

---

Instead of tapping the keys on the onscreen keyboard, you can "trace" to type words.



This feature is available only for Latin-based languages.

1. Turn on the Trace keyboard in **Settings > Language & input > HTC Sense Input**.
2. Slide your finger from one letter to the next to enter a word.
3. Lift your finger when the word is completed.
4. If you want to continue entering text, slide your finger over the letters again to enter the next word.



If the word that appears after you traced isn't the one you want, you can:

- Tap a word from the suggestion list.
- Tap the arrow next to the suggestion list to see more choices.

### Turning Trace keyboard on or off

1. Go to Settings, and then tap **Language & input**.
2. Tap  beside **HTC Sense Input**.
3. Select or clear the **Trace keyboard** option.

---

## Entering text by speaking

---

No time to type? Try speaking the words to enter them.

1. Tap an area where you want to enter text.
2. On the onscreen keyboard, press and hold .
3. When you see the animated microphone button and the words "Speak now", say the words you want to enter.



To set the voice input language, tap the language bar above the microphone button. You can choose one or more languages. Available languages may vary.

4. If a word doesn't match what you've spoken and it's underlined, tap the underlined word to delete it or to see more choices.
5. Enter punctuation marks by saying the name (for example, say "comma").

## Battery

---

### Displaying the battery percentage

---

You can check the percentage of remaining battery power right from the status bar.

1. Go to Settings.
2. Tap **Battery**.
3. Select **Battery Percentage**.

---

### Checking battery usage and history

---

Check how much battery is being used by the system software and hardware. You can also see how long you've been using HTC Desire 620G dual sim since the last charge.

1. Go to Settings.
2. Tap **Battery**. You'll see a ranking list of items that are using the battery and how much power is being used.
3. Tap an item to check how it's using the battery. Or tap the graph to check the battery usage history.

---

### Tips for extending battery life

---

How long the battery can last before it needs recharging depends on how you use HTC Desire 620G dual sim.

In times when you need to extend the battery life more, try out some of these tips:

#### Check your battery usage

Monitoring your battery usage helps you identify what's using the most power so you can choose what to do about it. For details, see [Checking battery usage and history](#) on page 29.

#### Manage your connections

- Turn off wireless connections you're not using. Go to Settings to turn on or off the data connection, Wi-Fi, or Bluetooth.
- Turn GPS on only when a precise location is needed, such as while using navigation or location-based apps. See [Turning location services on or off](#) on page 72.
- Turn on Airplane mode when you don't need any wireless connections and you don't want to receive calls or messages.

## Manage your display

- Lowering the brightness and setting the screen timeout to a shorter time help save battery power.
- Don't use a live wallpaper for your Home screen. Animation effects are nice to show off to other people but they drain your battery.

Changing your wallpaper to a plain, black background can also help a little. The less color is displayed, the less battery is used.

For more details, see [Settings and security](#) on page 87 and [Personalizing](#) on page 37.

## Manage your apps

- Install the latest software and application updates. Updates sometimes include battery performance improvements.
- Uninstall or disable apps that you never use.

Many apps run processes or sync data in the background even when you're not using them. If there are apps that you don't need anymore, uninstall them.

If an app came preloaded and can't be uninstalled, disabling the app can still prevent it from continuously running or syncing data. In **Settings > Apps**, swipe to the **All** tab, tap the app, and then tap **Disable**.

## Limit background data and sync

Background data and sync can use a lot of battery power if you have many apps syncing data in the background. Determine which apps can be set with longer sync times, or sync manually.

- If you have many email accounts, consider manually syncing some accounts.
- In Play Store, tap  > **Settings**, and then clear **Add icon to Home screen** to avoid automatically adding Home screen app shortcuts whenever you've installed new apps. Also tap **Auto-update apps > Do not auto-update apps** if you're fine with updating apps from Play Store manually.

## Other tips

To squeeze in a little bit more battery power, try these tips:

- Tone down the ringtone and media volume.
- Minimize the use of vibration or sound feedback. In Settings, tap **Audio profiles > ** and choose which ones you don't need and can disable.
- Check your apps' settings as you may find more options to optimize the battery.

## HTC Dot View

---

### Personalizing HTC Dot View

---

If you bought the HTC Dot View™ case designed for HTC Desire 620G dual sim, use its app to personalize what's seen through the case.

To use the app, tap  > HTC Dot View.




The HTC Dot View app is available in Google Play™. Make sure to install the latest app update.

### Wallpaper

Choose a preset wallpaper, or create your own dotted wallpaper from a photo.

1. In the HTC Dot View app, tap **Theme**.
2. Choose a preset pattern as your wallpaper.  
To create your own wallpaper, tap **+**, and then choose whether to use an existing photo from Gallery or take a new photo.
3. If you selected or taken a photo, crop the photo, and then tap **Done**.
4. Tap **Apply**.

For best results when creating your own wallpaper, use a simple image with distinct colors between the subject and background. For example, use an image that shows a high-contrast subject on a simple background.





### Not seeing recent calls on HTC Dot View?

By default, up to 3 received or dialed numbers will be displayed on HTC Dot View.

- If you're not seeing them, open the HTC Dot View app, and then select **Show call history**.
- If you've set a screen lock with credentials, you need to select **Bypass security screen** to display the recent calls.

### Need more details?

For more details, see the HTC Dot View Get started guide that comes with the case.

# HTC BlinkFeed

## Your dynamic Home screen

Stay in touch with friends or get the latest about your interests right on HTC BlinkFeed. Set up which social networks, news sources, and more will appear.

- Tap a tile to view the content or to comment on a post or status update.
- Scroll to the top and pull down on the screen to manually refresh the stream.



While on HTC BlinkFeed, you can press the  button or  button to scroll to the top.

- On HTC BlinkFeed, swipe right to open the slideout menu to choose the type of feeds to display. Select Highlights to see a mix of articles from selected feeds and your favorite news sources.



## Turning HTC BlinkFeed on or off

1. On HTC BlinkFeed, slide two fingers together, and then tap .
2. While HTC BlinkFeed is selected, tap **Remove**.
3. To add it back, swipe right, and then tap the **+** button that has the word **BlinkFeed**.

## Selecting feeds

Discover stories and articles on HTC BlinkFeed based on your interests, favorite categories, and popular news channels or websites.

1. On HTC BlinkFeed, swipe right to open the slideout menu.
2. Tap  > **Add content**.
3. Choose a category.
4. Select one or more feed sources.

You can tap a name first to check out a particular feed, and then tap  to add it to HTC BlinkFeed.

---

### Customizing the Highlights feed

---

When you select topics and services for HTC BlinkFeed, the top trending articles from the selected sources, recent status updates, and more are shown. If you want to temporarily show fewer items in your Highlights feed, you can filter out some of your selected topics and services.

1. On HTC BlinkFeed, swipe right to open the slideout menu.
2. Tap  > **Settings**.
3. Tap **Choose Highlights topics**.
4. Select the news sources and topics you want to appear in the Highlights feed.

---

### Subscribing to multiple regional editions

---

Want to keep up to date on current events in more than one locale? You can add several locales.

1. On HTC BlinkFeed, swipe right to open the slideout menu.
2. Tap  > **Add content**.
3. Tap , and then select a locale or region.
4. Select the feed sources to add.

---

### Adding topics of your interest

---

Looking for a more specific topic? Search for and select topics of your interest to display them on HTC BlinkFeed.

1. On HTC BlinkFeed, swipe right to open the slideout menu.
2. Tap **Search for content**, and then enter the topic you're looking for.
3. Tap a result, and then tap  to add it under Custom topics.

---

## Showing content from your apps and social networks

---

See your friends' posts in social networks or show content from your HTC apps right on HTC BlinkFeed.



You need to sign in to your social networks to see their feeds on HTC BlinkFeed.

1. On HTC BlinkFeed, swipe right to open the slideout menu.
2. Tap  > **Services & Apps**, and then select the apps and social networks you like.

## Reading articles in HTC BlinkFeed

1. While on HTC BlinkFeed, swipe up or down to find an article you want to read.
2. Tap the tile to view the article.



If related articles are found, you can scroll down to the end to see the links.

---

## Saving articles for later

---

Don't have time to read that potentially interesting article? You can bookmark articles to your reading list.

Do one of the following:

- While viewing an article, tap .
- On HTC BlinkFeed, press and hold the tile of the article you want to bookmark. Then tap **Read later**.

To access your reading list on HTC BlinkFeed, swipe right, and then tap **News reading list** in the slideout menu.

## Deleting tiles on HTC BlinkFeed

Want to get rid of a tile? Now you can easily remove any tile on HTC BlinkFeed.

1. On HTC BlinkFeed, press and hold the tile you want to remove.
2. Tap **Remove**.

## Posting to your social networks

You can easily post a status update from the Home screen.



You must sign in to your social network account to post.

1. On HTC BlinkFeed, swipe right to open the slideout menu.
2. Tap  > **Compose**, and then choose a social network.
3. Compose your status update and post it on your social network.

# Personalizing

## Home wallpaper

Choose from the available wallpapers, or use any photo you've taken with the camera.

1. Press and hold an empty space on a widget panel.
2. In the pop-up menu, tap **Home screen wallpaper**.
3. Tap one of the following:


HTC wallpapers	Tap a preset wallpaper to preview it.
Live wallpapers	Tap a preset animated wallpaper to preview it.
Gallery or Photos	Choose an existing photo and crop it.

4. Tap Apply or Done.

## Launch bar

The launch bar gives you one-touch access to commonly used apps. You can replace the apps on the launch bar with other apps you often use.

1. Press and hold the app you want to replace, and then drag it out to .



2. Tap  to go to the Apps screen.
3. Press and hold an app, and then drag it to the empty slot on the launch bar.



- You can also group apps on the launch bar into a folder.
- The apps on the lock screen are the same as the ones on the launch bar.

## Adding a widget to your Home screen

Widgets make at-a-glance important information and media content easily available. Choose from a selection of widgets and add the most useful ones to your Home screen.

1. Press and hold an empty space on a widget panel.
2. In the pop-menu, tap **Add apps and widgets**.
3. Tap ▼ > **Widgets**.
4. Scroll through the widgets, or tap 🔍 to search for a specific widget.
5. Press and hold and then drag the widget to a widget panel you want to add it to.


---

### Changing the settings of a widget

---

You can modify basic settings of some widgets.

1. Press and hold a widget on your Home screen, and then drag it to .



2. Customize the widget settings.

---

### Resizing a widget

---

Some widgets can be resized after you've added them to your Home screen.

1. Press and hold a widget on the Home screen, and then release your finger. If a border appears, that means the widget is resizable.
2. Drag the sides of the border to enlarge or shrink the widget size.

## Adding Home screen shortcuts

Place apps you often use on any widget panel of your Home screen. You can also add shortcuts to frequently used settings, bookmarked webpages, and more.

1. Press and hold an empty space on a widget panel.
2. In the pop-menu, tap **Add apps and widgets**.
3. Tap ▼ > **Apps or Shortcuts**.

4. Scroll through the apps or shortcuts, or tap  to search for one.
5. Press and hold and then drag an app or a shortcut to a widget panel you want to add it to.



To add an app from the Apps screen, press and hold the app, and then drag it to a widget panel.

## Editing Home screen panels

### Adding or removing a widget panel



- You won't be able to add a new widget panel if you've already reached the maximum limit.
- HTC BlinkFeed always appears as the first panel (if it's not removed). A widget panel cannot be added before HTC BlinkFeed.

1. Press and hold an empty space on a widget panel.
2. In the pop-up menu, tap **Manage home screen pages**.
3. To add a new widget panel, swipe left until you see the **+** icon, and then tap it.
4. To remove a widget panel, swipe left or right until you see the panel, and then tap **Remove**.
5. When done, press .

### Arranging widget panels



A widget panel cannot be moved and inserted before HTC BlinkFeed.

1. On HTC BlinkFeed or any widget panel, slide two fingers together to customize the Home screen.
2. Press and hold a widget panel thumbnail, and then drag it left or right to the position that you want.
3. When you're done arranging widget panels, press .


---

## Moving a widget or icon

---

You can easily move a widget or icon from one widget panel to another.

1. Press and hold the widget or icon with one finger.
2. With another finger, flick left or right to rotate the screen to another widget panel.



3. Release the widget or icon.

---

## Removing a widget or icon

---

1. Press and hold the widget or icon you want to remove, and then drag it to .
2. When the widget or icon turns red, lift your finger.

## Changing your main Home screen

Set HTC BlinkFeed or a widget panel as your main Home screen.


1. Press and hold an empty space on a widget panel.
2. In the pop-up menu, tap **Manage home screen panels**.
3. Swipe left or right until you see the panel that you want to use as your main Home screen.
4. Tap **Set as home**.
5. Press .



Pressing  from an app will first return you to the last panel you were in. Just press  again to go to your main Home screen.

## Grouping apps on the widget panel and launch bar

1. Press and hold an app, and then drag it over to another app to automatically create a folder.



2. Tap the folder to open it.
3. Tap the folder window's title bar, and then enter a new folder name.
4. Add more apps into the folder. Tap **+**, select your apps, and then tap **Done**.

You can also add shortcuts to settings or information to a folder. Add a shortcut first to a widget panel, and then drag it over to the folder.

---

### Removing items from a folder

---

1. On the launch bar or widget panel, tap a folder to open it.
2. Press and hold an app or shortcut in the folder, and then drag it out to .

## Arranging apps

On the Apps screen, you can rearrange the apps and change the layout.

1. From HTC BlinkFeed or any widget panel, tap .
2. Tap , and then choose how to arrange apps, such as alphabetically. If you want to group apps into folders or rearrange them, select **Custom**.
3. Tap  > **Grid size** to choose whether to display more or fewer apps per page.

---

### Moving apps and folders

---

1. On the Apps screen, tap  > **Custom**.
2. Tap  > **Rearrange apps**.
3. Press and hold an app or folder, and then do one of the following:
  - Drag the app or folder to another position on the same page. Wait until you see the occupying icon move away before releasing your finger.
  - Drag the app or folder to the  or  arrow to move it to another page.
4. When you're done moving apps and folders, tap .

---

## Grouping apps into a folder

---

1. On the Apps screen, tap ▼ > Custom.
2. Tap ≡ > Rearrange apps.
3. Press and hold an app, and then drag it over to another app to automatically create a folder.
4. To add more apps, drag each app over to the folder.
5. To name the folder, open the folder, tap its title bar, and then enter a folder name.
6. When done, tap ✓.

---

## Removing apps from a folder

---

1. On the Apps screen, tap ▼ > Custom.
2. Tap ≡ > Rearrange apps.
3. Tap the folder to open it.
4. Press and hold an app, and then drag it out to the Apps screen. Wait until you see the occupying icon move away before releasing your finger.
5. When you're done removing apps, tap ✓.

---

## Hiding or unhiding apps

---

1. On the Apps screen, tap ≡ > Hide/Unhide apps.
2. Select the apps you want to hide, or clear their check boxes to unhide them.
3. Tap Done.

## Adding a widget on the lock screen

Choose from our selection of lock screen widgets.

1. Go to Settings.
2. Tap Security, and then select the Enable widgets option.
3. On the lock screen, pull from the right edge until you see a + icon.
4. Tap +.
5. Tap a widget that you want to add to the lock screen.

## Turning the lock screen off

Rather not have to unlock your phone every time you wake it up? You can turn the lock screen off in Settings.

1. Go to Settings.
2. Tap **Security > Screen lock > None**.

To turn the lock screen on again, in Security settings, tap **Screen lock > Slide**.

# Phone calls

## Making a call

You can either dial a number directly or browse through your contact list and call logs to make a call.

1. Open the Phone app.
2. Slide the Notifications panel open, and then choose which card to use for placing your call.
3. Enter the first few digits of a phone number or first few letters of a contact name. A list of matching numbers and names from the Call history and your contacts are then displayed.
4. Scroll through the filtered list, and then tap the name or number you want to call.
5. To hang up, tap .

## Calling a speed dial number

1. Open the Phone app.
2. Slide the Notifications panel open, and then choose which card to use for placing your call.
3. On the phone keypad:
  - The number 1 key is generally reserved for your voicemail. Press and hold this key to call voicemail and retrieve your voicemail messages.
  - Press and hold the key that is associated with the contact you want to call.

---

### Assigning a speed dial key

---

1. Open the Phone app.
2. Tap  > **Speed dial**. You can also press and hold an unassigned number key.
3. On the Speed dial screen, choose a speed dial key to assign.
4. Select a contact from the list.

## Making an emergency call

In some regions, you can make emergency calls from HTC Desire 620G dual sim even if the micro SIM card has been blocked or if you don't have one installed.



If you don't have a network signal, you won't be able to make an emergency call.

1. Open the Phone app.
2. Dial the emergency number for your locale, and then tap .



If you've enabled but forgotten your lock password or lock pattern, you can still make emergency calls by tapping **Emergency call** on the screen.

## Answering or rejecting a call

When you receive a phone call from a contact, the Incoming call screen appears.

- Press and hold  to see your call options, and then drag it to  or .
- To decline a call and send a text message to the caller, drag  to , and then select a message to send.

---

### Muting the ringing sound without rejecting the call

---

Do one of the following:

- Press the VOLUME DOWN or VOLUME UP button.
- Press the POWER button.

## What can I do during a call?

When a call is in progress, you can turn the speakerphone on, place the call on hold, and more.

---

### Putting a call on hold

---

To put the call on hold, tap . To resume the call, tap  again.

---

## Switching between calls

---

If you're already in a call and you accept another call, you can switch between the two calls.

1. When you receive another call, press and hold  to see your call options, and then drag it to  to accept the second call and put the first call on hold.
2. To switch between the calls, tap .



---

## Turning the speakerphone on or off during a call

---



To decrease potential damage to your hearing, do not hold HTC Desire 620G dual sim to your ear when the speakerphone is on.

- On the call screen, tap  to turn the speakerphone on.
- To turn the speakerphone off, tap .

## Muting the microphone during a call

On the call screen, tap  to toggle between turning the microphone on or off.

## Setting up a conference call

Conference calling with your friends, family, or co-workers is easy. Make the first call (or accept a call), and then simply dial each subsequent call to add it to the conference.



Make sure your SIM card is enabled with conference calling service. Contact your mobile operator for details.

1. Make a call to the first conference call participant.
2. When connected, tap  > **Add call**, and then dial the number of the second participant.



Make sure to select the same SIM card you used to call the first participant.

3. When connected to the second participant, tap  > **Merge calls**.
4. To add another participant, tap  > **Add call**, and then dial the number of the contact.



Make sure to select the same SIM card you used to call the other participants.

5. When connected, tap  > **Merge calls** to add the participant to the conference call.
6. To end the conference call, tap .

## Checking calls in the Call History

Use Call History to check missed calls, your dialed numbers, and received calls.

1. Open the Phone app.
2. Tap  to view the Call History.
3. Tap a name or number in the list to view a detailed call log. Or, tap  beside it to call.

To display incoming, outgoing, or missed calls, tap the blue, green, or red arrows respectively.

---

## Adding a new phone number to your contacts from Call History

---

1. In the Call History , tap the phone number, and then tap **Add to contacts**.
2. Choose whether to create a new contact or save the number to an existing contact.

## Switching between silent, vibrate, and normal modes

Do one of the following:

- To change from vibrate to normal mode, press the VOLUME UP button.
- To change from silent to normal mode, press the VOLUME UP button twice.
- Press and hold the POWER button for a few seconds, and then select a sound profile on the options menu.

# Messages

## Sending a text or multimedia message via Android Messages

1. Open the Messages app.
2. Slide the Notifications panel open, and then choose which card to use for placing your call.
3. Tap .
4. Tap the area that says **Type name or number**, and then enter a contact name or mobile number. You can also select a contact or a group.
5. Tap the area that says **Type text message**, and then enter your message.



- There is a limit on the number of characters for a single text message. If you exceed the limit, your text message will be delivered as one but will be billed as more than one message.
- Your text message automatically becomes a multimedia message if you enter an email address as the recipient, add a message subject, attach an item, or compose a very long message.

6. To add an attachment, tap , choose an attachment type, and then select the item that you want.
7. Tap  to send your message.

---

### Viewing and saving an attachment from a multimedia message

---

- If there's a media attachment such as a photo or video in a received message, tap it to view the content.
- To save the attachment, press and hold the multimedia message (not the thumbnail), and then choose to save the attachment from the options menu.

# Storage and files

## Types of storage

Want to know where your apps, data, and files are?

<b>Phone storage</b>	Phone storage combines both the app storage, where apps, email, data, and text messages are stored, and the file storage, where photos, videos, and music files are kept.
<b>Storage card</b>	Use a storage card for storing more files. You can also set apps such as Camera to store directly to the card.
<b>External USB storage</b>	<p>When you plug in an external USB storage device —such as a USB flash drive or an SD card reader— you can open certain files such as photos, videos, music, and documents that are stored on the external device.</p> <p>You need a special cable to connect a USB storage device to your phone. HTC Desire 620G dual sim supports up to 64 GB of USB storage devices. Portable hard drives are not supported.</p>

## Copying files to or from HTC Desire 620G dual sim

You can copy your music, photos, and other files to HTC Desire 620G dual sim.

1. Connect HTC Desire 620G dual sim to the computer using the supplied USB cable. You'll see options for viewing or importing files on the computer screen.
2. Choose to view files.
3. Copy the files from your computer to HTC Desire 620G dual sim, or vice versa.
4. After copying the files, disconnect HTC Desire 620G dual sim from the computer.

## File Manager

Use the File Manager app to browse and organize files and folders on your phone storage and storage card. You can also manage files and folders on an external USB storage device such as a thumb drive when you have it connected to your phone.

1. Open the File Manager app.
2. On the app's Home screen, tap a file storage to open it.

3. To rename a file or folder, press and hold it, and then tap  > **Rename**.
4. To select multiple items, tap  > **Select file or folder**. Then tap each item you want to select, or tap  > **Select All**.
5. After selecting items, tap the icons at the bottom of File Manager to share, copy, cut, or delete them. You can only share files and not folders.
6. After copying or cutting items, navigate to another folder or file storage, and then paste them.

# Backup and reset

## Backup

---

### Backing up settings to Google

---

You can choose to automatically back up some settings such as Wi-Fi and bookmarks to Google servers using your Google Account so you can restore them when needed.

1. Go to Settings.
2. Tap **Backup & reset**, and then select the **Back up my data** option.
3. Tap **Backup account**.
4. Choose the Google account you want to use.

---

### Backing up data, media, and apps to your storage card

---

Back up data such as contacts, messages, calendar events, and bookmarks as well as photos and music to your storage card. You can also back up third-party apps that you installed if you want to easily reinstall them from your storage card next time.

1. Open the Backup and Restore app.
2. In the Backup tab, tap **Personal data**.
3. Choose the types of data and media that you want.
  - Tap  next to the Contact option. Clear the check boxes next to the mobile operator name if you don't want to include SIM contacts in the backup.
  - If you have existing text and multimedia messages on your phone, tap  next to the Message option, and then choose whether to back up both types of messages.
4. Tap **Backup to SD card**.
5. When you're prompted for a folder name, use the default name to base it on the date and time of backup, or enter a name that you want. Each data and media type will be stored in separate subfolders under the created folder on your storage card.
6. After backup has finished, tap **OK**, and then tap .
7. Tap **Application**, choose the apps that you want, and then tap **Backup to SD card**.

---

## Restoring data, media, and apps from your storage card

---

You can choose which data and media types and which apps you want to restore to your phone.

1. Open the Backup and Restore app.
2. Tap the **Restore** tab.
3. Under Personal data backup history, tap the date or folder name you want to restore from.
4. Choose the types of data and media you want to copy from your storage card, and then tap **Restore**.
5. Under Apps backup, tap **Application**, choose the apps that you want, and then tap **Restore**.

## Reset

---

### Restarting HTC Desire 620G dual sim (Soft reset)

---

If HTC Desire 620G dual sim is running slower than normal, is unresponsive, or has an app that is not performing properly, try rebooting and see if that helps solve the problem.

1. If the display is off, press the POWER button to turn it back on.
2. Press and hold the POWER button, and then tap **Reboot**.



If these steps don't work, you can remove and reinstall the battery, and then turn HTC Desire 620G dual sim on to restart it.

---

### Resetting HTC Desire 620G dual sim (Hard reset)

---

If HTC Desire 620G dual sim has a persistent problem that cannot be solved, you can perform a factory reset (also called a hard reset or master reset).



Factory reset will remove apps you've downloaded and installed, your accounts, as well as system and app data and settings. Be sure to back up any data and files you want to keep before you do a factory reset.

Factory reset may not permanently erase all data from your phone, including personal information.

#### Performing a factory reset from settings

1. Go to Settings.
2. Tap **Backup & reset**.
3. Tap **Factory data reset**.
4. Tap **Reset phone**, and then tap **Erase everything**.

### Performing a factory reset using hardware buttons

If you can't turn HTC Desire 620G dual sim on or access settings, you can still perform a factory reset by using the hardware buttons on HTC Desire 620G dual sim.

1. Remove the battery, wait for a few seconds, then reinsert the battery.
2. Press and hold the VOLUME UP button, and then press and hold the POWER button.
3. Wait for the screen with the Android image to appear and to be in recovery mode, and then release the POWER and VOLUME UP buttons.
4. Press the POWER button.
5. Press the VOLUME DOWN button to select **wipe data/factory reset**, and then press the VOLUME UP button.
6. Press the VOLUME DOWN button to select **Yes--delete all user data**, and then press the VOLUME UP button. A message appears when the data has been wiped.
7. To restart the phone, select **reboot system now**, and then press the VOLUME UP button.

# Search and web browser

## Getting instant information with Google Now

Do you want to know the weather or your morning commute time before you start your day? Google Now™ delivers quick and up-to-date information that matters to you—all without the search.

Depending on your location, time of day, and previous Google searches, Google Now displays information cards that include:

- The day's weather and the weather forecast for upcoming days.
- The traffic conditions on your way to work or your commute back home.
- The directions and travel time to your next appointment.
- The next train or bus arriving at your platform or bus stop.
- Your favorite team's score and stats while you enjoy the game.

To refresh the information, just pull down the screen.

---

### Setting up Google Now

---



Before setting up Google Now:

- Make sure that you're signed in to your Google account.
- Turn location services on and make sure that you have an Internet connection. For more information on location services, see [Turning location services on or off](#) on page 72.

1. Open the Google app. Or swipe up from the  button.
2. Tap **Next** on the **Get Google Now!** screen.
3. Tap **Yes, I'm in**. Google Now information cards will start to appear on the Google search screen.
4. To see all available information cards, swipe up the screen and tap **More**.

Depending on the information that you've allowed to share, more information cards will appear on the Google search screen as you use HTC Desire 620G dual sim to search the Web, create appointments, and more.

---

## Changing card settings

---

You can easily customize the settings of Google Now cards to suit your information needs. For example, you can change the weather units in the Weather card or your transportation mode in the Traffic card. You can also specify the details on certain cards or keep a card from appearing on the Google search screen.

1. Open the Google app. Or swipe up from the  button.
2. On a card, tap .
3. Set options for the card.



For certain cards that need specific details, such as your work address or sports teams and stocks you follow, scroll to the bottom of the screen, and then tap .

### Dismissing and hiding cards

1. Open the Google app. Or swipe up from the  button.
2. Do any of the following:
  - To dismiss a card, swipe it left or right.
  - To keep the card from appearing on the Google search screen, tap  on a card and then choose to not receive updates.

---

## Turning off Google Now

---

1. Open the Google app. Or swipe up from the  button.
2. Scroll to the bottom of the screen, and then tap  > **Settings**.
3. Tap the **On/Off** switch next to Google Now, and then tap **Turn off**.

## Searching HTC Desire 620G dual sim and the Web

You can search for information on HTC Desire 620G dual sim and on the Web by using Google Search. Start your search by entering a keyword or by using GoogleVoice Search™.



Some apps, such as People or Mail, have their own search function, which you can use to search only within those apps.

## Performing searches on the Web and HTC Desire 620G dual sim

1. Open the Google app. Or swipe up from the  button.
2. In the search box, enter what you want to search for. As you type, matching items on HTC Desire 620G dual sim and suggestions from Google web search are shown.



To search for the information exclusively on HTC Desire 620G dual sim, tap **Search phone** at the bottom of the suggestion list.

3. If what you're searching for is in the list of suggestions, tap the item to open it in its compatible app.

## Searching the Web with your voice

Use Google Voice Search to find information on the Web just by speaking to HTC Desire 620G dual sim.

1. Open the Google app. Or swipe up from the  button.
2. Say "Ok Google", and then say what you want to search for. After speaking, matching items from Google web search are shown.
3. If what you're searching for is in the list, tap the item to open it in its compatible app. Otherwise, tap  to search again.

## Setting search options

1. Open the Google app. Or swipe up from the  button.
2. Tap  > **Settings** to set the following options:

Phone search	Select which apps on HTC Desire 620G dual sim are included when doing a search.
Voice	Set the Google Voice Search language, speech output, and more.
Accounts & privacy	Manage your location history, enable recent web searches to show, or clear your search history.
Notifications	Enable or disable notifications for Google Now updates.

## Browsing the Web

Visit your favorite websites or search the Web using Google Chrome™.

1. Open the Chrome app.
2. Tap the URL box on top of the screen.
3. Enter the webpage address or your search keywords.

4. To open more browser tabs, tap  > **New tab**.
5. To return to the previous webpage you've viewed, press the  button.

## Bookmarking a webpage

Add your favorite webpages as bookmarks so you can access them quickly.

1. While viewing a webpage, tap  > .
2. On the Add Bookmark screen, you can edit the bookmark name and save the bookmark in a new category folder.
3. Tap **Save**.

To view and open a bookmark, tap  > **Bookmarks**. Navigate to the bookmark you want to open, and then tap it.

## Clearing your browsing history

1. While viewing a webpage, tap  > **Settings** > **Privacy**, and then tap **Clear browsing data**.
2. Choose which types of data to delete, and then tap **Clear**.

# People

## Your contacts list

The People app lists all contacts from online accounts you're logged in to.

1. Open the People app.
2. On your contacts list, you can:
  - View your profile and edit your contact information.
  - Create, edit, find, or send contacts.
  - Tap a contact photo to find ways to quickly connect with the contact.



To sort your contacts by their first or last name, tap  > **Settings** > **Sort list by**.

---

### Filtering your contacts list

---

When your contacts list gets long, you can choose which contact accounts to show.

1. On the People  tab, tap  > **Contacts to display**.
2. Choose the accounts that contain the contacts you want to display.



If you want to filter by contact groups, tap **Customize** and then tap the contact groups that you want shown.

---

### Searching for contacts

---

1. Open the People app.
2. Tap , and then enter the first few letters of the contact name.

## Setting up your personal contact information

Store your personal contact information (such as mobile and phone numbers, email addresses, and more) to easily send it to other people.

1. On the People  tab, tap **Set up my profile**.
2. Enter your name and contact details.
3. To add more information (such as your personal website), tap **Add another field**.
4. Tap **Done**.

## Adding a new contact

1. On the People  tab, tap .
2. Choose where you want to store the new contact.
3. Tap the **Name** field, and then enter the contact name.
4. Enter the contact information in the fields provided.
5. If available, tap **Add another field** to add more information.
6. Tap Done.

## Editing a contact's information

1. On the People  tab, tap a contact to view the contact details.
2. Tap  > Edit.
3. Enter the new information.
4. Tap Done.

## Getting in touch with a contact

1. Open the People app.
2. Tap a contact's photo (not the name), and then choose how you want to get in touch with that contact.



## Importing contacts from your SIM card

1. On the People app, tap  > Import/Export.
2. Select the SIM that contains the contact.
3. If you're signed in to a supported email account, tap which account to use for storing the imported contacts. You can also store contacts in your Google account.
4. Tap the contacts you want to import.

## Importing contacts from the storage

1. On the People app, tap  > **Import/Export** .
2. Choose the storage where the contacts are saved.
3. If you're signed in to a supported email account, tap which account to use for storing the imported contacts. You can also store contacts in your Google account. HTC Desire 620G dual sim will automatically import contacts from .vcf files.

## Sending contact information

1. On the People app, tap a contact to view the contact details.
2. Tap  > **Share**.
3. Choose how you want to share the .vcf file.

## Contact groups

Organize your friends, family, and colleagues into groups.

---

### Creating a group

---

1. On the Groups  tab, tap  and choose the account where you want to create the group.
2. Enter a name for the group.
3. Type a contact's name or tap  and select contacts.



You can only add contacts from the same account where you're creating the group.

4. When your group is complete, tap **Done** or **Ok**.

---

### Editing a group

---

1. On the Groups  tab, tap the group that you want to edit.
2. Tap  > **Edit**. You can:
  - Change the group name.
  - Add more contacts to the group.
  - Remove contacts from the group.
3. Tap **Done** or **Ok**.

# Email

## Adding an email account

Set up email accounts such as a Microsoft® Exchange ActiveSync® account or an account from a Web-based email service or email provider.



- If you're adding a Microsoft Exchange ActiveSync or a POP3/IMAP email account, ask your network administrator or email service provider for additional email settings that you may need.
- Some email accounts, such as corporate emails, may require advanced security administration.


1. Open the Mail app.
2. Enter the email address and password for your email account, and then tap **Next**.
3. Select an email account type.
4. Set the sync options for this email account, and then tap **Next**.
5. Enter a name for your email account, and then tap **Next**.

To add more email accounts in the Mail app, tap  > **Settings** > **Add account**.

## Checking your mail

The Mail app is where you read, send, and organize email messages from one or more email accounts that you've set up on HTC Desire 620G dual sim.

1. Open the Mail app. The inbox of one of your email accounts appears.
2. Do any of the following:
  - Tap an email message to read.
  - To display email messages in another mail folder, tap , and then tap the folder you want to view.
  - To switch between email accounts or view email messages from all your accounts, tap .



- To archive, delete or label multiple conversations, tap the sender image or letter tile before the email message or conversation. Then tap the onscreen buttons to choose what to do with the selected messages or conversations.
- To change an email account's settings, select the account, tap  > **Settings**.

## Sending an email message

1. Open the Mail app.
2. Switch to the email account that you want to use.
3. Tap .
4. Fill in one or more recipients.



Want to loop in more recipients in a carbon copy (Cc) or blind carbon copy (Bcc) of the email message? Tap  > **Add Cc/Bcc**.

5. Enter the subject, and then compose your message.
6. To add a photo attachment, tap  > **Attach file**.
7. Tap .

To save the email as draft and send it later, tap  > **Save draft**. Or tap the  button.

---

## Resuming a draft email message

---

1. In an email account inbox, tap  > Drafts.
2. Tap the message, and then tap .
3. When you finish editing the message, tap .

## Reading and replying to an email message

1. Open the Mail app.
2. Switch to the email account you want to use.
3. In the email account inbox, tap the email message or conversation you want to read.
4. To reply to the sender, tap . Or, tap , and then choose whether to **Reply all** or **Forward**.


## Searching email messages

1. Tap .
2. Tap the tab that corresponds to the part of the email that you want to search.
3. In the search box, enter the words you want to search for.
4. Tap a result to open the email message.

## Viewing your Gmail Inbox

All your received email messages are delivered to your Inbox.

1. Open the Gmail app.
2. Do any of the following from your Inbox.
  - Tap an email message (not the sender image or letter tile) to read, forward, or reply to the message.
  - Tap the inbox at the top bar to switch to your other Gmail™ account or to display drafts, sent messages, or other email labels.
  - Tap the sender image or letter tile to select one or more messages or conversations. You can then tap the onscreen buttons at the top bar to archive, delete, or mark the selected messages or conversations.



Get help in using Gmail by tapping  > Help.

## Sending an email message in Gmail

1. In the inbox of the Gmail account you want to use, tap  (or tap  > Compose).
2. Fill in one or more recipients.



Want to loop in more recipients in a carbon copy (Cc) or blind carbon copy (Bcc) of the email message? Tap  > Add Cc/Bcc.

3. Enter the email subject, and then compose your message.
4. If you want to attach a photo or video, tap  > Attach file, and then tap the attachment type.
5. Tap  to send.

## Replying to or forwarding email messages in Gmail

1. In the Gmail inbox, tap the email message or conversation.
2. To reply to the sender, tap . Or, tap  and choose whether to **Reply all** or **Forward**.
3. Do one of the following:
  - If you're replying to the sender or you selected **Reply all**, enter your reply message.
  - If you selected **Forward**, specify the message recipients.



Tap **Respond inline** if you want to interleave your new message with the received email. But this removes any attachments or formatting in the original email message.

4. Tap  to send.

# Camera

## Using Android Camera

You can take photos and videos using Android Camera.

1. Open the Camera app.
2. Do one of the following:
  - To take a photo, tap .
  - To start recording video, tap . Tap  to stop.
  - To take a selfie, tap  to switch to the front camera, and then tap .
  - To capture a panoramic photo, tap , and then tap . Pan HTC Desire 620G dual sim as smoothly as you can to the direction you want to capture. You can tap  anytime to stop capturing frames.

You can also adjust camera settings by tapping .

# Gallery and Video Highlights

## Viewing photos and videos in Gallery

Remember the good times. Gallery lets you view all the photos and videos on HTC Desire 620G dual sim. You can also filter by albums, locations, and more.

1. Open the Gallery app.
2. Tap  and choose how to filter the photos and videos.
3. Tap a tile to browse the photos and videos inside.
4. Tap a photo or video to view it in full screen.
5. Swipe left to view the next photo or video.

## Editing photos

Make your pictures even better. Gallery has an array of editing tools that let you crop, rotate, and apply effects on your photos.

1. Browse to the photo that you want to edit.
2. Tap . Do one of the following:
  - Choose a photo effect.
  - Tap , and then tap **Crop**. Drag the crop box over the part of the photo that you want to crop, or drag the markers to resize the crop box.
  - Tap , and then tap **Rotate**. Press and drag the top part of the photo in 90-degree increments.

## Viewing and editing Video Highlights

Want to share the excitement of the day's events? With Video Highlights, your best photos and videos (highlights) are automatically compiled into a short video with background theme and music.

This video is about half a minute long. You can change the content, theme, and music, and also save or share the video.

1. Open the Video Highlights app. Shots taken on the same day are grouped together.
2. Tap a tile. The large tile on top automatically plays a video, showing the highlights taken on a particular date.

3. To change the highlights in the video:
  - Tap **Content**, and then tap a thumbnail to include or exclude it from the video.
  - Tap  to shuffle the highlights.
4. Tap **Themes** to choose from a variety of color schemes and music themes to apply to the video.
5. Tap **Music** to change the default soundtrack to your own music.  
To restore the default soundtrack, tap  > **Restore default track**.



Do not reproduce, distribute, or otherwise use copyrighted materials in connection with the Video Highlights feature unless you have secured the copyright owner's permission first.

6. To trim the chosen soundtrack, include audio that was captured with the video, and enable content to play back chronologically, tap  > **Video and audio settings**.
7. To view the Video Highlights in full screen, hold HTC Desire 620G dual sim in landscape orientation.
8. To create a video file of the highlights, tap  > **Save**.  
This will be saved in the Video Highlights album.
9. To share the Video Highlights, tap  and select how to share the video.

# Music

## Listening to music

Enjoy your favorite songs on HTC Desire 620G dual sim using the Play Music app.

1. Open the Play Music app.
2. Swipe right, and then tap **My Library**.
3. Browse by artists, albums, or other categories.



If you are subscribed to Google Play Music, tap  and choose the location of the music you want to play.

4. Tap a song to play.
5. On the preview screen at the bottom, tap the song name to display the full view.
6. Use the onscreen icons to control music playback, repeat the song, and more.



## Creating music playlists

Personalize your music experience by creating music playlists. Make a playlist containing just your favorite songs or create one to match your mood for the day.

1. Open the Play Music app.
2. Browse to the song that you want to add to a playlist.
3. Tap  > **Add to playlist**.

4. Tap **New playlist**, and enter a playlist name.
5. Browse to other songs and repeat the steps to add them to the playlist.

To view the playlist you've created, on the main screen, swipe right and tap **Playlists**.

---

### Playing the songs in a playlist

---

1. Open the Play Music app.
2. Swipe right, and tap **Playlists**.
3. Tap the playlist, and then tap the image beside the playlist name to start playing the songs.

---

### Deleting music playlists

---

1. Open the Play Music app.
2. Swipe right, and tap **Playlists**.
3. On the playlist you want to delete, tap  > **Delete**.

## Adding a song to the queue

While playing a song, you can also browse other tracks stored on HTC Desire 620G dual sim. Add a song or an album to the queue so it plays when the current playlist has finished playing.

1. While a song is playing, browse for other tracks.
2. Do any of the following:
  - When you find the album, song, or folder that you like, tap  > **Add to queue**.
  - Browse for an artist, and on the album that you like, tap  > **Add to queue**.

To display the song queue, go to the song's full view and tap .

# Travel and maps

## Turning location services on or off

In order to find your location on HTC Desire 620G dual sim, you need to enable location sources.

1. Go to Settings.
2. Tap **Location**, and then tap the on/off switch to turn location services on or off.
3. Tap **Mode** and then select the location mode you want. For example, for a better estimate of your location, choose **High accuracy**. To save battery power, choose **Battery saving**.

Turning off a location source (for example GPS) means no applications on HTC Desire 620G dual sim will collect your location data through that location source. However, third party applications may collect — and HTC Desire 620G dual sim may continue to provide — location data through other sources, including through Wi-Fi and signal triangulation.

## About Google Maps

Google Maps™ lets you track your current location, view real-time traffic situations, and receive detailed directions to your destination.

It also provides a search tool where you can locate places of interest or an address on a map, or view locations at street level.



- To find your location with Google Maps, you need to enable location sources.
- The Google Maps app does not cover every country or city.

## Getting around maps

When you open Google Maps, you can easily find your location on the map or check out nearby places by panning and zooming in and out on the map.

1. Open the Maps app.
2. Tap  to show your current location. The blue marker  or  shows your current location on the map.
3. If you want to see more information overlaid on the map, swipe right from the left edge of the screen, and then tap a map view such as **Public transit** or **Public transport** in the slideout menu to toggle the view on and off.

---

## Navigating the map

---

You can navigate the map using finger gestures.

- Slide your finger in any direction to pan.
- Double-tap the map or slide two fingers apart over an area to zoom in.  
To zoom in while holding the phone with one hand, double-tap with your thumb and hold the second tap, and then drag your thumb down.
- Double-tap the map with two fingers or slide two fingers together over an area to zoom out.  
To zoom out while holding the phone with one hand, double-tap with your thumb and hold the second tap, and then drag your thumb up.
- Press and hold an area with two fingers and then drag your fingers in a circular motion to rotate the map.
- Press and hold an area with two fingers and then swipe up to see an angled view of the map. Swipe down to return to overhead view.

## Searching for a location

Use Google Maps to search for a location, such as an address or a type of business or establishment (for example, museums).

1. Open the Maps app.
2. Tap the search box and then enter the place you want to search for.
3. Tap the **Enter** key on the keyboard or tap a suggested search item.

- If there is only one search result, it will be marked with a place marker . Tap this icon or swipe up from the bottom to see details.



- If there are multiple search results, they will be indicated by red dots or smart map icons. Swipe up from the bottom to see the search results. Then tap the card of the place that you want to check its address, get directions, and more.

To view details of the next or previous location on the search, swipe left or right.

## Getting directions

Get detailed directions to your destination. Google Maps provides travel directions by car, public transit, bike, or foot.

- Open the Maps app.
- Tap .
- Choose how you want to get to your destination.
- Use your current location as starting point, or tap **My location** to enter your starting point or select a location from your search history.
- Tap **Choose destination**, and then enter or select your destination.



If you're taking public transit, tap  to set the date and time of travel, or tap **Options** to set your route preferences.

- Tap a route or transit option to view the directions on the map. You'll also see the travel duration on the info sheet at the bottom of the screen.
- Tap the info sheet to view the directions in a list.

When you're finished viewing or following the directions, tap  to reset the map. Your destination is automatically saved in the Google Maps history.

# Google Play and other apps

## Getting apps from Google Play

Google Play is the place to go to find new apps for HTC Desire 620G dual sim. Choose from a wide variety of free and paid apps ranging from productivity apps, entertainment, to games.



- A Google Wallet™ payment service is required to purchase a paid app. You will be asked to confirm method of payment when you purchase an app.
- The name of the Play Store app may differ depending on your region.
- The ability to purchase apps varies by region.

---

### Finding and installing an app

---

When you install apps and use them on HTC Desire 620G dual sim, they may require access to your personal information or access to certain functions or settings. Download and install only apps that you trust.



Be cautious when downloading apps that have access to functions or a significant amount of your data on HTC Desire 620G dual sim. You're responsible for the results of using downloaded apps.

1. Open the Play Store app.
2. Browse or search for an app.
3. When you find the app that you like, tap it and read its description and user reviews.
4. To download or purchase the app, tap **Install** (for free apps) or the price button (for paid apps).
5. Tap **Accept**.



Apps sometimes get updated with improvements or bug fixes. To automatically download updates, after installing the app, tap **⋮** > **Auto-update**.

To open the app, go to the Apps screen and tap the app.

---

## Restoring apps from Google Play

---

Upgraded to a new phone, replaced a lost one, or performed a factory reset? Restore apps that you previously downloaded.

1. Open the Play Store app.
2. Swipe right from the left edge of the screen to open the slideout menu.
3. Tap **My apps**, swipe to the All tab, and then tap the app you want to restore.
4. Install the app.

For more details, refer to the Google Play help.

## Downloading apps from the web

You can download apps directly from websites.



- Apps downloaded from websites can be from unknown sources. To help protect HTC Desire 620G dual sim and your personal data, we strongly recommend that you only download from websites you trust.
- Before you can install the downloaded app, make sure that you've set HTC Desire 620G dual sim to allow installation of third-party apps in **Settings > Security > Unknown sources**.

1. Open the browser, and then go to the website where you can download the app you want.
2. Follow the website's download instructions for the app.



After installing the app, make sure to go back to **Settings > Security** and clear the **Unknown sources** option.

## Uninstalling an app

If you no longer need an app that you've downloaded and installed, you can easily uninstall it.



Most of the preloaded apps cannot be uninstalled but can be disabled instead.

From the Apps screen, press and hold the app you want to remove, and then drag it to **Uninstall**.



If you purchased an app in Play Store, you can uninstall it for a refund within a limited time. To know more about the refund policy for paid apps, refer to the Google Play help.

---

### Disabling an app

---

If an app cannot be uninstalled, you can disable it instead.

1. Go to **Settings > Apps**
2. Swipe to the All tab, and then select the app that you want to disable.
3. Tap **Disable**.

Disabled apps will be removed from the Apps screen, and will not sync data on the background anymore.

## Using the Clock app

Check the time and set up alarms.

---

### Setting an alarm

---

You can set up one or more alarms.

1. Open the Clock app.
2. Tap .
3. Tap **+**.
4. Set the time.
5. If you want the alarm for multiple days, choose the **Repeat** option and select when the alarm will go off.

Tap the on/off switch next to the alarm you want to go off.

## Setting the date and time manually

1. Go to Settings.
2. Tap **Date & time**.
3. Tap **Automatic date & time** and turn it off.
4. Clear the **Automatic time zone** option, and then set the time zone, date, and time as required.

## Viewing the Calendar

Use the Calendar app to view your events, meetings, and appointments. If you've signed into your online accounts, related events will also appear in Calendar.

1. Open the Calendar app.
2. Tap , and then choose a calendar view.

## Scheduling or editing an event

You can create or edit events on HTC Desire 620G dual sim, and also sync events with your Exchange ActiveSync calendar. You can also create, modify, and sync events with your Google calendar.



Editing events is not supported for all accounts.

1. Open the Calendar app.
2. On any Calendar view, do one of the following:

**Create an event** Tap  > **New event**. Select the calendar you will add the event to.

**Edit an event** View an event, and then tap .

3. Enter and set the event details.
4. To invite contacts from your Exchange ActiveSync account, tap **Guests**. You can also invite contacts from your Google account.
5. Tap **Done**.

## Choosing which calendars to show

1. In any calendar view, tap  > **Settings**.
2. Choose an account, and then select or clear the calendars you wish to show or hide.



You can also choose which calendars to sync with HTC Desire 620G dual sim. Calendars are synced on HTC Desire 620G dual sim even if they are hidden.

## Watching videos on YouTube

Check out the latest video sensations using the YouTube® app.

1. Open the YouTube app.
2. Browse or search for a video.
3. When you find the video that you like, tap it.



Want to watch the video at a later time instead? Tap  next to the video title, and then tap **Add to > Watch later**. You can access the video again from your account profile's Watch later list.

4. While watching a video, you can:
  - Turn HTC Desire 620G dual sim sideways to watch the video in full screen.
  - Tap the video screen to pause or to resume playback, or drag the slider to jump to a different part of the video.
  - Scroll down the video information panel to see related videos and comments from other viewers.
  - Browse other videos by minimizing the video screen. Tap  or drag the video screen down to minimize. To close the video thumbnail, swipe it left or right.

Minimize the video screen, and then tap  to open the slideout menu. You can view your account profile and manage your subscriptions and video lists.

## Creating video playlists

Organize your favorite videos into playlists and watch them in the YouTube app.



Make sure that you're signed in to your Google account.

1. Open the YouTube app.
2. Browse or search for a video.
3. Tap  next to the video title, and then tap **Add to > New playlist**.
4. Enter the playlist name, and then tap **OK**.  
If you don't want to share the video playlist, select **Private** before you tap **OK**.
5. To add another video to your playlist, browse or search for the video, and then tap  next to the video title.
6. Tap **Add to**, and then tap the playlist name.

To access and watch your video playlists, minimize the video screen and then tap  to open the slideout menu. Tap the playlist you want.

# Internet connections

## Turning the data connection on or off

Turning your data connection off saves battery life and money on data charges.

1. With two fingers, swipe down from the status bar to open Quick Settings.
2. Tap the **Data connection** tile.
3. Choose which card you want to use for your data connection, or tap **Off** to turn the data connection off.

When choosing a card for your data connection, make sure to select the one that has 3G service enabled in Settings. For details, see [Choosing which micro SIM card to connect to the 3G network](#) on page 87.

## Wi-Fi

To use Wi-Fi, you need access to a wireless access point or “hotspot”.



The availability and strength of a Wi-Fi signal varies depending on objects the Wi-Fi signal has to pass through (such as buildings or a wall between rooms).

### Turning Wi-Fi on and connecting to a wireless network

1. Go to Settings.
2. Tap the Wi-Fi on/off switch to turn Wi-Fi on.
3. Tap **Wi-Fi**.

Detected Wi-Fi networks will be listed.



If the wireless network that you want is not listed, tap **+** to manually add it.

4. Tap the Wi-Fi network you want to connect to. If you selected a secured network, you'll be asked to enter the network key or password.
5. Tap **Connect**. You'll see the Wi-Fi icon  in the status bar when connected.

The next time HTC Desire 620G dual sim connects to a previously accessed secured wireless network, you won't be asked to enter the key or other security information again.

---

## Connecting to a Wi-Fi network via WPS

---

If you're using a Wi-Fi router with Wi-Fi Protected Setup™ (WPS), you can connect HTC Desire 620G dual sim easily.

1. With two fingers, swipe down from the status bar to open Quick Settings.
2. Tap the **Wi-Fi** tile to turn Wi-Fi on.
3. Press and hold the **Wi-Fi** tile to open the Wi-Fi screen.
4. Tap , and then press the WPS button on your Wi-Fi router.



To use the Wi-Fi Protected Setup (WPS) PIN method, tap  > **WPS Pin Entry**.

---

## Connecting to a different Wi-Fi network

---

1. With two fingers, swipe down from the status bar to open Quick Settings.
2. Tap the **Wi-Fi** tile to turn Wi-Fi on.
3. Press and hold the **Wi-Fi** tile. Detected Wi-Fi networks are displayed.



To manually scan for available Wi-Fi networks, tap  > **Scan**.

4. Tap a Wi-Fi network to connect to it.

## Managing your data usage

If you're on a limited data allowance, it's important to keep track of the activities and apps that usually send and receive data, such as browsing the web, syncing online accounts, and sending email or sharing status updates.

Here are some other examples:

- Streaming web videos and music
- Playing online games
- Downloading apps, maps, and files
- Refreshing apps to update info and feeds
- Uploading and backing up your files to your online storage account
- Using HTC Desire 620G dual sim as a Portable Wi-Fi hotspot
- Sharing your mobile data connection by USB tethering

To help you save on data usage, connect to a Wi-Fi network whenever possible and set your online accounts and emails to sync less frequently.

## Turning data roaming on or off

Connect to your mobile operator's partner networks and access data services when you're out of your mobile operator's coverage area.



Using data services while roaming may be costly. Check with your mobile operator for data roaming rates before you use data roaming.

1. Go to Settings.
2. Tap **Roaming > Data roaming**.
3. For each card, configure whether to enable or disable data roaming.

## Keeping track of your data usage

Monitor your data usage to help prevent going over your monthly data allowance.



Your actual data usage may differ and may be higher than the data usage measured by HTC Desire 620G dual sim.

1. Go to Settings.
2. Under **Wireless & networks**, tap **More > Data usage**.
3. Select the tab that shows the mobile operator you use for your data connection.
4. If the data connection is not on, tap the **Mobile data** switch to turn it on.
5. Select **Set mobile data limit** to automatically disable your data connection when you reach the set limit.  
Then, drag the upper limit line to set your monthly data limit.
6. Drag the lower warning line to set an alert before you reach your monthly data limit.
7. Drag the vertical line markers to see how much data you've used during a certain period.



- If you're connecting HTC Desire 620G dual sim to another portable Wi-Fi hotspot, tap **☰ > Mobile hotspots** to restrict background data from downloading that may incur extra data fees.
- To also display Wi-Fi data usage, tap **☰ > Show Wi-Fi usage**.

## Viewing the data usage of apps

1. Go to Settings.
2. Under **Wireless & networks**, tap **More > Data usage**.
3. Select the tab that shows the mobile operator you use for your data connection.
4. If the data connection is not on, tap the **Mobile data** switch to turn it on.

5. Drag the vertical line markers to see how much data you've used during a certain period.
6. Scroll down the screen to see a list of apps and their data usage info.
7. Tap an app to see more details.

## Connecting to a virtual private network (VPN)

Add virtual private networks (VPNs) so you can connect and access resources inside a secured local network, such as your corporate network.

Before you can connect to your organization's local network, you may be asked to:

- Install security certificates
- Enter your login credentials
- Download and install a required VPN app on HTC Desire 620G dual sim

Contact your network administrator for details. Also, HTC Desire 620G dual sim must first establish a Wi-Fi or data connection before you can start a VPN connection.

---

### Adding a VPN connection

---



You must first set a lock screen PIN or password before you can use credential storage and set up the VPN.

1. Go to Settings.
2. Under Wireless & networks, tap **More**.
3. Tap **VPN > +**.
4. Enter the VPN settings and set them up according to the security details your network administrator gave you.
5. Tap **Save**.

The VPN is then added to the VPNs section of the VPN settings screen.

---

### Connecting to a VPN

---

1. Go to Settings.
2. Under Wireless & networks, tap **More**.
3. Tap **VPN**.
4. Tap the VPN that you want to connect to.
5. Enter your log in credentials, and then tap **Connect**. When you're connected, the VPN connected icon appears in the notification area of the status bar.

You can then open the web browser to access resources such as your corporate network intranet.

---

## Disconnecting from a VPN

---

1. Slide the Notifications panel open.
2. Tap the VPN connection to return to the VPN settings screen, and then tap the VPN connection to disconnect from it.

## Using HTC Desire 620G dual sim as a Wi-Fi hotspot

Share your data connection with other devices by turning HTC Desire 620G dual sim into a Wi-Fi hotspot.



- Make sure the data connection is turned on.
- You must have an approved data plan associated with your account from your mobile service provider to use this service.

1. Go to Settings.
2. Under Wireless & networks, tap **More**.
3. Tap **Tethering & portable hotspot > Wi-Fi hotspot**.
4. Tap **Set up Wi-Fi hotspot**.
5. Enter a Wi-Fi hotspot name or use the default name.
6. Choose the type of security and set the password (key) for your Wi-Fi hotspot. If you selected **None** in Security, you don't need to enter a password.



The password is the key other people need to enter on their device so they can connect and use HTC Desire 620G dual sim as a Wi-Fi hotspot.

7. Tap **Save**.
8. On the Tethering & portable hotspot screen, tap the switch to turn on the Wi-Fi hotspot.

HTC Desire 620G dual sim is ready to be used as a Wi-Fi hotspot when you see  on the status bar.

## Sharing your phone's Internet connection by USB tethering

No Internet connection available for your computer? No problem. Use the data connection of HTC Desire 620G dual sim to connect to the Internet.



- Make sure you have a USB tethering service enabled by your mobile operator.
- You may need to have USB tethering added to your data plan, and it may incur additional cost. Contact your mobile operator for details.

1. Connect HTC Desire 620G dual sim to your computer using the provided USB cable.
2. Go to Settings.
3. Under Wireless & networks, tap **More**.
4. Tap **Tethering & portable hotspot**.
5. Select the **USB tethering** option.

# Bluetooth

## Connecting a Bluetooth headset

You can listen to music over a Bluetooth stereo headset, or have hands-free conversations using a compatible Bluetooth headset.



- To listen to music with your headset, the headset must support the A2DP Bluetooth profile.
- Before you connect your headset, make it discoverable so HTC Desire 620G dual sim can find it. Refer to your headset manual for details.

1. With two fingers, swipe down from the status bar to open Quick Settings.
2. Tap the **Bluetooth** tile to turn Bluetooth on.
3. Press and hold the **Bluetooth** tile. The Bluetooth screen opens.
4. If you don't see your headset listed, tap **Search for devices** to refresh the list.
5. When you see the name of your headset in the Available Devices section, tap the name. HTC Desire 620G dual sim pairs with the headset and the headset connection status is displayed in the Paired Devices section.



If automatic pairing fails, enter the passcode supplied with your headset.

When the Bluetooth headset is connected to HTC Desire 620G dual sim, the Bluetooth connected icon  is displayed in the status bar.

## Unpairing from a Bluetooth device

1. With two fingers, swipe down from the status bar to open Quick Settings.
2. If Bluetooth is off, tap the **Bluetooth** tile to turn Bluetooth on.
3. Press and hold the **Bluetooth** tile. The Bluetooth screen opens.
4. In the Paired devices section, tap  next to the device to unpair.
5. Tap **Unpair**.

# Settings and security

## Managing your micro SIM cards

You can set which card to use as the default card for voice call and messaging.

1. Go to Settings.
2. Tap **SIM management**.
3. You can:
  - Turn either card on or off.
  - Tap a card name to rename it, enter your mobile number, and more.
  - Choose which card to use for voice call and messaging. Or select the **Always ask** option if you want apps to prompt you to choose a card whenever you make calls or send messages.

## Choosing which micro SIM card to connect to the 3G network

When you have two micro SIM cards inserted on your phone, only one card can connect to the 3G network. The other card will connect to the 2G network only. You can set which card you want to connect to the 3G network.

1. Go to Settings.
2. Tap **Mobile networks**.
3. Tap **3G service** > **Enable 3G**.
4. Choose the card you want to connect to the 3G network.

## Assigning a PIN to a micro SIM card

You can help to protect the micro SIM card by assigning a Personal Identification Number (PIN).



Make sure you have the default PIN provided by your mobile operator before continuing.

1. Go to Settings, and then tap **Security**.
2. Tap **Set up SIM card lock**.

3. Select which card you want to assign a new PIN to.
4. Choose to lock the card, enter the default PIN of the card, and then tap **OK**.
5. To change the card PIN, tap **Change SIM PIN**.

---

### Restoring a micro SIM card that has been locked out

---

If you enter the wrong PIN more times than the maximum number of attempts allowed, the micro SIM card will become “PUK-locked.”

You need a Pin Unlock Key (PUK) code to restore access to HTC Desire 620G dual sim. Contact your mobile operator for this code.

1. On the Phone dialer screen, enter the PUK code, and then tap .
2. Enter the new PIN you want to use, and then tap .
3. Enter the new PIN again, and then tap **OK**.

## Protecting HTC Desire 620G dual sim with a screen lock

Help protect your personal information and help prevent others from using HTC Desire 620G dual sim without your permission by setting a screen lock pattern, face unlock, PIN, or password.

You'll be asked to unlock the screen every time HTC Desire 620G dual sim is turned on or when it's idle for a certain period of time.

1. Go to **Settings**.
2. Tap **Security > Screen lock**.
3. Select a screen lock option and set up the screen lock.
4. Tap **Automatically lock**, then specify the idle time before the screen is locked.



You can also clear **Make pattern visible** or **Make passwords visible** if you don't want your screen lock to display as you enter it onscreen.

## Turning Airplane mode on or off

When you enable Airplane (Flight) mode, all wireless radios on HTC Desire 620G dual sim are turned off, including the call function, data services, Bluetooth, and Wi-Fi.

When you disable Airplane mode, the call function is turned back on and the previous state of Bluetooth and Wi-Fi is restored.



If USB tethering is turned on, enabling Airplane mode turns it off. You need to manually turn USB tethering on after you disable Airplane mode.

Press and hold POWER, and then tap **Airplane mode**.

When enabled, the Airplane mode icon ✈️ is displayed in the status bar.

## Adding and syncing an account

1. Go to Settings.
2. Under Accounts, tap **Add account**.
3. Choose an account type, and then enter your login information.
4. Choose the types of information that you want to sync on HTC Desire 620G dual sim.

## Removing an account

1. Go to Settings.
2. Under Accounts, tap an account type.
3. Tap the account that you want to remove.
4. Tap  > **Remove account**.

Removing an account does not delete information from the online service itself.

## Turning automatic screen rotation off



Automatic rotation is not supported in all apps.

1. Go to Settings.
2. Tap **Display**.
3. Clear the **Auto-rotate screen** option.

## Adjusting the time before the screen turns off

After a period of inactivity, the screen turns off to conserve battery power. You can set the idle time before the screen turns off.

1. Go to Settings.
2. Tap **Display**, and then tap **Sleep**.
3. Tap the time before the screen turns off.

## Adjusting the screen brightness manually

1. Go to Settings.
2. Tap **Display** > **Brightness**.
3. If the **Auto** option is enabled, tap it to turn it off.
4. Drag the brightness slider to the left to decrease or to the right to increase the screen brightness.

## Changing the display language

Changing the language adjusts the keyboard layout, date and time formatting, and more.

1. Go to Settings.
2. Tap **Language & input** > **Language**.
3. Tap the language you want to use.

## Working with certificates

Use client and Certificate Authority (CA) digital certificates to enable HTC Desire 620G dual sim to access VPN or secured Wi-Fi networks, and also to provide authentication to online secure servers. You can get a certificate from your system administrator or download it from sites that require authentication.



Some apps such as your browser or email client let you install certificates directly in the app. See the app's help for details.

---

### Installing a digital certificate

---



You must set a lock screen PIN or password before installing a digital certificate.

1. Save the certificate file in the root folder on HTC Desire 620G dual sim.
2. Go to Settings.
3. Tap **Security > Install from phone storage**.
4. Tap  and choose to install the certificate from the internal storage or SD card.
5. If you have more than one certificate in the root folder, select the certificate you want to install.
6. Enter a name for the certificate and tap **OK**.

# Trademarks and copyrights

©2014 HTC Corporation. All Rights Reserved.

HTC, the HTC logo, HTC Desire, and HTC BlinkFeed are trademarks or service marks of HTC Corporation.

Google, Android, Android Beam, Android Market, Google Calendar, Google Chrome, Google Maps, Google Now, Google Play, Google Talk, Google Wallet, Google Voice Search, Google+, Gmail, and YouTube are trademarks of Google Inc.

Microsoft and ActiveSync are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.

Wi-Fi® is a registered trademark of the Wireless Fidelity Alliance, Inc.

microSD is a trademark of SD-3C LLC.

All other trademarks and service marks mentioned herein, including company names, product names, service names and logos, are the property of their respective owners and their use herein does not indicate an affiliation with, association with, or endorsement of or by HTC Corporation. Not all marks listed necessarily appear in this User Guide.

Screen images contained herein are simulated. HTC shall not be liable for technical or editorial errors or omissions contained herein, nor for incidental or consequential damages resulting from furnishing this material. The information is provided “as is” without warranty of any kind and is subject to change without notice. HTC also reserves the right to revise the content of this document at any time without prior notice.

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or storing in a retrieval system, or translated into any language in any form without prior written permission of HTC.

# Index

---

## A

---

- Airplane mode 89
- Alarms
  - setting 77
- Android Market
  - See Google Play
- Messages 49
- Apps
  - arranging 41
  - grouping into a folder 41, 42
  - hiding or unhiding 42
  - icons on Home screen 38
  - installing 75, 76
  - installing from the web 76
  - on Home screen 38
  - restoring 76
  - uninstalling 77

---

## B

---

- Backup
  - restoring backed up apps 76
- Battery
  - charging 13
  - checking usage 29
  - saving battery power 29
- Bluetooth
  - connecting a Bluetooth headset 86
- Browser
  - bookmarks 58
  - history 58
  - using 57

---

## C

---

- Calendar
  - creating an event 78
  - views 78
- Camera
  - basics 67
- Capture screen 24
- Change phone language 90

- Clock
  - alarm 77
  - setting date and time 78
- Conference call 47
- Contacts
  - adding 60
  - contact groups 61
  - editing 60
  - filtering 59
  - importing 60, 61
  - personal profile 59
  - sending contact info 61
- Copying
  - files to computer 50
  - text 24

---

## D

---

- Data connection
  - data roaming 82
  - sharing 85
  - turning on or off 80
  - usage 81
- Data transfer
  - See Transfer contacts
- Display
  - changing the time before the screen turns off 90
  - screen brightness 90
  - screen rotation 89
  - Sleep mode 20

---

## E

---

- Email
  - See Mail

---

## F

---

- Factory reset 53
- Files
  - copying to computer 50
- Finger gestures 17

## Folder

- grouping apps 41
- removing items 41, 42

---

**G**


---

## Gallery

- editing 68
- Video Highlights 68
- viewing 68

## Gestures

- touch gestures 17

## Gmail 65

## Google Chrome

- browser 57

## Google Maps 72

## Google Now

- setting up 55
- turning off 56

## Google Play

- installing apps 75
- refund 77

## Google Voice Search 57

## GPS (Global Positioning System)

See Locations

---

**H**


---

## Hands free 86

## Hard reset

See Factory reset

## Headphones

See Bluetooth

## Home screen

- widgets 38
- apps 38
- changing your main Home screen 40
- folder 41
- HTC BlinkFeed 33
- launch bar 37
- rearranging widgets and icons 39
- removing widgets and icons 39
- shortcuts 38
- wallpaper 37

## HTC BlinkFeed

- about 33
- adding or removing locales 34
- deleting tiles 35
- posting to social networks 36
- reading articles 35

- saving articles for later 35
- selecting feeds 34
- setting up custom topics 34
- turning on or off 33

---

**I**


---

## Internet connection

- VPN 83
- Wi-Fi 80
- Wi-Fi Hotspot 84

---

**K**


---

## Keyboard

- dictionary 27
- entering text 25
- entering text by speaking 28
- HTC Sense keyboard 25
- layout 25
- multi-language keyboard 26
- predictive text 26
- shortcuts 27
- speech recognition 28
- Trace keyboard 28

---

**L**


---

## Language

- system language 90

## Locations

- turning on location services 72

## Low battery 29

---

**M**


---

## Mail

- attachments 63
- carbon copy, blind copy (cc, bcc) 63
- draft 63
- replying 64
- searching 64
- sending 63

## Making calls

- calling 44

## Maps

- Google Maps 72

## Market

See Google Play

## Master reset

See Factory reset

microSD card 12

Music

- adding a song to a queue 71
- listening 70
- playlist 70

---

## P

---

Pair a Bluetooth headset 86

People

See Contacts

Phone calls

- calling 44
- conference call 47
- emergency call 45
- missed calls 44
- muting the microphone 47
- putting a call on hold 45
- speakerphone 46

Power

- charging the battery 13
- checking battery usage 29
- saving power 29
- sleep mode 20

Print screen

See Capture screen

PUK (PIN Unblock Key) 88

---

## R

---

Reset 53

---

## S

---

Screen

- adjusting brightness 90
- capture 24
- changing the time before the screen turns off 90
- rotation 89
- Sleep mode settings 90

Screen shot

See Capture screen

SD card 12

Search

- searching phone and Web 56
- voice search 57

Security

- protecting SIM card with PIN 87
- security certificates 83

Settings

- display language 90
- Storage 50

Setup

- initial setup 15

SIM card

- SIM PIN 87

Sleep mode 20

Slideshow

See Video Highlights

Soft reset 53

Software updates 16

Sound

- switching profiles 48

Speakerphone 46

Storage

- copying files 50
- types of storage 50

---

## T

---

Tethering

See USB Tethering

Transfer contacts 15

---

## U

---

Updates

See Software updates

USB Tethering 85

---

## V

---

Video Highlights 68

Voice input 28

Voice search 57

VPN

- adding a connection 83
- connecting 83
- disconnecting 84

---

## W

---

Wallpaper 37

Wi-Fi

- connecting to another network 81
- connecting via WPS 81
- turning on 80

Wi-Fi hotspot 84

Widgets

- adding 38

- changing settings 38
- rearranging 39
- removing 39, 40
- resizing 38

Word prediction

- bilingual prediction 27

---

Y

---

YouTube 79