

Padfone Station (P05)

Padfone (A86)

User Manual

E8634 First Edition August 2013

Copyright © 2013 ASUSTeK COMPUTER INC. All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTEK COMPUTER INC ("ASUS").

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification of alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

Table of Contents

Package contents	5
------------------	---

Using your PadFone

Basics	6
Setup Wizard	
Screen Views	
Navigating your PadFone	9
Making calls	10
Setting up your contacts list	10
Connecting to the world	11
Connecting to mobile networks	11
Connecting to Wi-Fi networks	
Using Bluetooth	

Using your PadFone Station

Basics	16
Unlocking your device	16
Home Screen	

Touching and typing

Using g	gestures1	8
Using t	he onscreen keyboard1	9
Using (Google voice typing2	0

Using apps and widgets

Using apps on the PadFone	21
Launching apps	
Messaging	
Surfing the web	
Managing notifications	22
Searching your PadFone or web	
Taking pictures	25
ASUS Splendid	26
SuperNote	27

Using apps on the PadFone Station	29
Managing Apps	.29
Task Manager	.33
File Manager	.34
Play Store	.37
Settings	39
Music	41
Gallery	42
Camera	45
Email	46
Gmail	48
MyLibrary	50
Local and Maps	
Polaris [®] Office	54
App Backup	
App Locker	
ASUS Echo	
ASUS Story	
SuperNote	
Parental Lock	
Using PadFone widgets	65
Adding widgets	65
Task Manager	66
Using PadFone Station widgets	67
Adding widgets	
ASUS Battery	.68

Package contents

Item	PadFone	PadFone Station	2-in-1 set
PadFone	•		•
PadFone Station		•	•
Power adapter	•		•
PadFone USB cable	•		•
Headset	•		•
Quick Start Guide	•	•	•
Important Notices	•		•
Warranty card	•		•

NOTES:

- ASUS PadFone and PadFone Station are purchased separately.
- · Contact your retailer if any of the items is damaged or missing.

Using your PadFone

Use your PadFone to enjoy the latest features and technologies of Android 4.2.2 (Jelly Bean) operating system. Do work and play on your PadFone to fully appreciate the tons of interactive applications and features, and the seamless connectivity solutions in data sharing and communication that Android 4.2.2 has to offer.

Basics

IMPORTANT:

- Before you start, ensure that you have read all the safety information and operating instructions in the Important Notices to prevent injury or damage to your device.
- Refer to your PadFone Quick Start Guide for instructions on installing the SIM card and charging your device.

Setup Wizard

The first time you turn on your PadFone device, you'll see the Setup Wizard. Touch and follow the instructions to set up your PadFone device.

NOTE:

You can skip some of the steps and set them up later.

To access it again, touch 🗰 to go to the All apps screen then touch Setup Wizard



Screen Views

The screen view rotates automatically when you hold your PadFone horizontally to vertically, and vice versa. To enable/disable Auto-rotate screen, go to **Settings** > **Display**. You can also touch from **ASUS Quick Settings**.

NOTE:

For more details about ASUS Quick Settings, refer to the section Managing notifications in Chapter 4.



Portrait view

Navigating your PadFone

After you finish setting up your PadFone, the Home Screen appears.



At the bottom of your Home Screen, you'll find three navigation icons , , , These icons, which are always available on the system bar, allow you to instantly return to a previous page, jump back to the Home Screen, or launch a recent app.

lcon	Description		
1	Allows you to go back to the previous screen, until you are in the Home Screen.		
	Opens your Home Screen.		
	Opens a thumbnail list of your most recent apps. To launch an app, touch the thumbnail image. If you wish to remove a thumbnail app, swipe it to the left or right.		

Making calls

To make a call:

- 1. Touch 📞 on the Home Screen.
- 2. Touch the keys to key in the number you wish to call.
- 3. Touch 🔨 to dial.
- 4. Touch **I** to end the call.

Setting up your contacts list

To set up your contacts, you can do any of the following:

- Touch Select Create a new contact. Follow the succeeding screen instructions to add a new contact.
- Import your contacts from your SIM card into your PadFone. To import your contacts from your SIM card:
 - 1. Install the SIM card into your PadFone.
 - 2. From the Home Screen, touch 2, to launch the People app.
 - 3. Touch Import contacts.
 - 4. Touch **Import from SIM card**. When prompted, select to which account you want to add the contacts.
 - 5. To import the contacts one at a time, touch to select a contact you wish to import, then touch **OK**. When prompted, touch **OK** to confirm.

Connecting to the world

Connecting to mobile networks

After installing the SIM card, you are ready to use your PadFone to make/receive voice calls or transmit/receive data. Different countries or regions may have different mobile networks available and you may have to configure your PadFone to access these networks.

To configure your Mobile networks setting:

- 1. Do any of the following to go to the Settings screen:
 - Touch (...) to go to the All apps screen then touch Settings [0].
 - Swipe your finger down from the top of the screen to go to ASUS Quick Settings then touch .
- 2. From the Settings screen, touch More....
- 3. Touch Mobile networks.

NOTE:

For more details about ASUS Quick Settings, refer to the section Managing notifications in Chapter 4.

IMPORTANT:

- If your PadFone does not connect to a network, contact your mobile network carrier for assistance.
- Refer to your PadFone Quick Start Guide for instructions on how to install a SIM card.

Connecting to Wi-Fi networks

Wi-Fi wireless networking technology allows you to exchange data wirelessly over a network. To use Wi-Fi, enable the Wi-Fi feature in your PadFone and connect to a wireless network. Some wireless networks are secured with a key or protected with digital certificates and requires additional steps to set up; others are open and you can easily connect to them.

TIP:

Turn OFF Wi-Fi when you're not using it to help save battery power.

To enable Wi-Fi and connect to a Wi-Fi network:

- 1. Do any of the following to go to the Settings screen:
 - Touch (...) to go to the All apps screen then touch Settings
 - Swipe your finger down from the top of the screen to go to ASUS Quick Settings then touch in touch is also touch Wi-Fi from ASUS Quick Settings to directly enable/disable Wi-Fi.
- 2. Slide the Wi-Fi switch to **ON**. When enabled, your PadFone scans for available Wi-Fi networks.
- 3. Touch **Wi-Fi** to display list of available Wi-Fi networks nearby. Secured networks are indicated with a lock icon.
- 4. Touch a network name to connect to it. If the network is secured or protected, you are prompted to key in a Password or key in other credentials.

NOTE:

For more details about ASUS Quick Settings, refer to the section Managing notifications in Chapter 4.

IMPORTANT:

If your PadFone finds a network that you have connected to previously, it automatically connects to it.

Using Bluetooth

Enabling or disabling Bluetooth in your device

Bluetooth is a wireless standard used for exchanging data over short distances. Bluetooth exists in many products, such as smartphones, computers, tablet devices, and headsets.

Bluetooth is very useful when transferring data between two or more devices that are near each other.

The first time you connect to a Bluetooth device, you must pair it with your PadFone.

TIP:

Turn OFF Bluetooth in your PadFone when you're not using it to help save battery power.

To enable or disable Bluetooth in your PadFone, you can do any of the following:

- Touch (...) to go to the All apps screen then touch Settings (...). Slide the Bluetooth switch to ON / OFF.
- Swipe your finger down from the top of the screen to go to ASUS Quick Settings, touch
 Bluetooth 3

Pairing your PadFone with a Bluetooth device

Before you can connect to a device, you must first pair your PadFone to that device. Once paired, the devices stay paired unless you unpair them.

To pair your PadFone to a device:

- 1. Touch $\underbrace{\dots}$ to go to the All apps screen then touch **Settings** $\underbrace{0}$. Slide the Bluetooth switch to **ON**.
- 2. Touch Bluetooth to display all available Bluetooth devices within range. If the device you want to pair with is not in the list, ensure that its Bluetooth feature is turned ON and set as Discoverable. See the technical documentation that came with the device to learn how to turn its Bluetooth ON and how to set it to discoverable.
- If your PadFone has finished scanning before your Bluetooth device is ready, touch Search for devices.
- 4. In the list of available devices, touch the Bluetooth device you want to pair with. Follow the succeeding screen instructions to complete the pairing. If necessary, refer to the technical documentation that came with the device.

Connecting your PadFone to a Bluetooth device

After you have paired your PadFone to a Bluetooth device, you can easily reconnect to it again manually, after it is back in range.

To connect:

- 1. Touch (...) to go to the All apps screen then touch **Settings** . Slide the Bluetooth switch to **ON**.
- 2. In the list of **PAIRED DEVICES**, touch the name of the paired device.

Unpairing and configuring a Bluetooth device

To unpair or configure a Bluetooth device:

- 1. Touch 🗰 to go to the All apps screen then touch **Settings** (i). Slide the Bluetooth switch to **ON**.
- 2. Touch **Bluetooth** to display the Bluetooth settings.
- 3. Touch the Bluetooth Quick Settings icon beside the connected Bluetooth device you want to unpair or configure.
- 4. From the Bluetooth Quick Settings screen, you can do any of the following:
 - Touch **Unpair** to unpair the device.
 - Touch **Rename** to rename the Bluetooth device.
- 5. Touch when you're finished.



Using your PadFone Station

Install your PadFone into your PadFone Station to extend its battery life and turn it into a tablet device.

IMPORTANT:

- Before you start, ensure that you have read all the safety information and operating instructions in the **Important Notices** bundled with your PadFone to prevent injury or damage to your device.
- Refer to your PadFone Station Quick Start Guide for instructions on inserting your PadFone into the PadFone Station.

NOTES:


- The image used is for reference only and may look different on your PadFone Station.
- The Home Screen may update and change with Android OS.

Basics

Unlocking your device

To unlock your device, touch and drag the lock icon out of the circle to the open locked icon.

Home Screen



Display recent apps

3

Touching and typing

Using gestures

Use your fingers to launch apps, move icons, select menu items, press buttons, type on the onscreen keyboard, and perform other useful gestures on your PadFone device's touchscreen.


To key in or type something, touch the part where you need to type and the onscreen keyboard will pop up.

The following table describes more useful gestures.

0		
Gesture	Description	
Pinch	Place two fingers on the screen and spread them apart to zoom in and bring them together to zoom out. This gesture can be used in selected apps, including Maps, Gallery, and Browser.	
Drag	Touch and hold an icon or item then, without lifting your finger, move your finger on the screen to move the icon or item.	
Touch and hold	Touch and hold an item until an action occurs.	
Swipe or slide	Quickly move your finger across the screen in one sweeping motion.	

Using the onscreen keyboard

You can type text using the onscreen keyboard. In most apps, the onscreen keyboard appears automatically when needed. In other apps, you can touch where you need to type to open the onscreen keyboard.



While typing on the onscreen keyboard, the keyboard displays suggestions that may match the text that you need. Touch a suggestion to use it.

Using Google voice typing

Google voice typing uses Google's speech-recognition technology, that converts spoken words into text input. You must be connected to the Internet when using this feature.

As you speak, the converted text is underlined and you can continue speaking to keep it, or you can delete it.

To use Google voice typing:

- 1. Touch text field where you want to type text.
- 2. Depending on the app you're using, you can do either of the following:
 - If you see the microphone icon \mathbf{Q} beside the text field, touch it.
 - If the onscreen keyboard is open, touch
- 3. When you see the microphone icon, speak clearly what you want to type. When you pause, Google voice typing transcribes the text you spoke and displays it on the text field.

TIPS:

- · Say "period", "comma", "question mark", or "exclamation point" to type these punctuation marks.
- Touch the Backspace key sto delete the underlined text.

4

Using apps and widgets

You can seamlessly use applications between your PadFone and PadFone Station.

NOTES:

- · PadFone and PadFone Station are purchased separately.
- Some downloaded applications may work on your PadFone but may not work on your PadFone Station, and vice versa.

Using apps on the PadFone

Launching apps

Touch (:::) to display all your apps. The main apps screen is where you can see all your apps. From the main apps screen you can:

- Touch an icon to launch an app.
- · Swipe the screen to display more apps.
- Drag an app icon into the Home Screen.
- See apps compatible with the PadFone Station.
- Explore widgets.
- Get more apps from the Play Store.

Messaging

Touch 💟 to compose and send a message.

Surfing the web

Touch (E) to launch the browser and surf the web.

Managing notifications

Notifications alerts you about new messages, calendar events, media service connections, PC sync

information, alarms, and more.


Enable the ASUS Quick Settings app to see more and do more from your Notifications area.

NOTES:

- If ASUS Quick Settings is not enabled, go to the All Apps screen, touch then select ASUS customized settings and enable Use ASUS Quick Settings.
- Depending on your sound settings, you will also hear a sound at the same time a notification icon is displayed on the top left of your screen everytime a new notification arrives.

To see your notifications, swipe your finger down from the top of the screen.

ASUS Quick Settings



	Description
(îr	Touch to enable or disable the Wi-Fi connection.
	Touch to enable or disable the Mobile Data function.
[a	Touch to enable or disable the Smart Saving function.
60	Touch to enable or disable the Reading Mode function, which allows you to adjust the screen or text of your chosen apps for your reading enjoyment.
Aa	Touch to enable or disable the Instant Dictionary app.
P	Touch to enable or disable the Wi-Fi Hotspot function.
*	Touch to enable or disable the Bluetooth connection.
6	Touch to enable or disable the GPS function.
-() -)	Touch to enable or disable the sound, vibrate, or mute mode.
\bigcirc	Touch to enable or disable the auto-rotate screen feature.
X	Touch to enable or disable the Airplane mode.
NFC	Touch to enable or disable the NFC function.
0	Touch to enable or disable the Auto-sync function.

Searching your PadFone or web

Use the Google Search bar at the top of your Home Screen to help you find anything that you need from your PadFone or from the web. To start searching, you can do either of the following:

- Touch Google on the search bar then key in your search item. As you key in your search item, Google lists suggestions that may match your search, touch a suggestion to search for it immediately or touch the arrow beside it to add the term into the search field.
- Touch V then when prompted to **Speak now**, speak clearly the item you're searching.

Taking pictures

Use the camera app, taking pictures and videos with your PadFone is fun and easy.

The camera app works with two cameras, one 2.0 megapixel camera at the front of your device and one 13 megapixel camera at the rear.

The front camera allows you take pictures and videos, while the rear camera allows you to take high resolution pictures and videos. The rear camera also allows you to take pictures in Panorama mode, where you can pan across a subject to create a single picture.

You can view your pictures and videos in the Gallery app.



taking video.


Touch on the Home Screen, then touch to start taking pictures or touch

to start

25

ASUS Splendid

ASUS Splendid allows you to easily adjust the display settings.




To use ASUS Splendid:

- 1. Touch (...) to go to the All apps screen then touch ASUS Splendid
- 2. Adjust the screen color temperature and contrast through the **Temperature** and **Enhancement** taps.
- 3. Touch **Done** to apply the changes.

SuperNote

SuperNote is a convenient app used for writing and painting on your PadFone. You can take notes, send instant messages, draw sketches, create e-cards with audio recordings or diaries with video, and a lot more.




Using SuperNote

To create a new notebook:

- 1. Touch Add a new n otebook.
- 2. Key in a name for the file and choose the notebook type to start writing on the page.

The following screen describes the SuperNote screen features on your PadFone.



NOTE:

• For more details using SuperNote on your PadFone, tap Tutorial for Phone.

Using apps on the PadFone Station Managing Apps

App shortcut

You can create shortcuts for your favorite apps on your PadFone Home Screen.

- 1. Touch (:::) to go to the All apps screen.
- 2. From the All apps screen, touch and hold the icon of the app you wish to move then drag and place the app on the Home Screen.

App info

You can view the detailed app information while you are creating a shortcut for the app. While holding an app from the All apps screen to the Home Screen, the **App info** will appear on the top of the Home Screen page. Drag the app to **App info** to display its detailed information.

Removing App from Home Screen

You can remove app shortcuts from your PadFone Home Screen. The original app will remain in your **All apps** screen. To remove an app in your Home Screen:

- 1. Touch and hold an app on your Home Screen until **X Remove** appears.
- 2. Drag the app to **X Remove** to remove it from the Home Screen.



App Folder

Create folders to organize your applications and shortcuts on your PadFone Station Home Screen.

- 1. On your PadFone Station's Home Screen, touch and drag an app or shortcut onto another app and a folder will appear.
- 2. Touch the new folder and tap **Unnamed Folder** to rename the folder.






Recent Apps

Recent apps are displayed on the left panel of the Home Screen. You can find detailed information and manage your apps from the Recent Apps list.

1. Touch the **Recent Apps** icon at the bottom of the Home Screen.



- 2. Swipe to the left or to the right to view **Recent Apps.** Swipe a recent app to the left or right to remove from the list.
- 3. Touch and hold a recent app to display the menu. Select to remove app from list or display app information.



Task Manager

ASUS Task Manager displays a list of currently running utilities and applications and their usages in percentages on your PadFone Station.

- 1. Touch (:::) to go to the All apps screen.
- 2. Touch **WIDGETS** to display the widgets menu.
- Touch and hold ASUS Task Manager to display the ASUS Task Manager box on the Home Screen.



- 4. Touch and hold the widget to display the sizing brackets. Pull the sizing bracket upward or downward to show the complete list of tasks.
- 5. Tap Solution beside each running app to close the app. Touch **Close All** to close running apps all at once.



File Manager

File Manager allows you to easily locate and manage your data either on the internal storage device or the connected external storage devices.

To access the internal storage device:

- 1. Touch (:::) to go to the **All apps** screen.
- 2. Go to All Apps screen, touch File Manager, then go to My Storage.



3. The Internal Storage (/sdcard/) and any connected external storage devices (/Removable/) are displayed on the left panel. Touch the source icon on the left panel to display the content list, and touch to select an item.

My Storage	G / Bensovable / MicroSD /	
Internal Storage	Type Name * Size	Dute
MicroSD	Android	6/28/2012 02:39
	🗐 🖸 АРК	5/10/2011 04:00
	AppleDaily	8/27/2011 02:43
	🔲 🗖 ber	5/11/2011 08:35
	D book	7/29/2013 02:05
	Books	8/27/2011 02:59
	C cBook	3/17/2011 07:01
	Comie	10/7/2011 04:43
	Content	3/21/2012 23:46
~	5 4 8	

4. Touch the Return folder icon to return to the root directory of My Storage.

			ADD FOLDER
My Storage	/ Bemovable / MicroSD /		
	Type Name	* Size	Date
MicroSD	Android		6/28/2012 02:39
	🗐 🗂 АРК		5/10/2011 04:00
	AppleDaily		8/27/2011 02:43
	🔲 🗖 ber		5/11/2011 08:35
	🔲 🖸 book		7/29/2013 02:05
	Books		8/27/2011 02:59
	C cBook		3/17/2011 07:01
	Comic		10/7/2011 04:43
	Content		3/21/2012 23:46
	5 6	Ø	

To access the external storage device:

1. Swipe your finger down from the top of the screen to go to **ASUS Quick Settings**, then touch **Open** under **External storage inserted**.



2. Touch the folder icon to display its contents.

			ADD FOLDER	
My Storage	G / Removable / MicroSD /			
	Type Name	+ Size	Date	
MicroSD	Android		6/28/2012 02:39	
	🗐 🖸 АРК		5/10/2011 04:00	
	AppleDaily		8/27/2011 02:43	
	E 🖸 ber		5/11/2011 08:35	
	🔲 🗖 book		7/29/2013 02:05	
	Books		8/27/2011 02:59	
	CBook		3/17/2011 07:01	
	Comic		10/7/2011 04:43	
	Content		3/21/2012 23:46	
a	5 습	a		_

To copy, cut, delete, or share files:

Tick the file you wish to copy, cut, share, or delete and touch the action icon found at the tool bar on the upper right corner of the File Manager screen.

You can also tick the file and drag/drop it to your desired destination folder.

g none	2 items selected						< 9448	E corr	×		Ē
My Stor	G	C / Removable / MicroSD / music /									
	LogFile	Тур	e	Name		Size		Date			
		10		2010-08-02 蘇打錄 - 十年一刻				11/30/201	1 20:31		
			0	01 Love.mp3		1.74MB		9/3/2010	08:11		
			0	02 To Hebe.mp3		5.28MB		9/3/2010	08:11		
9		×	0	03 離島.mp3		3.89MB		9/3/2010	08:11		
	MyPainter	10	9	04 沒有管理員的公寓.mp3		4.92MB		9/3/2010	08:11		
	NewTaipeiCityData	11	Q.	05 我對不起我.mp3		5.21MB		9/3/2010	08:11		
	Recordings	10	0	06 我想我不會變你.mp3		6.07MB		9/3/2010	08:11		
			9	07 寂寞寂寞就好.mp3		6.47MB		9/3/2010	08:11		
		10	0	08 你太猫狂.mp3		4.29MB		9/3/2010	08:11		
		-	100	5	ð						


Play Store

Access lots of fun games and tools in the Play Store using your Google account. If you don't have a Google account, please create one.


To access the Play Store:

- 1. Touch (:::) to go to the All apps screen.
- 2. From the All apps screen, tap Play Store





4. Type your Email and Password to Sign in if you already have an account.



5. After signing in, you can start downloading and adding apps to your device from the Play Store.



NOTES:

- You cannot restore the deleted applications, but you can login with the same ID and download them again.
- Some applications are free and some might charge you through a credit card.

Settings

Settings screen allows you to configure the settings of your PadFone Station, including **Wireless & networks, Device, Personal, Accounts,** and **System** settings. Touch the tabs on the left to switch screens and do the configurations.

There are two ways to go to the **Settings** screen.


From the All apps screen:

Touch Settings to display the settings menu.



From ASUS Quick Settings:

Swipe your finger down from the top of the screen to launch the ASUS Quick Settings panel.



Notification Panels

Notification panels will appear under the Quick Setting panel for alerts or updates in apps, incoming emails, and utillity status.




IMPORTANT:

Swipe a notification to the right or to the left to remove item from the list.

Music

Touch **Play Music** on the Home Screen to play your music files. This application automatically collects and displays all the audio files stored in your PadFone Station and connected external storage devices. You can shuffle and play all audio files randomly or flip to select an album for your listening pleasure. Use the buttons on the top to conveniently sort or search your audio files.



NOTE:


The audio and video codec supported by your PadFone Station: Decoder Audio Codec: AAC LC/LTP, HE-AACv1(AAC+), HE-AACv2(enhanced AAC+), AMR-NB, AMR-WB, MP3, FLAC, MIDI, PCM/WAVE, Vorbis, WAV a-law/mu-law, WAV linear PCM Video Codec: H.263, H.264, MPEG-4, VP8

Encoder Audio Codec: AAC LC/LTP, AMR-NB, AMR-WB Video Codec: H.263, H.264, MPEG-4

Gallery

Touch **Gallery** on the All apps screen to browse for images or video files. This app automatically collects and displays all the images and video files stored in your PadFone.

From the Gallery, you can display images in a slideshow or touch to select for image or video files. You can also use the menu buttons on the upper right corner of the Gallery screen to sort the files by album, by location, by time, by people, or by tags.




Sharing and deleting albums

Touch and hold an album in the Gallery until the Tool bar on top appears.

Using the Tool bar options, you can upload, delete, or share selected albums online.

					Tool ba	ar 🗌	
V DONE	2 selected					<,	î
C Screensh	ots (3)	in Wonderland □ • (1)	2		 Facebook for WebStorage Messaging See all 		
			5	đ			




Share the selected album through ASUS Webstorage, Bluetooth[®], or Gmail[®]

Sharing, deleting, and editing images

Touch an image in the Gallery and use the tool bar on the upper right corner to share, delete, or edit a selected image.






Share the selected album through Amazon Kindle, ASUS Webstorage, or Bluetooth®

CAUTION!

You cannot restore a deleted file.




Check the image information, and edit the selected image

Camera

Touch **Camera** from the Home Screen to take pictures or record videos. You can use the front camera or the back camera to take pictures or record videos.

The image and video files are saved to Gallery.

Camera/video mode



Email

Email allows you to add several e-mail accounts and conveniently browse and manage your e-mails.

To set up an email account:

- 1. Touch (\cdots) to go to the All apps screen.
- 2. Touch **Email [11]** to launch the email app.
- From the email app screen,key in your Email address and Password, then touch Next.
- Wait while your PadFone automatically checks your incoming and outgoing mail server settings.
- 5. Configure the Account options and touch Next.
- Provide a name for the account and key in the name you want displayed on the outgoing messages. Touch **Next** to log into your mail inbox.


	Em	ail acco	ount								
	Yeu o	an setup er	nail for mos	t accounts	in just a fee	steps.					
	fread a								Minut	anap	
	Parra								.160		
1	2	3	4	5	6	7	8	9	0		a
1	2 q	3 w	4 e	5 r	6 t	7 y	8 u	9 i	0	P	•
l	1	1		5 r f.	6 t			9 i k		Р	×
1	q '	w	e	r f c	t	y		1		Р	

i I ⊂ a tr ccount settings		⊕1 % £12 - 85 2045
Account options		
Index checking bequericy Every 15 minutes	•	
Send email from this account by default.		Previous
Notfy me when anual arrived.		Next
😴 Sync email from this account.		
Relational cally download attachments when connected to Wi-Fi		

Account to	etup									* *	67 6 - 10 2007
	time the	chavez201	ne (sptional) I (égmail.co	m	and em	ail is o	n its w	ay!	Nes		
1	2	ne (Burlayed		5	6	nia feli cent	e Me Mark	9	0		a
	a '	w '	E	R	T	Y	U		0	Р 1	
-	A	S	D	F	G	н	J	к	L		one
		Z	x	С	v	В	N	M			
En	1@#	Ŷ				See 6			1	?	:-)
ó				-		0	8				

To add email accounts:

- Touch (IIII) to go to the All apps screen, touch
 Email (IIIII) and login using the account that you've previously set up.
- Touch Settings on the upper right corner to display the preferences for this account.
- 3. Touch **Add account** on the upper right corner to add another account.





NOTE:


You can include all your e-mail accounts in Email.

Gmail

Gmail (Google mail) allows you to access your Gmail account, receive, and compose e-mails.

To set up a Gmail account:


Touch Gmail from the All apps screen.
 Touch Existing and type your existing
 Email and Password, then touch Sign in.




NOTE:

Touch New if you do not own a Google Account.

 Wait while your PadFone communicates with Google servers to set up your account.



 You can use your Google account to backup and restore your settings and data. Touch to sign in to your Gmail.



IMPORTANT:

If you have several e-mail accounts in addition to Gmail, use **Email** to set up and access all your e-mail accounts at same time.


MyLibrary

MyLibrary, an integrated interface for your e-book collections, allows you to place your purchased or downloaded e-books into different bookshelves and genres.

Touch (:::) to go to the All apps screen, then touch **MyLibrary**.

IMPORTANT:


- MyLibrary supports e-books in ePub, PDF and TXT format.
- You may need Adobe Flash[®] player to open some e-books. Download Adobe Flash[®] player before using MyLibrary.



Reading your e-books

To read e-books:


- 1. Touch to select an e-book on the bookshelf.
- 2. Touch the screen to show the tool bar on the top.



NOTES:


- Android initiates the download and installation of necessary resource if you would like to use the text-to-speech function.
- Tap on the Bookmark list and select the marked page to show the bookmark icon on the upper right corner of the screen.

3. Flip pages like a real book or move the page scroll at the bottom.



Making notes on your e-books

1. Touch and hold on a desired word or sentence until the tool menu and the dictionary definition are displayed.




- 2. Once selected, you either highlight the selected word with a marker, add a note, use text-to-speech function for the selected text, or simply copy the word.
- 3. Move the selection point to extend the selected region to a whole phrase or sentence if needed.

Local and Maps

Local

Local allows you to easily find places such as nearby attractions, restaurants, coffee shops, or gas stations. It also allows you to check in your current location at a specific time and share this information with others.



Maps

Maps allows you to find establishments, view maps, and get directions. Use the tool bar on the top to get directions or create your own maps.



Polaris® Office

Polaris[®] Office is a set of interrelated desktop applications that allows you to create, read, and edit documents, spreadsheets, and presentations.

To use Polaris® Office:

- 1. Touch (:::) to go to the All apps screen.
- 2. In the All apps screen, touch Polaris® Office.



- 3. Touch any of the following:
 - Touch **Browser** to view the files/folders in the local storage.
 - Touch **Clouds** to add a cloud service account.
 - Touch **Form type** to view all documents by type.
 - Touch Favorites to view your favorite files.

Adding new files

To add new files, touch and on the upper right corner of the screen:

- Touch Document (.doc) or Document (.docx) to start the word processor to edit documents.
- Touch **Sheet** (.xls) or **Sheet** (.xlsx) to start the spreadsheet to perform calculation and manage information.
- Touch Slide (.ppt) or Slide (.pptx) to start the application to create and share presentations.
- Touch **Text** to create text files.

Adding Accounts

You are allowed to edit your files with Polaris® Office from other accounts, including Google Docs,

WSBoxNet, and WSDropbox.

- 1. Touch Clouds.
- 2. Select a desired service to add.
- 3. Key in your e-mail account and password and touch Done to add the account.



App Backup

App Backup allows you to back up your installed apps and app data on both the internal and external storage, and restore your installed apps and app data after updating your device firmware.

NOTE:

App Backup cannot restore an app that requires an account authentication. If you have problems with such an app, go to Settings > Apps to clear the app data and log in again.

To use App Backup:

- 1. From the All apps screen, touch on **App backup**.
- 2. Accept the End User License Agreement.

3. You can now start using App Backup to back up or restore your installed apps and data.





To backup an app:

- Tick the apps you would like to back up and select a **Backup** Type to back up the app data only or both the app and the app data.
- When done, touch **Backup** on the upper right corner of the screen to start backup.

 Image: Select the app data you want to back up
 Exckup Type: Data Orly

 Backup List
 Select the app data you want to back up

 Restore List


To restore an app:

 Touch **Restore List** to display the Restore List page.

0

Touch a backup file you would like to restore.

 Touch **OK** on the confirmation message to start restoring an app.



App Locker

App Locker allows you to password-protect your apps.

To use App Locker:

- 1. From the All apps screen, touch on **App Locker**.
- 2. Set up your password.



- Tick the apps you would like to lock.
- You can also deactivate App Locker or change the password from Settings on the upper right corner.



NOTES:


• Locked apps will have lock icons on the Home Screen.



• You will be asked for your password everytime you access the locked apps.

ASUS Echo

ASUS Echo lets you use your voice to make calls, search for contacts, adjust the device volume, adjust screen settings, switch on/off Wi-Fi/Bluetooth, and more.



To use ASUS Echo:

- 1. Touch 🗰 to go to the All apps screen then touch **Echo**
- 2. Touch or record a voice command. ASUS Echo will perform an action accordingly.

ASUS Story

ASUS Story allows you to create and share photo stories.

To use ASUS Story:

- 1. From the All apps screen, touch on **Story**.
- 2. Touch Create Story to create a photo story.

3. Key in the story name and touch **OK**.

4. Select photos you want to add to the story and touch **Done**.








To edit and share a story:


1. Touch a story name from the **ASUS Story** main page.



2. Touch 📝 on the upper right corner of the screen to edit a photo story.




3. Touch \blacksquare on the upper left corner of the screen then touch \blacksquare to share a photo story.



SuperNote

SuperNote is a convenient app used for writing and painting on your PadFone Station. You can take notes, send instant messages, draw sketches, create e-cards with audio recordings or diaries with video, and lots more.




Using SuperNote

To create a new notebook:

- 1. Touch Add a new notebook.
- 2. Key in a name for the file and choose the notebook type to start writing on the page.

The following screen describes the SuperNote screen features on your PadFone Station:



NOTE:

For more details using SuperNote on your PadFone Station, tap Tutorial for Pad.

Parental Lock

Parental Lock is an app that allows you to control your device via the Device Tracker website.

NOTE:

Before using Parental Lock, ensure that you register on Device Tracker at devicetracker.asus.com

To use Parental Lock:

- 1. From the All apps screen, touch on Parental Lock.
- 2. Touch Next.

2. Assign and confirm your PIN code.

- Enter the e-mail account that you registered on Device Tracker.
- 4. Touch **Finish** when done.



	ank Skep I										
	The PB	i code allo	ws you to i	enable or d	isable the	Parental Lo	ck function	s or items.			
	Enter y	our PIN co	de								
	Confere	the PIN o	ode:								
- 1	1	1									
	2	3	4	5	6	7	8	9	0		•
ľ	2 q	3 w	4 e	5 r	6 t	7 y	* 8 u	9 i	0	P	•
		1	4 e d	5 T f	6 t g	7 y h		9 i k	_	P	Oone
	q	w	_	5 r f c	1	<u> </u>		1	_	P	
	q	w s z	d	т f	1	h	U J	i k	_	P	

erential L	ank - Day J										1/2 - 10 21
-		CALCORE									
	Please You ca	enter the a n also rem	ccount that	it you regist ol your devi	arred on the	e Device Tr inge your P	acker webs IN code or	ite for devi the Device	ce authent Tracker w	cation. ebsite	
		ogle accou		Asus acc							
1	2	3	4	5	6	7	8	9	0		
		1	1		T		1		_	+	_
	9	W	e	- F -	t	У	u	1	0	р	
=	q	s	ed	T t	1	y h	u j	i k	•	_	iest
=	_	_		f c	t g v		u j n	i k m	•	_	lert T
12 14 56	_	5	6	r f	1	h	i	1		_	iest 1 .com

Using PadFone widgets

Adding widgets

Widgets are useful and fun applications that brings information and services conveniently to your Home Screen at-a-glance. You can find them in the Widgets tab in the All Apps screen, ready to be moved into your Home Screen.

To see your widgets, touch (...) on your Home Screen then touch the Widgets tab at the top of screen.

From the main Widgets screen, you can:

- Drag a widget to another screen.
- · Swipe left or right to move between screens and view more widgets.

IMPORTANT:

- You may be prompted to perform additional tasks (such as registration, activation) before you can use a selected widget.
- If there is not enough room on the screen where you placed a widget, the widget won't get added to that screen.

To remove a widget:

Touch and hold the widget until X Remove appears then without lifting your finger, drag the widget into X Remove.

Task Manager

Task Manager is an easy and quick way to close running apps. It effectively cleans your cache and frees more cache space for your PadFone.

- 1. Touch (\cdots) to go to the All apps screen.
- 2. Touch **Widgets** to display the widgets menu.
- 3. Touch and hold **Task Manager** to display the Task Manager app.

		Т	ask Manage	er	
Shows number of running apps ——	1(Dtas	ks 896/1746 MB	Close All-	 Shows cache size status Touch to close all running apps
	Դ	8	Google Search	8	
	Դ	34	Calendar 0.2%	8	
Touch to lock/ unlock an app —	Դ		Browser 0.2%		— Touch to close an app
	₽	Ń	Tutorial 0.7%	8	
	6	•	AO Link 0.5%		
	A		ASUS Studio		

Additional options:

- To resize Task Manager, touch and hold anywhere on the app until the resize border appears. Touch and drag the sizing handle to adjust to your preferred screen size. You can do this to create additional room for more apps.
- To remove Task Manager, touch and hold the app until **X Remove** appears, then without lifting your finger, drag the app into **X Remove**.

Using PadFone Station widgets

Adding widgets

Use widgets to conveniently access useful and fun applications on your PadFone Station's Home Screen. You can find them in the Widgets tab in the All Apps screen, ready to be moved into your Home Screen.

To see your widgets, touch (:::) to go to the All apps screen, then touch Widgets.

From the main Widgets screen, you can:

- Drag a widget to another screen.
- · Swipe left or right to move between screens and view more widgets.

IMPORTANT:

- You may be prompted to perform additional tasks (such as registration, activation) before you can use a selected widget.
- If there is not enough room on the screen where you placed a widget, the widget won't get added to that screen.

To remove a widget:

Touch and hold the widget until X Remove appears then without lifting your finger, drag the widget into X Remove.

ASUS Battery

This special widget shows the individual battery status of your PadFone and PadFone Station by percentage and color. The more battery power, the brighter the color.

- 1. Touch (:::) to go to the All apps screen.
- 2. Touch **Widgets** to display the widgets menu.
- 3. Touch and hold **ASUS Battery** to display the ASUS Battery app.



4. The notifications panel also display the battery status. The battery status of the PadFone and PadFone Station are shown separately. When battery is low, the battery icon turns from blue to red with an exclamation mark. There will also be a warning sound to notify you when the battery is running low.

