ALL RIGHTS RESERVED

Spice Retail Ltd ©2014. All rights are reserved. No part of this document can be reproduced without permission. All trademarks and brand names mentioned in this publication are property of their respective owners. While all the efforts have been made to ensure the accuracy of contents in this manual, we presume no responsibility for errors or omissions or statements of any kind, whether such errors are omissions or statements resulting from negligence, accidents, or any other cause.

We operate a policy of continuous development and reserve the right to make changes, modifications and improvements to the device, device features/specifications or any of its parts without prior notice. Your device may have preinstalled bookmarks and links for third party internet sites and may allow you to access third party sites. These are no affiliated with Spice, and Spice does not endorse or assume liability for them. If you access such sites, take precautions for security or content.

The limited warranty does not cover user manuals or any third party software, settings, content, data or links, whether included/downloaded in the product, whether included during installment, assembly, shipping or any other time in the delivery chain or otherwise and in any way acquired by you.

To the extent permitted by applicable law(s), Spice does not warrant that any Spice software will meet your requirements, will work in combination with any hardware or software applications provided by a third party, that the operations of the software will be uninterrupted or error free or that any defects in the software are correctable or will be corrected.

User's Manual is provided just to guide the user about the functionality of the device. This does not seem to be any certificate of technology. Some functions may vary due to modifications and up-gradations of software or due to printing mistake.

SAFETY PRECAUTIONS

Please read the following safety guidelines before using the device.

- Do not use the phone while you are driving.
- Do not place magnetic storage media near your phone. Radiation from the phone may erase the information stored on them.
- Keep your phone and its accessories away from children.
- Mobile phones can interfere with the functioning of medical devices such as hearing aids or pacemakers. People having active medical implants should keep their cell phone at least 15 cm away from the implant.
- Permanent hearing loss may occur if you use earphones or headphones at high volume.
- Use a wireless hands-free system (headphone/ headset) with a low power Bluetooth emitter.
- Keep your calls short or send a text message (SMS) instead. This advice applies specially to children adolescents and pregnant women.
- Use cell phone when the signal quality is good.

Notice:

- Do not dismantle the device or accessories otherwise, manufacturer is not liable to pay for damages as the device and accessories are not covered by warranty.
- Use only original batteries and charging devices.
- Please back up your important data timely and keep them properly. The company is not liable for any failure to call or loss of data due to mis-operation, poor signal or power cut, etc.
- All the screens in this manual are for reference only, and some contents actually
 displayed may depend upon the presetting of the service provider or the
 network operator, or the SIM card. If any functions referred to in this manual are
 different from those of your device, please follow your device.

• Do not put use it in a place with flammable gas such as a petrol pumps. The temperature recommended for using the device is 5-35°C. Do not touch the charger, power cable or socket with wet hands. This may cause an electric shock.

If your phone or any of its accessories do not function normally, then please visit your nearest authorized service facility. The qualified personnel will assist you, and if necessary, will arrange for the service.

SAR (Specific Absorption Rate)

Your device conforms to the Indian guidelines for exposure to radio waves. The limits are given in terms of a unit referred to as the Specific Absorption Rate (SAR), which is a measure of the amount of radio frequency energy absorbed by the body when using a mobile phone. The SAR value as per the Indian guidelines standard is 1.6 Watts per kg (Watt/kg), averaged over a 6 minutes period and taken over a volume containing a mass of 1 gram of human tissue. The highest SAR value of this device when tested is **0.344W/Kg**.

TABLE OF CONTENTS

ALL RIGHTS RESERVED	
SAFETY PRECAUTIONS	
TABLE OF CONTENTS	
WHAT'S IN THE BOX?	7
1. UNDERSTANDING YOUR DEVICE	
1.1 GENERAL INFO	8
1.2 DEVICE OVERVIEW	9
2. GETTING STARTED	9
2.1 INSTALLING CARDS &BATTERY	9
2.2 POWERING ON/OFF THE DEVICE	10
3. BASIC OPERATIONS	11
3.1 CALLING	11
3.2 MESSAGING	13
3.3 CONTACTS	15
3.4 EMAIL	17
3.5 BROWSER	17
4. HOME SCREEN	18
4.1 STATUS BAR	18
4.2 CUSTOMIZING SCREEN	19
5. MULTIMEDIA	19
5.1 MUSIC PLAYER	19
5.2 CAMERA	
5.3 VIDEOS	21
5.4 GALLERY	21
5.5 FILE MANAGER	22
5.6 SOUND RECORDER	22
5.7 FM RADIO	22
6. NETWORK	23
6.1 WI-FI	23
6.2 BLUETOOTH	23
6.3 3G SERVICE	
7. SETTINGS	24
7.1SIM MANAGEMENT	

	7.2 WI-FI	.24
	7.3 BLUETOOTH	.24
	7.4 DATA USAGE	.24
	7.5 MORE	.24
	7.6 AUDIO PROFILES	.25
	7.7 DISPLAY	.25
	7.8 STORAGE	.25
	7.9 BATTERY	.25
	7.10 APPS	.25
	7.11 LOCATION	.26
	7.12 SECURITY	.26
	7.13 LANGUAGE & INPUT	.26
	7.14 BACKUP & RESET	.26
	7.15 ADD ACCOUNT	.27
	7.16 DATE & TIME	.27
	7.17 SCHEDULED POWER ON&OFF	.27
	7.18 ACCESSIBILITY	.27
	7.19 PRINTING	.27
	7.20 ABOUTPHONE	.27
8	APPLICATIONS & UTILITIES	
	CALCULATOR	.28
	CLOCK	.28
	CALENDAR	.28
	DOWNLOADS	.28
	GMAIL	.28
	MAPS	.28
	PLAY STORE	.29
	FACEBOOK	.29
	TODO	.29
	YOU TUBE	.29
	GOOGLE SEARCH	.29
	WHATSAPP	.29
	SPICE CLOUD	
		.30

	QUIKR	.30
	ASKME	.31
	SWIFTKEY - THE MIND-READING KEYBOARD	.31
	FLIPKART	.31
	HUNGAMA	.31
	PLAY BOOKS	.31
	PLAY GAMES	.32
	DR. SAFETY	.32
	GAME PLANET	.32
	SPICE GANG	.33
	DOCUMENTS TO GO	.33
9.	SPECIFICATIONS	34
10). SUPPORT AND CONTACT	35

WHAT'S IN THE BOX?

Your package comes with the following items. If any of these is missing, please contact your retailer

- Device
- USB Cable
- Adapter
- User's Manual
- Headset
- Battery
- Flip cover
- Warranty Card
- After Sales Service Center List

1. UNDERSTANDING YOUR DEVICE

1.1 GENERAL INFO

Mi-517 is a multi SIM phone that encloses features, such as **Android version 4.4.2**, **Wi-Fi, BT, 1.3 GHz Quad core Processor, 8GB ROM+1GB RAM ,8.0MP AF back Camera & 2.0MP front camera, etc.** This phone is provided with two SIM slots for two different SIM cards. The SIM card inserted in the slot1 is called Master SIM, and the other one in the slot2 is known as Slave SIM. You can select to operate SIMs as per your personal and professional needs.



1.2 DEVICE OVERVIEW



Position of Keys

1.USB Connector	2. Home Key Headset Connector
3. Front Camera	4. Volume Keys
5.Power Key	6. Speaker
7. Camera	

2. GETTING STARTED

2.1 INSTALLING CARDS &BATTERY

Please switch off your device before inserting or removing the battery/SIM card or memory card.

Installing SIM Card and Battery

Your device is provided with two SIM slots for two different SIM cards. In order to install battery and SIM card in the device, please follow the steps mentioned below:

- Remove the back cover of the device.
- Hold the device with front facing downwards; pull battery cover.
- Insert the SIM cards in the device.
- Attach the battery.
- Push the battery cover until it clicks into place.

Installing Memory Card

Your device supports T-Flash card, which is a multimedia memory card used to multiply the memory of the device. The T-flash card is small and should be pulled out and installed carefully and prudently in order to avoid any kind of damage. Please follow the steps mentioned below to install the memory card in the device:

- Switch off your device.
- Remove the battery cover.
- Slide the T-Flash card into the slot and attach the battery.
- Push the battery cover until it clicks into place.

Charging the Battery

The device prompts a warning tone and message stating insufficient battery when the battery power is low.

Please follow the instructions mentioned below to charge your device:

Plug the connector of the charger into the jack of the device.

Plug the charger into a standard AC wall outlet.

Charging...... Fully Charged......

You must fully charge the battery before using the device for the first time. It is recommended to charge the battery for three hours before using the device for the first time.


2.2 POWERING ON/OFF THE DEVICE

Turning On the Device

After installing the SIM cards and charging the battery, you are now ready to turn on your device.

Long press and hold the Power Key to turn on the device.

- The first screen that appears is known as the home/idle Screen.
- If screen turns off, press the Power Key to turn on the display.



Turning Off the Device

Press and hold the Power Key for 3 seconds > A pop-up window appears, select Power off > Select OK to confirm.

3. BASIC OPERATIONS

3.1 CALLING

To Make Calls


If the icon ______a ppears on the screen, then you can make or receive calls.

To make a call, please follow the steps mentioned below:

Click Enter the phone number using the on-screen keyboard.



- After entering phone number, tap
- To end the call, tap



Answer/Reject an Incoming Call

When you receive an incoming call, a notification message appears on the screen. In order to accept the call, drag towards right. If you wish to reject the call, drag towards left.

Other Options during the call

Manage other voice call features

During a call, please select:

- to mute/unmute the microphone.
- III: to hold the call.
- to open loud speaker.

- add/make another call.
- : use the dial pad.

3.2 MESSAGING

Your device features, sending and receiving of SMS (Short Message Service) and MMS (Multimedia Message Service). Go to Main Menu and then select Messaging.



Creating a Message

- Tap to compose new message.
- In To field; enter the recipient's phone number.
- Type message in the Type message to compose field.
- Tap to Send.

Receiving and Managing Messages

When you send and receive messages to/from a contact, these messages are grouped as a message thread. A message thread looks like an exchanged conversation.

To reply to a text message

- Enter the Main Menu, select Messaging.
- Select a message thread to open it.
- Select Type message to enter your message.
- Click > to Send.

MULTIMEDIA MESSAGE


A Multimedia message or MMS can contain letters, an image, an audio or video file. To create and send a MMS, please follow the steps mentioned below:

- Enter the Main Menu, select Messaging and select
 Add subject; In the To field, enter the recipient's phone number or email address and enter the Subject.
- To insert text, tap Type message, and then enter your message. Tap
 to insert a picture or video file and so on



3.3 CONTACTS

This function helps you browse through the phonebook of your device.



To add a Contact


- From the Main Menu select Phone.
- Enter number > select add new contact.
- Select the storage.
- You can enter contact information such as name, phone number, email address etc, if you select storage as "Phone".
- Tap Done to save the contact.


Tip: Or from the main menu select People, tap to create New contact.

To import contacts

- From the main menu select People.
- Import/Export.
- Select to import contacts from Phone storage/Phone contact/ SIM Card/ SD Card.
- Select source to import the contacts from.
- Select Next.
- Select the destination, such as Phone to copy contacts to.

- Select Next.
- Select all to import all contacts or select mark the required contacts and select Ok





3.4 EMAIL

Your device allows you to compose, read and send emails.

Setting up an Email Account

- Enter the Main Menu, tap Email.
- Enter your Email address and Password.
- Tap Next. The device will automatically retrieve email settings.
- Enter Name and Account display name.
- Tap Next.

3.5 BROWSER

Browser is a tool which enables you to access the Internet.

To open a web page

- From the Main Menu, select a Browser.
- Tap the address bar.
- Type the URL and select Go.
- Tap to access more functions, such as bookmarks, history and other browser related settings.

To scroll the page

- Use finger gestures to scroll up or down.
- To scroll left or right, tap and swipe your finger towards right/left.


4. HOME SCREEN

From Home screen, you can quickly access common features, view notifications of missed calls, received messages and check connection status.



4.1 STATUS BAR

The Status bar icons indicate different types of information. The table below lists various icons that might appear on the status bar of the device.



4.2 CUSTOMIZING SCREEN

The device features a touch screen with idle displays and access to utilities at just one-touch. So swipe right or left to navigate through various screens accessing your favorite features.

Your device offers various options to customize the look and display of your device. In the idle screen long press to choose from various options:

- Wallpaper
- > Style
- Widgets

5. MULTIMEDIA

Your device features various multimedia options, such as Camera, File Manager, FM Radio, Gallery, Sound Recorder, Music Player and Videos.


5.1 MUSIC PLAYER

Use the Music player to play music files. The songs saved in your SD Card can be played

using the Music Player of the device.

Select Music from the screen

The songs are categorized by Artist, Albums, Songs and Playlists. You can make your favorite playlist by long pressing on a song and selecting Add to Playlist.



5.2 CAMERA

Your device is equipped with camera and camcorder, which enables you to capture photos and videos.



Capturing an Image

Select Camera.

Aim the phone at the subject, then to take the shot.

Capturing a Video

Select Camera. Aim the phone at the subject.

To start recording, select

To stop recording, select

5.3 VIDEOS

You can view/play your videos stored on your SD Card through the Videos.

5.4 GALLERY


You can view the captured images, recorded video clips, and downloaded images in the Gallery. Both picture folder and video folder will be displayed, images or videos will be displayed in thumbnails.

5.5 FILE MANAGER

You can browse, open and manage the data saved in the Device and Memory card by accessing the File Manager sub-menu. The device provides a certain space for users to manage files and supports the T-Flash card. You can use the file browser to conveniently manage various directories and files on the T-Flash card.

5.6 SOUND RECORDER

You can use the sound recorder to record sounds and also select to save the recordings in your phone.



5.7 FM RADIO

You can use your phone to listen to FM radio stations once the original headset is plugged into the connector. Please press the side key to adjust the volume.

6. NETWORK

6.1 WI-FI

Connect to a wireless network to browse Internet.

- Enter Main Menu and tap Settings.
- Tap 'ON' to activate Wi-Fi.
- Tap Wi-Fi> Network notification to start detecting networks. The available networks will then be listed.
- Tap add network icon to add a connection.

Note:

- If the device before the connection is successful, the equipment information will be saved in the pop-up window selected connection, select forget to remove device information.
- If the device does not encrypt selected connection in the pop-up window to connect.
- If the device is encrypted, the pop-up window will appear, enter the password.
- Network connection is successful; the status bar icon appears Wi-Fi connection.

6.2 BLUETOOTH

You can transfer data, such as music to other device using Bluetooth. Search the device and accept/transfer data. The received data is automatically stored in the directory.

- Enter Main Menu and tap Settings
- Tap 'ON' to activate Bluetooth

6.3 3G SERVICE

3G network offers high quality equivalent to that of fixed networks under global standard radio interfaces and can provide a wide range of services. In addition to making

it possible to easily communicate with anybody, anywhere and anytime on a global scale, it also permits high-speed, large-volume data communications and image transmissions. Your device supports 3G network, also HSPA/HSPA+. You can choose preferred network. Set steps:

Setting>>wireless & networks>>more>>mobile networks>>3G
 service>>enable 3G/network mode

7. SETTINGS

Select Settings to view and adjust the settings of your device. The Settings menu is categorized into following categories:

7.1SIM MANAGEMENT

Your device supports two SIM cards, which can be managed by accessing the SIM Management sub-menu. You can view/change the roaming settings of the cards using this menu.

7.2 WI-FI

Access this sub-menu to change/view the Wi-Fi settings. Please refer to network section for detailed information on Wi-Fi and bluetooth.

7.3 BLUETOOTH

Access this sub-menu to change/view the Bluetooth settings. Please refer to network section for detailed information on bluetooth.

7.4 DATA USAGE

Access this sub-menu to view the Data usage of your device.

7.5 MORE

Access this sub-menu to change/view settings related to Airplane mode, default SMS

app, tethering & portable hotspot, VPN, mobile networks and USB Internet.

7.6 AUDIO PROFILES

Your device provides four pre-defined user profiles that allow the operations of the device to best suit the environment you are in. The profiles are General, Silent, Meeting and Outdoor.

7.7 DISPLAY

With this function you can configure the display characteristics of the device including brightness, auto-rotate screen, day dream etc.

7.8 STORAGE

View and manage the data storage of your device:

- Total Space and Available Space: Lists the amount of space on the micro SD card installed in your device and the amount you have used to store photos, videos, music, and other files.
- Un-mount SD Card: Un-mounts the micro SD card from your device so that you can format the card or safely remove it when the device is on.
- Available Space: The amount of internal phone storage used by the operating system, its components, applications (including those you downloaded), and their permanent and temporary data.

7.9 BATTERY

You can check the battery status of the device by accessing this sub-menu.

7.10 APPS

This sub-menu enables you to manage all the installed, running and applications saved in the device memory and SD card. You can remove and manage installed applications, view and control running applications, allow installation of non-Spice build in market

7.11 LOCATION

The settings related to location can be configured using this sub-menu.

7.12 SECURITY

You can protect your device from unauthorized users by setting the PIN code or entering a password.

Setup Screen Lock

You can set up a lock for your screen in form of Pattern, PIN code or password.

- Go to Settings > Security
- Set up screen lock
- Select a desired form (Slide, Pattern, PIN, Voice Unlock, Face Unlock, password)

Enable or Disable SIM card PIN

When PIN code is enabled, you are required to enter the PIN code before making a call.

- Go to Settings > Security.
- On the SIM card lock tab, select Set up SIM card lock.
- Select a SIM card.
- Use PIN to Lock SIM card. Click to enable/disable.
- Enter the current PIN code.
- To change the PIN code, select Change PIN.
- Enter the old PIN code.
- Enter the new PIN code and confirm.

7.13 LANGUAGE & INPUT

Use the Language &input settings to select the language for the text on your device and for configuring the onscreen keyboard, including words that you've added to its dictionary.

7.14 BACKUP & RESET

You can use the Privacy settings to manage your personal information, such as backup of the data, automatic restore and factory date reset.

7.15 ADD ACCOUNT

Use this function to add, remove, and manage your Google and other supported accounts. You also use these settings to control how and whether all applications send, receive, and sync data on their own schedules, and whether all applications can synchronize user data automatically.

7.16 DATE & TIME

You can select to set date, time and time zone using this sub-menu.

Use Automatic unless you need to override the network values.

Use 24-hour format: Select to set 24-hour formats on or off.

Select Date format: Select from a variety of formats.

7.17 SCHEDULED POWER ON&OFF

You can set the time for auto power on /off. Do turn the status on before using that function, and then the time.

7.18 ACCESSIBILITY

You can use the Accessibility settings to configure any accessibility plug-ins you have installed on your device.

7.19 PRINTING

You can enable or disable the cloud print.

7.20 ABOUTPHONE

You can view system information Including System updates, Status, Battery use, Legal

8. APPLICATIONS & UTILITIES

For your entertainment purpose, your device is provided with several interesting games, applications and utilities. Please ensure that you have GPRS setting in your device to access the applications. Contact your operator for GPRS settings.

CALCULATOR

Calculator helps you perform basic arithmetic functions, such as addition, subtraction, multiplication and division.

CLOCK

The clock function gives you an access to alarm clock.

Select Clock from the screen

Select from the various options available, select Alarm

CALENDAR

This phone supports Calendar. You can view calendar or edit an event using it.

DOWNLOADS

In this application, you can view your downloads, e.g. audios/ Videos/pictures/ applications, you can re-download and cover these files.

GMAIL

Gmail is Google's web-based email service. Google Mail is configured when you first set up your device. Depending on your synchronization settings, Google Mail on your device is automatically synchronized with your Google Mail account on the web.

Go to Gmail. Select Create or Sign in your Google account.

Follow the on screen instructions to login or create your Gmail username and password. Once logged in, you can begin reading and sending emails from your Gmail account.

MAPS

Maps is a Google's mapping service to search for places of interest.

PLAY STORE

Play store allows you to find and download applications and fun games for your device.

Go to Play Store and setup your Google account.

Select Create to create a new account or Sign in to sign in your existing account.

Once you are signed in you can begin searching and downloading programs from the market. Tap Apps to view the list of applications available and tap Games to view the list of games available.

FACEBOOK

Facebook is a very popular social networking site around the world giving people the power to share and make the world more open and connected. Millions of people use Facebook every day to keep up with friends, uploads an unlimited number of photos, share links and videos, and learn more about the people they meet. Please ensure that you have GPRS settings in your device to open Facebook. Contact your operator for GPRS settings.

TODO

You can add tasks to your Todo list, so that you don't miss out your important work. It is a convenient way to list down your vital tasks.

YOU TUBE

YouTube is an online video streaming service that allows you to view, search, and upload videos.

To start using YouTube

Tap the Application Tab to enter Main Menu > Select YouTube.

Videos are grouped into various categories. Tap a category to see the available videos for that category.

GOOGLE SEARCH

The best of Google in one app. Say "Ok Google" and find everything from nearby restaurants to the calories in cheesecake. Google also shows you the info you need before you ask, like updates on your favorite teams and traffic alerts. Google now automatically gives you the information you need throughout your day.

WHATSAPP

The application and enjoy chatting with your friends and colleagues over network. This messenger is a smart phone messenger which allows you to enjoy unlimited conversations Download the latest version of WhatsApp by clicking the WhatsApp Downloader and chat with your friends anytime anywhere. It is a third party network based application; please contact your operator.

SPICE CLOUD

Spice Cloud" provides Spice end user with Cloud Backup and seamless access to your Photos, Documents, Media Files and Contacts across your Devices along with advanced Security and anti-theft features. User can access them all using the web interface at www.spicecloud.in. The key features of Spice cloud are:

- 2GB free back-up space and user can extend the limit as per their requirement.
- Multiple device sharing option.
- Backup all your content onto Secure Cloud based Server and store them for eternity.
- Real time data synchronization across devices.
- Track down your device remotely.

PLAY MUSIC

Google Play Music makes it easy to discover, play and share the music you love. It also allows you to listen to your music collection anywhere. All your music is stored online, so no need to worry about syncing, storage space or offline playback.

OLX

Start using the #1 Free Classifieds App!!! The best way to buy and sell 'on the go' and in your local area. OLX allows you to easily post your ads for free and search for classified ads in your local area. Whether it is a flat screen TV, mobile phones, electronics, used cars, an apartment to rent, or a second-hand piece of furniture, OLX provides you with millions of buyers and sellers to connect to, all for free!

QUIKR

Quikr is one of best local classifieds app which will help to buy, sell, rent or find anything! Either finding the perfect job near your home, rent/ buy apartments, find tuition classes etc. Even you can post a free ad in less than a minute & sell your stuff - phones, antiques, baby stuff, furniture, cars/bikes, etc.

ASKME

Ask me is a convenient and intuitive interface to find nearest restaurant, hotel, coffee shop, ATM, mall, movie theatres and cinema apart from other entertainment options across local events in your own locality. It also comes with FREE FRESH and HOT DEALS across different cities in India.

SWIFTKEY - THE MIND-READING KEYBOARD.

It's a touchscreen keyboard for your Android <u>smartphone</u> with one that provides accurate <u>autocorrect</u> and predicts your next word before you press a key. SwiftKey learns as you use it to make corrections and predictions based on the way that you write. Apart it supports various language and themes you can download the same from the option available under Swiftkey setting.

FLIPKART

Flipkart Android app makes you enjoy shopping from anywhere, at any time. Now make your shopping simple and delightful. Get the best deals and discounts on your favorite products ranging from clothing to books and many more.

HUNGAMA

Explore all of Hungama's music library of 2 million+ official songs spread across Bollywood, Tamil, Telugu, Malayalam, Punjabi, Devotional, Regional music and Popular International music and videos. Apart download wallpapers, follow your favorite celebrities, latest Bollywood news. There are 5 free download worth Rs 50.

PLAY BOOKS

With Google Play Books for Android start reading today with millions of titles from Google Play on your Phone. Take your favorite books with you on the go and personalize your reading experience. Shop books in your browser on Google Play. Great Reading Experience within the book, Change font, search information about book (archive books reading) Manage your library after Night-reading mode offline Read books Voice Over support Discover Millions of Titles Google Play on books Millions of free available instantly

Free preview pages Unlimited storage of books in the digital cloud Worry-free archive Google Play **Syncs** With Your books library Access all your books wirelessly from the digital cloud - Automatic page position syncing across devices -- pick up reading where you left off.

PLAY GAMES

The Google Play Games app is the easiest way for you to discover new games, track achievements and scores, and play with friends around the world.

DR. SAFETY

Protect your privacy, find your phone or tablet when you lose it, improve your Facebook privacy and identify malicious apps that steal your info including fake banking apps. Dr. Safety provides 100% detection according to AV-TEST and is also certified by PCSL and AV-Comparatives.

- -- Virus Scanner scans all of your apps and files to ensure they are not malicious
- -- Privacy Scanner identifies which apps collect and steal your personal info using the Trend Micro Smart Protection Network
- -- Safe Surfing blocks malicious websites including phishing and fake bank sites
- --Lost Device Protection finds your device back when you have lost it
- -- Call & Text Blocking blocks unwanted contact with whitelists and blacklists of phone numbers

All of the above help filter applications for your protection. You no longer need to worry about personal data's being stolen. Dr. Safety efficiently clears malicious mobile applications off your phone. More importantly, with the in-app security certified apps recommendation platform. It also allows you to download apps with confidence and play recommended games and utilities without worries.

GAME PLANET

Game planet is a spice gaming portal, which lets you access the world of interesting and exciting games. Please ensure that you have GPRS setting in your device to access the applications. Contact your operator for GPRS settings. Features:

- One stop solution for ALL gaming needs.
- Clear categorization for easy access to Game genre in which users are interested.
- It provides an extensive selection of new games for all ages and is geared to deliver complete Customer satisfaction.
- Easy User Interface.
- Game Content gets refreshed on frequent basis.
- Notify users with new games available.

Note: charges applicable.

SPICE GANG

SpiceGang has different content categories from where you can download wallpapers, play GPRS games, get sports update, connect to your friends and do much more. All services within Spice Gang are GPRS based services. Please contact your operator for GPRS settings.

DOCUMENTS TO GO

This application allows you to view various files on your device. Just save your document in the memory card and view those through Documents To Go application.

9. SPECIFICATIONS

Screen (FWVGA)	12.7cm IPS
Battery	3000mAh
Dimensions	147.3*73.8*9.8mm
Weight	120g
Band	GSM900/1800 WCDMA2100
Standby Time	300h
Maximum Talk Time	8h
Power Adapter	90-380V, 5V-1A

^{*} The standby time and maximum talk time depend upon the network signals and settings.

10. SUPPORT AND CONTACT

You can visit www.si2imobility.com/spicemobiles for additional information, downloads and services related to your Spice handset. For further assistance or queries, you can call on SPICE customer helpline number 18602001003 or mail at customercare@smobility.in or product@smobility.in.

Note :After sales service of the device is confined to the country in which the purchasing is done.

Help us save Our Environment...GO GREEN..!!

All our endeavors are directed towards providing environment friendly products to you. The materials used in our devices are recyclable and can be reused to make new products. We strive to make products that are safe for our consumers as well as the environment. Come join hands with us and make world a better place to live.

Preserve natural resources for future generations by recycling your phone. The phone contains some metals, when recycled properly; these can be put back into circulation, decreasing the need for new metal mining. Recycling reduces the need for raw materials, saves energy, helps mitigate Global Warming and reduces pollution, reduces waste products in landfills; therefore preserving natural resources for the future and saving the planet.

Follow some simple steps and contribute towards saving the planet.

DOs

Recycle your handset and its accessories.

To protect natural resources and to promote re-use of the material, kindly separate batteries from other type of waste.

DONTs

Do not dispose off your mobile and its battery in fire.

Do not dispose your mobile with the regular waste.

Do not over charge your handset. Remove the charger when battery is full.

Don't trash your phone, instead RECYCLE it



This logo signifies that this product and/or its constituents should not be disposed off with other household waste.

Hazards of Improper handling, accidental breakage, damage and /or improper recycling of hazardous elements

If this product is improperly handled, broken or damaged or carelessly recycled or disposed off in the fire, can result in environmental and data security concerns, including the following:

- Affect nearly every system in the human body and result in birth defects, brain, heart, liver, kidney and skeletal system damage. They will also significantly affect the nervous and reproductive systems of the human body;
- When burned, create cancer-producing dioxins which are released into the air we breathe; If thrown in landfills, may leach into groundwater affecting your local community;
- In warm climates, the oxidation of mercury in the environment can be accelerated, leading to the creation of oxidized Hg atoms that are known to be associated with ozone depletion; and Improper recycling additionally results in data security issues, as private electronic information remains on hard drive, if not properly removed before disposal.

How to Recycle

Please get your electronics products recycled only through authorized recyclers, approved by Pollution Control Board. We provide facility of recycling of our products. For details of our collection centers, please visit our website or call our customer care. Help us to GO GREEN.

Constitution of Hazardous Elements in your Device:

Your device does not contain the following hazardous elements in a proportion higher than the limits provided hereunder: maximum concentration value of 0.1% by weight in homogenous materials for lead, mercury, hexavalent chromium, polybrominated biphenyls and polybrominated diphenyl ethers; and maximum concentration value of 0.01% by weight in homogenous materials for cadmium.