

User Manual

LAVA Flair E1

Exciting Features

Congratulations on becoming a proud owner of the Flair E1 Android mobile phone. You have now joined the millions of satisfied customers spread across the Globe. Your Flair E1 device offers you these exciting features and much more:

- Android 4.4.2
- 3.5 inch HVGA Screen
- Cameras (front VGA and back 2MP)
- 1.0 GHz Processor
- 512MB ROM +256 MB RAM
- External Memory(Expandable to 32GB)

INTRODUCTION

Thanks for choosing our Android smart phone. If you'd like your phone to live a long and fruitful life, please read this guide carefully and keep it for future reference. You never know when you might need it.

And don't worry if the pictures we use to demonstrate your phone's functionalities look a little different from what you see on its screen. It's the functions that matter.

Disclaimer

Lava Mobiles reserves all the rights to change the specifications and the content of this product without any prior information.

Some contents and services accessible through this device belong to third parties and are protected by copyright, patent, trademark and or other intellectual laws.

Third Party services may be terminated or interrupted at any time. We do not bear any responsibility or authority for the warranty or usage of these applications.

Never attempt to disassemble your phone. You alone are responsible for how you use your phone and any consequences of its use.

Table of Contents

Disclaimer	3
1 .Safety	5
1.1 Safety Precautions	5
1.2 Using your phone safely	5
2 .Understanding your Phone	9
2.1 Your Phone	9
2.2 Description Icons	10
2.3 Charging the battery	10
2.4 Power ON/OFF	11
2.5 Enter Main Menu	11
2.6 Enter Sub Menu	11
2.7 Use Notification Panel	11
2.8 Expand Main Interface	12
2.9 Add icons on the main interface	12
2.10 Move icons on the main interface	12
2.11 Delete icons on the main interface	12
2.12 Change wallpapers	12
2.13 Install APK through File Manager	13
3 .Using your Phone	13
3.1 Main Menu & Its Functions.....	13
3.2 Wi-Fi	17
4 .Inputting Text	18
5 .Maintenance	18
6 .Taking Care of your Device	19
7 .LAVA Warranty Certificate	21

1. Safety

1.1 Safety Precautions



Please read through the following briefings carefully, and act in accordance with these rules, so as to prevent causing any danger or violating any law.

--Your mobile phone model has been designed to comply with applicable safety requirements for exposure to radio waves. The radio wave exposure guidelines employ a unit of measurement called Specific Absorption Rate (SAR). The recommended SAR limit for mobile handset is 1.6 Watt/Kg averaged over a period of 6 minutes and taken over a volume containing 1g of human tissue.

--Use your cell phone when the signal strength is good. Keep your calls short or instead use headset or send a text message. This advice applies especially to children, adolescents and pregnant women.

--If you are using a Bluetooth headset device, please make sure it has a low power emitter.

1.2 Using your phone safely



On The Road

Using phone while driving is illegal in many countries. Please follow local laws and drive safely at all times.



Near Sensitive Electronics

Don't use your phone near sensitive electronic equipment, particularly medical devices such as pacemakers as it could cause them to malfunction. It can also interfere with the operation of fire detectors and other automatic-control equipment.

For more information about how your phone affects pacemakers or other electronic equipment, please contact the manufacturer or your local distributor.

Your phone may cause interference when used near TV, radio or automated office equipment.



While Flying

Your phone can cause interference with aircraft equipment. So it's essential you follow airline regulations and if airline personnel asks you to switch off your phone, or disable its wireless functions, please do as they say.



In Hospital

Your phone may interfere with the normal operation of medical equipment. Follow all hospital regulations and turn it off when you're asked to by posted warnings or medical staff.



At a Petrol Station

Don't use your phone at petrol stations. In fact, it's always best to switch off whenever you're near fuel, chemicals or explosives.



Around Water

Keep your phone away from water (or any other liquid). It's not a waterproof model.



Making Repairs

Never take your phone apart. Please leave that to the professionals. Unauthorized repairs could break the terms of your warranty.



Broken Antenna

Don't use your phone if the antenna is damaged as this may cause injury.



Around Children

Keep your mobile out of children's reach. It should never be used as a toy and it might not be good for their health.



Original Accessories

Only use the original accessories supplied with your phone or those approved by the manufacturer. Using unapproved accessories may affect performance, void the warranty, break national regulations or even cause injury.



Near Explosives

Turn off your phone in or near areas where explosive materials are used. Always obey local laws and turn off your phone when requested.



Emergency Calls

To make an emergency call your phone must be turned on and must be in an area where there's network

coverage. Dial the national emergency number and press 'SEND'. Explain exactly where you are and don't hang up until help has arrived.



Working Temperature


The working temperature for your phone is between 0 Degree and 40 Degree Celsius. Please don't use the phone outside the specified range. Using the phone under extreme temperature conditions might cause problems.















At very high volumes, prolonged listening to a mobile phone can damage your hearing.

2. Understanding your Phone

2.1 Your Phone



2.2 Description Icons

Icons	Descriptions	Icons	Descriptions
	Shows the network signal strength		Shows the phone's battery capacity
	Speaker has been activated		You have unread SMS
	Call on hold		USB storage is turned on
	The ringing type is set on Vibration		Flight Mode
	Wi fi is ON	E	Data network in use
	You have missed calls		Alarm is active
	On call		

2.3 Charging the battery

The rechargeable Li-polymer battery that comes with your phone is ready to be used, but is not charged. It is easy to do so & can be done in 4 simple steps below:

1. Connect the charger to your phone, and plug the charger into a socket.
2. The battery indicator in the corner of the screen will scroll to show you that it's charging.
3. When fully charged, the battery indicator will stop scrolling.
4. Disconnect the charger from your mobile and unplug.

2.4 Power ON/OFF

Press the power key to power ON/OFF the phone.

When you turn your phone on, it'll automatically check the SIM and show the following information on screen:

- **Input SIM1 PIN:** If you've set a PIN for your SIM1.
-

Note:

The PIN is supplied with your SIM. Please replace it with your own PIN code as soon as possible. Enter the wrong PIN three times, and your SIM will be locked. Then you'll need to contact your network service provider to ask for a PUK code to unlock it. It is applicable for both the SIMs if you are using 2 SIM Cards.

2.5 Enter Main Menu

In Idle mode, press the Menu key to enter the main menu on the desktop and click the Home key to return.

2.6 Enter Sub Menu

Once at the main menu, click the icon to select the submenu. Press **Back Key** to return to the previous menu and press the **Home Screen** to return to the home screen.

2.7 Use Notification Panel

As a new notification appears in the notification area, slide down in the area to view the contents of the notification.

2.8 Expand Main Interface

The main interface may extend and exceed the screen width to provide more space for newly added shortcuts and tools.

Slide your finger horizontally on the main interface to extend to the left or right area of the main interface.

2.9 Add icons on the main interface

Long press the icon on the main menu until it's enlarged and the mobile phone vibrates and copies the icons on the main menu to the main interface.

2.10 Move icons on the main interface

1. Long press the icon on the main interface until it's enlarged.
2. Drag the icon to the desired position and then release it.

2.11 Delete icons on the main interface

1. Long press the icon on the main interface until it's enlarged.
2. Drag the icon to "REMOVE" to delete it.

2.12 Change wallpapers

1. Long press "Touch screen" to open the menu.
2. Choose "WALLPAPERS"
3. Choose from "Gallery /"Live Wallpapers"/ "Wallpapers", and Select the wallpaper and press "Set Wallpaper" to complete.

2.13 Install APK through File Manager

APK is a supported file format for the Android mobile operating system.

1. Please copy the downloaded APK file into the SD card, and then insert the SD card into the phone.
2. In Idle mode, click Main Menu to enter the main menu.
3. Click “File Manager” to enter the directory of SD card.
4. Click the APK file you wish to install, and follow the installation wizard.

3. Using your Phone

3.1 Main Menu & Its Functions

Single press on main menu icon allows you to view a list of features available with your phone-

1.Clock

Allows you to set the Alarm from Clock.

2.Browser

Allows you to browse the internet.

3.Calculator

Allows you to make tedious calculations quickly.

4.Calendar

View the calendar & add events.

5.Camera

Allows you to click pictures anytime you want. Your smart phone has High Definition Camera which ensures you

always click good quality pictures.


Pictures are stored in the Gallery folder. In Camera, easily choose Camcorder mode to record Video Files.

6.Contact

Allows you to see your list of Contacts. Access phonebook through this function.

7.Gmail

Allows you setup your gmail account.



8.Gallery


Allows you to view photos & videos.

9.Play Store

Log in to your Gmail account to view all the applications & download from lakhs of applications available under the Google Market called Play Store.

Note:

The application downloads and installations are strictly restricted to the memory availability of the phone. The applications exceeding the memory limits are not supported in the device.



Note:


To use this app please connect to an internet connection.

10.Messaging

Allows you to view sent and received messages as a thread.

11.Music

View the list of songs available on your phone. View the artists, albums, playlists & more.



12.Phone

Allows you to make quick outgoing calls.

13.File Manager

You may install the files in APK format & also view your files.

14.Settings

Modify settings under the following-

- Wi-Fi
- Bluetooth
- Dual SIM setting
- Data Usage
- More
- Audio profiles
- Display
- Storage

- Battery
- Apps
- Location
- Security
- Language & Input
- Backup & Reset
- Add account
- Date & Time
- Accessibility
- Printing
- About phone

15.SIM Toolkit

This service is provided by the operator. It provides many types of personalized message services.

16.Sound Recorder

Allows you to record sounds.

3.2 Wi-Fi

Your Smart Phone supports Wi-Fi which allows you to connect to a Wireless connection. This is useful for surfing internet on phone

- a. Enter "Settings" interface & search Wi-Fi available networks. Select the network you want to connect to.

4. Inputting Text

Intelligent keyboard

Your smart phone automatically corrects and suggests words as you type.



Cut, Copy and Paste

Touch and hold text content to bring up the magnifying glass. Then slide your finger to move the insertion points. Choose to cut, copy, or paste. It is very easy to copy text from web pages, email, or text messages.

5. Maintenance

Use a dry soft cloth to wipe general dirt.

Do not use hard cloth, benzene or thinner to wipe the phone otherwise the surface of the phone will be scratched or could even result in fading of color.

6. Taking Care of your Device

Your device is a product of superior design and craftsmanship and should be handled with care: The following suggestions will help you protect your phone:

- Always keep small parts of the phone away from children.

- Keep the device dry. Precipitation, humidity, and all types of liquid or moisture can contain minerals that will rust electronic circuits. If your device gets wet, remove the battery, and allow the device to dry completely before replacing it.

- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.

- Do not store the device in extreme high or low temperature. High temperatures can shorten the life of electronic devices and damage batteries.

- Do not attempt to open the device other than as instructed in this guide.

- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.

- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device.

- Do not paint the device. Paint can clog the moving parts and prevent proper operation.

- Use indoor chargers.

E-Waste Management:

Recycle Your Handset



The WEEE logo (shown at the left) appears on the product (battery, handset, and charger) to indicate that this product must not be disposed of or dumped with your other household wastes. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling of such hazardous waste.

Specified collection points for recycling of such hazardous waste. Collection and proper recovery of your electronic waste equipment at the time of disposal will allow us to help preserve the environment. Recycling of the electronic waste equipment will ensure safety of human health and environment. For more information on best practices for disposal of electronic and electrical waste, please visit to our web site: www.Lavamobiles.com

Customer Care Support

Check www.lavamobiles.com web site for additional information, downloads, and service related to your LAVA product.

Lava Customer Care Service**No:1860-200-7500****10.00AM till 7.00PM available on Monday to Sunday**

7. LAVA Warranty Certificate

Limited warranty:

LAVA international Ltd. (LAVA) provides limited warranty for your mobile phone and original accessories delivered with your mobile phone (hereinafter referred to as “product”)

The warranty period for the transceiver is one (1) year and for battery, charger and headset is six (6) months from the date of purchase.

LAVA warranty:

Subject to the conditions of this Limited Warranty, LAVA warrants a product to be free from defects in design, material and workmanship at the time of its original purchase by you, and for a subsequent period of one (1) year for transceiver and six (6) months for battery & charger.

You shall have no coverage or benefits under this warranty in the event that any of the following conditions are applicable:

- 1.The product has been subjected to abnormal use or conditions, improper storage, exposure to excessive moisture or dampness, exposure to excessive temperature, unauthorized modification, unauthorized repair (including but not limited to use of unauthorized spare parts in repairs), abuse, accidents, Acts of God, spills of food or liquids, improper installation
- 2.You have not notified Lava of the defect in the product during the applicable warranty period.
- 3.The product serial no. code or the accessories date code has been removed, defaced or altered.
- 4.The product has been used with or connected to an accessory (i) Not supplied by Lava or its affiliates, (ii) Not fit for use with the product or (iii) Used otherwise

than in manner intended.

5. The seals of the battery enclosure have been broken or shown evidence of tempering or the product's battery has been used in equipment other than that for which it has been specified usable by LAVA.

6. All plastic surfaces and all other externally exposed part that is scratched or damaged due to normal use.

To get maximum of your new product, we recommend you to:

- Read the guidelines for safe and efficient use as mentioned in the manual.
- Read the terms and conditions of your Lava warranty in the manual.
- Keep your original receipt; you will need it for warranty services if asked to produce.
- Present this Lava Warranty Certificate along with original proof of purchase whenever you require any warranty services.

In case Lava product needs service, please visit the nearest Lava service centers given in the service guide. Please visit our Website