


spice

Registered Office: Spice Retail Ltd., S Global Knowledge Park,
19A & 19B, Sector - 125, Noida - 201 301, U.P.
E-Mail: customercare@smobility.in
Customer Helpline Number: 1860 200 1003

spice

User Manual



X LIFE 512


ALL RIGHTS RESERVED

Spice Retail Ltd ©2014. All rights are reserved. No part of this document can be reproduced without permission. All trademarks and brand names mentioned in this publication are property of their respective owners. While all the efforts have been made to ensure the accuracy of contents in this manual, we presume no responsibility for errors or omissions or statements of any kind, whether such errors are omissions or statements resulting from negligence, accidents, or any other cause.

We operate a policy of continuous development and reserve the right to make changes, modifications and improvements to the device, device features/specifications or any of its parts without prior notice. Your device may have preinstalled bookmarks and links for third party internet sites and may allow you to access third party sites. These are not affiliated with Spice, and Spice does not endorse or assume liability for them. If you access such sites, take precautions for security or content.

The limited warranty does not cover user manuals or any third party software, settings, content, data or links, whether included/downloaded in the product, whether included during installment, assembly, shipping or any other time in the delivery chain or otherwise and in any way acquired by you.

To the extent permitted by applicable law(s), Spice does not warrant that any Spice software will meet your requirements, will work in combination with any hardware or software applications provided by a third party, that the operations of the software will be uninterrupted or error free or that any defects in the software are correctable or will be corrected.

 ***User's Manual is provided just to guide the user about the functionality of the device. This does not seem to be any certificate of technology. Some functions may vary due to modifications and up-gradations of software or due to printing mistake.***

SAFETY PRECAUTIONS

Please read the following safety guidelines before using the device.

- Do not use the phone while you are driving.
- Do not place magnetic storage media near your phone. Radiation from the phone may erase the information stored on them.
- Keep your phone and its accessories away from children.
- Mobile phones can interfere with the functioning of medical devices such as hearing aids or pacemakers. People having active medical implants should keep their cell phone at least 15 cm away from the implant.
- Permanent hearing loss may occur if you use earphones or headphones at high volume.
- Use a wireless hands-free system (headphone/ headset) with a low power Bluetooth emitter.
- Keep your calls short or send a text message (SMS) instead. This advice applies specially to children adolescents and pregnant women.
- Use cell phone when the signal quality is good.

Notice:

- Do not dismantle the device or accessories otherwise, manufacturer is not liable to pay for damages as the device and accessories are not covered by warranty.
- Use only original batteries and charging devices.
- Please back up your important data timely and keep them properly. The company is not liable for any failure to call or loss of data due to mis-operation, poor signal or power cut, etc.
- All the screens in this manual are for reference only, and some contents actually displayed may depend upon the presetting of the service provider or the network operator, or the SIM card. If any functions referred to in this manual are different from those of your device, please follow your device.

- Do not put use it in a place with flammable gas such as a petrol pumps. The temperature recommended for using the device is 5–35°C. Do not touch the charger, power cable or socket with wet hands. This may cause an electric shock.



If your phone or any of its accessories do not function normally, then please visit your nearest authorized service facility. The qualified personnel will assist you, and if necessary, will arrange for the service.

Myths and Facts

- Various Myths about Mobile Handsets & Mobile base stations:
- Myth – Mobile phone use cause headaches.
- Fact – Headaches are not related to Mobile phone use and there is no scientific evidence.
- Myth– It is safer using a mobile phone in a car as the car shields from the radiation.
- Fact – The RF radiation is increased by Mobile phones when used in a car to overcome the shielding.
- Myth– Mobile phones cause brain cancer to the people who use it.
- Fact – There is no scientific evidence that Mobile Phone can cause brain cancer.
- Myth – Nobody is investigating the health effects of RF radiation.
- Fact – The World Health Organization, many national & international organizations and independent expert groups are coordinating to investigate health effects of RF radiation.

SAR (Specific Absorption Rate)

Your device conforms to the Indian guidelines for exposure to radio waves. The limits are given in terms of a unit referred to as the Specific Absorption Rate (SAR), which is a measure of the amount of radio frequency energy absorbed by the body when using a mobile phone. The SAR value as per the Indian guidelines standard is 1.6 Watts per kg (Watt/kg), averaged over a 6 minutes period and taken over a volume containing a mass of 1 gram of human tissue. The highest SAR value of this device when tested is **0.663Watt/kg.**

TABLE OF CONTENTS

ALL RIGHTS RESERVED.....	1
SAFETY PRECAUTIONS	2
TABLE OF CONTENTS.....	4
WHAT'S IN THE BOX?.....	7
1. UNDERSTANDING YOUR DEVICE.....	7
1.1 GENERAL INFO	7
1.2 DEVICE OVERVIEW	8
2. GETTING STARTED	8
2.1 INSTALLING CARDS & BATTERY	8
2.2 POWERING ON/OFF THE DEVICE	10
3. BASIC OPERATIONS	11
3.1 CALLING	11
3.2 MESSAGING	12
3.3 CONTACTS.....	14
3.4 EMAIL	16
3.5 BROWSER	16
3.6 FLIP COVER	17
4. HOME SCREEN	18
4.1 STATUS BAR.....	18
4.2 CUSTOMIZING SCREEN	19
5. MULTIMEDIA.....	20
5.1 MUSIC PLAYER.....	20
5.2 CAMERA.....	21
5.3 VIDEOS	22
5.4 GALLERY	22
5.5 FILE MANAGER	23
5.6 SOUND RECORDER	24
5.7 FM RADIO	24
6. NETWORK.....	25
6.1 WI-FI.....	25
6.2 BLUETOOTH	25
6.3 3G SERVICE	26
7. SETTINGS	26
7.1 SIM MANAGEMENT	27

7.2 WI-FI.....	27
7.3 BLUETOOTH.....	27
7.4 DATA USAGE.....	27
7.5 MORE.....	27
7.6 AUDIO PROFILES.....	27
7.7 DISPLAY.....	27
7.8 POWER SAVING.....	28
7.9 STORAGE.....	28
7.10 BATTERY.....	28
7.11 APPS.....	28
7.12 LOCATION.....	28
7.13 SECURITY.....	29
7.14 LANGUAGE & INPUT.....	29
7.15 BACKUP & RESET.....	29
7.16 ADD ACCOUNT.....	30
7.17 DATE & TIME.....	30
7.18 SCHEDULED POWER ON&OFF.....	30
7.19 ACCESSIBILITY.....	30
7.20 PRINTING.....	30
7.21 ABOUTPHONE.....	30
8. APPLICATIONS & UTILITIES.....	31
ASK ME.....	31
BACKUP AND RESTORE.....	31
CALCULATOR.....	31
CALENDAR.....	31
CLEAN MASTER.....	32
CLOCK.....	32
DOWNLOADS.....	32
FILE MANAGER.....	32
FLASHLIGHT.....	32
FIIPKART.....	33
GAME PLANET.....	33
GMAIL.....	33
GOOGLE SEARCH.....	34
GOOGLE+.....	34
HANGOUTS.....	34

MAPS	34
MYNTRA	35
OLX.....	35
OPERA MINI.....	35
PAYTM.....	35
PLAY STORE	36
SPICE ARENA	36
SPICE GANG	36
TEENPATTI	36
TODO	37
YOU TUBE	37
WHATS APP DOWNLOADER.....	37
9. SPECIFICATIONS.....	38
10. SUPPORT AND CONTACT.....	38
ENVIRONMENTAL CONCERN.....	39

WHAT'S IN THE BOX?

Your package comes with the following items. If any of these is missing, please contact your retailer

- Device
- USB Cable
- Adapter
- User's Manual
- Headset
- Battery
- Back Cover
- Flip cover
- Warranty Card
- After Sales Service Center List

1. UNDERSTANDING YOUR DEVICE

1.1 GENERAL INFO

Xlife-512 is a multi SIM phone that encloses features, such as **Android version 4.4.2, Wi-Fi, BT, 1.0 GHz Qual core Processor, 4GB ROM+512M RAM ,8.0MP back Camera &2.0MP front camera, etc.** This phone is provided with two SIM slots for two different SIM cards. The SIM card inserted in the slot1 is called Master SIM, and the other one in the slot2 is known as Slave SIM. You can select to operate SIMs as per your personal and professional needs.



1.2 DEVICE OVERVIEW



Position of Keys

1. Receiver	2. Front Camera
3. Touch Screen	4. LCD Display
5. Menu Key	6. Home Key
7. Back Key	8. Back Camera
9. Volume key(+)	10. Flash light
11. Volume key(-)	12. Power key
13. Battery cover	14. Speaker

2. GETTING STARTED

2.1 INSTALLING CARDS & BATTERY

Please switch off your device before inserting or removing the battery/SIM card or memory card.

Installing SIM Card and Battery


Your device is provided with two SIM slots for two different SIM cards. In order to install battery and SIM card in the device, please follow the steps mentioned below:

- Remove the back cover of the device.
- Hold the device with front facing downwards; pull battery cover.
- Insert the SIM cards in the device.
- Attach the battery.
- Push the battery cover until it clicks into place.

Installing Memory Card

Your device supports T-Flash card, which is a multimedia memory card used to multiply the memory of the device. The T-flash card is small and should be pulled out and installed carefully and prudently in order to avoid any kind of damage. Please follow the steps mentioned below to install the memory card in the device:

- Switch off your device.
- Remove the battery cover.
- Slide the T-Flash card into the slot and attach the battery.
- Push the battery cover until it clicks into place.



Charging the Battery

The device prompts a warning tone and message stating insufficient battery when the battery power is low. Please follow the instructions mentioned below to charge your device:

- Plug the connector of the charger into the jack of the device.
- Plug the charger into a standard AC wall outlet.

Charging..... Fully Charged.....

You must fully charge the battery before using the device for the first time. It is recommended to charge the battery for three hours before using the device for the first time.

2.2 POWERING ON/OFF THE DEVICE

Turning On the Device

After installing the SIM cards and charging the battery, you are now ready to turn on your device.

- Long press and hold the Power Key to turn on the device.
- The first screen that appears is known as the home/idle Screen.
- Drag the lock icon side wards to unlock the screen.
- If screen turns off, press the Power Key to turn on the display.

Turning Off the Device

Press and hold the Power Key for 3 seconds > A pop-up window appears, select Power off > Select OK to confirm.

