

דפ כּוּחַ עוֹשֵׂה מְצֻדָּה



Let's get started

Messaging and Email

Email setup

1. From the home screen, tap **Email** .
2. Select an email provider.
3. Enter the email address and password and then tap **NEXT**.
4. Once your email has synced with your phone, tap **DONE**. You can now read and send emails.



Text and Picture Messaging

Send a text message

1. From the home screen, tap **Messaging** .
2. Tap **Compose**  to begin a new message.
3. In the To field, enter a number or a contact name, or tap **Contacts**  to select a contact from the address book.
4. Tap the **Enter message** field and enter your text.
5. To send a picture message, tap **Attach**  by selecting a picture, or choose another file to attach.
6. Tap **Send**.



App Home Screen Shortcut

With app shortcut, you can use an apps function directly from your home screen.

1. Press and hold an app to open the list of functions.
2. Select the function you would like.
3. You are immediately taken to it!



What else is in the box?

- LG Phoenix® Plus
- Pre-Installed SIM Card
- Battery (Non-Removable)*
- Micro USB Cable
- Travel Charger
- Let's Get Started Guide
- Product Safety & Warranty Information

*Rear cover and battery are not removable. Do not attempt to remove.

AT&T Apps*

AT&T offers a multitude of apps designed to make your everyday life easier.



Setup and Transfer

Restore content from your old device, set up your email, social networking, and more.



AT&T DriveMode®

Help avoid distractions while driving. Silence incoming text alerts.



AT&T Call ProtectSM

More control over nuisance calls with AT&T Call Protect.



AT&T Smart LimitsSM

Manage your kids' phone use and set limits.

Find More Information

Manage Your Account with myAT&T

- On your phone: **From the home screen, swipe right to select > myAT&T**



- On the web: att.com/myATT

With myAT&T, you can:

- Add money to your account
- Track your usage
- Shop for equipment and accessories
- Suspend service if your phone is stolen
- And more

Compatible device and online account required. Data and messaging rates may apply for download and app usage.

More Help?

- On your phone: **From the home screen, swipe right to open > AT&T Folder > Device Help**
- On the web: att.com/DeviceHowTo



Give Us a Call

- 611 from any AT&T wireless prepaid phone
- 800.331.0500 or prepaid 800.901.9878

Accessories

- att.com/WirelessAccessories
- Visit your AT&T store



AT&T 4-Star
Eco-Rating 2.0
att.com/ecospace

WIRELESS
EMERGENCY
ALERTS
CAPABLE 

AT&T Eco Rating 2.0 only applies to LG Phoenix® Plus. For limited factors evaluated visit att.com/EcoSpace. Wireless Emergency Alerts is a registered Trademark and Service Mark of CTIA.

Contains Li-Ion battery – recycle or dispose of properly. LTE is a trademark of ETSI. 4G LTE not available everywhere. LG, LG Life's Good, and the LG logo are registered trademarks of LG Corp. Phoenix Plus is a registered trademark of LG Electronics, Inc. 2018 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks are the property of their respective owners.

*Compatible device and subscription may be required. Data and messaging rates may apply. Restrictions and limitations may apply. For more app information, go to <https://att.com/shop/apps>.

Quick Start



Need more help?
Go to **AT&T Folder > Device Help**

Fingerprint Sensor

How to Set Up

1. Tap **Settings** > **General** > **Privacy and Security** and tap **“Lock screen & security”**.
2. Select **“Fingerprints”** and hit **NEXT** to add your fingerprint.
3. Select a second way to unlock your phone. Choose either **Knock Code**, **Pattern**, **PIN**, or **Password**. Follow steps to set up.
4. Scan your fingerprint by placing your finger on the **Rear Key**. Lift and move slightly until it is fully registered.
5. Tap **ADD MORE** or **OK** to finish.



Easily Adjust Settings

Settings Menu

1. Tap **Settings** on the 2nd home screen.
2. Select the tab for the settings you wish to adjust.



Quick Settings

1. To adjust certain settings quickly, swipe down from the top of the screen to open the Notifications panel.
2. From this panel, you can adjust screen brightness, turn on or off the silent or vibrate functions, control screen rotation, and turn on or off features such as **Wi-Fi** and **Bluetooth**.
3. Tap **down arrow** to edit the settings shortcuts that appear on the Notifications panel.
4. Tap **Settings** to open the full Settings menu.



Capture and Share Life's Moments

Don't just capture the moment, share it!


Take a Picture

1. From the home screen, tap **Camera**.
2. Tap **Camera** to adjust your camera settings. Zoom in and out by pinching with your fingers on the screen.
3. To take a photo, tap **Shutter** or press a **Volume key**.



Record a Video

1. Tap **Video** to adjust camcorder settings.
2. To begin recording, tap **Record**.
3. You can snap a photo while recording video by tapping **Photo**.
4. Tap **Pause** to pause recording, and **Resume** to resume.
5. Tap **Stop** to stop recording.



Share a Picture or Video

1. From the home screen, tap **App Drawer**.
2. Tap an album and then tap a photo or video.
3. Then tap **Share** and select an option for sharing.

Call Family & Friends

Make a Call

1. From the home screen, tap **Phone**.
2. Enter a phone number with the dial pad, or tap **Contacts** to select a contact from the list.
3. Tap **Call** to place the call.



Check Voicemail

1. From the home screen, tap **Phone**.
2. Press and hold the **1 key**.
3. Follow voice prompts to listen to messages.



Visual Voicemail

1. From the Phone app Dial screen, tap **Visual Voicemail**.
2. Tap **Play** at the top right of the screen to play all your voicemails, or tap a message, and then tap **Play** to listen to it.



Get Connected

Connect to Wi-Fi

1. From the home screen, swipe down from the top of the screen to open the Notifications panel. Then select **Settings** > **Networks** > **Wi-Fi**.
2. Tap **Wi-Fi** to turn on Wi-Fi.
3. Tap a network name. Enter a password if required, and then tap **CONNECT**.



Use Bluetooth

1. From the home screen, swipe down from the top of the screen to open the Notifications panel. Then select **Settings** > **Networks** > **Bluetooth**.
2. Tap **Bluetooth** to turn on Bluetooth.
3. The LG Phoenix[®] Plus will automatically search for devices. Tap a device to pair. See the **Bluetooth** device's user manual for more information on pairing.



Note: To reset your voicemail password, go to att.com/resetvm.