



s700

User Manual

Claims

We reserve our right to make changes and improvements to any of the products described in this manual without prior notice. Under no circumstances shall we be responsible for any loss of data, income, or any special, incidental, consequential or indirect damages howsoever caused.

The content of this manual is provided “as is”. To the fullest extent permissible by law, we make no representations or warranties of any kind, either express or implied, for, but not limited to, the accuracy, merchantability, and fitness of this manual for a particular purpose.

Contents

For Your Safety.....	6
Brief Introduction	7
Your phone’s label.....	7
Phone image.....	8
Key definition.....	9
Touch screen.....	10
Silent mode.....	11
Screen sleep.....	11
Screen lock.....	12
Wireless off	13
Making phone calls.....	13
Power on/off.....	14
Home screen.....	15
Home screen.....	15
Extended Home screen.....	15
Create Home screen shortcuts and widgets.....	15
Remove items from the Home screen.....	16
Move objects on the Home screen.....	16
Create and delete folders on the Home screen.....	17
Customize Home screen wallpaper.....	17
Notification and connection status icons.....	19
Getting Started.....	20
Installing the battery.....	20
Charging the battery.....	21
Battery tips.....	22
Use and maintenance.....	23
System settings.....	25
Wireless & networks.....	25
Call settings.....	29
Sound	29
Display	31
Location & Security	31
Applications	33
Accounts & sync.....	34
Privacy.....	35
SD card & phone storage.....	35
Language & keyboard.....	36
Voice input & output.....	36
Accessibility.....	37
Date & time.....	37
About phone	38

<u>Contacts</u>	38
<u>Your contact list</u>	38
<u>Search for a contact</u>	40
<u>Add a contact</u>	40
<u>Assign favorites</u>	41
<u>Edit contact details</u>	41
<u>Delete contact</u>	42
<u>Communicate with a contact</u>	42
<u>Display a contact group</u>	44
<u>Contacts settings</u>	44
<u>Email and Messaging</u>	45
<u>Email</u>	45
<u>SMS and MMS messaging</u>	50
<u>Browser</u>	58
<u>About the Browser</u>	58
<u>Zoom and navigation in Web pages</u>	58
<u>The Browser screen</u>	59
<u>Manage bookmarks</u>	59
<u>Set your home page</u>	61
<u>Browser history</u>	62
<u>View the most visited webs</u>	62
<u>Download Web files and applications</u>	62
<u>View your downloads</u>	63
<u>Browser settings</u>	63
<u>Calendar</u>	67
<u>Calendar views</u>	67
<u>Create an event</u>	67
<u>Go to today</u>	67
<u>View an event</u>	68
<u>Camera, Camcorder & Gallery</u>	68
<u>Before you begin</u>	68
<u>Camera</u>	69
<u>Video Recorder</u>	69
<u>Settings of Camera, Camcorder and Gallery</u>	70
<u>Gallery</u>	71
<u>Music & Video player</u>	73
<u>Music</u>	73
<u>Tools</u>	78
<u>Alarm Clock</u>	78
<u>Calculator</u>	81
<u>File Manager</u>	81
<u>Battery Information</u>	82
<u>Accessories</u>	83
<u>Safety of the battery</u>	83

<u>Rapid travel charger.....</u>	<u>84</u>
<u>Data cable.....</u>	<u>84</u>

For Your Safety

	SWITCH ON SAFELY Do not use in prohibited areas or when it may cause any interference or danger.
	SWITCH OFF IN HOSPITALS Follow any restrictions. Switch the phone off near medical equipment.
	SWITCH OFF WHEN REFUELING Do not use the phone at a refueling point. Do not use near fuel or
	SWITCH OFF IN AIRCRAFT Follow any restrictions. Switch off the phone during the flight as wireless
	ROAD SAFETY Obey all local laws. Please use the hands-free kit while driving.
	ACCESSORIES AND BATTERIES Use only approved accessories and batteries. Do not attempt
	BACKUP IMPORTANT INFORMATION Remember to make backup copies or keep a written record of all
	CONNECTING TO OTHER DEVICES When connecting to any other device, read its user manual
	MAINTENANCE Only authorized and qualified personnel may repair this product.
	WATER RESISTANCE Your phone is not water-resistant. Keep it dry.
	INTERFERENCE All wireless devices may be susceptible to interference, which could affect its


Damage to the security seal will invalidate the warranty.

Warning: Improper use will invalidate the warranty.

Brief Introduction

Your phone's label

The barcode label includes important information about services and customer support. Please keep it properly.

Phone image

Note: All the illustrations, simulated screen and related images in the manual are for reference to your handset for actually.



Functions Description	
1. Send key	9. Charging indicator light
2. Menu key	10. Power key
3. Home key	11. Earphone port
4. Search key	12. USB port
5. Back key	13. Receiver
6. End key	14. Front Camera
7. Volume Up key	15. Speaker
8. Volume Down key	16. Back Camera

Key definition

A few simple keys make it easy to operate.

Send key:

⌘ Press to answer an incoming call.

⌘ Press to enter the call log interface.

Home key

⌘ Press to return to the home screen from anywhere on your phone.

⌘ Long press to pop up the recent applications window.

⌘ Press home key on home screen to choose main interface window.

Back key: Press to go back to previous menu, or to dismiss a dialog box or menu.

Menu key: Press to open a list of actions you can take on the current screen.

Volume keys: Press to adjust the volume of the call, video, FM etc.

End key: When on a call, press to hang up.

Touch screen

Selection

To select an item or button on the screen, touch the item directly with your fingertip. You will know which item on the screen is selected when its color changes.

Context menus

To open the context menu for an item on the screen, touch & hold the item on the screen with your fingertip.

Scroll

To scroll up or down in a list or page on the screen, you can slide your finger up/down on the screen.

Crop pictures

When creating wallpaper or an icon from a picture, you can control how the picture is cropped. Touch & hold an edge of the cropper to reveal the sizing arrows then drag the edge in or out to the size you want. Touch & drag the center of the cropper to reselect the chosen area of the picture.

Drag items

In some contexts you can drag items on the screen with your fingertip. Moving the cropper frame within a picture is

one example.

Screen orientation

Your screen's orientation will switch automatically when the phone orientation changes. Press the **Menu** key, then select [Settings](#)> [Display](#)>[Auto-rotate screen](#). Unselect the check box to let your screen keep the portrait orientation.

Silent mode

Press the **Menu** key, then select [Settings](#)> [Sound](#)>[Silent mode](#).

Other ways to silence your phone:

Press and hold the **Volume down key** to zero volume.

Long press **Power key** and select **Silent mode** in the Phone options list

Screen sleep

After a period of inactivity, your phone will go to sleep (display will turn black). In sleep mode, your phone uses less battery power. You can control this behavior by:

Set screen timeout period

1. Press the **Menu key** to select [Settings](#)>[Display](#).
2. Select [Screen timeout](#), then select a time from the menu.

Prevent sleep while charging

1. Press the **Menu key** to select [Settings>Applications](#).
2. Select [Development](#), and then select the [Stay awake](#) check box.

Lock screen & put phone to sleep (immediately)

Press the **Power key**, phone will go to sleep mode or lock screen except on a phone call,

Screen lock

While not in a call, to lock your control buttons and screen from accidental touch activation, press the **Power or End key**.

You can increase the security of your phone by setting a screen unlock pattern. Once set, in order to unlock your screen, you'll have to draw the correct unlock pattern. You can set your screen unlock pattern as follows:

1. Press the **Menu key** and select [Settings](#).
2. Select [location & Security](#), then scroll down and enter into the Screen unlock pattern section.
3. Set or change your unlock pattern by selecting [Pattern](#), [PIN](#), or [Password](#), as applicable.
4. Follow the prompts to define your pattern.

Note: You must slide your finger along the screen to

create the pattern, not select individual dots. Connect at least four dots.

5. When you unlock your screen, if you want your pattern to be hidden as you draw it, clear the [Use visible pattern](#) check box.

Wireless off

If you need to turn off all your phone radios, switch to “airplane” mode by:

1. Return to the **Home** screen, then press the **Menu key** and select [Settings](#).
2. Select [Wireless & networks>Mode Settings](#), then select the [Airplane mode](#) check box. When selected the airplane mode icon  displays on the status bar and all wireless connections are disabled.
3. To enable wireless connections again, return to this settings screen and clear the [Airplane mode](#) check box.

Tip: To set your handset as Airplane mode quickly, press and hold the **Power key** to open the option menu, and select [Airplane mode](#).

Making phone calls

Press the icon  to dial a number and press the **End key**

to end a call.

While in a call, press the **Menu key** to reveal the in-call options.

Dialpad: Displays the on-screen dial pad.

Speaker: Turn on the speakerphone.

Mute: Mutes your side of the conversation.

End: end the call

Add call: Add new call.

Bluetooth: The Bluetooth headset is being used via Bluetooth connection.

Power on/off

To power off your phone, press and hold the **Power key**. On release, the phone options menu opens. Then select **Power off**.

To power on again, press and hold the **Power key**. (**Tip:** The phone will vibrate after you press and hold the **Power key**, and please be patient to wait for the phone to power on.)

Home screen

Home screen

The **Home** screen is your starting point for using all the applications on your phone. You can customize your **Home** screen to display applications, shortcuts and widgets as you like.

Extended Home screen

The Home screen actually extends beyond the screen width. Slide your fingertip left and right along the screen to reveal the full width of the Home screen. This additional space gives you more room to customize **Home** with applications, shortcuts, and widgets.

Create Home screen shortcuts and widgets

1. Start from the Home screen, then touch & hold the screen with your fingertip. The [Add to Home screen](#) menu opens.
2. Select a [Shortcuts](#) to applications or some of your saved information (such as a music playlist, a Web bookmark, or folder, etc), [Widgets](#) (analog clock, calendar, or music, etc), [folders](#) (all contacts, contacts with phone numbers, or starred contacts), or [Wallpapers](#) for your Home

screen.

3. The application, shortcuts, folders, or widgets appear on the screen. If you select Wallpaper, you'll be asked to select a picture.

Tip: To create an application shortcut quickly, touch the application tab to reveal all the application icons, then touch & hold an application icon. Its shortcut is added to the Home screen.

Remove items from the Home screen

To remove a shortcut or widget from your Home screen, touch & hold the item. Then click **Remove** on the dialog box to delete the item. At the same time, the application tab turns into a Trash button. Drag the item to the Trash button and release.

Move objects on the Home screen

1. To move an icon or other item on the Home screen, you must first touch & hold it to enter move mode. The object will magnify when it's ready to be moved.
2. Without lifting your finger (or you'll drop out of move mode), drag the object to the new position. To move an item to a section of the Home screen not in view, move it

to the edge of the screen and hold it there for a moment. The screen view will shift; position the object and release.

Create and delete folders on the Home screen

You can add folders to hold application icons or shortcuts:

1. Press the **Menu key** and select **Add**, or touch & hold the screen to open the **Add to Home screen** menu.
2. Select **Folders>New folder**. A new folder appears on the screen.
3. Touch & hold any of the application icons or shortcuts to enter move mode (the icon will magnify), then drag the item to the top of the new folder.
4. Touch the folder once to open it; touch the folder's title bar to close it.
5. To rename a folder, first open the folder. Then touch & hold the folder title bar to open the Rename folder dialog box. Type your new folder name, then select **OK**.
6. To delete a folder, touch & hold the folder to enter move mode. Drag the folder to the Trash button and release.

Customize Home screen wallpaper

Wallpaper your Home screen with pictures you have

stored on your memory card, or select a picture from the Wallpaper gallery that comes preinstalled on your phone:

1. Press the **Menu key** and select [More>Wallpaper](#).
Alternatively, you can touch & hold the Home screen to open the [Add to Home screen](#) menu.
2. Select [Wallpaper](#), and then select either [Pictures](#) or [Wallpapers](#)
3. If you select [Wallpapers](#), then scroll through the gallery. Touch a thumbnail to highlight it and view the larger version. When you chose one picture as your wallpaper, make sure it's highlighted, and then select [Set wallpaper](#).
4. If you select [Pictures](#), your picture album opens. Note that if this is the first time you have viewed the pictures stored on your memory card from your phone, it may take a while for the pictures to load.

Navigate to find the picture you want to use, and then select it.

The cropper appears. Touch & hold an edge of the cropper to reveal the sizing arrows, then drag the edge in or out to size. Touch & drag the center of the cropper to move it within the picture.

When you're happy with the cropped area, select [Save](#)

or press the **Back key**.

Notification and connection status icons

Along the top of your phone screen is the status bar. On the left side, icons will appear, notifying you of a new message, upcoming calendar event or something else you should notice. On the right side of the status bar, you'll see connection status icons.

-  New SMS or MMS
-  Alarm is set
-  Song is playing
-  Data is syncing
-  SD card unload
-  More (undisplayed) notifications
-  Call in progress
-  Missed call
-  Speakerphone is on
-  Ringer is off (Silent mode)
-  Ringer on vibrate only
-  Phone on mute
-  Content downloaded
-  Sign-in/sync error

 GSM signal, roaming, no signal

 GPRS service connected, data flowing

 Edge service connected, data flowing

 W-CDMA service connected, data flowing

 Wi-Fi service connected, network available

 Battery charge indicators: full, half-full, low, very low!

 Battery is charging

 Wireless services are off (Airplane mode)

 Bluetooth® is on, Bluetooth device connected


 No SIM card in phone

 USB connected


Getting Started

Installing the battery

1. Take off the battery cover.




2. Installing a SIM-card



Note: The SIM-card slot is at the downside of the battery.

3. Installing battery



Charging the battery

Warning: To avoid damaging the phone, please do not remove the battery when the phone is charging.

To ensure the best performance of your phone's battery, please charge the battery fully before using it for the first time (Approx. 12 hours), using the method described below. Please note: some batteries require several full charge/discharge cycles to reach their best performance.

1. Make sure the battery has been installed properly before charging.
2. Plug the travel charger into the USB connector, and then plug the other end of the travel charger into the electrical outlet.

Tips:

- ♣ If your phone is off, there will be a **blue** light at the upper left corner of the phone's front side when being charged. When the phone is fully charged, the **blue** light will disappear. It may take 4-5 hours to fully charge.
- ♣ If your phone is on, there will be a charging indicator  on the status bar while charging.
- ♣ When your phone is on, try to avoid making or answering calls while charging.
- ♣ The phone also can be charged from your PC when it is connected with the USB cable, but it will take a longer time to charge if you mount USB storage.
- ♣ If your battery energy is too low, your phone may be unable to be switched on. Please charge your phone for a few minutes before you switch it on.

Battery tips

- ↘ Use only the batteries, data cable and chargers approved by the original manufacturer. Do not use a non-approved data cable or chargers, as it may damage the battery.
- ↘ Do not short-circuit the battery. Please store the battery

inside the battery box to prevent accidental short-circuiting of the battery contacts.

- ✦ Do not place or charge the battery in very hot or very cold locations as extreme temperatures can adversely affect the battery.
- ✦ Please keep the charger and handset out of the reach of young children.
- ✦ Please ensure that the metal contacts of the battery are kept clean and free of dirt.
- ✦ The battery can be charged and discharged hundreds of times, but it will be eventually worn out. Please replace the battery when the battery capacity falls to approximately 50% of its original storage capacity.

Use and maintenance

The following suggestions will help you use and maintain your mobile.

- ✦ Please keep dry. Rainwater, humidity, and any kinds of liquid or moisture might contain minerals which could corrode the circuit.
- ✦ Moving parts may be damaged if you put or use the phone in a dirty or dusty place.

- ✎ Please do not use or store the phone in a high temperature environment, as this may result in damage to the electronic or plastic parts.
- ✎ Please do not use or store the phone in a very low temperature environment.
- ✎ Please do not use any chemicals, detergent, or caustic detergents to clean the mobile. If you want to clean it, please wipe it gently using a soft cloth made damp with some soapy water.
- ✎ Please do not paint the phone. Paint might clog the moving parts and prevent proper operation.
- ✎ Only use the headset provided, or an approved spare.
- ✎ If the mobile has gotten wet, please switch it off immediately and remove the battery. Leave it to dry thoroughly before using it again.
- ✎ To get the maximum talk and standby times from your battery, please turn down the volume and reduce the backlight and contrast.
- ✎ Please keep all metal objects away from the charger port located at the top of the phone to avoid damaging the electronic circuits.

System settings

Control phone-wide settings from the Home settings screen: Press the **Menu key** to select [Settings](#). You can also select the [Settings](#) icon from the [Application](#) screen.

Wireless & networks

Mode Settings

1. [Airplane mode](#): Disable all wireless connections.
2. [Only SIM1 on](#): Turn on or off SIM1 connection.
3. [Only SIM 2 on](#): Turn on or off SIM2 connection.
4. [Both SIM on](#): Turn on both SIM connections.

Wi-Fi

Wi-Fi on/off

Select [Wi-Fi](#) check box if you prefer to use Wi-Fi for your data connection.

[Menu Key > Settings > Wireless & networks > Wi-Fi settings](#)

Note: Please turn off Wi-Fi if you don't use it to save battery

Wi-Fi Search and connection

1. Press [Menu Key > Settings > Wireless & networks > Wi-Fi settings](#).

2. View and scan for available networks - Press the **Menu key** and select [Scan](#).
3. Connect to a network - Select it from the network list.
4. Provide your username or password if required.
5. Press Wi-Fi check box again to turn off.

Manually add Wi-Fi network

1. Press Menu Key > Settings > Wireless & networks > Wi-Fi settings.
2. Click [Add WPS network](#), input SSID and Pin Number, then click [Start](#).

Bluetooth

Bluetooth on/off

Press Menu Key > Settings > Wireless & networks > Bluetooth, click this check box again to turn Bluetooth services off.

Bluetooth settings

You can make the Bluetooth settings as the following:

1. Rename your device.
2. Select to be discoverable, or not discoverable.
3. Click [Advanced settings](#) to make Bluetooth advanced settings.
4. Rescan for devices –select [Scan for devices](#).

Send/Receive files

1. Scan for devices.
2. Select the device you want to pair with.
3. Type PIN to pair.
4. After the pair succeeds, you can send/receive files between two devices via Bluetooth.

Tips: You can send bookmarks in browser, pictures in gallery, camera and camcorder, or files in File Manager.

Disconnect with cell phone

Click the phone name and choose **cancel**.

Tethering & portable hotspot

Share your phone's mobile data connection via USB or as a portable Wi-Fi hotspot.

USB tethering

You can tether your phone to your computer with a USB cable, to share your phone's internet connection with your computer.

Note: you can't mount your phone's micro SD card on your computer when USB tethered

Portable Wi-Fi hotspot

You can turn your phone into a portable Wi-Fi hotspot, to share your phone's internet connection with one or more

computers or other devices.

1. When your phone is serving as a Wi-Fi hotspot, you can't use your phone's applications to access the internet via its Wi-Fi connection.

2. You configure the hotspot with the Wi-Fi hotspot settings.

Mobile network settings

1. **Data Enabled:** Enable data access over mobile network.
2. **Data Connection:** Default SIM for data connection.
3. **SIM 1 data roaming:** Connect to data services when roaming.
4. **SIM 2 data roaming:** Connect to data services when roaming.

SIM 1 other settings

1. **Access Point Names:** Do not change this setting unless advised to do so by your wireless operator.
2. **Use only 2G networks:** Choose 2G network to save battery.
3. **Network operators:** Select a network operator.

SIM 2 other settings

1. **Access Point Names:** Do not change this setting unless advised to do so by your wireless operator.

2. **Use only 2G networks:** Choose 2G network to save battery.
3. **Network operators:** Select a network operator.

Call settings

SIM 1 / SIM 2 Call Settings

Fixed Dialing Numbers

This feature allows you to restrict outgoing calls to a fixed set of numbers.

To enable this feature you must know the SIM PIN2 code for your phone.

You can get this number from your wireless operator if this feature is supported.

Voicemail

Select to set a voicemail number that isn't being read from the SIM card.

Other Call Settings

From selecting this, you can choose [Call forwarding](#), [Caller ID](#) and [Call waiting](#).

Sound

Silent mode

Select to open the silent mode. All sounds except media &

alarms are silenced.

Vibrate

Select to have your phone vibrate for incoming calls.

Volume

Select to open the volume control, then slide your finger along the volume bar to set incoming call volume and notification volume.

SIM 1/SIM 2 ringtone

Select to set your default incoming call ringtone.

Notification ringtone

Select to set your default notification ringtone.

Audible touch tones

Select to have a tone sound when you use the onscreen Dialer.

Audible selection

Select to have a sound play when you select an item on the screen.

Haptic feedback

Vibrate when pressing soft keys and on certain UI interactions

Display

Brightness

Select to open the brightness control, then slide your finger along the brightness bar to set the level. In sunlight, increase the level.

Auto-rotate screen

Select to switch orientation automatically when the phone orientation changes (except the home screen)

Animation

Select to show animation when opening/closing windows.

Screen timeout

Adjust the delay before the screen automatically turns off

Camera

Set camera default values

Enable proximity sensor

Calibrate enable proximity sensor

G-Sensor Calibration

Calibrate the G-Sensor

Location & Security

My location

Use wireless networks

Select to use wireless networks.

Use GPS satellites

Enable your handset to receive GPS data.

Screen unlock

Create a pattern you will be asked to draw before your screen is unlocked. You can select to make the pattern visible or invisible as you draw it.

SIM card lock

Lock your SIM card for extra security. You can also change your SIM card PIN from this screen. If you don't know your SIM PIN, you can obtain it from your wireless operator.

Passwords

Select Visible passwords to have your password display as you type it.

Device administration

Select device administrators to add or remove device administrators.

Credential storage

Allow applications to access secure certificates and other credentials.

Install from SD card

Install encrypted certificates from SD card.

Set password

Set or change the credential storage password.

Clear storage

Clear credential storage of all contents and reset its password.

Applications

Unknown sources

Select this check box if you want the ability to download applications from the Web. With this check box not selected, you will only be able to download applications from Android Market.

To ensure your personal data and phone remain secure, it is recommended you not select this check box.

Manage applications

View all the applications stored on your phone and how much space they occupy. If you've downloaded an application from Android Market, you can uninstall it from this screen.

Select a specific application to:

1. Clear your user data – Choose one application, press

Clear data.

2.

Uninstall - If you've downloaded an application from Android Market, you will be able to uninstall it from this screen by selecting [Uninstall](#).

Running services

View and control currently running services.

Development

If you are an application developer, you may be interested in these settings:

USB debugging

If you want be able to communicate with your phone directly via USB, select the [USB](#) debugging check box.

Stay awake

To prevent your phone from sleeping while charging (via power adapter or USB), select the [Stay awake](#) check box.

Allow mock location

To allow mock location, select the Allow mock location, select the [Allow mock location](#) check box.

Accounts & sync

Before using this function, please add your e-mail account firstly. Choose [Background data](#) box, your email account

and related applications will sync automatically.

Privacy

Back up my data

Back up my settings and other application data.

Automatic restore

Reinstall an application, restore backed up settings or other data.

Factory data reset

You can also select to reset your phone to factory settings. This will erase all your data and downloaded applications.

SD card & phone storage

View and manage the data storage on your phone

SD card

Monitor and manage the use of your memory card from this screen:

1. View the total space of your memory card.
2. View how much space you are using on your memory card.
3. Mount SD card: Insert an SD card for mounting.
4. Format SD card: Format(erase) the SD card.

Internal phone storage

Available space: Report how much internal storage is free.

Language & keyboard

Select language

Choose language area and the language setting.

Android keyboard

Android keyboard settings

Voice input & output

Voice input

Voice recognizer settings

Language

Select local language.

SafeSearch

Moderate-Filter explicit images only apply to Google search by voice.

Block offensive words

Hide recognized offensive voice results.

Voice output

Listen to an example

Play a short demonstration of speech synthesis.

Always use my settings

Default settings below override application settings.

Default Engine

Sets the speech synthesis engine to be used for spoken text.

Install voice data

Install the voice data required for speech synthesis.

Speech rate

Speed at which the text is spoken.

Language

Sets the language-specific voice for the spoken text.

Accessibility

Accessibility service may collect all words you input, including the number for your credit card but not the code.

Power button

During a call, press the power button to end the call instead of turning off screen

Date & time

Set time, time zone, and date - Use [Automatic](#) unless you need to override the network values.

Time format - Select from 12- or 24-hour formats.

Date format - Select from a variety of formats.

About phone

[Check Update](#): update to latest version for your phone.

[Status](#): This screen lists a variety of information, including your phone number, the network you are currently using, the type of network, signal strength, whether you are roaming or not, any Wi-Fi addresses you're connected to, and more.

[Battery use](#): what has been using the battery.

Select [Legal information](#) for copyright and licensing information, as well as the Google Terms of Service for the Google applications on your phone.

[System tutorial](#): learn how to use your phone.

[Model number](#): View the model number.

[Android version](#): view the version information for your phone.

[Baseband version](#)

[Kernel version](#)

[Build number](#)

Contacts

Your contact list

To view the contacts on your phone, select [Contacts](#) in the

Home screen.

Contacts belonging to a specific group (you can choose which group) are listed in the **Contacts** tab.

Only those contacts you star as “favorites” are listed in the **Favorites** tab. (Read “Contacts settings” to learn how to change which contact group displays in **Contacts**.)

From the **Contacts** tab, you can:

Take action on a contact

Touch & hold the contact’s name to open the option menu.

From the menu you can select to **View contact**, **call contact**, **Text contact**, **Add to favorites**, **Edit contact** or **Delete Contact**.

Go to Contact details screen

Select the contact’s name to open the Contact details screen, where all the information you’ve saved for this contact is displayed.

To edit a contact’s details, press the **Menu key** to select **New contact**.

Tip: Only the contacts stored in your phone can be displayed. You can import the contacts from your SIM card or SD card. In the Contacts main menu, press the **Menu key** to select **Import /Export**.

Search for a contact

1. Browse through your contacts by sliding your fingertip up and down on the screen. A rapid brush movement in either direction accelerates the scrolling. Touch the screen to stop the scrolling.
2. Or press the **Menu key** to select [Search](#) in the Contacts main menu, type the keywords in the text box, then tap the magnifier beside the text box to start searching.

Add a contact

1. Press the **Menu key** to select [New contact](#) in the Contacts main menu.
2. Add all the information you want to store for this contact in the appropriate fields. You must add some information to save a contact.
To add more fields, select **+**.
3. Assuming you have a memory card inserted with pictures in it, you can assign a Caller ID icon to your contact by selecting the caller ID icon beside the name text box. The Pictures application opens. Navigate to a picture and select it, size the cropper with your fingertips. When finished, select [Save](#). The picture is associated

with your contact.

4. To save your contact, press the **Back key**, or press the **Menu key** to select **Done**.

Assign favorites

Use **Favorites** as a way to display only those contacts you contact most frequently. To add a contact to **Favorites**:

1. From **Contacts**, touch & hold the contact you want to add to **Favorites**. The context menu opens.
2. Select **Add to favorites**.
3. Now your contact will be listed in **Favorites** and display with a colored star. Their details screen will also display the colored star.

Edit contact details

You can always make changes to the information you've stored for a contact:

1. From **Contacts**, touch & hold the contact whose information you want to edit. The context menu opens.
2. Select **Edit contact**. The **Edit contact** screen appears.
3. Make your edits, then select **done**. To cancel, select **Revert**.

Delete contact

1. From contacts, touch & hold the contact. To context menu opens. Select [Delete contact](#) to delete the selected contact.
2. Or in contact detail menu, press the **Menu key** to select [Delete contacts](#).

Communicate with a contact

From Contacts you can quickly call or text a contact's default number, as displayed below their name on the screen. However, to view all the information you've stored for a contact, and to initiate other types of communication with that contact, open the Contact details screen. To open a contact's details screen, simply select their name from Contacts.

Call a contact

From the contact details

1. In the Call mobile section, select the number you want to dial.
2. The number is dialed.

Send a text or multimedia message to a contact

To send a text or multimedia message to a contact, you

must have a mobile number stored for them in contact details.

From the contact list

1. Touch & hold the contact's name to open the context menu.
2. Select **Text contact**. A Compose screen opens for your new message.

From the Contact details screen

1. In the Text mobile section, select a phone number.
2. A Compose screen opens for your new message.

Send email to a contact

To send an email message to a contact, you must have an email address stored for them in their contact details.

1. Select the contact you want to email. Their Contact details screen opens.
2. In the email section, select the email address. If you are fetching POP3 or IMAP email accounts to your phone, then select the account you wish to use to send. A Compose screen opens for your new message.
3. Complete your message and select **Send**.

Display a contact group

To select which contact group to display in Contacts, press the **Menu key** and select [Display options](#) to view details.

Contacts settings

To set Contacts preferences, from [Contacts](#) or [Favorites](#), press the [Menu key](#) to open the option menu:

SIM contacts import

If you have stored names and phone numbers on your SIM card, you can add these to the Contacts stored on your phone by selecting this settings option [Import/Export](#).

Once the list of names and numbers appears you can:

1. Import all names/numbers in the list – Press the **Menu key** and select [Import/Export](#), then select [import from SIM card/SD card](#).
2. Import only certain names/numbers in the list - Select the name/number you want to import, then repeat for others as you wish. (As soon as you select the name/number, it is imported.)

SIM contacts export

1. Export all names/numbers in the list – Press the **Menu key** and select [Import/Export](#), then select [export to](#)

SD card.

Share visible contacts

Share the contact details via Bluetooth or Gmail

Email and Messaging

Email

POP3 and IMAP email accounts

Add an email account

1. Open the Application menu to select the [Email](#) application.
2. The Set up new account screen appears.
3. Type your account email address and password.
4. If you want, select the [Send email from this account by default](#) check box. This setting only applies if you have more than one POP3 or IMAP account set up.
5. Select [Next](#).

If you have a popular email account, the application will set everything up for you! Before you go to your Inbox, you can name the account (if you don't, your email address will be used). You are also asked to type your name as you want it to display on outgoing messages. You must complete this field before you can select [Next](#) and go to your Inbox.

For less popular accounts, follow the prompts to type the email server, protocol, and other account information yourself. After your account settings have been verified, select [Next](#) to go to your Inbox.

6. To add more accounts (up to five), from your Accounts screen, press the Menu key and select Add account.

Use your POP3 and IMAP email account

Once you've set up an account, you can do the following:

Refresh Inbox

From the Inbox, press the **Menu key** and then select [Refresh](#) to update your Inbox with any previously-unfetched email.

Read email

You can display or collapse the messages in your Inbox by selecting [Inbox](#). Unread messages display with a colored band. (Each account you add will use a different color.)

To open an email for reading, select it.

Forward, Reply, Reply all, Delete, Mark as unread

You can forward, reply, reply all, delete or mark as unread to an email message from either the Inbox or the read view:

1. From the read view, press the **Menu key** and select the

action you want to take.

2. From the Inbox, touch & hold the message to open its context menu. Select the action you want to take.

Compose new

From the Inbox or your accounts screen:

1. Press the **Menu key** and select [Compose](#).
2. Add recipients by typing a name or address in the To field, matching contacts will appear. Select the recipient or continue typing the address. Add as many as you wish.
3. Type a subject and message.
4. Select [Send](#), [Save as draft](#), or [Discard](#). Pressing the **Back key** will also save as draft unless you have not typed anything.

Empty Trash

Once you've moved a message to the Trash, a Trash folder will display below your Inbox. To empty messages in the Trash you must delete each message individually:

1. Expand the Trash folder to display the messages.
2. Touch & hold the message you want to delete to open the context menu.
3. Select [Delete](#).

Note: The message is only deleted from your phone, not from the account server.

Remove an email account

You can always remove a POP3 or IMAP email account from your phone by doing the following:

1. Go to your Inbox.
2. Press the **Menu key** and select [Accounts](#). Your Accounts screen opens.
3. Touch & hold the account you want to remove to open the context menu.
4. Select [Remove account](#).
5. You will be asked to confirm before the account is removed.

Edit account settings

To open your Account settings screen, do the following:

1. From your account Inbox, press the **Menu key** and select [Account settings](#).
2. The Account settings screen appears. You can do the following from this screen:

Account name Select to change the name of your account as it appears on your Accounts screen.

Your name Select to change your name as it appears in

outgoing email.

Signature Select to change your signature.

Amount to synchronize Select the time for email synchronization.

Email check frequency Select this pop-up menu to set how frequently your email account is checked for new messages. Note that whenever you open a folder, email is refreshed, regardless of this setting.

Default account If you have more than one POP3 or IMAP email account set up on your phone and want to use this account by default when selecting Compose from the Accounts screen, select this check box.

Email notifications If you want an icon to appear in the status bar when a new message arrives, select this check box.

Select ringtone Select to decide on a ringtone to use for incoming email.

Vibrate Select to have your phone vibrate when email arrives.

Incoming settings Select Incoming settings if you need to edit the username/password, server, port, or option to delete email from server.

Sync contacts Select to synchronize contacts from your account.

Sync calendar Select to synchronize calendar from your account.

To save your settings, press the **Back key**.

SMS and MMS messaging

Press the **icon**  to open the SMS & MMS Messaging application.

About text and multimedia messages

SMS messages are also known as “text” messages and can each be around 160 characters. If you continue to type after the limit is reached, your message will be delivered as one, but count as more than one message. These are called “concatenated” messages.

MMS messages are also known as “multimedia” or “picture” messages and can contain text, picture, audio, and video files.

When you compose a message, the phone will automatically convert a text message into a multimedia message as soon as you add a subject or an attachment, or if you address the message using an email address

rather than a phone number.

The message list

Text and multimedia messages are grouped with the replies you receive into conversations or “message threads” or just “threads”. Message threads are listed in order of when you received them (newest at the top). To open a thread for reading, select it. Read more below.

Unread messages appear with a green band on the left.

The Read view

Select a message in the list to open it for reading.

Note: Messages you send are also listed in the Read view.

Reading multimedia messages

If you have selected to auto-retrieve your multimedia messages, then both the message header and body will be downloaded. To view your message, select the “play” button.

If you are downloading only the headers, then you must first select the Download button to retrieve the message body. If you are concerned about the size of your data downloads, you can check the message size before you download.

Once the message has been downloaded, select the “play” button to view the message.

From a message read view, you can do the following:

Reply to a message

1. Simply start typing your message in the text box at the bottom of the screen to reply to a message.
2. You can always press the **Menu key** and select to add a subject or an attachment to convert it to a multimedia message.

Links in messages

If a message contains a link to a Web page, it will be selectable. To view the Web page in the Browser, simply select it.

Forward messages

In the message read view, touch & hold the message to open the context menu, then select [Forward](#) to forward it to others.

Delete messages

Your messages will be saved until you explicitly delete them.

1. Delete one message in a thread: With the message thread open in Read view, touch & hold the individual

message you want to delete to open the context menu.

Select [Delete message](#).

2. Delete all messages in a thread: With the message thread open in Read view, press the **Menu key** and select [More>Delete thread](#). You can also delete an entire thread from the message list by pressing & holding the thread to open the context menu, then selecting [Delete thread](#).
3. Delete all message threads: From the message list, press the **Menu key** and select [Delete All](#).

View message details

To view details about a particular message, in the Read view, touch & hold the message to open the context menu.

Select [View message details](#).

Compose text and multimedia messages

1. Press the **Menu key** and select [Compose](#). The Compose screen opens.
2. Add recipients by typing a name, phone number, or email address in the [To](#) field. Matching contacts will appear. Select the recipient or continue typing. Add as many recipients as you wish. If you send the message to an email address, the message will automatically

convert from a text to a multimedia message.

3. To add a subject, press the **Menu key** and select [Add subject](#). If you add a subject, the message will convert to a multimedia message.
4. To add an attachment, press the **Menu key** and select [Attach](#). Adding an attachment will always convert the message to a multimedia message. Select from audio or picture files. You can select to take a new picture if you want, or record an audio file. Any recordings you make will be stored automatically in the Music application in a playlist named "My recordings".

To remove an attachment, select the attachment's [Remove](#) button.

5. Type your message. As you type, you'll be able to track how many characters/messages you're creating. Remember that text messages have a limit around 160 characters. Once you go over that limit, a new message is actually created but automatically joined into one when received.
6. You can also save a draft.
7. As your message sends, progress displays in the title bar.

Save message as draft

1. While composing, press the **Back key**.
2. Your message automatically saves as a draft.
3. To resume composing, in the message list, touch to open the message to edit.

Text and multimedia message settings

To set text and multimedia message preferences, from the message list, press the **Menu key** and select [Settings](#).

You can set the following from this screen:

Storage settings

[Delete old messages](#): When the box limits are reached, old messages are removed.

[Text message limit](#): One conversation is limited up to 200 messages.

[Multimedia message limit](#): One conversation is limited up to 200 messages.

Text message settings

[Delivery reports](#): To receive a report on the delivery status of your message, select this check box. Status can be:

- ☐ Successful delivery.
- ☐ Temporary delivery failure; an attempt to deliver will be made again.

ⓧ Unsuccessful delivery; no attempt to re-deliver will be made.

Manage SIM card messages: Text messages can also be stored on your SIM card. The exact number depends on your card, but it is usually around 25-50. To view messages on your SIM card, delete them, and copy them to your phone memory, select this setting.

Multimedia message settings

Delivery reports: To receive a report on the delivery status of your message, select this check box. Status can be:

- ⓧ Successful delivery
- ⓧ Temporary delivery failure; an attempt to deliver will be made again
- ⓧ Unsuccessful delivery, where no attempt to re-deliver will be made

Read reports: To receive a report on whether each recipient has read or deleted the message without reading it, select this check box.

Auto-retrieve: To retrieve all your Multimedia messages automatically (the header plus the message will download to your phone), select this check box. If you clear this check box, then only the message headers will be

retrieved and display in your message list. You can retrieve the full message by selecting the [Download](#) button that displays in the header. Once the message has downloaded, select the “play” button to expand the message.

[Roaming auto-retrieve](#): If you are concerned about data traffic and just want the message headers to download while roaming, clear the [Roaming auto-retrieve](#) check box. Otherwise, you can select this check box to have your messages download even while roaming.

Notifications

[Notifications](#): To display message notifications in status bar.

Select ringtone

You can set a ringtone from the default ringtone of the handset for new messages.

Vibrate

If you turn the handset into vibration mode, When a new notification and message arrive, the handset will remind you.

Browser

About the Browser

To open the Browser, select the [Browser](#) application in the [Home](#) screen.

The Browser always opens to the last Web page you were viewing. The first time you enter the Browser after powering on, your home page will display. You can change your home page by pressing the **Menu key** and selecting [More > Settings > Set home page](#).

Zoom and navigation in Web pages

While viewing a Web page, take advantage of the following zoom and navigation techniques:

Zoom in

1. Touch the screen to open the zoom-in and zoom-out controls .
2. Touch the **+** control to zoom in. With each touch you zoom in closer.

Zoom out

Touch the screen to open the zoom-in and zoom-out controls .

Touch the **–** control to zoom out. With each touch you

zoom out further.

Navigate

Slide your fingertip in any direction to shift your page view.

The Browser screen

From the Browser screen you can do the following:

Add a bookmark

Bookmark the Web page you are currently viewing:

1. Press the **Menu key** and select [Bookmarks](#).
2. From the Bookmarks screen, select [Add bookmark](#).
3. Confirm the URL and name, then select [OK](#).

To view all your bookmarks, press the **Menu key** and select [Bookmarks](#).

Refresh a Web page

To refresh the contents of the current page, press the **Menu key** and select [Refresh](#).

Manage bookmarks

You can store as many bookmarks as you want on your phone.

Bookmark any page

1. Press the **Menu key** and select [Bookmarks](#). The Bookmarks screen opens.

2. Select [Add bookmark](#).
3. Type a name and location (URL) in the dialog box.
4. Select [OK](#).

Send bookmarked page's URL

1. Press the **Menu key** and select [Bookmarks](#). The Bookmarks screen opens.
2. Touch & hold the bookmark you want to send. The context menu opens.
3. Select [Share link](#).
4. Send the link via email or message etc., and then a Compose screen opens with the URL as the message.
5. Address your message and finish composing.

View bookmarked page

1. Press the **Menu key** and select [Bookmarks](#). The Bookmarks screen opens.
2. Touch & hold the bookmark you want to open. The context menu opens.
3. Select [Open](#) or [Open in new window](#).

Edit bookmark

1. Press the **Menu key** and select [Bookmarks](#). The Bookmarks screen opens.
2. Touch & hold the bookmark you want to edit. The context

menu opens.

3. Select [Edit bookmark](#). The edit bookmark dialog box opens.
4. Type your change and select [OK](#).

Add shortcut to Home

1. Press the **Menu key** and select [Bookmarks](#). The Bookmarks screen opens.
2. Touch & hold the bookmark you want to add. The context menu opens.

Select [Add shortcut to Home](#). then a shortcut created on the home screen.

Copy link URL

1. Press the **Menu key** and select [Bookmarks](#). The Bookmarks screen opens.
2. Touch & hold the bookmark you want to copy. The context menu opens.

Select [Copy link URL](#).

Set your home page

You set your home page from the Settings screen:

1. Press the **Menu key** and select [More>Settings](#). The Settings screen opens.

2. In the [Page content settings](#) section, select [Set home page](#) to open the dialog box.
3. Type the URL of the page you want to set as home, then select [OK](#).

Browser history

The [history](#) screen lists the recent sites you've visited on the Web.

From the Browser screen, press the **Menu key** to select [Bookmarks](#), then select the [History](#) tab to view your Web site history.

View the most visited webs

From the Browser screen, press the **Menu key** to select [Bookmarks](#), then select the [Most visited](#) tab to view the webs you most visited.

Download Web files and applications

Before you download any files or applications using the Browser, note the following:

- Before you download Web applications, you must explicitly “allow” downloading from the Settings screen in [Home screen](#):

1. Press the **Menu key** and select [Settings](#).

2. Select [Applications](#), then on the Application settings screen, select the [Unknown sources](#) check box.
- All items downloaded from the Web are stored on your memory card, so be sure you have a card installed in your phone before you download from the Browser.
 - The Browser will only allow you to download items that are supported by an application installed on the phone.

Warning: Applications downloaded from the Web can be from unknown sources. To protect your phone and personal data, only download applications from sources you trust, such as Android Market.

[View your downloads](#)

To see which files or applications you've downloaded:

1. From the Browse screen, press the **Menu key** and select [More>Downloads](#).

2. The Download history screen appears with the list of downloads. If you have no downloads, nothing will be shown on this screen.

[Browser settings](#)

From the Browser screen, press the **Menu key** and select [More>Settings](#) to set Browser preferences.

Page content settings

Text size

Select to open the [Set text size](#) menu. Default setting is Normal, but you can increase the size to [Large](#) or [Huge](#), or decrease to [Small](#) or [Tiny](#). Note that this text size setting only affects pages you view through the Browser.

Default zoom

Select Far, Medium, Close for your browser.

Open pages in overview

Show overview of newly opened pages

Text encoding

Select a text encoding for your web browser.

Block pop-up windows

Select this check box if you want pop-up windows to be blocked.

Load images

Select this check box if you want images on Web pages to load. For faster page loading, clear this check box.

Auto-fit pages

Select to size pages to the screen automatically.

Landscape-only display

Display pages only in the wider, landscape screen

orientation

Enable JavaScript

Select to enable JavaScript on pages. Disabling JavaScript may cause some Web pages to not work properly.

Open in background

Select if you want links to new pages to open in a new window in the background.

Set home page

Your currently-set home page is shown on the Settings screen. To change your home, select [Set home page](#), type the URL for your home page, then select [OK](#).

Privacy settings

Select one of the privacy settings to clear the following:

- Browser cache
- Browser page-visited history
- all cookie data
- saved form data

Accept cookies

Select this check box if you want the Browser to save cookies. Some Web sites might not work properly with cookies disabled.

Remember form data

Select this check box if you want the Browser to remember text you have typed in forms, so that you can select the same text later rather than retyping it.

Enable location

Allow sites to request access to your location

Clear location access

Clear location access for all websites

Security settings

Remember passwords

Select this check box to save usernames and passwords to various Web sites.

Clear passwords

Select [Clear passwords](#) to clear all your saved passwords.

Show security warnings

Select this check box if you want a warning to be displayed when you are going to an insecure Web site.

Advanced settings

Set search engine

Select a search engine

Website settings

Advanced settings for individual websites

Reset to default

Select if you want to reset all Browser settings to factory default values, except for your home page.

Calendar

To open Calendar service, select the Calendar application in the Application screen. You can view calendar, view month, edit event, etc.

Register on the Google Market at first, then you can use the following function.

Calendar views

You can slide the **blue-bar** at the bottom of the screen to view the **Calendar** by **Week**, **Day**, **List**, **Month**.

Create an event

3. From any interface of the calendar, select one day and press “+” at the upper-right corner to create an event.
4. Type the information in blank you are supposed to fill.
5. After you’ve finished, press **save** to save the event you have edited.

Go to today

Press the image at the left bottom of the screen, to view the calendar of current day.

View an event

With any event edited, there appears a **colored bar** in the date box. Press the date box to view the event.

Camera, Camcorder & Gallery

Before you begin

All the pictures you can capture or view and all the videos you can record or play on your phone are stored on a memory card, which must be installed in your phone. Before you can use the Camera or Camcorder, or view pictures/videos in [Gallery](#), make sure you have a card installed.

Load pictures and videos onto your memory card

Read the instructions below to add pictures or videos to your memory card.

6. Mount your memory card to your computer by doing the following:
 - Remove the memory card and insert it into a card reader attached to your computer.
7. On your computer, find the mounted USB drive and open it.
8. Copy image or video files into this folder.

9. When finished, close the USB drive window and unmount or eject the drive as required by your computer's operating system.

Camera

Take a picture

Captured pictures are saved to the “sdcard/CDIM/camera” folder on your memory card.

1. To open the Camera, select [Camera](#) in the [Application](#) screen.

2. The Camera opens in capture mode. Frame your picture within the screen and hold the phone steady. Press the icon at the right bottom to take a picture.

Tip: In capture mode, press the **Menu key** to select [Switch to video](#) or **slide up the button** to [Switch to video](#), the screen switch to video recording mode.

View your pictures

To view the pictures you've captured, press the image at the upper-right corner, or in capture mode, press the **Menu key** to select [Gallery](#).

Video Recorder

Record a video

1. To open the Camera, select [Camera](#) in the Home screen.
2. The Camera opens in record mode. Press the **Camera key** in the screen to record a video.

Play your videos

To view the videos you've captured, go to the [Gallery](#) application, or in record mode, press the **Menu** key to select [Gallery](#)

The newest video you recorded will display as a small window on the screen, touch the small window, and select [Play](#) to play the video.

Settings of Camera, Camcorder and Gallery

In capture mode, press the **Menu key** to select [Settings](#),

Select focus mode

Select focus mode from auto, infinity, macro, fixed.

Select antibanding

Select antibanding from auto, 50HZ, 60HZ, off.

Select scene mode

Select scene from auto, night.

Select picture size

Select picture size from 2M, VGA, QVGA.

Select picture quality

Select picture quality from Super Fine, Fine, Normal.

Select color effect

Select effect from none, mono, sepia, negative, solarize, aqua.

Camera settings

Restore to defaults.

Select camera

Select the back or front camera.

Select white balance

Select white balance from auto, incandescent, daylight, fluorescent, cloudy, twilight.

Gallery

View pictures and videos in Gallery

To view the pictures you've captured, the video you've recorded, as well as any you've stored on your memory card, go to the [Gallery](#) application.

1. To open [Gallery](#), select the [Gallery](#) in the Home screen.
2. Depending on how many pictures and videos you've stored, they may take a few minutes to load.
3. If you've stored your pictures and videos in folders on

your memory card, then the folders will display as separate “albums”. The top album always contains all the pictures in all the albums, and the second one always contains all the videos in all the albums. Select an album to view the pictures and videos.

4. To open a picture in full-screen view, touch the picture. Once in full-screen, select the arrows to scroll through the pictures within that album.

Zoom and navigate

When viewing a picture in full-screen view, you can zoom in and out, and navigate around the picture when it doesn't fit within the screen:

Zoom in

1. Touch the screen to open the zoom-in and zoom-out controls .
2. Touch the + control to zoom in. With each touch you zoom in closer.

Zoom out

7. Touch the screen to open the zoom-in and zoom-out controls .
8. Touch the – control to zoom out. With each touch you zoom out further.

Music & Video player

Music

Your library of music

Press the Home key and select the **Music** to open your music library.

Your music is organized into four categories: Artists, Albums, Songs, Now and Playlists. Select a category to view the lists within each. Once in a category, keep selecting until you reach the music you want to play. For example, if you select the Artists category, you will see a list of artists in A-Z order. If you select an artist, the list opens to display that artist's albums. Select an album, and the album's song list displays.

Supported music formats

Your phone will play the following music file formats:

- ② MP3
- ② MIDI
- ② AAC
- ② AAC+
- ② AMR

Load music onto your memory card

All the music you can listen to on your phone is stored on a memory card. Read the instructions below to add music to your memory card.

1. Mount your memory card to your computer by doing one of the following:

Remove the memory card and insert it into a card reader attached to your computer.

2. On your computer, find the mounted USB drive and open it.
3. Although your phone will find all music files on your memory card, it's advisable to keep the number of files or folders at the root level to a minimum. So, if you wish, create a folder at the top-level called "music" (or whatever you want) to store your files.
4. Open this folder and copy music files into it. If you want, create folders within "music" to organize your music further.

When finished copying, close the USB drive window and unmount or eject the drive as required by your computer's operating system.

Play back music

At any level in your Library, touch & hold a listing (a song,

artist, album, or playlist) to open the context menu. Select **Play** to begin play and go to the Playback screen.

You can do the following using the Playback screen:

Shuffle songs

Shuffle plays songs in random order. Touch  to toggle shuffle on and off. When the icon is grey, shuffle is off.

Repeat mode

Touch  to step through repeat modes:

Repeat all songs:  (green icon)

Repeat current song: 

Don't repeat:  (grey icon)

Go to any point in song

Slide fingertip in progress bar to desired point in a song.

Pause/resume play

Touch  to pause;  to resume play.

Fast forward

Touch & hold .

Go to next song

Touch once .

Rewind

Touch & hold .

Go to beginning of song

Touch once .

Go to previous song

Touch twice .

Party shuffle

To start “party shuffle” (all the songs in your library are added to a playlist in random order), press the **Menu key** and select [Party shuffle](#). To exit party shuffle, press the **Menu key** and select [Party shuffle off](#).

If a song is playing while you are on the Library screen, you can switch to the Playback screen quickly by selecting the lower song bar.

Playlists

You can create as many playlists as you wish. Note that the “Recently added” playlist is a system playlist and cannot be deleted or renamed. Also, if you make any voice recordings as part of a MMS message, they will be stored automatically in a playlist called “My recordings”.

Create a playlist on your phone

1. From the Library, select a category.
2. From the list that appears, touch the artist, album, or song that you want on a playlist.
3. Touch & hold the song to open the context menu.

4. Select [Add to playlist](#).
5. In the Add to playlist menu that opens, select [New](#) to create a new playlist, or one of the existing playlists.
6. The song(s) are added.

Manage your playlists

1. Go to the Library screen and select [Playlists](#).
2. All your playlists appear. You can do the following from this screen:

Play songs in list

Select the playlist.

Delete playlist

Touch & hold the playlist to open the context menu.

Select [Delete](#).

Rename playlist

Touch & hold the playlist to open the context menu.

Select [Rename](#).

Open the keyboard (if not already open) and type the new name.

Select [Save](#).

Create ringtones from songs

You can set any of your songs as a phone ringtone:

1. From the Library, select a song you want to use as a

phone ringtone.

2. Touch & hold the song in the list to open the context menu.
3. Select [Use as phone ringtone](#). The ringtone is set as your default incoming call ringtone.
4. Or in the play mode, Press **menu** to select [Use as ringtone](#).

Delete music from memory card

All the music you play on your phone is stored on the inserted memory card. From your phone, you can delete music stored on the card:

1. From the Library screen, select either [Artists](#), [Albums](#), or [Songs](#) category.
2. Go to the screen that shows the artist, album, or song that you want to delete.
3. Touch & hold the item to open the context menu.
4. Select [Delete](#). You will be asked to confirm that you want to delete the item from your memory card.

Tools

Alarm Clock

To open alarm clock, select the [Clock](#) in [Application](#)

screen. The clock offers as many alarms as you want.

Set an alarm

Three alarms are set up for you, ready to customize. All two default alarms are turned off by default.

To begin, select one of the default alarms to open Alarm settings. Set the following options:

Alarm

Select the check box to turn alarm on (checked) or off (cleared). This is the same check box that appears on the main Alarm Clock screen.

Time

The time the alarm will go off is shown. To change this time, select [Time](#) to open the time selector. Tap the **+** or **–** buttons and the [AM/PM](#) button to set the time you want, then select [Set](#).

Tip: Touch & hold the **+** or **–** buttons to move through the numbers quickly.

Ringtone

The current ringtone selection is shown. Select [Ringtone](#) to pick another ringtone that will play when the alarm rings. (When you select a ringtone, it plays briefly.)

Vibrate

Select this check box to have your phone vibrate when it goes off.

Repeat

The current repeat selection is shown. To change the setting, select [Repeat](#) and make a selection from the menu. To have your alarm will only go off once at the set time, don't select any of the options. A one-time alarm is shown on the Alarm Clock screen without any days under the set time.

Label

To name an alarm, select [Label](#), then touch the textbox to change the label, then select [OK](#) to save it.

Delete alarm

To delete the alarm, press the **Menu key** and select [Delete alarm](#).

Once your alarm goes off, you will receive an alert with the options to [Snooze](#) (for 10 minutes) or [Dismiss](#).

Add more alarms

To add more than three alarms, from the main Alarm Clock screen, press the **Menu key** and select [Add alarm](#).

Calculator

To open Calculator, select the [Calculator](#) application in [Application](#) screen.

The Calculator offers two panels: basic and advanced. Switch back and forth between panels by pressing the **Menu key** and selecting [Advanced panel](#) or [Basic panel](#), as you wish.

Calculator panels

Two calculator panels are available: basic and advanced. Use the Basic panel to enter numbers and perform basic addition, subtraction, multiplication, and division. Use the Advanced panel to insert advanced operators or delimiters, such as sine, cosine, tangent, square root, parentheses, etc.

☉ Switch back and forth between calculator panels by pressing the **Menu key** and selecting [Advanced panel](#) or [Basic panel](#), as you wish. As soon as you select an advanced operator, the panel switches back to Basic, where your operator appears.

File Manager

Select [File Manger](#) in the Application screen to view the

files in your phone or memory card.

Note: The files in your phone can not be operated.

1. Touch **SD card** to open the folder. Touch and hold the screen to open the context menu, select **New Folder** to create a new folder. Or touch and hold a folder to open the context menu, then you can copy, cut, rename, or delete the folder.
2. Touch and hold a file to open the context menu, you can copy, cut, paste, send, rename the file, view the detail or delete the content in the file.

Search file

The directory of the folder you visited shows on the upper side of the screen. Touch the rightmost icon to open the search textbox, input the file name you want to search in this folder, then press the magnifier to start searching.

Battery Information

Type	Capacity
Li-ion	1400mAh

--The battery life depends on many factors, including the SIM card, network conditions, settings, usage and environment.

--Making calls, turning on the backlight and multimedia

player will consume more battery power.

--The standby time is shorter when the network is not available than in the standard status.

--For power saving, the backlight turns off automatically if your phone stands idle for an assigned time.

--The performance of battery varies with the charging status, temperature, local radio wave and backlight status.

Accessories

Safety of the battery

1. Please use the battery provided by the original manufacturer. Use of any other battery will invalidate the warranty and the manufacturer of the phone will take no responsibility in repairing the phone damaged by the use of unapproved fittings.
2. Please keep any metal things (e.g. Keys in your pocket) away from the contact point of your battery to avoid short circuits.
3. Do not bend or open the battery by force.
4. Please keep the battery away from water or fire.
5. The battery can not be charged in very hot or very cold locations as extreme temperatures can adversely affect

the battery.

Rapid travel charger

The rapid travel charger can help you to quickly charge the battery. Plug the charger to an AC wall socket and plug the other end into the charger port of the phone. Please make sure the battery is correctly inserted on the phone before charging. Please do not remove the battery while charging.

Data cable

Only use the data cable approved by the phone manufacturer. The use of any other types would invalidate any approval or warrant applying to the phone and could be dangerous.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types s700 (FCC ID: WA6S700) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is

0.53 W/kg and when properly worn on the body is 0.54 W/kg. This device was tested for typical body-worn operations with the back of the handset kept 1.5cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.5cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

FCC WARNING

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device,

pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications not expressly

approved by the manufacturer could void the user's authority to operate the equipment.

NOTE 3: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.