



Copyright

All mobile products by GIGA-BYTE COMMUNICATIONS INC. mentioned in this document, including the device, accessories, software, text, music, and pictures, are owned by, or authorized by original manufacturers to GIGA-BYTE COMMUNICATIONS INC. Reproduction, transfer, distribution, or storage of part or all of the contents in this document in any form without the prior written permission of GIGA-BYTE COMMUNICATIONS INC. is prohibited.

GIGA-BYTE Group, GIGA-BYTE COMMUNICATIONS INC.

Safety Information

This section contains important information on safe and efficient operation. Please read this information before using the device.

- Use only the batteries and power adapter provided by the manufacturer. Use of unauthorized accessories may void your warranty.
- · Do not remove the battery while the phone is charging.
- · Avoid using the phone near electromagnetic sources such as TVs, radios, and microwave ovens.
- · Unplug the power adapter from the wall outlet during lightning storms to avoid electric shock or fire.
- Do not expose the phone or the battery to direct sunlight.
- Do not store your phone in temperatures higher than 60°C or 140°F.
- Do not use harsh chemicals or detergents to clean your phone.
- Do not handle the phone with wet hands while it is being charged. This may cause an electric shock or serious damage to the phone.

SAFETY PRECAUTIONS FOR BATTERY USE

- · Use only approved battery.
- Keep the battery dry and away from any liquid since this may cause a short circuit.
- Keep the battery away from metal objects since this may cause a short circuit.
- · Do not use damaged or deformed batteries.
- · If the battery emits a foul odor, discontinue use.
- · Keep the battery away from babies and small children.
- · If the battery leaks:
 - Do not allow the leaking fluid to come in contact with your skin, eyes or clothing. If already in contact, rinse
 with clean water immediately and seek medical advice.
 - Keep the battery away from fire since this may cause the battery to explode.
 - · Do not attempt to open or service the battery yourself.
 - · Do not dispose battery in fire or water.
 - Recycle or dispose used batteries according to the local regulations.
- Prevent to place the battery in extreme temperature condition, it maybe influence the battery efficiency.

ROAD AND ENVIRONMENTAL SAFETY

- Turn off the phone in areas with a potentially explosive atmosphere or where flammable objects exist such as gas stations, fuel depots, and chemical plants among others. Sparks from these areas could cause explosion or fire and result in injury or even death.
- Do not use hand-held phones while driving a vehicle. Use hands-free devices as an alternative.

SAFETY IN AIRCRAFT

Do not use the phone on board an aircraft. The phone's network signals may cause interference to the navigation system. As a safety measurement, it is against the law in most countries to use the phone on board an aircraft

Copyright © 2013 All Rights Reserved.

Android is a trademark of Google Inc. Use of this trademark is subject to Google Permissions. Bluetooth and the Bluetooth logo are trademarks owned by Bluetooth SIG, Inc. Java, JME and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the United States and other countries.

CE SAR Compliance

This device meets the EU requirements (1999/519/EC) on the limitation of exposure of the general public to electromagnetic fields by way of health protection.

The limits are part of extensive recommendations for the protection of the general public. These recommendations have been developed and checked by independent scientific organizations through regular and thorough evaluations of scientific studies. The unit of measurement for the European Council's recommended limit for mobile devices is the "Specific Absorption Rate" (SAR), and the SAR limit is 2.0 W/kg averaged over 10 gram of body tissue. It meets the requirements of the International Commission on Non-Ionizing Radiation Protection (ICNIRP).

For body worn operation, this device has been tested and meets the ICNIRP exposure guidelines and the European Standard EN 62311 and EN 62209-2, for use with dedicated accessories. Use of other accessories which contain metals may not ensure compliance with ICNIRP exposure guidelines.

SAR is measured with the device at a separation of 1.5 cm to the body, while transmitting at the highest certified output power level in all frequency bands of the mobile device.

The maximum SAR value for each frequency hand is listed below:

Band	Position	SAR10g (W/kg)
GSM900	Head	0.534
GSM1800	Head	0.205
WCDMA Band VIII	Head	0.567
WCDMA Band I	Head	0.576

WEEE Notice

The WEEE logo on the product or on its box indicates that this product must not be disposed of or dumped with your other household waste. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling of such hazardous waste. Isolated collection and proper recovery of your electronic and electrical waste equipment at the time of disposal will allow us to help conserve natural resources. Moreover, proper recycling of the electronic and electrical waste equipment will ensure safety of human health and environment. For more information about electronic and electrical waste equipment disposal, recovery, and collection points, please contact your local city center, household waste disposal service, shop from where you purchased the equipment, or manufacturer of the equipment.

RoHS Compliance

This product is in compliance with Directive 2002/95/EC of the European Parliament and of the Council of 27 January 2003, on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS) and its amendments.

European Union Regulatory Conformance

The equipment complies with the RF Exposure Requirement 1999/519/EC, Council Recommendation of 12 July 1999 on the limitation of exposure of the general public to electromagnetic fields (0–300 GHz). This equipment meets the following conformance standards: EN 300 328 V1.7.1, EN 301489-1 V1.9.2, EN 301489-3 V1.4.1, EN 301489-7 V1.3.1, EN 301489-17 V2.1.1, EN 301489-24 V1.5.1, EN 301 511 V9.0.2, EN 301 908-1 V5.2.1/ -2 V5.2.1, EN50360:2001/AC:2006, EN62209-1:2006/-2:2010, EN62311:2008, EN 62479:2010, EN 300 440-1V1.6.1/ -2 V1.4.1, EN 55022:2010/AC:2011 Class B, EN55024:2010, EN 55013:2001/A1:2003/A2:2006, EN 61000-3-2:2006/A2:2009, EN 61000-3-3:2008, EN 50332-1:2000/-2:2003 and EN 60950-1:2006/A11:2009. Changes or modifications to this product not authorized by the manufacturer could void the EMC compliance and negate your authority to operate the product. This product has demonstrated EMC compliance under conditions that included the use of compliant peripheral devices and shielded cables between system components. It is important that you use compliant peripheral devices and shielded cables between system components to reduce the possibility of causing interference to radios, televisions, and other electronic devices. We, hereby, declare that this cellular, Wi-Fi, & Bluetooth radio is in compliance with the essential requirements and other relevant provisions of Directive 1999/FJEC.

Intellectual Property Right Information

Right to all technologies and products that comprise this device are the property of their respective owners: This product has an Android platform based on Linux, which can be expanded by a variety of Java-Script-based application SW. Google, the Google logo, Android, the Android logo, Gmail, and YouTube are trademarks of Google Inc. Bluetooth and the Bluetooth logo are trademarks owned by Bluetooth SIG, Inc. Wi-Fi, the Wi-Fi CERTIFIED log, and the Wi-Fi logo are registered trademarks of the Wireless Fidelity Alliance. Java, JME and all other Java-based marks are trademarks or registered trademarks of the Wireless Fidelity Alliance. In the United States and other countries, microSD is a trademark of SD Card Association.

Products with 2.4-GHz Wireless LAN Devices France

L'utilisation de cet equipement (2.4GHz wireless LAN) est soumise à certaines restrictions: cet equipement peut être utilisé à l'interieur d'un batiment en utilisant toutes les frequences de 2400 a 2483.5MHz (Chaine 1–13). Pour une utilisation en environement exterieur, les frequences comprises entre 2400-2454 MHz peuvent être utilisé. Pour les dernières restrictions, voir http://www.art-telecom.fr.

For 2.4–GHz wireless LAN operation of this product, certain restrictions apply. This equipment may use the entire–2400–MHz to 2483.5–MHz frequency band (channels 1 through 13) for indoor applications. For outdoor use, only 2400-2454 MHz frequency band may be used. For the latest requirements, see http://www.art-telecom.fr.

Sound Pressure Level requirement

This device have been tested to comply with the Sound Pressure Level requirement laid down in the applicable EN 50332-1 and/or EN 50332-2 standards. Permanent hearing loss may occur if earphones or headphones are used at high volume for prolonged periods of time.

Prevention of Hearing Loss

Warning statement requirement under EN 60950-1:A12.

To prevent possible hearing damage, do not listen at high volume levels for long periods.



Note:

For France, headphones/earphones for this device are compliant with the sound pressure level requirement laid down in the applicable EN 50332-1: 2000 and/or EN50332-2: 2003 standard as required by French Article 1,5232-1



A pleine puissance, l'écoute prolongée du baladeur peut endommager l'audition de l'utilisateur.

General Information

This section contains important information on safe and efficient operation. Please read this information before using the device. Ignorance of the following notices may lead to violations of the law.

- · Before using the device, please make sure you have fully charged the battery.
- · Do NOT remove the battery from the device during charging.

- · Before inserting SIM card into the device, make sure that the device is switched off.
- · Do NOT attempt to dissemble the device on your own. This should be done by an authorized person.
- Use the device in accordance to instructions when in public facilities.
- In some countries, it is a violation against the law to record phone conversations. Always ask permission of the other party when you are going to record a conversation.
- · To protect your ears, turn down the volume before you use stereo headsets or other audio devices.
- To avoid damaging the touch screen and the device, do NOT apply excessive pressure on them, and remove the device from your pants' pocket before you sit down. It is also recommended that you only use the stylus or your finger to interact with the touch screen. It is not covered by the warranty that you crack the touch screen because of the improper usage.
- When you use the device for a long time, such as talking on the phone, browsing online, or charging the battery, the device may become warm. In most cases, this condition is normal.
- Refer servicing to the provider, or an authorized technician under the following conditions: 1. The device
 has been damaged. 2. When you follow the instructions to use your device, it does not operate normally. 3.
 The device has been exposed to water. 4. Liquid has been spilled or an object has fallen onto the device.
- Do Not push unauthorized objects into slots and openings in your device.
- The device should be placed away from heat sources such as stoves, radiators, heat registers, or other products that produce heat.
- Condensation may form on or within your device, when you move your device between environments with very different temperature and/or humidity ranges. To avoid damaging your device, make the moisture to evaporate before you use the device.
- To avoid damaging your device, do Not put your device on an unstable table, stand, bracket, or other places.
- Before you clean your device, unplug it, please. Use a damp cloth for cleaning, but do Not use water, liquid cleaners, or aerosol cleaners to clean the touch screen.

C€0700 � ቇ∑

Table of Contents


Copyright)-1
Safety Information)-2
General Information)-6
Objection 4 Continue Objects of	
Chapter 1 Getting Started	
1.1 Your Phone	
1.2 Installing or uninstalling the SIM Card, Battery, and Memory Card	
1.3 Charging the Battery	1-5
1.4 Turning the Phone On or Off	
1.5 Lock / Unlock	
1.6 Initial Settings	
1.7 Adjusting the Volume	
1.8 Contact	
1.9The Home Screen	1-1
Chapter 2 Phone Functions & Input2	2-1
2.1 Voice Calls	
2.2 Using On-Screen Keyboard 2	
,	
Chapter 3 Email & Messages3	
3.1 Creating and sending a text message	
3.2 Multimedia Message	
3.3 Voice Message	3-3
3.4 E-mail Accounts	3-3
3.5 Using E-mail	3-5
Chapter 4 Using the Internet4	
4.1 Connecting to the Internet 4	
4.2 Bluetooth modes	1-2
Chapter 5 Multimedia Applications	- 4
5.1 Photos and Videos	
5.1 Priotos and Videos	
5.3 Music 5	
5.3 Music)-O
Chapter 6 Programs	2 4
6.1 Pre-installed programs introduction	
6.1 Pre-installed programs introduction	
0.2 DIUWSEI	ว-ง ร ₋ ร

6.4 Calendar	. 6-5
6.5 Gmail	6-6
6.6 Maps	. 6-6
6.7 Latitude	. 6-7
6.8 Local	. 6-7
6.9 Navigation	6-7
6.10 Google Search	6-8
6.11 Talk	. 6-8
6.12 YouTube	6-8
6.13 Play Store	6-8
6.14 News and Weather	. 6-9
6.15 Best Choice	. 6-9
6.16 FM Radio	
6.17 Sound Recorder	
6.18 Connecting your phone to a computer	
6.19 File Explorer	6-10
6.20 Downloads	6-11
6.21 Google+	. 6-11
6.22 Screenshots.	6-11
Chapter 7 Managing Your Phone	. 7-1
7.1 Phone Settings	
7.2 Managing Basic Settings	. 7-4
7.3 Protecting Your Phone	. 7-5
7.4 Resetting Your Phone	. 7-6
7.5 Specifications	
•	

1. Getting Started


1.1 Your Phone

This section introduces you to the hardware of the device.



No.	Items	Functions
1		Press and hold for several seconds to turn the phone on or off. To set your phone to the sleep mode, press the power button briefly. Press again to turn the display back on.

2	Earphone jack	Use a headset for hands-free conversation or listening to
-		music.
3	P sensor/ Light sensor	P Sensor: The screen will turn off automatically when the device is close to the face during a phone call. Light Sensor: Adjust the brightness of the screen according to the environment.
4	Front Camera Use this front Camera to take pictures or record video.	
5	Receiver The source of voice.	
6	Touch screen Display screen.	
7	Home	 Go back to Home Screen. Press and hold to bring up recent activities.
8	Menu	Press to view the options of the menu.
9	Return	Return to the previous page.
10	Search	Connect to the website or find features in the phone.
11	MIC	Sound Receiver.




No.	Items	Functions
12	5.0MP Camera	The camera on the back of the device supports 5-mega-pixel photo and high-quality video.
13	Flash LED	Help photo shooting.
14	Back cover	You need to open the cover to install or uninstall the battery and the SIM card.
15	Speaker	The source of music and voice.
16	Volume	Press upward or downward to turn louder or down volume. Press down key fully to enter vibration mode.
17	Micro-USB port	 Connect USB cable and the AC adapter to charge the battery mildly. USB tethering: Share your

	phone's mobile data
	connection via USB cable.


1.2 Installing or uninstalling the SIM Card, Battery, and Memory Card

To remove the back cover


Please turn over your phone with the back cover facing up.



2. Please move your fingertip into the slot.



Pull the back cover with your fingertip and remove it.



SIM card

The SIM card contains your phone number, memory storage, and details of network service.

To install the SIM card

There are two slots for SIM cards. Left slot is for SIM2; right slot is for SIM1, the gold contacts are facing down. And the cut-off corner is facing toward the outside



To install the SIM1 card



To remove the SIM card


- First, remove the battery.
- Use your finger to slide the SIM card out of card slot.

Batterv

Your phone comes with a rechargeable battery. Battery life varies depending on the network, used applications, and the type of connections attached to your phone.

To install the battery

Make sure the contact of the battery is close to connectors in the battery slot.



To remove the battery

Use your fingertip to lift the battery, then remove it.

NOTE:

- To ensure battery performance and avoid risk from fire.
- Use only the original battery designated for the phone.
- Do not store the battery in temperature lower than -10°C or higher than 45°C.

To replace the back cover

 Please insert the cover into the slot from the top.



2. Then, press two point on the left and right of back cover fully until hearing clicks.



Memory card

You may need a microSD card to store photos, music, videos and other data.


To install the memory card

- 1. Insert the memory card with the gold contact facing down.
- 2. Push the memory card until it clicks into slot.



To remove the memory card


- For safe removal, tap Application Drawer > APPS tab > Settings > Storage > Unmount SD card.
- 2. Push the memory card to eject it from the slot.



1.3 Charging the Battery

When you take your phone out of box for the first time, the battery isn't at full of power. Please charge the battery fully before using.

- Connect the USB cable to the AC adapter, and then, connect to the device via the USB cable.
- Plug the AC adapter to a socket to start the charge.



NOTE:

To ensure safety, do not remove the battery from the phone while the AC adapter is connected or while it is being charged.

1.4 Turning the Phone On or Off

After installing the SIM card and charging the battery, you are now ready to turn your phone on.

To turn on your phone

Press and hold the power button until the phone shortly vibrates.

To turn off your phone

- Press and hold the power button for several seconds
- 2. A pop-up window appears, then tap "Power off".
- 3. Select "OK" to confirm.

To set your phone to the sleep mode

To set your phone to the sleep mode, press the power button briefly. It will turn the display off. To turn the display on, press the power button briefly again.

1.5 Lock/Unlock

There are four functions you may use when turning the device on or coming back from sleep mode.



Unlock the device

Drag G icon on screen and slide to Unlock icon for unlocking the device.





Taking pictures

Drag G icon to Camera icon to taking some pictures.



Muting the speaker

Drag G icon to Mute icon to mute the speaker..



Making a phone call

If you what to make a phone call, please drag the G lcon to Phone icon.



1.6 Initial Settings

Before initializing your device, please remember to insert your SIM card first. When turning on your phone for the first time or resetting your phone, you need to follow the steps as below:

- On the "Welcome" screen, you could change the default language, or tap "Start" to continue the setting. In this step, you can tap "Emergency Call" to make an emergency call.
- 2. In the screen of "Make it Google", you can tap
 "Get an account" to create a new account, tap
 "Sign in" to sign in the Google account, or tap
 "Not now" to do it later. Please follow the
 on-screen instruction to log in.

- In the screen of "Use Google location", you can allow or disallow Google's location service to collect anonymous location data. You can also allow or disallow Google to use My Location for Google search results and other Google services. Then. tao "Next".
- 4. Set up your name to personalize some apps. Then, tap "Next".
- In the screen of "Google services", you could get some information about Google Term of Service from here.
- Finally, tap "Finish" to complete the whole initial settings.

NOTE:

Some applications and functions needed to connect to the Internet such as location-based services and the automatic synchronization of your online accounts may incur the fees of the connection from your service provider. You may enable or disable the Internet later.

1.7 Adjusting the Volume

To adjust the volume of ringtone, media, and alarm

- Tap Application Drawer > APPS tab > Settings > Sound > Volumes.
- 2. Slide the volume bar to adjust each volume. Do as the following:
 - a. Drag the slider towards the left to decrease the volume, or drag the slider towards the right to increase the volume. Tap "OK" to save your settings.
 - b. Tap Application Drawer > APPS tab > Settings > Sound > Silent mode to set the phone to the silent mode.

NOTE:

When the phone is set to the silent mode, all sounds are turned off except media and alarm.

1.8 Contact

"Contact" is your phonebook that lets you store friends' names, phone numbers, e-mail addresses and other information."Contact" can connect to your Google, Corporate accounts, and integrate your contacts information.

Adding a Contact

- 1. Tap Application Drawer > APPS tab > Contact.
- 2. Tap less tab > tap less to add a new contact.
- 3. Choose where you want to synchronize the new contact with, Phone, SIM1 or SIM2.
- A new contact screen appears.
- Tap each field to fill out the contact information.
- 6. Tap "DONE" to save it.

NOTE:

The SIM card contact can't add picture to contact information.

Searching for Contacts

On Contact Screen, do any of the following to easily <u>search</u> for contacts:

 Tap Type the first few letters of the contact name to search. The list is filtered when typing.
 When finish searching, you could tap to go back to the contacts screen.



Contact groups

If you want to categorize the contacts, please follow the steps as below:

To add Contact groups in local groups

- 1. Tap Application Drawer > APPS tab > Contact.
- 2. Tap at tab. You can tap or to switch the group of sorts.
- On local groups screen, tap to add a new group.
- 4. Enter the new group name, then tap "OK".
- 5. Tap one of groups.
- 6. Tap "Add members" to select new members.
 Tap "Ok" to save your settings.
- 7. Members of the group are displayed below.

To add Contact groups in remote groups

- 1. Tap Application Drawer > APPS tab > Contact.
- 2. Tap atab. You can tap are or to

switch the group of sorts.

- On remote groups screen, tap to add a new group.
- Select an account to add the group (If you have two more accounts).
- 5. Enter the group name.
- Type persons' name to add members. Members of the group are displayed below.
- 7. Tap "DONE" to finish settings.

Manage Accounts

- 1. Tap Application Drawer > APPS tab > Contact.
- 2. Tap Menu > Accounts.
- You could turn on "Accounts & sync". If so, Applications can sync, send, and receive data automatically.

Import / Export Contacts Import Contacts from SIM card.

- Tap Application Drawer > APPS tab > Contact.
- 2. Tap Menu > Import/export > Import from SIM
- You can select SIM1 or SIM2 (If SIM2 card inserted). Then tap "OK".
- You can select an account to save the import contacts.
- Select contacts you want, or check "All". Then tap "Ok".
- You can check the import situation in the status bar.

Import Contacts from storage

- 1. Tap Application Drawer > APPS tab > People.
- Tap Menu > Import/export > Import from storage.
- 3. You can select an account to save the import contacts.
- Select the Card files. Please follow the steps in the submenu.

You can check the import situation in the status bar.

Back up Contacts Export Contacts to SIM card

- Tap Application Drawer > APPS > Contact.
- Tap Menu > Import/export > Export to SIM card.
- You can select SIM1 or SIM2 (If SIM2 card inserted). Then tap "OK".
- Select contacts you want, or check "All". Then tap "Ok".

Export Contacts to storage

- 1. Tap Application Drawer > APPS tab > Contact.
- 2. Tap Menu > Import/export > Export to storage.
- Tap "OK" to confirm.

Favorite Contacts

You can add the most frequently called contacts to the favorite contact list which helps you to find contacts quickly and easily.

Add to Favorites

- 1. Tap Application Drawer > APPS tab > Contact.
- On tab, tap the desired contact into the information screen.
- Tap icon to add to Favorites.
- When you tap tab on the Contacts screen, you will find the contact in the favorite list.

Remove from Favorites

- Tap Application Drawer > APPS tab > Contact.
- Tap itab, the favorite contacts are displayed.
- 3. Tap the desired contact into the information screen.
- 4. Tap icon to remove it from Favorites.



1.9 The Home Screen

On Home Screen, you can quickly access common features and view notifications of missed calls, received messages, battery, and the status of the connection.

Default Home Screen: Main functions



You can slide the Home Screen from the left side to the right side or from the right side to the left side to switch it. The icons located at the bottom of the home page have different functions:

Icons	Descriptions
📞 📮 🜐 🚰 🌀	Favorites Tray can keep your most important shortcuts and folders.
	Tap to launch Application Drawer.

Self-defined Home Screen: You can add the shortcuts and widgets.



How to Navigate

- Tap: You can tap the icon on the screen to activate the application.
- Press and Hold: Press and hold the icon on the Home Screen to make it movable. Press and hold an icon in the Application Drawer to add it to the Home Screen you want.
- Slide: Slide the Home Screen from the left side to the right side or from the right side to the left side to change different pages.
- Drag: After pressing and holding the icon on the Home Screen, you can arrange it. Drag it to anywhere you like on the screen or to remove.

Status Icons

The icons of the status bar indicate different types of information. Tap the status bar and scroll down to view notifications or view system information.

Types	Icons	Descriptions
	٠	Call is in progress.
Phone call	Ð	Your call is on hold.
Pilone can	₽	Mute the call.
	٧	Speaker is on.
	Ø,	Vibration is on.
Volume	\cap	Wired headset connected.
	Ç	Wired microphone headset connected.
		Battery is full.
Battery		Battery is low.
Battery		Battery is very low.
	ź	Battery is charging.
Network and Connection	 	Maximum signal strength. Fewer bars indicate lower signal strength. Left icon is SIM1 signal (WCDMA+GSM). Right icon is SIM2

		signal (GSM).
	364 H4 364 E44	GPRS\ EDGE\ 3G\ HSDPA is in progress.SIM1 supports GPRS\ EDGE\ 3G\ HSDPA networks.SIM2 supports GPRS\ EDGE networks.
	\$	Wi-Fi is connected.
		Wi-Fi is in progress.
	*	Wi-Fi Network is activated.
	X	Airplane mode.
	ş	Portable Wi-Fi hotspot is activated.
	0	Both USB tethering and Portable Wi-Fi hotspot are activated.
		GPS is on.
	8	Bluetooth is on.
	ψ	The device is connected to PC via the USB cable.
Notification	ÿ	New text message.
TOUIICAUOII	~	New e-mail.

Σ	New Gmail.
0	Alam.
1	Event notification.
کر	Missed call.
۱Ď۱	USB debugging is connected.
A	General notification.
FM	FM radio is on.
0	Playing a song.
<u>+</u>	Downloading an application.

Shortcuts in status bar

Tap the status bar and scroll down to use shortcuts.

Icons	Functions
?	Enable/disable Wi-Fi.
*	Enable/disable Bluetooth.
@	Enable/disable GPS.
↓ ↑	Enable/disable mobile network.
	Tap to adjust the brightness.

Recent apps list

Recent apps list provides an efficient way of switching between recently used applications. Switch to an app by touching it.



- 1. Press and hold the Home key.
- 2. A Recent app list screen will appear.
- 3. Remove an item by swiping left or right.
- 4. Or jump instantly from one task to another using the list.

Using Widgets

You may add and customize widgets on the Home Screen as you like.



To add widgets

- Tap Application Drawer > WIDGETS tab.
 Select a widget you want. Then, tap and hold.
- Select a widget you want. Then, tap and hold the widget icon to any Home Screen thumbnail you want to add it.
- Tap and hold the widget icon, drag to move it among the Home Screens.



To delete widgets

- Tap and hold a widget icon which you want to delete on the screen. The widget will enlarge and "Remove" will appear on the top of Home Screen.
- 2. Drag the widget icon to the "Remove" to delete it.

Folders

You can also add / delete folders to your Home Screen and Favorites Tray.

To create folders

- Tap and hold an app icon, then drag it over to another app icon, they will automatically create a new folder. You can also drag other apps to add into the same folder.
- 2. Tap the folder to open it.
- 3. Tap "Unnamed Folder" to name the folder.

To delete folders

- Tap and hold a folder of Home Screen. The folder will enlarge and "Remove" will appear on the top of Home Screen.
- 2. Drag the folder to the "Remove" to delete it.



Setting the wallpaper

Customize the wallpaper of your Home Screen with default wallpapers or with pictures in your phone.



Set wallpaper from Live wallpapers or Wallpapers

- 1. Long press any place on the Home Screens.
 There is a menu that will pop up.
- 2. Tap "Wallpapers" or "Live Wallpapers".
- All system wallpapers are displayed. You can tap to preview it.
- 4. Tap "Set wallpaper" to set up your selection.

Set wallpaper from Pictures

- Long press anywhere on the Home Screens.
 There is a menu that will pop up.
- Tap "Gallery", you can view all pictures on the album.
- 3. Tap to select a picture you want to use.
- 4. Use your finger to select the crop area.
- 5. Tap "CROP" and the cropped image will be your wallpaper on the Home Screen.



2. Phone Functions & Input

Phone Functions

Tap Application Drawer > APPS tab > Phone.

2.1 Voice Calls

Making a call

To make a call from the Phone screen

- 1. Go to the Phone screen.
- 2. Use the keypad to input phone number.
- Tap then choose SIM1 or SIM2 to make the phone call.





NOTE:

Tap
to delete a number. Tap and hold
to erase entire numbers.

To make a call from Contacts

- 1. Tap Application Drawer > APPS tab > Phone.
- 2. Tap 🚨
- 3. Tap a contact you want to call.
- If SIM2 inserted, there is a menu will pop up. You may select "SIM1" or "SIM2" to make a phone call.

To make emergency calls

You have to unlock your device before making an emergency call. Enter the international emergency number 112, and tap SIM1 or SIM2 to make the emergency call.



To make international calls

- Go to the Phone screen.
- Tap and hold 0 until the "+" is displayed which is international prefix code.
- Enter the country code, area code, and phone number.
- Tap and SIM1 or SIM2 to make the international call.

Answering a call

When there is an incoming call:

- The phone will ring if the ring volume is turned on
- A notification message will appear on the screen.

To accept or reject an incoming call

- · To accept a call, slide to Talk icon on the screen.
- To reject a call, slide to End icon on the screen.

Quick response an incoming call

When there is an incoming call, you can quick response with message by sliding to Messaging icon on the screen



To put a call on hold

If you are having a call conversation, you can tap

If you are having a call conversation, you can tap

If you are having a call conversation, you can tap

To switch between calls

If you are having a call conversation, and there is another incoming call, slide the Talk icon to put the first call on hold and answer the second call.

Tap to switch between calls.

To set up conference calls

- When you are already having a call conversation, tap to enter another phone number.
- 2. When someone answer your phone call, tap Amerge calls to set up the conference call.

If you are having a call conversation, and there is another incoming call, you can tap to set up



the conference calls also

NOTE:

Conference call is a network service. Please check with your network carrier for this function.

To manage other voice call features

When you are having a call conversation

- Tap to activate speakerphone, or tap again to cancel it.
- Tap to mute microphone, or tap again to un-mute it.

Ending a call

Tap End icon to end a call.

2.2 Using On-Screen Keyboard

On-screen keyboard appears in portrait mode when an application requires text input, such as messaging and writing e-mails. The keyboard input method is activated by the default settings.

Using on-screen keyboard

- · Use the keys on the on-screen keyboard.
- · Tap the keys to enter the characters.

Setting the Input Method

Your phone supports several text input methods, and you could select which one you prefer.

- 1. Tap Application Drawer > APPS tab > Settings
- > Language & input.
- Tap "Default" .There is a pop-up window will show.
- 3. Select an input method you want to use.

Basic input settings

Tap Application Drawer > APPS tab > Settings > Language & input.

- 1. Language settings:
 - Select languageSpelling correcton
 - Personal dictionary
- 2. Keyboard & input settings:
 - Android keyboard
 - Google voice typing
 TouchPal keyboard
- Speech settings:
 - Voice Search
- Safe Search
 Mouse/Trackpad
 - Pointer speed

Personal dictionary

On the personal dictionary screen, tap to add the self-defined words in the personal dictionary. When you compose, you can use them. Tap the self-defined word in the personal dictionary to edit it or tap to delete it.



TouchPal Input Method



General settings

- · Keypress sound:
 - You can adjust keypress sound here.
- Keypress vibration:
- You can adjust keypress vibration here.
- · Resize keyboard height:
- You could adjust keyboard height here. · Keypress popup:
- Enable or disable popup effect for keypress. · Alternative symbols:
- - Show alternative symbol on buttons. You could slide-down or long-press the keyboard to input these symbols.
- · Skin:

Customize your own skin.

Keyboard layout:

Set portrait or landscape layout and some other functions.

Smart input:

Keyboard intelligence for western languages.

Languages

Set up Multilanguage keyboard.

Dictionary management:

You can choose backup or restore your dictionary.

Help & About


Check update, see what recommended application in the market, or about the version.



Using TouchPal Input Method



Icons	Functions
	Tap to go to quick settings.
0	Tap to activate settings.
	Tap to copy, cut or paste words.
	Tap to activate voice input.
	Tap to close input keyboard.
•	Tap to active Capital letter mode.



TouchPal Curve Input



Using Curve let you type faster than normal IME. Input a word by drawing through letters.

Put your finger on the first letter of the word and draw a path from letter to letter, then lifting up your finger after the last letter. And the predicted words will show on the screen.



Android keyboard

· Input languages:

You can change input language.

Auto-capitalization:

The first letter of sentences to be capitalized.

· Vibrate on keypress:

Phone vibrates when user presses any key on the on-screen keyboard.

Sound on keypress:

Phone sounds when user presses any key on the on-screen keyboard.

Popup on keypress:

Checking this option will enable the letters to popup when the user presses them on the keyboard.

Show settings key:

Automatic/Always sh

Automatic/Always show/Always hide.

· Voice Input key:

Voice input on main keyboard, on symbols keyboard, and off.

· Add-on dictionaries:

You can install Multilanguage dictionaries.

· Auto correction:

Spacebar and punctuation automatically correct mistyped words.

· Show correction suggestions:

Display suggested words while typing.

 Advanced settings: Options for expert users.

Using Android keyboard

• To toggle between upper and lower case letter display, tap .

 To display the numerical and symbols keyboard, tap 2123



How to select input method

- 1. When you are using any one of input methods.
- 2. Slide down the status bar list.
- Tap "Select input method", to show all the input method.
- 4. Then, tap one of them you want to use.

3. Email & Messages

Use Messaging to access text and MMS messages. Use Email to send and receive e-mail messages via your Internet e-mail accounts.

3.1 Creating and sending a text message

Your phone offers several ways to create and send a new text message.

From Message screen

- Tap Application Drawer > APPS tab > Messages.
- Tap to create a new message.
- In the "To" field, enter the recipient's phone number or tap to add from your contacts.
- 4. Type your message in the "Type message" field.
- Tap to send your message. You may select SIM1 or SIM2 (If SIM2 inserted).

From Contact screen

- 1. Tap Application Drawer > APPS tab > Contact.
- 2. Tap a contact to display the contact information.
- 3. Tap the icon = to send the message.
- 4. Compose your message.
- Tap to send your message. You may select SIM1 or SIM2 (If SIM2 inserted).

From Phone screen

- 1. Tap Application Drawer > APPS tab > Phone.
- 2. Tap tab to view all call history.
- 3. Tap a call contact from the call log.
- Tap icon to send the message.
- 5. Compose your message.

6. Tap to send your message. You may select SIM1 or SIM2 (If SIM2 inserted).

NOTE:

If you exit Messages before sending, unsent message will be saved as a draft automatically.

Receiving and Managing Messages

When you send and receive messages from a contact, these messages are grouped as a message thread. A message thread looks like an exchanged conversation.

To reply to a text message

- Tap Application Drawer > APPS tab > Messages.
- 2. Tap a message you want to reply.
- 3. Enter your message in "Type message".
- 4. Tap > to send your message.

To forward a text message

- Tap Application Drawer > APPS tab > Messages.
- Tap a message to view the whole thread.
- Tap and hold a message to show Message options list.
- 4. Tap "Forward".
- 5. Enter recipient's phone number in the "To" field.
- 6. Tap ➤ to send your message. You can select SIM1 or SIM2 (If SIM2 inserted).

3 Email & Messages

To delete all messages

- Tap Application Drawer > APPS tab > Messages.
- Tap Menu > Delete all threads. Menu button is on the down intermediate of the screen.
- 3. Tap "Delete" to delete all messages in this message box.

To delete a message thread

- Tap Application Drawer > APPS tab > Messages.
- Tap and hold a message thread you want to delete.
- 3. Tap 📋 to delete the message thread.

To delete a message within a thread 1. Tap Application Drawer > APPS tab >

- Messages.
- 2. Choose a message you want to delete.
- Tap and hold it until a Message options list shows.
- 4. Tap "Delete" to delete the message.

3.2 Multimedia Message

A Multimedia message or MMS can contain letters, an image, an audio, or a video file.

Creating and sending an MMS message

Your phone offers several ways to create and send a MMS message.

Send MMS from Message screen

- Tap Application Drawer > APPS tab > Messages.
- Tap to create a new message.
- Enter the recipient's phone number in the "To" field
- 4. Tap to attach pictures, capture picture,

- video, capture video, audio, record audio, or slideshow file. The message converts to a MMS message automatically.
- 5. Enter your message with the on-screen keyboard in "Type message" filed.
- Tap > to send your message.

Send MMS from People screen

- 1. Tap Application Drawer > APPS tab > Contact.
- 2. Tap a contact.
- Tap icon to write a message back.
- 4. In the "To" field, and enter the recipient's phone number.
- Tap to attach pictures, capture picture, video, capture video, audio, record audio, or slideshow file. The message converts to a MMS message automatically.
- Enter your message with the on-screen keyboard in "Type message" filed.
- 7. Tap > to send your message.

From Phone screen

- Tap Application Drawer > APPS > Phone.
- 2. Tap tab.
- Tap a call in the list of the tab.
- 4. Tap 🖪 icon.
- In the "To" field, and enter the recipient's phone number.
- Tap to attach pictures, capture picture, video, capture video, audio, record audio, or slideshow file. The message converts to a MMS message automatically.
- Tap "Type message", and then, enter your message with the on-screen keyboard.
- 8. Tap > to send your message.



3.3 Voice Message

Your phone can send voice message.

To create a voice message

- Tap Application Drawer > APPS tab > Messages.
- Tap to create a new message.
- Enter the recipient's phone number in the "To" field
- Tap > Record audio.
- Tap to record an audio file.
- 6. Tap to stop recording.
- 7. Tap to listen to your recording.
- Tap to continue, or tap to record again.
- Tap "Play" to listen to your recording again, Tap "Replace" to be replaced another attachment, or tap "Remove" to delete your recording from the MMS message.
- 10. Enter your message with the on-screen keyboard in "Type message"
- 11. Tap > to send your message.

3.4 Email Accounts

All your received email messages are delivered to your phone.

Setting up an Internet e-mail account

- 1. Tap Application Drawer > APPS tab > Email.
- Enter your e-mail address and Password. Tap "Next".
- 3. Select the e-mail account of types.
- The phone will retrieve the e-mail settings automatically.
 - If the e-mail settings are pre-configured, the e-mail setup wizard displays a successful

message.

- If the e-mail settings are not found, manual setup is in process automatically. You can follow the instructions to complete the settings.
- Enter Account name and then, tap "Next" to finish the settings.

NOTE:

The Account name is the name shown on the Email screen.

To open Email

Tap Application Drawer > APPS tab > Email to open your e-mail.

To add the second e-mail account

- 1. Tap Application Drawer > APPS tab > Email.
- 2. Tap Menu > Settings > ADD ACCOUNT.
- Please follow the "Account setup" steps to finish the settings

To delete an e-mail account

- 1. Tap Application Drawer > APPS tab > Email.
- Tap Menu > Settings.
- Tap one of your accounts (If you have two more e-mail accounts).
- 4. Tap "Remove account" which is on the bottom of the page.
- 5. Tap "OK" to confirm.





Customizing Account settings

You can configure the account settings of your e-mail accounts such as Account name, Email check frequency, and Default account, etc.

To set up your name and account name

- 1. Tap Application Drawer > APPS tab > Email.
- 2. Tap Menu > Settings.
- Tap one of your accounts (If you have two more e-mail accounts).
- Tap "Account name" or "Your name" and enter a name you want.
- 5. Tap "OK" to confirm.

To set up the e-mail check frequency

- 1. Tap Application Drawer > APPS tab > Email.
- 2. Tap Menu > Settings.
- Tap one of your accounts (If you have two more e-mail accounts).
- Tap "Inbox check frequency". You can set how often to check for new e-mail automatically.

To set up default account

- 1. Tap Application Drawer > APPS tab > Email.
- Tap Menu > Settings.
- Tap one of your accounts. (If you have two more e-mail accounts)
- Check "Default account" to set this account as a default one.

To select an account

- 1. Tap Application Drawer > APPS tab > Email to open your e-mail.
- Tap Account name arrow to view all e-mail accounts.
- 3. Tap an e-mail account you want to access.



To configure Email settings

Tap Application Drawer > APPS tab > Email, then tap Menu > Settings > General to set up the application of your e-mail.

3 Email & Messages

3.5 Using E-mail

Composing and sending an E-mail

- Tap Application Drawer > APPS tab > Email, and then, tap Account name arrow to select an account.
- 2. Tap M to compose a new email.
- Enter the recipient's e-mail address in the "To" field or tap to add from contacts.
- 4. Enter the Subject.
- 5. Compose your e-mail.
- 6. Tap to send your e-mail.

Sending an E-mail from People screen

You can send an e-mail to a contact with an e-mail address stored in People.

- 1. Tap Application Drawer > APPS tab > People.
- Tap a contact whom you want to email to.
- 3. Tap the contact's Email address. Tap "Email" in the submenu.
- 4. Enter the Subject and compose your e-mail.
- 5. Tap to send your e-mail.

Adding attachments to an e-mail message

Before sending your message, tap Menu > Attach file, and then, choose an attachment you want to attach.

Receiving e-mails

E-mails will be received automatically when your phone connects to wireless networks.

Reading e-mails

The Inbox displays the e-mail headers. When you open the e-mail, it shows the message of text, unless the attachments. Please download the e-mail attachments to view it.

To reply or forward an e-mail

1. Open an e-mail.

- 2. Do any of the following:
 - Reply: Tap to reply the e-mail.



- Reply all: Tap > to reply all recipients and sender.
- Forward: Tap > to forward the e-mail to other people.
- 3. Enter the recipient in the "To" field if need.
- Compose your message.
- 5. Tap to send your e-mail.

To delete an e-mail

- 1. Tap Application Drawer > APPS tab > Email.
- In your mailbox screen, you can view the e-mails.
- Check the e-mails, and then tap to delete the e-mail.



4. Using the Internet

4.1 Connecting to the Internet

Your phone connects to the Internet via:

- Wi-Fi
- GPRS/ EDGE/ 3G/ 3.5G

NOTE:

If you connect to the Internet, you may be charged. If you want to stop the connection. you need to tap Application Drawer > APPS tab > Settings > WIRELESS & NETWORKS section > More > Mobile networks > to unmark Data enabled.

Wi-Fi

Your device can connect to the detected network through Wi-Fi.

- 1. Tap Application Drawer > APPS tab > Settings > WLAN.
- 2 Switch to turn "WLAN" on or off

To connect to a Wi-Fi network

- 1. Tap "WLAN", check WLAN function and turn it on. Begin to search the available Wi-Fi networks
- 2. Detected networks are displayed below. Tap one network then tap "Connect".
- 3. If you select an open network, the connection is established automatically.
- 4. To connect a secured connection, you will be prompted for the password. Enter the password then tap "Connect".
- 5. When Wi-Fi is connected, the connection icon
 - will be displayed on the status bar.

To add Wi-Fi network

- 1. Tap Application Drawer > APPS tab > Settings > WLAN.
- In Wi-Fi screen, tap Menu >ADD NETWORK. An on-screen window will pop-up.
- 3. Follow the on-screen instructions and enter the necessary information, then tap "Save" to save the settings.



To configure Wi-Fi settings

- Tap Application Drawer > APPS tab > Settings > WLAN.
- Tap Menu > Advanced to check the Wi-Fi. settinas.

4 Using the Internet

Tethering & portable hotspot

Share your phone's mobile data connection via USB, Bluetooth, or as a portable Wi-Fi hotspot.

- Tap Application Drawer > APPS tab > Settings > WIRELESS & NETWORKS section > More > Tethering & portable hotspot.
- You can turn on/off USB tethering, Portable Wi-Fi hotspot, Bluetooth tethering and configure the portable Wi-Fi hotspot settings.

VPN settings

Set up & manage Virtual Private Networks (VPNs.)

- Tap Application Drawer > APPS tab > Settings > WIRELESS & NETWORKS section > More > VPN
- You must set lock screen PIN or password before using credential storage. Please tap OK go to Unlock selection, then choose which way you want to lock the screen.
- 3. After you set it up. It will go back to VPN screen.
- 4. Tap "Add VPN network" to edit VPN network.
- 5. After filling in all necessary information, tap "Save" to finish the settings.

To start a data connection

If you set up multiple data connections, select the connection you want to use.

- Tap Application Drawer >APPS tab > Settings > WIRELESS & NETWORKS section > More > Mobile networks.
- Check "Data enabled" to enable data access over Mobile network.
- 3. If you would like to use network when roaming, please check "Data roaming".

4.2 Bluetooth modes

Bluetooth on your phone operates in three different modes:

- On: Bluetooth is turned on. Your phone detects other Bluetooth devices, but your phone is not visible to others.
- Discoverable: Bluetooth is turned on, but your phone is not visible to other Bluetooth devices.
- Off: Bluetooth is turned off.

To turn Bluetooth on or off

- Tap Application Drawer > APPS tab > Settings > Bluetooth.
- 2. Switch or tap to turn it on.
- Tap "Bluetooth" to view the menu options.
- Tap the device's name to make your device visible to others.



4 Using the Internet

Connecting to Bluetooth Devices

A connection to a Bluetooth device is called a partnership. You need to pair and create a partnership with a Bluetooth device to exchange information.

- Tap Application Drawer > APPS tab > Settings > Bluetooth.
- Tap "SEARCH FOR DEVICES" to search for a new device.
- 3. Detected Bluetooth devices are displayed on the screen .Tap one device to connect.
- 4. Start to pair, enter the password, and then tap "OK" to finish pairing.

NOTE:

- The password enter on your phone must be the same one be entered on the device which you want to pair with. The password is required at the first time, once a partnership has been created, the password will no longer require again.
- 2. If you want to view the received files, you can tap Menu > Show received files.



5.1 Photos and Videos

Your phone is equipped with a 5.0 megapixels camera to take photos and videos.

Taking a photo




lcon	Function
	Displays the last image. Tap to go to Review Screen. You need to insert your SD card first.
Ö	Indicates capture mode. Tap to switch to video or panorama mode.

•	Tap to take a photo.
茔	Tap to configure camera settings.
٠,5	Display the flash mode.
-O +	Tap to zoom in or out.
<u>@</u>)	Tap to switch between rear and front camera.

- Tap Application Drawer > APPS tab > Camera.
 The screen switches to landscape view automatically.
- Tap to take a picture.



Recording Video




lcon	Function
00:06	Indicates the recording time.
V	Displays the last video. Tap to go to Review Screen. You need to insert your SD card first.
	Indicates capture mode. Tap to switch to camera or panorama mode.
	Press to record video.

艼	Tap to configure Camcorder settings.
-O+	Tap to zoom in or out.
.	Tap to switch between rear and front camera.

- 1. Tap Application Drawer > APPS tab > Camera
- 2. Switch to recorder mode.
- 3. Aim the phone at the subject.
- 4. Tap to start to record, tap again to stop recording.

Taking a panorama picture



- 1. Tap Application Drawer > APPS tab > Camera.
- 2. Choose panorama mode.
- 3. Aim the phone at the subject.
- Tap to record the all view by moving slowly. Then tap again to finish recording.

lcon	Function
	Indicates how long you record.
Sec. -	Displays the last panorama. Tap to go to Review Screen. You need to insert your SD card first.

I	Indicates capture mode. Tap to switch to camera or video mode.
•	Press to record a panorama.

Reviewing a photo

After taking a picture, the function of reviewing a photo:

Tap sto share your picture.









Tap to Gallery view the picture.

Reviewing a video

After recording video, the function of reviewing video:



Icon	Function
<	Tap to share your video.
00	Tap to play or pause the video.
00:01 - 00:07	Slide to go forward or backward.

Configuring camera and camcorder settings

In the camera or camcorder screen, tap at to view and set up your camera or camcorder.

Mode	Setting	Available options
	Flash mode	Auto, On and Off
	White Balance	Auto, Incandescent, Daylight, Fluorescent and Cloudy
	Exposure	+2 \ +1 \ 0 \ -1 \ -2
	Scene mode	Auto, ASD, Action, Portrait, Landscape, Night, Night Portrait, Theatre, Beach, Snow, Sunset, Steady Photo, Fireworks, Sports, Party, Candlelight, Backlight, Flowers, AR
Camera	Store location	Turn on/off
	Picture size	5MP, 3MP, 2M, 1.3M, 1M, SVGA, VGA,CIF, QVGA, QCIF
	Picture quality	Super fine, Fine, Normal, Jpeg 100%, Jpeg 95%, Jpeg85%, Jpeg 75%, Jpeg 65%, Jpeg 55%
	Storage Location	SDcard, Phone
	Color effect	None, Sepia, Mono, Negative, Solarize, Posterize, Aqua
	Saturation	Level 0-10

Contrast

Level 0-10

	Contrast	Level 0-10
	Select Auto	Spot Metering, Center
	Exposure	Weighted, Frame
	Mode	Average
	Anti	50Hz, 60Hz, Off and
	Banding	Auto
	Touch AF/ AEC	On and Off
	Selectable	Auto, Spot Metering,
	Zone Auto	Center Weighted,
	Focus	Frame Average
	Sharpness	Level 0-6
		Auto, ISO100,
	Select ISO	ISO200, ISO400,
		ISO800, ISO1600
	Focus	Auto, Normal, Infinity,
	Mode	Macro, CAF
	Face	On and Off
	Detection	
	Shutter	On and Off
! <u></u>	Sound	
	Flash mode	On and Off
	White	Auto, Incandescent,
	White Balance	Daylight, Fluorescent
		and Cloudy
	Time lapse	Off, 1s, 1.5s, 2s, 2.5s,
	interval	3s, 5s, 10s
Camcorder	Video	720P,D1, FWVGA,
Camboluel	quality	WVGA, VGA,
]	WQVGA, CIF, QVGA
		and QCIF
	Store	Turn on/off
	location	
	Video	H264, H263, MPEG4
	Encoder	,,

Audio	AAC and AMRNB
Encoder	
Video	Unlimited, 10 minutes
duration	and 30 seconds.
Color effect	None, Mono, Sepia,
	Negative, Solarize,
	Posterize, Aqua

5.2 Viewing Photos and Videos

To view photos in the album

- 1. Tap Application Drawer > APPS tab > Gallery.
- Tap one of picture folders to view the images in thumbnails.
- 3. Tap an image to view.
- Slide the screen from left side to right side or from right side to left side to view all the photos in this album.

To play slideshow

- 1. While viewing an image, tap Menu > Slideshow.
- 2. Tap screen again to stop the slide show.

To set the image as Wallpaper

- While viewing the image, tap Menu > Set picture as > Wallpaper.
- 2. Drag your finger to select the crop area.
- 3. Tap "CROP" to set the image as the wallpaper.

To save a image as Contact photo

- While viewing the image, tap Menu > Set picture as > Contact photo.
- 2. Choose a contact to add image.
- 3. Drag your finger to select the crop area.
- Tap "CROP" to save the image as the contact photo.

To edit an image

While viewing the image, to edit an image:

- To rotate image, tap Menu > Rotate left/ Rotate right.
- To crop, tap Menu > Crop.
 - Drag your finger to select the area you want to keep.
- Tap "CROP" to save the image.
- To add effects, tap Menu > Edit.
 - Using effects on the bottom to apply to the image.
 - 2. Tap "Save" to save the image.

To view file properties

- 1. While viewing the image, tap Menu > Details.
- 2. The file information is displayed.
- 3. Tap "Close" to return to the image.

Play video from the video file

- Tap Application Drawer > APPS tab > Gallery > Camera > select a video file you want.
- Tap to play it.

Play video from Videos


- 1. Tap Application Drawer > APPS tab > Videos.
- 2. Choose a video you want to play.
- The videos will be played automatically, tap to stop playing

5.3 Music

You have to copy your audio files to the storage card before playing music, because the music player only plays audio files saved in the storage card of your phone. Tap Application Drawer > APPS tab > Music

Music Screen

 Playback screen: Displays the playback area with the playback controls.



Icon	Function
•	Album art picture or animation
O Makaowa artist: O montas	The display area of audio information.

14	Tap to go to the
	previous song.
N 11	Tap to play or pause
	the song.
	Tap to go to the next
4	song.
	Slide to go forward or
	backward.
	Tap to go to Now
Printer.	playing list. Displays the
	list of currently playing
	songs and those on
	queue for playback.
	Tap to shuffle, when
\sim	it's green means the
	shuffle is on.
\$	Tap to enable or disable
	the repeat function. You
	can choose to repeat all
	songs or repeat current
	song.

Library Displays folder categories which could make searching for media files quickly and easily.




Playlists

Tap to go to play list. You may see Recently added and My recordings in this page.



Now playing list

Tap lime when you are listening to music, you could tap and hold the icons on the left of each recording files to arrange its sequence.



To play music


- 1. Tap Application Drawer > APPS tab > Music.
- Tap Songs, and all songs on the phone will be displayed.
- 3. Tap to select a song, and then it will play automatically.

Changing Playback options

While playing music, tap Menu button on the down right side of screen.

- Tap "Library" to see all playlists.
- Tap "Party shuffle" to play all songs in shuffle order.

- Tap "Add to playlist" to add the song to Current playlist, New or My recordings.
- Tap "Use as ringtone1" or "Use as ringtone2" to set up your personal ringtone.
- Tap "Delete" to delete the song which is playing.



To edit your music

In player screen, you could set up effects, tap Menu > Sound effects.

- Drag or tap Equalizer to turn it on.
- 2. Tap arrow to show different effect list
- Tap to select an effect you want items will be adjusted automatically.



Creating a new playlist

Add songs to a specific playlist or create a playlist.

- Tap Application Drawer > APPS tab > Music.
- In Songs tab, tap and hold a song you want to add, then tap "Add to playlist" in the pop-up submenu.
- Tap "New" to create a new playlist. Input a name for the created playlist, and then tap "Save". The song will be added to the new playlist automatically.
- 4. You may check this new playlist in Playlists tab.

To remove a music file from the playlist

- 1. Tap Application Drawer > APPS tab > Music.
- In Songs tab, tap and hold the song you want to delete. Then, tap "Delete" in the pop-up suhmenu
- Tap "OK", and then, the song will be deleted from the list.



6. Programs

6.1Pre-installed programs introduction

Icons	Programs	Description
	Best Choice	Allows you to use the phone easily, we recommend and provide you the best software and functionality.
	Browser	Browses the web and download files from the Internet.
*	Calculator	Performs arithmetic functions, such as addition, subtraction, multiplication, and division, etc.
	Calendar	Creates and tracks schedule or appointments.
Ve)	Camera	Captures still images.
	Chrome	Google's browser service
	Clock	Sets up alarm clock.
	Contact	Stores names, numbers, e-mail, and other information.

	Downloads	To view files and items you've downloaded from mail or any other sources, like Play Store.
*	Dropbox	Bring and share your photos, docs, and videos anywhere.
	Email	Sends and receives e-mail messages.
	File Explorer	Manages all files.
90.9	FM Radio	Listen to music/ news on the FM Radio.
	Gallery	Views and edits photos and videos.
	Gmail	Google's web-based e-mail service.
Q +	Google+	You can check friends' updates and post updates of your own.
*	Latitude	You can share your location with your friends and view your friends' locations on the map.

•	Locals	Search for places that you want near your location.
	Maps	Google's mapping service help you search for the places you want.
3	Messages	Sends and receives all types of messages, such as text message and MMS.
**	Messenger	Google's instant messaging.
	Music	Plays and manages the music and audio files on your phone.
	Navigation	Help you get the destination.
George Scow	News & Weather	Google's news and weather services.
3	Phone	Makes and receives phone calls.
<u> </u>	Play Store	Find applications and fun games which you can download and install on your phone.

8	Search	Google's search service.
141	Settings	Configures the phone settings, wireless settings and call settings of your phone.
	Sound Recorder	Record a voice note
*	System Update	Check the system update information.
talk	Talk	Google's instant messaging program.
	Touchpal Keyboard	To set up your Touchpal Keyboard
	Videos	Play videos.
***	Voice Dialer	Use your voice to place calls.
You	YouTube	It is online video streaming service that allows you to view, search, and upload videos.



6.2 Browser

Open the Browser to view web pages.

- 1. Tap Application Drawer > APPS tab > Browser.
- An address bar appears at the upper side of screen, and you can type the URL there.
- You can open several web pages at the same time.

Tap to view all of web pages that are opening.

- Tap to open a new web page.
- Tap to close a web page.
- Tap to view BOOKMARKS.



To set the Home page

- While viewing a web page, tap Menu > Settings
 General > Set homepage.
- 2. Tap "Other" to enter the URL of the page that you want to set as your home page.
- 3. Tap "OK" to save your settings.

To add the Bookmarks

- While viewing a web page, tap Menu > Save to bookmarks.
- Edit the bookmark label and other information if needed
- Tap "Add to" to save the bookmark to Home screen, Bookmarks, or Other Folder.
- 4. Tap "OK" to save your settings.

Managing Bookmarks

 While viewing a web page, tap Menu > Bookmarks. You can view bookmarks, HISTORY and SAVED PAGES.

Managing a Web Page

The following table lists the Menu options. Depending on the function, some options may be unavailable.

On an onen web nage, tan Menu:

On an open web page, tap Menu:		
Homepage	Tap to go back homepage.	
Stop	Tap to stop opening another web page.	
Refresh	Tap to refresh web page.	
Forward	Forward to the next webpage.	
Back	Tap to go back to last web page.	
Manage Permissions	Tap to configure a number of settings for individual websites that you visit.	
Bookmarks	Tap to select from the list of the saved favorite web pages to visit.	
Save to bookmarks	Add the web page to Bookmarks.	
Share page	Tap to share the web	

	page.
Find on page	Tap to find the text on the web page.
Save for offline reading	Tap to save the web page to view in offline mode.
History	Tap to view the history.
Settings	Tap to set up some functions.
General	Set homepage: Enters the URL and sets as your home page. Form auto-fill: Fill out web forms with a single touch. Auto-fill text: Set up text to auto-fill in web forms.
Privacy & security	Tap to configure privacy settings: Clear cache: Clear locally cached content and databases. Clear history: Clear browser navigation history. Show security warnings: Show warning if there's a problem with a site's security. Accept cookies: Allow sites to save and read "cookie" data. Clear all cookie data: Clear all browser cookies. Remember form data:

	Remember data I type in forms for later use. Clear form data: Clear all the saved form data. Enable location: Allow sites to request access to your location. Clear location access: Clear location access for all websites. Remember passwords: Save usernames and passwords for websites. Clear passwords:
	Clear all saved passwords.
Accessibility	Tap to configure browser settings: Force enable zoom: Override a website's request to control zoom behavior. TEXT SIZE: Adjusts the text size. INVERTED SCREEN RENDERING: Black become white and vice versa.
Advanced	Set search engine: Select a search engine. Open in background: Open new tabs behind the current tab. Enable JavaScript:

	Enable plug-ins: Always on, On demand, and Off. Website settings: Advanced settings for individual websites. Default zoom: Set up zooming functions. Open pages in overview: Show
	overview of newly- opened pages. Auto-fit pages: Enable/disable the webpage to fit the screen. Block pop-ups: Blocks the pop-up windows when browsing web page. Text encoding: Sets up text encoding. RESET DEFAULTS:
Bandwidth management	Restore default settings. Search result preloading: Allow browser to preload high confidence search results in the background. Video preloading: allow browser to preload video when server allows. Load images: Display images on web

Enables/disables
JavaScript on web
page.
Enable plug-ins:

	pages.
Labs	Quick controls: Slide thumb from the left or right edge to open quick controls and hide app and URL bars. Fullscreen: Use fullscreen mode to hide the status bar. Slide Tab Transitions: Swipe from the edge to reveal the next/previous tab in the list. WebGL: enables WebGL.

6.3 Calculator

With Calculator, you can perform basic arithmetic functions on your phone.

- Tap Application Drawer > APPS tab > Calculator.
- In Calculator screen, tap "Menu" to select the advanced panel.

6.4 Calendar

Calendar helps you schedule and sound alarms for appointments, meetings, and events.

- Tap Application Drawer > APPS tab > Calendar.
- If you do not log in your Google Account, tap Menu > New to create an account, or tap "Existing" to sign in the Google account. Please follow the on-screen instruction to log in.
- Tap Calendar arrow > Day, Week, Month, or Agenda to change the displays of your events.

- Tap is to go back to today.
- 5. Tap Menu > Settings to see more settings.



To view a event

- 1. Tap Application Drawer > APPS tab > Calendar.
- Tap Calendar arrow > Agenda to display the events.

To add and schedule an event

- 1. Tap Application Drawer > APPS tab > Calendar.
- 2. Tap Menu > New event.
- Enter the details of the event.
- Select the dates in the fields of "From" and "To".
 For an all-day event, check "ALL DAY".
- 5. To set up the "repetition", select one of the options from the list.
- To set up a reminder, select the time from the list.
- When finished, tap "DONE" to return to the calendar.

NOTE:

The added and scheduled events will be showed in the status bar.

6.5 Gmail

Gmail is Google's web-based email service. Gmail can be configured when you set up your phone for the first time. Depending on your settings of the synchronization, Gmail on your phone may be synchronized with your Gmail account on the web automatically.

- 1. Tap Application Drawer > APPS tab > Gmail.
- If you do not log in your Google Account, tap "NEW" to create an account, or tap "Existing" to sign in the Google account. Please follow the on-screen instruction to log in.
- Once logged in, you can begin reading and sending emails from your Gmail account.

6.6 Maps

Google's mapping service help you search for the places you want.

NOTE:

If you connect to the Internet and turn on the GPS, you may be charged.

To open Map

- Tap Application Drawer > APPS tab > Maps.
- 2. Do any of the following:
 - My location: <u>Tap</u> to go back to my location.
- Search: Tap to search for a place you want. You need type in a keyword to begin to search.
- To get the direction: Tap to input your start point and your destination, and then, Maps will direct you to attend the destination. You can select Car, Bus, or Walk mode.

- Find places: Tap at to find restaurants, cafes, bars, attractions.
- Check layers: Tap , then you can select different layers and functions.

Tap Menu to set more options as below:

- To clear the map: Tap Menu > Clear Map.
- To view terms, privacy, and notices: Tap Menu
 Settings > Terms, Privacy & Notices.
- To view information about Maps: Tap Menu > Settings > About.

6.7 Latitude

You can share your location with your friends and view your friends' locations on the map.

NOTE:

- 1. If you connect to the Internet and turn on the GPS, you may be charged.
- Google's GPS positioning might occur some inaccuracy, which depends on the surroundings and weather status.

Log in Latitude

- 1. Tap Application Drawer > APPS tab > Latitude.
- If you do not log in your Google Account, tap "NEW" to create an account, or tap "Existing" to sign in the Google account. Please follow the on-screen instruction to log in.
- Once logged in, tap your account to change your photo, send location to others, check in, view your location history, or edit privacy settings.

Add your friends

- 1. Tap Application Drawer > APPS tab > Latitude.
- 2. Tap , and then follow the instructions.

Chink in your location

- 1. Tap Application Drawer > APPS tab > Latitude.
- 2. Tap to search nearby places.
- 3. Tap a place to check in your location.

6.8 Local

Use Google maps to search places that you want to find near your current location and the details about the location you select displays on the screen.

NOTE:

If you connect to the Internet and turn on the GPS, you may be charged.

- Tap Application Drawer > APPS tab > Local, or tap Local when using Google maps.
- 2. To search: Tap , and enter the places you want, or tap the category in the list.
- 3. The system will display the locations you want, tap one of them to check the detailed information. Tap the star on the top of the screen to add it to Maps. Helps you find the place quickly. Tap to go back to Maps. Tap to get the direction. Tap to to make a phone call to this place.

6.9 Navigation

Tap Application Drawer > APPS tab > Navigation. Navigation is an Internet-connected GPS navigation system with voice guidance. Helps you get to the destination.

NOTE:

- If you connect to the Internet and turn on the GPS, you may be charged.
- 2. In some locations and regions, Navigation may not be available.

6.10 Google Search

Search for the information in the Internet and on the phone. Tap Application Drawer > APPS tab > Search. You can also see the search bar on the Home screen

6.11 Talk

Talk is Google's instant messaging program.

To sign in Talk

- 1. Tap Application Drawer > APPS tab > Talk.
- If you do not log in your Google Account, tap "NEW" to create an account, or tap "Existing" to sign in the Google account. Please follow the on-screen instruction to log in.
- 3. Once logged in, you can begin to use Talk and do any of the following:
- Select one of your accounts.(If you have two more accounts)
- Send chat invitation to friends: Tap
- To configure Talk settings: Tap Menu > Settings.
- To view the blocked friends: Tap Menu > Settings > your account > Blocked friends.
- To invite a person to your chat: In the chat screen, tap Menu > Add to chat.
- To end a chat: In the chat screen, tap Menu > End chat.
- To view terms and privacy: Tap Menu > Settings > your account > Terms & privacy.
- To Sign out: Tap Menu > Sign out.

6.12 YouTube

YouTube is an online video streaming service that allows you to view, search, and upload videos.

To Play YouTube

- Tap Application Drawer > APPS tab > YouTube
- Videos are grouped into categories, tap "BROWSE" tab. Tap a category to watch the available videos.
- 3. Tap a video to play.

To upload your video

- 1. Tap Application Drawer > APPS tab > YouTube.
- Tap "ACCOUNT" tab, and then sign in your account
- 3. Tap Uploads
- 4. Tap a video to upload.

6.13 Play Store

Play Store allows you to find and download applications and fun games to your phone.

- Tap Application Drawer > APPS tab > Play Store.
- If you do not log in your Google Account, tap "NEW" to create an account, or tap "Existing" to sign in the Google account. Please follow the on-screen instruction to log in.
- Once logged in, you can search and download programs from the market. Slide the screen to switch the pages of play store.
- You can also tap Menu > My apps to view the programs you have downloaded.



6.14 News and Weather

News and Weather will show the weather and news of your city automatically.

- Tap Application Drawer > APPS tab > News & Weather. Slide the screen to switch between the pages of weather and news.
- 2. Tap Menu > Refresh to update the information.
- Tap Menu > Settings. You can adjust the settings of the weather and news.

NOTE:

If you connect to the Internet, you may be charged.



6.15 Best Choice

For easy to use, we recommend you the best software and functionality. With this function, you can find the web links to the services you need easily.

- Tap Application Drawer > APPS tab > Best Choice.
- Tap a desired function, and then, download it online

6.16 FM Radio

You can listen to music/news on the FM Radio. Before use, please insert the headset.

- Tap Application Drawer > APPS tab > FM Radio.
- Tap to switch voice source between your headset and speaker.
- 3. Tap to save to the new station.
- 4. Slide to search the FM stations, tap or to go to the available station.
- 5. Tap to close and exit FM Radio.



6.17 Sound Recorder

To Record a voice note

- Tap Application Drawer > APPS tab > Sound Recorder.
- In the recording screen, tap to record a voice note. Tap to stop the recording. Tap to play the recording.
- 3. Tap M to save or tap M to exit.



To play a voice note

After recording, the file will be stored in the memory card. Please use Music to play it.

- Tap Application Drawer > APPS tab > Music > Playlists > My recordings.
- Displays the list of the voice note, and then, tap the voice note you want to play it.

6.18 Connecting your phone to a computer

If you want to copy files between your computer and your phone storage. Please have your device connect to PC with the USB cable first.



Tap and drag down Status Bar and tap "Media device" or "USB Storage" on your device.

- Media device(MTP):Lets you transfer media files on Windows, or using Android File Transfer on Mac(see www.android.com/filetransfer)
- USB storage:used as USB storage, copy file.

6.19 File Explorer

File manager helps you manage the files in your phone and in your SD card.

 Tap Application Drawer > APPS tab > File Explorer.



2. Tap the folder you want to browse it.

screenshots in Gallery.

6.20 Downloads

Files and other items you downloaded in Email or Browser are stored on your SD card. You can view, reopen or delete what you've downloaded.

- Tap Application Drawer > APPS tab > Downloads.
- 2. Choose "Sort by size" or "Sort by date".

6.21 Google+

You can check your friends' updates, post updates of your own and chat with your friends in Google+.

Tap Application Drawer > APPS tab > Google+.

On your friends's page, tap the arrow besides your friend's name. It will show:

- Stream: To check friends' updates and share your messages, locations, pictures with your friends.
- Profile: To view your personal information, posts and photos.
- Messenger: May start a conversation with friends here
- Hangout: May start a hangout with friends here.
- Photo: To view pictures from your circles and upload pictures from your phone.
- Circles: To add new friends and create new circles.
- Local: looking for restaurant, cafes, bars or attractions nearby.

6.22 Screenshots

You could use this function to capture any screen from the device. Please press and hold Volume Key down and Power Key at the same time. The screenshots will be saved in /sdcard/Pictures/Screenshots and you may view



7.1 Phone SettingsTap Application Drawer > APPS tab > Settings to view and adjust the settings of your phone.

Wireless & networks settings

Wireless & networks settings		
Application	Description	
WLAN	Enable/disable Wi-Fi. And set up and manage wireless access points.	
Bluetooth	Enable/disable Bluetooth. And manage connections, set up the name of the device and the discoverability of the device.	
Data usage	Enable/disable mobile network data. Measure mobile network and Wi-Fi data by your phone and display on chart.	
More:		
Airplane mode	Enable/disable all wireless connections.	
VPN	Set up & manage Virtual Private Networks (VPNs).	
Tethering & potable hotspot	Share your phone's mobile data connection via USB or as portable Wi-Fi hotspot.	
Wi-Fi direct settings	Set up peer-to-peer connectivity.	
Mobile networks	Set options for roaming, networks, APNs.	

DEVICE

DEVICE			
Application	Description		
Dual SIM Settings:			
Configure dual SIM	Set SIM name, turn on/off SIM card, mobile network setting and call settings,etc.		
Preferred SIM settings	Choose which SIM card uses for Voice/UUSD/MMI, data, SMS, count down time and preferred callback.		
Sound:			
Volumes	Set up the volume of ringtone, media, and alarm.		
Silent mode	Silence all sounds except media & alarms.		
Phone ringtone	Set up your default ringtone (SIM1 and SIM2) of incoming calls.		
Default notification	Set up your default ringtone of notifications.		
Vibrate on ring	Set up the vibrate mode on ring.		
System	Check to turn on/off dial pad touch tones, touch sounds, screen lock sound, and vibrate on touch.		
Display:			

Brightness	Adjust the brightness of the screen.
Wallpaper	Set up the wallpaper from gallery, live wallpaper, and wallpapers.
Auto-rotate screen	Enable/disable the screen direction automatically.
Sleep	Set up the screen shut down when your phone is inactivity.
Lock screen setting	Set up which lock screen you want to use.
Font size	Select the font size from the list.
Storage	View the storage usage of phone.
Battery	View the battery usage of phone.
Apps:	
Manage apps	Manage and remove the installed applications.
Preferred install location	Change the preferred installation location for new apps.

PERSONAL

Application	Description
Account & sync	Allow/disallow applications to sync data automatically. And add new accounts.
Location services:	
Google's location	Let apps use data

service	from sources such as Wi-Fi and mobile networks to determine your approximate location.
GPS satellites	Let apps use GPS to pinpoint your location.
Location & Google search	Let Google use your location to improve search results and other services.
Security:	
Screen lock	Lock screen with a slide, face unlock, pattern, PIN, or password.
Encrypt phone	Require a numeric PIN or password to decrypt your phone each time you power it on.
Set up SIM card lock	Lock SIM card and change the PIN of your SIM card.
Make passwords visible	Enable/disable to show the password as you type.
Device administrators	View or deactivate device administrators.
Unknown sources	Allow installation of non-Market apps.
Trusted credentials	Display trusted CA certificates.
Install from SD card	Install certificates form SD card.
Clear credentials	Remove all certificates.
Language & input:	
language	Select a language for your phone.

Spelling correction	Allow/disallow text to correct spelling automatically.
Personal dictionary	You can add, edit, and delete the self-defined words.
Default	Select an input method.
Android keyboard	Settings for Android keyboard.
Google voice typing	Settings for Google voice typing.
TouchPal keyboard	Settings for TouchPal keyboard.
Voice Search	Set up language, safe search, and black offensive words.
Pointer speed	Adjusts the pointer speed.
Backup & reset:	
Back up my data	Back up app data, Wi-Fi passwords, and other settings to Google services.
Backup account	Backing up to debug-only private cache.
Automatic restore	When reinstalling an app, restore backed up settings and data.
Factory data reset	Erases all data on phone.

SYSTEM

Application	Description
Data & time:	
Automatic date &	Check to use the
time	provided values of the

	network.
Automatic time zone	Use network-provided
Automatic time 20116	time zone.
Set date	Set up the date for
Jot date	your phone.
Set time	Set up the time for
	your phone.
Select time zone	Set up the time zone
	for your phone. Set up the clock to
Use 24-hour format	24-hour format.
	Set up the preferred
Select date format	date format.
Accessibility:	
	Provides spoken
TalkBack	feedback to help blind
* *	and low-vision users.
Large text	Adjusts the text size.
Large text	
	During a call, pressing
Power button ends	Power ends the call
call	instead of turning off
	the screen.
Auto-rotate screen	Set up the screen direction
Auto-rotate screen	automatically.
	Allow/disallow speak
Speak passwords	password.
	Select short, medium,
Touch & hold delay	and long time.
	Install scripts from
Install web scripts	Google that make their
	web content more
	accessible.
Developer options:	
USB debugging	Debug mode when
	USB is connected.
Development device	Display your phone's

ID	device ID.
Stay awake	Screen will never sleep while charging.
Allow mock locations	Allow mock locations.
Desktop backup password	Desktop full backups aren't currently protected.
Strict mode enabled	Flash screen when apps do long operations on main thread.
Pointer location	Screen overlay showing current touch data.
Show touches	Show visual feedback for touches.
Show screen updates	Flash areas of screen when they update.
Show CPU usage	Screen overlay showing current CPU usage.
Force GPU rendering	Use 2D hardware acceleration in applications.
Window animation scale	Set up of windows "inside windows" that come in and out of view.
Transition animation scale	Set up speed of windows come in and out of view such as opening settings.
Background process limit	Set up to Control apps running in the background.
Show all ANRs	Show App not responding dialog for background apps.

About phone:	
Additional system updates	Update your phone and display the last check time.
Status	Battery status, battery level, etc.
Legal information	To view the legal information of phone.
Model number	Display your phone of model name.
Android version	Display your phone of Android version.
Kernel version	Display your phone of kernel version.
Build number	Display your phone of software version.

7.2 Managing Basic Settings

Date and Time

You can set up the date and the time on your phone.

To set up the date and time

- Tap Application Drawer > APPS tab > Settings > Date & time.
- If you check "Automatic data & time", the system will get the information of the current date and time automatically. You can set up the date and the time manually also.
- If you check "Automatic time zone", the system will get the information of time zone automatically. You can tap "Select the time zone" to select a time zone from the list also.
- 4. Tap "Set date". Please adjust the month, the day, and the year. Tap "Set" to save the settings.
- Tap "Set Time". Please adjust the hour and the minute. You can switch AM/PM. Tap "Set" to save the settings.
- 6. Check "Use 24-hour format" if you want.



7. Tap "Select date format" to select the date format you want.

Setting Alarms

You can set up many alarms on your phone.

To set the alarm

- 1. Tap Application Drawer > APPS tab > Clock.
- 2. Tap "Alarm set" to set up a new alarm.
- 3. Tap "Add alarm".
- 4. Check "Turn alarm on".
- Tap "Time" to set up. Please adjust the hour and the minute. You can switch AM/PM. Tap "Set" to save the settings.
- Tap "Repeat" to select a day to sound the alarm. Tap "OK" to save the settings.
- Tap "Ringtone" to set up the preferred ringtone when your alarm sounds. Tap "OK" to save the settings.
- Check "Vibrate" to enable/disable the vibration when the alarm sounds.
- 9. Tap "Label" to enter the description for the alarm. 10. Tap "OK" to save the settings of the alarm.
- Activate an alarm

Tap an alarm to activate it.

To turn off the backlight when the phone is idle

- Tap Application Drawer > APPS tab > Settings > Display > Sleep.
- Select from the list of screen timeout. Your setting is saved automatically.

To adjust the brightness

- Tap Application Drawer > APPS tab > Settings > Display > Brightness.
- Drag the slider of brightness to the left to decrease the brightness, or to the right to increase the brightness. Tap "OK" to finish.
- 3. Tap "Automatic brightness" to let device adjust

brightness by itself.

To change the screen orientation

- Tap Application Drawer > APPS tab > Settings > Display
- Check "Auto-rotate screen" to adjust the screen automatically.

To display the screen when your device is charging

- Tap Application Drawer > APPS tab > Settings > Developer options.
- Check "Stay awake" to display the screen even when your device is charging.

To change the ringtone of an incoming call

- Tap Application Drawer > APPS tab > Settings > Sound.
- Tap "Phone ringtone" .On "SIM1" or "SIM2" tab (If SIM2 inserted), tap "Phone ringtone".
- Select a ringtone from the list.
- 4. Tap "OK" to finish.

To change ringtone of events

- Tap Application Drawer > APPS tab > Settings > Sound.
- 2. Tap "Default notification".
- Select a ringtone from the list.
- Tap "OK" to finish.

7.3 Protecting Your Phone

You can protect your phone from unauthorized users by requiring the PIN or entering a password.

Enable the PIN of the SIM/RUIM card

When the PIN is enabled, you are required to enter the PIN before making a call.

 Tap Application Drawer > APPS tab > Settings > Security > Set up SIM/RUIM card lock.

- 2. Tap "SIM1" or "SIM2" tab. (If SIM2 inserted).
- Check "Lock SIM card". Input the PIN, and then, tap "OK".

Change the PIN of the SIM/RUIM card

- Tap Application Drawer > APPS tab > Settings > Security > Set up SIM card lock.
- 2. Tap "SIM1" or "SIM2" tab. (If SIM2 inserted).
- 3. Tap "Change SIM PIN". Type the old PIN. Then tap "OK".
- 4. Type the new PIN. Then tap "OK".
- Re-type the new PIN. Then tap "OK" to change the PIN.

Set up Password Protection

- Tap Application Drawer > APPS tab > Settings > Security > Screen lock > Password.
- Enter your password, and then, tap "Continue".
 Confirm your password, then, tap "OK".
- If you want to disable screen lock security, please tap Application Drawer > Settings > APPS tab > Security > Screen lock. Confirm your password, and then, tap "Continue". Tap "None" to disable it.

Set up unlock pattern

You can further secure your data by locking the screen and requiring a screen unlock pattern every time after your phone is turned on or it wakes up from the sleep mode every time (screen is off).

- Tap Application Drawer > APPS tab > Settings > Security > Screen lock > Pattern.
- 2. Draw the unlock pattern by connecting at least four dots. Then tap "Continue".
- 3. Draw the unlock pattern again, and then, tap "Confirm".
- If you want to disable the function, please tap Application Drawer > APPS tab > Settings > Security > Screen lock. Confirm the saved pattern, and then, tap "None" to disable it.

Set up face unlock

You can use front-facing shot to verify your identity to unlock your phone.

- Tap Application Drawer > APPS tab > Settings > Security > Screen lock > Face Unlock.
- 2. Tap Set it up>Continue.
- 3. Show your face in front of your phone until face captured. Then tap continue.
- 4. Set up Pattern or PIN as the backup lock.
- If you want to disable the function, please tap Application Drawer > APPS tab > Settings > Security > Screen lock. Confirm the saved pattern, and then, tap "None" to disable it.



7.4 Resetting Your Phone

With Clean Boot, you can reset your phone to its factory defaults. When you reset your phone, the data stored in your phone may be erased.

- Tap Application Drawer > APPS tab > Settings > Backup & reset.
- 2. Tap Factory data reset > Reset phone > Erase



everything to reset the phone.

NOTE:

Before reset your device, please remember to back up all your data and information.

7.5 Specifications

System Information	
Platform	Android 4.0
Processor	1GHz Dual-core
Memory	ROM 4 GB RAM 512 MB
Display	
Size	4"
Resolutions	800 x 480 pixels
Size	
Dimensions (L x W x H)	124.2 x 63.8 x 10.45 mm
Weight	130.5 grams with battery
Power	
Battery Rechargeable	Li-ion pack 1500 mAh
Power Adapter AC	100-240V, 47-63Hz,
input	0.5A max.
DC output	5V, 1A
Standby time	Up to 135 hours (It may vary depending on the availability of local networks and the individual usage.)
Talk time	Up to 5 hours (It may vary depending on the availability of local networks and the individual usage.)
Radio Band & Standard	
GSM/GPRS/EDGE	850/ 900/ 1800/ 1900 MHz
WCDMA/HSDPA	900/ 2100 MHz
	_

Connectivity	
GPS	GPS, AGPS
Wi-Fi	IEEE 802.11 b/g/n
Bluetooth	Bluetooth 3.0
USB	Micro USB
Audio Jack	3.5 mm stereo audio jack
Digital Camera	
Rear Camera	5.0MP Color Camera with AF and Video Recording
Front Camera	0.3MP
External Memory	
Memory Card	microSD supports up to 32GB
Temperature	
Operating	-15°C to 55°C
SIM Card Slot	·
Dual SIM card slot.	

NOTE:

- Specifications are subject to change without the prior notice. They may vary in some regions also.
- 2. Mobile data interruption, unexpected error in CPU and high power consumption could be caused by in-app AD in Android phone. We suggest you try to remove those apps with AD which had been installed in your device for preventing any abnormal situation happens and saving more power as well.
- If this document is modified, please download the latest version on GSmart's official website.

GIGA-BYTE COMMUNICATIONS INC. B2, No. 207, Sec. 3, Pai-Hsin Road, Hsin-Tien Dist., New Taipei City 231, Taiwan +886-2-89132220

www.gigabytecm.com