

# alcatel

## PIXI<sup>4</sup>

7" 3G ANDROID



### User manual

# Table of Contents

	<b>Safety information .....</b>	<b>5</b>
	<b>General information .....</b>	<b>12</b>
	<b>Warranty.....</b>	<b>14</b>
<b>I</b>	<b>Your device .....</b>	<b>17</b>
	1.1 Keys and connectors.....	17
	1.2 Getting started .....	18
	1.3 Home screen.....	20
<b>2</b>	<b>Text input.....</b>	<b>27</b>
	2.1 Using Onscreen Keyboard.....	27
	2.2 Swift key .....	27
	2.3 Text editing.....	28
<b>3</b>	<b>Contacts .....</b>	<b>29</b>
	3.1 Consult your contacts .....	29
	3.2 Managing contact groups.....	30
	3.3 Adding a contact .....	30
	3.4 Editing your contacts .....	31
	3.5 Contacts importing, exporting and sharing .....	31
	3.6 Accounts .....	32
<b>4</b>	<b>Gmail .....</b>	<b>33</b>
<b>5</b>	<b>Messaging .....</b>	<b>35</b>
<b>6</b>	<b>Phone call .....</b>	<b>36</b>
	6.1 Placing a call .....	36
	6.2 Answering or rejecting a call.....	36
<b>7</b>	<b>Calendar &amp; Time .....</b>	<b>37</b>
	7.1 Calendar .....	37
	7.2 Time .....	38
<b>8</b>	<b>Getting connected .....</b>	<b>40</b>
	8.1 Connecting to the Internet.....	40
	8.2 Connecting to Bluetooth devices .....	41
	8.3 Connecting to a computer .....	42
	8.4 Connecting to virtual private networks.....	43

<b>9</b>	<b>Play Store .....</b>	<b>45</b>
9.1	Locate the item you want to download and install.....	45
9.2	Download and install.....	46
9.3	Manage your downloads.....	47
<b>10</b>	<b>Multimedia applications .....</b>	<b>49</b>
10.1	Camera .....	49
10.2	Gallery .....	51
<b>11</b>	<b>Maps .....</b>	<b>53</b>
11.1	Get My Location .....	53
11.2	Search for a location .....	54
11.3	Star a location.....	55
11.4	Get driving, public transportation or walking directions	56
11.5	Arrangement of Layers .....	57
<b>12</b>	<b>Others.....</b>	<b>58</b>
12.1	File Manager .....	58
12.2	Other applications .....	58
<b>13</b>	<b>Settings .....</b>	<b>59</b>
13.1	Wireless & networks .....	59
13.2	Device.....	60
13.3	Personal.....	62
13.4	Accounts .....	64
13.5	System.....	66
<b>14</b>	<b>Making the most of your tablet.....</b>	<b>69</b>
<b>15</b>	<b>Accessories .....</b>	<b>69</b>
<b>16</b>	<b>Troubleshooting .....</b>	<b>70</b>



[www.sar-tick.com](http://www.sar-tick.com)

This device meets applicable national SAR limits of 2.0 W/kg. SAR values can be found on page 10 of this user guide. When carrying the device or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 10 mm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not using it.



To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.



The tablet contains magnets which may interfere with other devices and items (such as credit card, pacemakers, defibrillators, etc.). Please maintain at least 15 cm of separation between your tablet and the devices/items mentioned above.

# Safety information

We recommend that you read this chapter carefully before using your device. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein.

## • **TRAFFIC SAFETY**

Given that studies show that using a device while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit, headset...), drivers are requested to refrain from using their device when the vehicle is not parked.

When driving, do not use your device or headphone to listen to music or to the radio. Using a headphone can be dangerous and forbidden in some areas. When switched on, your device emits electromagnetic waves that can interfere with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure that there is no problem:

- Do not place your device on top of the dashboard or within an airbag deployment area,
- Check with your car dealer or the car manufacturer to make sure that the dashboard is adequately shielded from device RF energy.

## • **CONDITIONS OF USE**

You are advised to switch off the device from time to time to optimise its performance.

Switch the device off before boarding an aircraft.

Switch the device off when you are in healthcare facilities, except in designated areas. As with many other types of equipment now in regular use, these devices can interfere with other electrical or electronic devices, or equipment using radio frequencies.

Switch the device off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, petrol station, or chemical plant, or in any potentially explosive atmosphere.

When the device is switched on, it should be kept at least 15 cm from

any medical device such as a pacemaker, a hearing aid or insulin pump, etc. In particular when using the device, you should hold it against the ear on the opposite side to the device, if any.

To avoid hearing impairment, move the device away from your ear while using the “hands-free” mode because the amplified volume might cause hearing damage.

Do not let children use the device and/or play with the device and accessories without supervision.

Please note that your device is a unibody device, the back cover and battery are not removable. Do not attempt to disassemble your device. If you disassemble your device the warranty will not apply. Also disassembling the device may damage the battery, and may cause leakage of substances that could create an allergic reaction.

Always handle your device with care and keep it in a clean and dust-free place.

Do not allow your device to be exposed to adverse weather or environmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc.). The manufacturer’s recommended operating temperature range is -0°C to +45°C.

At over 45°C the legibility of the device’s display may be impaired, though this is temporary and not serious.

Do not open, dismantle or attempt to repair your device yourself.

Do not drop, throw or bend your device.

Do not use the device if the glass made screen is damaged, cracked or broken to avoid any injury.

Do not paint it.

Use only battery chargers and accessories which are recommended by TCL Communication Ltd. and its affiliates and are compatible with your device model. TCL Communication Ltd. and its affiliates disclaim any liability for damage caused by the use of other chargers or accessories.

Remember to make back-up copies or keep a written record of all important information stored in your device.

Some people may suffer epileptic seizures or blackouts when exposed to flashing lights, or when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your device or enabling a flashing-lights feature on your device.

Parents should monitor their children's use of video games or other features that incorporate flashing lights on the device. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. To limit the likelihood of such symptoms, please take the following safety precautions:

- Do not play or use a flashing-lights feature if you are tired or need sleep.
- Take a minimum of a 15-minute break hourly.
- Play in a room in which all lights are on.
- Play at the farthest distance possible from the screen.
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after playing, stop the game and see a doctor.

When you play games on your device, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow the instructions to avoid problems such as tendinitis, carpal tunnel syndrome, or other musculoskeletal disorders.

## • **PRIVACY**

Please note that you must respect the laws and regulations in force in your jurisdiction or other jurisdiction(s) where you will use your device regarding taking photographs and recording sounds with your device. Pursuant to such laws and regulations, it may be strictly forbidden to take photographs and/or to record the voices of other people or any of their personal attributes, and duplicate or distribute them, as this may be considered to be an invasion of privacy. It is the user's sole responsibility to ensure that prior authorization be obtained, if necessary, in order to record private or confidential conversations or take a photograph of

another person; the manufacturer, the seller or vendor of your device (including the operator) disclaim any liability which may result from the improper use of the device.

Please note by using the device some of your personal data may be shared with the main device. It is under your own responsibility to protect your own personal data, not to share with it with any unauthorised devices or third party devices connected to yours. For products with Wi-Fi features, only connect to trusted Wi-Fi networks. Also when using your product as a hotspot (where available), use network security. These precautions will help prevent unauthorised access to your device. Your product can store personal information in various locations including a SIM card, memory card, and built-in memory. Be sure to remove or clear all personal information before you recycle, return, or give away your product. Choose your apps and updates carefully, and install from trusted sources only. Some apps can impact your product's performance and/or have access to private information including account details, call data, location details and network resources.

Note that any data shared with TCL Communication Ltd. is stored in accordance with applicable data protection legislation. For these purposes TCL Communication Ltd. implements and maintains appropriate technical and organisational measures to protect all personal data, for example against unauthorised or unlawful processing and accidental loss or destruction of or damage to such personal data whereby the measures shall provide a level of security that is appropriate having regard to

- (i) the technical possibilities available,
- (ii) the costs for implementing the measures,
- (iii) the risks involved with the processing of the personal data, and
- (iv) the sensitivity of the personal data processed.

You can access, review and edit your personal information at any time by logging into your user account, visiting your user profile or by contacting us directly. Should you require us to edit or delete your personal data, we may ask you to provide us with evidence of your identity before we can act on your request.

#### • **BATTERY**

Following new air regulation, the battery of your product is not charged. Please charge it first.

Please note your tablet is a unibody device, the back cover and battery are not removable. Observe the following precautions for battery use:

- Do not attempt to open the back cover and replace the inner



rechargeable Li-polymer battery. Please contact the dealer to replace it.

- Do not attempt to eject, replace and open battery.
- Do not punctuate the back cover of your device.
- Do not burn or dispose of your device in household rubbish or store it at temperature above 50°C.
- Dispose of used batteries according to the instructions. Risk of explosion if battery replaced by an incorrect type.



This symbol on your device, the battery and the accessories means that these products must be taken to collection points at the end of their life:



- Municipal waste disposal centres with specific bins for these items of equipment.

- Collection bins at points of sale.

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

### **In European Union countries:**

These collection points are accessible free of charge.

All products with this sign must be brought to these collection points.

### **In non-European Union jurisdictions:**

Items of equipment with this symbol are not to be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled.

#### **• CHARGERS**

Mains powered chargers will operate within the temperature range of: 0°C to 40°C.

The chargers designed for your device meet with the standard for safety of information technology equipment and office equipment use. They are also compliant to the eco design directive 2009/125/EC. Due to different applicable electrical specifications, a charger you purchased in one jurisdiction may not work in another jurisdiction. They should be used for this purpose only.

The charger shall be installed near the equipment and shall be easily accessible.

## • RADIO WAVES

### THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES

Your device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) recommended by international guidelines. The guidelines were developed by an independent scientific organization (ICNIRP) and include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The radio wave exposure guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2 W/kg.

Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The highest SAR values under the ICNIRP guidelines for this device model are:

Maximum SAR for this model and conditions under which it was recorded:	
9003X(Head)	1.4 W/kg
9003X (Body-worn)	0.504 W/kg

During use, the actual SAR values for this device are usually well below the values stated above. This is because, for purposes of system efficiency and to minimize interference on the network, the operating power of your device is automatically decreased when full power is not needed. The lower the power output of the device, the lower its SAR value.

Body-worn SAR testing has been carried out at a separation distance of 10 mm. To meet RF exposure guidelines during body-worn operation, the device should be positioned at least this distance away from the body.

If you are not using an approved accessory ensure that whatever product is used is free of any metal and that it positions the device the indicated distance away from the body.

Organizations such as the World Health Organization and the US Food and Drug Administration have suggested that if people are concerned and want to reduce their exposure they could use a hands-free accessory to keep the wireless device away from the head or body during use, or reduce the amount of time spent on the device.

## • LICENCES



microSD Logo is a trademark.



The Bluetooth word mark and logos are owned by the Bluetooth SIG,

Inc. and any use of such marks by TCL Communication Ltd. and its affiliates is under license. Other trademarks and trade names are those of their respective owners.

### **9003X Bluetooth Declaration ID D030189**



The Wi-Fi Logo is a certification mark of the Wi-Fi Alliance.

Your device uses non-harmonized frequency and is intended for use in all European countries.

The WLAN can be operated in the EU without restriction indoors, but cannot be operated outdoors in France.

Google, the Google logo, Android, the Android logo, Google Search™, Google Maps™, Gmail™, YouTube, Google Play Store, Google Latitude™ and Hangouts™ are trademarks of Google Inc.

The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License (the text will show when you touch and hold **Google legal** in **Settings > About Tablet > Legal information**)<sup>(1)</sup>.

We hereby point out that the end user warranty for infringement IPR is solely limited to the EU.

If and to the extent that the Product is exported, taken with or used by end customer or end user outside the EU any responsibility, warranty or indemnification of manufacturer and its suppliers in regard to the Product expires (including any indemnification in regard to infringement IPR).

<sup>(1)</sup> It may not be available according to the countries.

# General information

- **Internet address:** [www.alcatel-mobile.com](http://www.alcatel-mobile.com)
- **Hotline Number:** see “TCL Communication Services” leaflet or go to our website.
- **Manufacturer:** TCL Communication Ltd.
- **Address:** Flat/RM 1910-12A, Block 3, China HongKong City, 33 Canton Road, Tsimshatsui, Kowloon, Hong Kong

On our website, you will find our FAQ (Frequently Asked Questions) section. You can also contact us by e-mail to ask any questions you may have.

An electronic version of this user guide is available in English and other languages according to availability on our server:

**[www.alcatel-mobile.com](http://www.alcatel-mobile.com)**

Your device is a transceiver that operates on Wi-Fi with 2.4GHz, Bluetooth with 2.4GHz.

This equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC, 2011/65/EU and 2009/125/EC. The entire copy of the Declaration of Conformity for your device can be obtained through our website:

[www.alcatel-mobile.com](http://www.alcatel-mobile.com).

## C€0560

### Company Address:

Room 1910-12A, Tower 3, China HK City, 33 Canton Road,  
Tsimshatsui, Kowloon, Hong Kong

### Disclaimer

There may be certain differences between the user manual description and the device's operation, depending on the software release of your device or specific operator services.

TCL Communication shall not be held legally responsible for such differences, if any, nor for their potential consequences, which responsibility shall be borne by the operator exclusively.

This device may contain materials, including applications and software in executable or source code form, which is submitted by third parties for inclusion in this device (“Third Party Materials”).

All third party materials in this device are provided “as is”, without warranty of any kind, whether express or implied, including the implied warranties of merchantability, fitness for a particular purpose or use/third party application, interoperability with other materials or applications of the purchaser and non-infringement of copyright. The purchaser undertakes that TCL Communication has complied with all quality obligations incumbent upon it as a manufacturer of mobile devices and devices in complying with Intellectual Property rights. TCL Communication will at no stage be responsible for the inability or failure of the Third Party Materials to operate on this device or in interaction with any other devices of the purchaser. To the maximum extent permitted by law, TCL Communication disclaims all liability for any claims, demands, suits or actions, and more specifically – but not limited to – tort law actions, under any theory of liability, arising out of the use, by whatever means, or attempts to use, such Third Party Materials. Moreover, the present Third Party Materials, which are provided free of charge by TCL Communication, may be subject to paid updates and upgrades in the future; TCL Communication waives any responsibility regarding such additional costs, which shall be borne exclusively by the purchaser. The availability of the applications may vary depending on the countries and the operators where the device is used; in no event shall the list of possible applications and software provided with the devices be considered as an undertaking from TCL Communication; it shall remain merely as information for the purchaser. Therefore, TCL Communication shall not be held responsible for the lack of availability of one or more applications wished for by the purchaser, as its availability depends on the country and the operator of the purchaser. TCL Communication reserves the right at any time to add or remove Third Party Materials from its devices without prior notice; in no event shall TCL Communication be held responsible by the purchaser for any consequences that such removal may have on the purchaser regarding the use or attempt to use such applications and Third Party Materials.

### **Accessory**

- Charger, 5.0V/1.0A
- USB cable, 5pins micro-USB

# Warranty

Your device is warranted against any defect or malfunctioning which may occur in conditions of normal use during the warranty period of twelve (12) months <sup>(1)</sup> from the date of purchase as shown on your original invoice.

Batteries<sup>(2)</sup> and accessories sold with your device are also warranted against any defect which may occur during the first six (6) months (1) from the date of purchase as shown on your original invoice.

In case of any defect of your device which prevents you from normal use thereof, you must immediately inform your vendor and present your device with your proof of purchase.

- (1) The warranty period may vary depending on your country.
- (2) The life of a rechargeable mobile device battery in terms of conversation time standby time, and total service life, will depend on the conditions of use and network configuration. Batteries being considered expendable supplies, the specifications state that you should obtain optimal performance for your device during the first six months after purchase and for approximately 200 more recharges.

If the defect is confirmed, your device or part thereof will be either replaced or repaired, as appropriate. Repaired device and accessories are entitled to a 30 days warranty for the same defect. Repair or replacement may be carried out using reconditioned components offering equivalent functionality.

This warranty covers the cost of parts and labour but excludes any other costs.

This warranty shall not apply to defects to your device and/or accessory due to (without any limitation):

- (1) Non-compliance with the instructions for use or installation, or with technical and safety standards applicable in the geographical area where your device is used;
- (2) Connection to any equipment not supplied or not recommended by TCL Communication Ltd.;

- 3) Modification or repair performed by individuals not authorised by TCL Communication Ltd. or its affiliates or your vendor;
- 4) Modification, adjustment or alteration of software or hardware performed by individuals not authorized by TCL Communication Ltd. ;
- 5) Inclement weather, lightning, fire, humidity, infiltration of liquids or foods, chemical products, download of files, crash, high voltage, corrosion, oxidation...

Your device will not be repaired in case labels or serial numbers (IMEI/SN) have been removed or altered.

There are no express warranties, whether written, oral or implied, other than this printed limited warranty or the mandatory warranty provided by your country or jurisdiction.

In no event shall TCL Communication Ltd. or any of its affiliates be liable for indirect, incidental or consequential damages of any nature whatsoever, including but not limited commercial or financial loss or damage, loss of data or loss of image to the full extent those damages can be disclaimed by law.

Some countries/states do not allow the exclusion or limitation of indirect, incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.



## EC declaration of conformity / Déclaration de conformité CE

Product / Produit : Tablet PC

Product identification / Identification du produit :

9003X/ PIXI 4 7" 3G Android type Pixi4-7 3G

We / Nous

TCT Mobile Europe SAS

55, avenue des Champs Pierreux

92000 Nanterre

France

Declare under our sole responsibility that the product above mentioned is conform to the applicable essential requirements of the directive 1999/5/EC and that all essential radio test suites have been carried out. Conformity assessment procedure : annex IV of the directive. / *déclarons sous notre entière responsabilité que le produit ci-dessus est en conformité avec les exigences essentielles applicables de la directive 1999/5/CE et que toutes les séries d'essais radio essentielles ont été effectuées. Procédure d'évaluation de conformité : annexe IV de la directive.*

Applied standards / Normes appliquées :

- Item 3.1.a ( protection of the health and of the safety of the user ) / Article 3.1.a ( *protection de la santé et de la sécurité de l'utilisateur* )

- EN 60950-1:2006 + A11:2009 + A1:2010 + A12:2011 + A2:2013
- EN 50332-1 :2013/EN 50332-2 :2013
- EN 62209-1 : 2006/EN 62209-2 :2010/EN 62311 :2008/EN 62479 :2010
- EN 50566 :2013/AC :2014
- EN 50360 :2001/A1 :2012

- Item 3.1.b ( protection requirements with respect to electromagnetic compatibility ) / Article 3.1.b ( *exigences de protection en ce qui concerne la compatibilité électromagnétique* )

- EN 301 489-1 V1.9.2 / EN 301 489-3 V1.6.1/EN 301 489-7 V1.3.1
- EN 301 489-17 V2.2.1/ EN 301 489-24 V1.5.1
- EN 55022 :2010/AC :2011/EN 55024 :2010
- EN 61000-3-2:2014/EN 61000-3-3 :2013

- Item 3.2 ( effective use of spectrum so as to avoid harmful interferences ) / Article 3.2 ( *utilisation efficace du spectre radioélectrique de façon à éviter les interférences dommageables* )

- EN 300440-1 V1.6.1/EN 300440-2 V1.4.1
- EN 300328 V1.9.1/EN 301511 V9.0.2
- EN 301908-1 V7.1.1/EN 301908-2 V6.2.1

This product also conforms to the applicable requirements of following directives, / *Ce produit est en conformité avec la directive,*

- directive 2011/65/EU (RoHS - restriction of the use of certain hazardous substances)

This product can connect with a Common Mobile Phone Charger which complies with below standards:

(Ce produit peut être utilisé avec un chargeur universel pour téléphone portable conforme aux standards suivants :)

- EN 60950-1:2006 + A11:2009 + A1:2010 + A12:2011 + A2 :2013

The chargers delivered with this product (When included into the box) also conform to the applicable requirements of the directive 2009/125/EC(Energy Related Product) / Les chargeurs livrés (le cas échéant) avec ce produit sont en conformité avec la directive 2009/125/EC(écoconception des produits)

Conformity of this product with the essential requirements of the R&TTE Directive 1999/5/EC has been reviewed by the following Notified Body: / *La conformité de ce produit a été vérifiée par l'organisme de certification (notify body) suivant.*

TELEFICATION B.V. Edisonstraat 12A, 6902 PK ZEVENAAR Netherlands

Identification number: 0560

Date :2016-03-14

Signature



Emmanuel Lambert

TCT Mobile Europe SAS / Technical Director, Europe

CE 0560

**TCT Mobile Europe SAS**  
Immeuble Le Capitole  
55, avenue des Champs Pierreux  
92000 Nanterre - FRANCE  
RCS Nanterre 440 038 222


TCT Mobile Europe SAS - Siège social : 55 Avenue des Champs Pierreux, Immeuble Le Capitole 92000 Nanterre France SAS au capital de 23 031 072 euros - RCS Nanterre B 440 038 222 - Siret 440 038 222 000 38 APE 4652Z



# I Your device


## I.1 Keys and connectors

### Front panel



Number	Description
①	Earphone socket
②	Micro-USB connector/Battery charge port
③	SIM card & MicroSD card socket
④	Front camera
⑤	Headphone
⑥	Power key
⑦	Volume Up/Down
⑧	Microphone

## Rear panel




Number	Description
9	Rear Camera
10	Speaker

## 1.2 Getting started

### 1.2.1 Set-up

#### Inserting the microSD and micro SIM card

Insert your microSD card and micro SIM card in the right direction to avoid damage. Please refer to the following instructions.




Before inserting/removing the microSD card and SIM card, you should ensure the tablet is off, to protect it from corruption or damage. In addition, regularly removing or inserting the SD card or SIM card may cause the tablet to restart.

## Charging the battery

To charge your tablet, connect the charger to your tablet and mains socket.

- When using your tablet for the first time, charge the battery fully (approximately 5 hours).


You are advised to fully charge the battery. Charging status (  63% ) is indicated by the percentage on screen while the tablet is powered off. The percentage increases as the tablet is charged.



To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger from the plug; switch off Wi-Fi, GPS, Bluetooth or background-running applications when not in use; reduce the backlight time, etc.

### 1.2.2 Power on your tablet

Hold down the **Power** key until the tablet powers on, unlock your tablet (Swipe, PIN, Password, Pattern) if necessary and confirm. The Home screen is displayed.



If you do not know your PIN code or if you have forgotten it, contact your network operator. Do not leave your PIN code with your tablet. Store this information in a safe place when not in use.

#### Set up your tablet for the first time

The first time you power on the tablet, you should set the following options:

- Touch ▼ to display the all languages list, slide up and down to select the tablet's language, then touch to continue.
- Insert SIM card or touch **SKIP** to continue.
- Select a Wi-Fi to connect or touch **NEXT** to continue.
- Set **Date and Time**, then touch **NEXT**.
- Enter your name to personalise some apps on tablet.

- Select a way(PIN, Password, pattern etc.) to protect your device.
- Following the instructions to finish the setup.
- When the tablet is powered on, you can connect to a Wi-Fi network to sign into your Google account and to use some features.

### 1.2.3 Power off your tablet

Hold down the **Power** key until the pop-up menu appears, select **Power off** to confirm.

## 1.3 Home screen

You can bring all your favourite icons (apps, shortcuts, folders and widgets) to your Home screen for quick access. Touch **Home** key to switch to Home screen.



#### Status bar

- Status/Notification indicators.

#### Favourite tray applications

- Touch to launch apps.
- Long press to move or change apps.

#### Application tab

- Touch to see all applications.

The Home screen extends on either side of the screen to allow more space for adding apps, shortcuts etc. Slide the Home screen horizontally left and right to get a complete view of the Home screen. The page indicators above the apps tray indicate which screen you are viewing.

## Recent key

- Touch to displays a list of recently used applications.

## Home key

- While on any application or screen, touch to return to the Home screen.

## Back key

- Touch to go back to the previous screen, or to close a dialogue box, options menu, the notification panel, etc.

## 1.3.1 Using the touchscreen

### Touch

To access an application, touch it with your finger.

### Touch and Hold

To open the available options for an item (for example, a contact or link in a Web page), touch and hold the item.

### Drag

Place your finger on any item to drag it to another location.

### Slide/Swipe

Slide the screen to scroll up and down the applications, images, web pages... at your convenience.

### Flick


Similar to swiping, but flicking makes it move quicker.

## Pinch/Spread



Place your fingers of one hand on the screen surface and draw them apart or together to scale an element on the screen.

## Rotate



Automatically change the screen orientation from portrait to landscape by turning the tablet sideways to have a better view.


## I.3.2 Status bar

From status bar, you can view both tablet status on the right side and notification information on the left side.

Touch and drag down the Status bar to open the **Quick settings panel** or the **Notification panel**. Touch and drag up to close it.

### Notification panel

When there are notifications, touch and drag down the Status bar to open the Notification panel and read the detailed information.




Touch to switch to the Quick settings panel.

Touch to clear all event-based notifications (other ongoing notifications will remain).

**Note:** After opening the Notification panel, touch the status bar or drag down it again to switch to the Quick settings panel.


## Quick setting panel

You can enable or disable functions or change modes by touching the icons on the Quick settings panel.



Touch to enter the Multi-user screen, which allows you to switch the user mode.

Touch to access Settings, which allows you to set more items.


**Note:** After opening the Quick settings panel, touch  to enter the Multi-user screen, which allows you to switch the user mode, or add new users.

## 1.3.3 Search bar


The tablet provides a Search function which can be used to locate information within applications, the tablet or the web.



## Search by text

- Touch the Search bar from Home screen.
- Enter the text/phrase you want to search for.
- Touch  on the keyboard if you want to search on the web.


## Search by voice


- Touch  from Search bar to display a dialogue screen.
- Speak the word/phrase you want to search for. A list of search results will display for you to select from.

## I.3.4 Lock/Unlock your screen

To protect your tablet and privacy, you can lock the tablet screen by choosing slide or creating a variety of patterns, PIN or password, etc.

**To create a screen unlock pattern** (refer to the section "Screen lock" for detail settings)

- Drag down the Status bar and open the Quick settings panel then touch the settings icon  to enter **Settings**, then touch **Security**. Select **Screen lock\Pattern**.
- Draw your own pattern.



Draw your unlock pattern

Touch to confirm by drawing pattern again



### **To create a screen unlock PIN/Password**

- Touch **Settings\Security\Select Screen lock\PIN** or **Password**.
- Set your **PIN** or **Password**.


### **To lock tablet screen**

Press the **Power** key once to lock the screen.

### **To unlock tablet screen**

Press the power key once to light up the screen, draw the unlock pattern you have created or enter PIN or password, etc. to unlock the screen.

If you have chosen **Swipe** as the screen lock, swipe the lock screen up with your finger to unlock the screen.



## **1.3.5 Personalise your Home screen**

### **Add**


You may long press a folder, an application or a widget to activate the Move mode, and drag the item to any Home screen as you prefer.

### **Reposition**

Long press the item to be repositioned to activate the Move mode, drag the item to the desired position and then release. You can move items both on the Home screen and the Favourite tray. Hold the icon

on the left or right edge of the screen to drag the item to another Home screen.

### **Remove**

Long press the item to be removed to activate the Move mode, drag the item up to the top of “” Remove, and release the item.

### **Create folders**

To improve the organisation of items (shortcuts or applications) on the Home screen, you can add them to a folder by stacking one item on top of another.

### **Wallpaper customised**


Long press a space place on Home screen, then touch WALLPAPERS to customise wallpaper.

## **1.3.6 Volume adjustment**

### **Using volume key**

Press **Volume** key to adjust the volume. To activate the **Silent** mode, press the **Volume down** key until the tablet silent.





### **Using Settings menu**

Drag down the status bar to open the quick setting panel and touch  to enter **Settings**, then touch **Sound & notification**. Now you can set the volume of media, notification, system and etc. to your preference.

## 2 Text input

### 2.1 Using Onscreen Keyboard

#### Onscreen Keyboard settings


- Touch  **all apps** from the Home screen, select  **Settings**\ **Language&input**, touch **Current Keyboard** to select **Swiftkey** keyboard;
- Touch  **all apps** from the Home screen, select  **Settings**\ **Language&input**, touch **Android Keyboard**, a series of settings are available for your selection.

### 2.2 Swift key

Touch to switch between "abc/Abc" mode; Touch & hold to switch between "abc/ABC" mode.

Touch to switch between symbol and numeric keyboard.

Touch & hold to show input options; When Wi-Fi or data connection is on, touch to enter voice input.




Touch & hold, then select to enter symbols/emotions.

## 2.3 Text editing


You can edit the text you have entered.

- Long press or double-tap within the text you would like to edit.
- Drag the tabs to change the high-lighted selection.
- Following options will show: **FORMAT**, **CUT**, **COPY**, **PASTE**, **SHARE**, **SELECT ALL**.



**You can also insert new text**


- Touch where you want to type, or long press a blank space, the cursor will blink and the tab will show. Drag the tab to move the cursor.
- If you have selected any text, touch the tab to show **PASTE** which allows you to paste any text you have previously copied.



## 3 Contacts

**Contacts** enables quick and easy access to the contact you want to reach. You can view and create contacts on your tablet and synchronise these with your Gmail contacts or other applications.

### 3.1 Consult your contacts




Touch the **Menu** key  to display contacts list option menu.

Following actions are enabled:

- **Contacts to display** Touch to display all the contacts or the customise contacts list.
- **Import/export** Import or export contacts between tablet, microSD card and internal storage.
- **Groups** Touch to display the groups contacts.
- **Accounts** Manage the synchronisation settings for different accounts.
- **Settings** Set contacts' display mode.

## 3.2 Managing contact groups


The contact group helps you to improve the organisation of your contacts. You can add, and view groups in the **Groups** screen.

Touch the **Groups** to view local groups. To create a new group, touch the icon , enter the group's name and touch **DONE** to confirm. If you have added accounts to your tablet, touch the **Groups** to view groups in accounts.

## 3.3 Adding a contact

Touch the icon  in the contact list to create a new contact.

You are required to enter the contact's name and other contact information. By scrolling up and down the screen, you can move from one field to another easily.





If you want to add more information, touch **More Fields** to add a new category.

When finished, touch  to save.

To exit without saving, you can touch the **Back** key to exit.

## Add to/remove from Favourites



To add a contact to Favourites, you can touch a contact to view details then touch  to add the contact to Favourites (the star will turn grey in colour).

To remove a contact from favourites, touch the grey star  on contact details screen.



Only device contacts can be added to Favourites.

## 3.4 Editing your contacts

To edit contact information, touch to choose the contact, then touch  on top of the screen, When finished, touch .

### Delete a contact

To delete a contact, touch the **Menu** key  and select **Delete** from the contact's detail screen.



The contact you have deleted will also be removed from other applications on the tablet or web the next time you synchronise your tablet.


## 3.5 Contacts importing, exporting and sharing

This tablet enables you to import or export contacts between tablet and microSD card.

From Contacts screen, touch  to open options menu, touch **Import/Export** to import/export contacts from/to Tablet, Internal storage or accounts.



You can import/export a single contact or multi contacts from/to Tablet, USB storage or Accounts. Follow the instructions and tap the checkbox beside the contact you want to import/export, and touch **OK** to confirm.

You can share a single contact or contacts with others by sending the contact's vCard to them via Bluetooth, Gmail, etc.

Touch a contact you want to share, then touch the **Menu** key , and select **Share** from contact details screen, then select the application to perform this action.


## 3.6 Accounts

Contacts, data or other information can be synchronised from multiple accounts, depending on the applications installed on your tablet.


To add an account, tap  from the notification panel to open the quick settings panel, and touch  to enter **Settings**, then touch **Accounts > Add account**.

You are required to select the kind of account you are adding, like Google, Email, etc.


As with other account set-ups, you need to enter detailed information, like user name, password, etc.

You can remove an account to delete it and all associated information from the tablet. Open the **Settings** screen, touch the account you want to delete, touch the **Menu** key  and select **Remove account**, then confirm.

### Turn on/off the sync & Auto-sync

Touch an account to enter the Sync screen, slide the switch  to turn on/off the account's sync. When activated, all changes to information on the tablet or online will be automatically synchronised to each other.

### Sync manually

You can also synchronise an account manually on **Accounts** screen, touch an account in the list, then touch the **Menu** key  and select **Sync now**.










## 4 Gmail

The first time you set up your tablet, you can select to use an existing Gmail or to create a new Email account.


As Google's web-based email service, Gmail is configured when you first set up your tablet. Gmail on your tablet can be automatically synchronised with your Gmail account on the web. Unlike other kinds of email accounts, each message and its replies in Gmail are grouped in your inbox as a single conversation; all emails are organised by labels instead of folders.

### 4.6.1 To create and send emails

- Touch the icon  from Inbox screen.
- Enter recipient(s) email address(es) in the To field.
- If necessary, touch  (**Cc/Bcc**) to add a copy or a blind copy of the message.
- Enter the subject and the content of the message.
- Touch  to add an attachment.
- Finally, touch  to send .
- If you do not want to send the mail right away, touch  and then select **Save draft** to save a copy.
- If you don't want to send or save the mail, you can touch the Menu key  and then select **Discard**.

To add a signature to emails, touch the icon , then select **Settings**, touch an account, then touch **Signature**. Touch **OK** after entering the signature.


### 4.6.2 To receive and read your emails

When a new email arrives, you will be notified by a ringtone or vibration, and an icon  will appear on Status bar.





Touch and drag down the Status bar to display the **Notification panel**, touch the new email to view it. Or you can also access the Gmail Inbox label and touch the new mail to read it.

You can search for an email by sender, receiver, subject, etc.

- Touch the icon  from **Primary** screen.


- Enter the keyword you want to search for in the searching box and touch  in the soft keyboard.


### 4.6.3 To reply or forward emails

- **Reply** When viewing an email, touch  to reply the sender of this mail.
- **Reply all** When viewing an email, touch  to reply all the sender of this mail.
- **Forward** Touch  to forward the received mail to other people.
-  To assign a star or remove the star from the conversation






### 4.6.4 Managing Gmails by Labels

To conveniently manage conversations and messages, you can organise them using a Label.

To label a conversation when reading a conversation's messages, touch the icon  and select the label to assign to the conversation.

To view conversations by labels when viewing your Primary or another conversation list, touch , then touch a label to view a list of conversations with that label.

Touch **Primary** to select an email to generate the following options:


-  Touch to archive the email message. To display the archived messages, you can touch  in **Primary** screen then touch **All mail**.
-  Touch to delete the email message.
-  Touch to mark an email message as read or unread.
-  Touch to move an email message to another label.

## 5 Messaging


You can create, edit and receive SMS and MMS messages with this tablet.


To access this feature, touch **Messaging** from the Home screen.





To check messages stored in your SIM card, touch the  icon from the Messaging screen, then touch **Settings** > **Text message (SMS)** > **Manage SIM card messages**.

### 5.6.1 Write message

On the message list screen, touch the new message icon  to write text/multimedia messages.



### 5.6.2 Sending a text message

Enter the mobile phone number of the recipient or touch  to select a contact and touch the **Type text message** field to enter text. When you finish, touch  to send the text message.



An SMS message of more than 160 characters will be charged as several SMS messages. Specific letters (accent) will also increase the size of the message. This may cause multiple SMS messages to be sent.


### 5.6.3 Sending a multimedia message



MMS enables you to send video clips, images, photos, animations, slides, and sounds to other compatible phones and email addresses.


An SMS message will be converted to an MMS message automatically when media files (image, video, audio, slides, etc.) are attached or Subject or email addresses added.

## 6 Phone call


### 6.1 Placing a call


Touch  on the home screen to access phone call interface.

Touch  to display the keyboard. Enter the desired number from the keyboard directly or select a contact from **Contacts** or Call log by sliding or touching tabs, then touch  to place the call. The number you entered can be saved to **Contacts** by touching **Add to Contact**.



### 6.2 Answering or rejecting a call

When you receive a call, drag the icon  rightward to answer the call, leftward to reject the call, upward to reject the call by sending a preset message.



# 7 Calendar & Time

## 7.1 Calendar

Use Calendar to keep track of important meetings, appointments, etc.


### 7.1.1 Multimode view


You can display the Calendar in daily, weekly, monthly, or Schedule view.

- Touch **Menu**  > **Month**, **Week** or **Agenda** label to change your Calendar view. Touch the icon  to return to Today's view.


### 7.1.2 To create new events

You can add new events from any Calendar view.


- Touch the icon  to access new event edit screen.
- Fill in all required information for this new event. If it is a whole-day event, you can select **All-day**.
- When finished, touch **SAVE** from the top of the screen.

To quickly create an event from Week view screen, touch an empty spot, then touch  to enter the event details screen of the time you have previously selected. Or you can also touch the empty spot to select the target area, and tap again to create the new event.


### 7.1.3 To delete or edit an event

- To delete or edit an event, touch the event to enter details screen, touch the icon  to edit the event.
- After entering the edit screen, touch **DELETE** to delete the event.

### 7.1.4 Event reminder

If a reminder is set for an event, the upcoming event icon  will appear on Status bar as a notification when the reminder time arrives.

Touch and drag down the status bar to open the notification panel, touch event name to view Calendar notification list.

Important options by touching the  **Menu** key from Calendar main screen:



- **Search** To search in the calendar.
- **Events** Mark the checkbox to show or hide the events.
- **Settings** To make a series of Calendar settings.
- **Help & feedback** Touch to get some help and feedback.



## 7.2 Time

**Clock** application includes four applications – **World clock**, **Alarm**, **Timer** and **Countdown**.


Touch  to add or set an alarm.

### 7.2.1 To set an alarm

From **Time** screen, touch  to enter **Alarm** screen, touch  to add a new alarm. Set hour and minute on the clock, and touch **OK** to confirm. Following options will show:

- **Repeat** Touch to select days you want alarm to work.
-  **Platinum** Touch to select a ringtone for the alarm.
- **Label** Touch to set a name for the alarm.
-  Touch to delete the selected alarm.

### 7.2.2 To adjust alarm settings

Touch the **Menu**  from **Alarm** screen and touch **Settings**. The following options can now be adjusted:

- **Style** Touch to select the clock style: Analog or Digital.

- **Automatic home clock** Mark the checkbox to activate Automatic home clock feature.
- **Home time zone** Touch to choose a home time zone.
- **Silence after** Touch to set the duration of alarms.
- **Snooze length** Touch to set temporary turn off time of an alarm.
- **Alarm volume** Touch to set the alarm volume.
- **Volume buttons** Touch to set side **Volume up/down** key behaviours when alarm sounds: **Snooze**, **Dismiss**.

# 8 Getting connected



To connect to the internet with this tablet, whichever is most convenient.

## 8.1 Connecting to the Internet


### 8.1.1 Wi-Fi




Using Wi-Fi, you can connect to the Internet when your tablet is within range of a wireless network. Wi-Fi can be used on your tablet.

#### To turn **Wi-Fi** on and connect to a wireless network

- Touch  on quick settings panel to go to **Settings**.
- Touch **Wi-Fi**, and slide the switch  beside Wi-Fi to turn on/off Wi-Fi.
- Touch **Wi-Fi**, the detailed information of detected Wi-Fi networks is displayed in the Wi-Fi networks section.
- Touch a Wi-Fi network to connect. If the network you selected is secured, you are required to enter a password or other credentials (you may contact your network operator for details). When finished, touch **Connect**.



#### To activate notification when a new network is detected

When Wi-Fi is on and the network notification is activated, the  will appear on the status bar whenever the tablet detects an available wireless network within range. The following steps activate the notification function when Wi-Fi is on:


- Drag down notification panel, and touch  to switch to Quick settings panel, then touch  to access **Settings**.
- Touch **Wi-Fi**. Then touch the **Menu** key and select **Advanced** from Wi-Fi screen.
- Slide the switch  besides **Network notification** to activate/deactivate this function.

#### To add a Wi-Fi network

When Wi-Fi is on, you may add new Wi-Fi networks according to your preference.

- Drag down notification panel, and touch  to switch to Quick settings panel, then touch  to access **Settings**.



- Touch **Wi-Fi**, and then touch  > **Add network**.
- Enter the name of the network and any required network information, then touch **Save**.

When successfully connected, your tablet will be connected automatically the next time you are within range of this network.


### **To forget a Wi-Fi network**

The following steps prevent automatic connections to networks which you no longer wish to use.


- Turn on Wi-Fi, if it is off.
- In the Wi-Fi screen, touch the name of the connected network.
- Touch **FORGET** in the dialogue.

## **8.2 Connecting to Bluetooth devices**

Bluetooth is a short-range wireless communication technology that you can use to exchange data, or connect to other Bluetooth devices for various uses.

To access this function, drag down the status bar to open the quick setting panel and touch  to access **Settings**. Then touch **Bluetooth**, your device and other available ones will display on the screen.

### **To turn on Bluetooth**

- Touch **Settings** in the home screen.
- Touch  to activate/deactivate Bluetooth function.

To make your tablet more recognisable, you can change your tablet name which is visible to others.

- Touch  and select **Rename this device**.
- Enter a name, and touch **RENAME** to confirm.

### **To make device visible**

- Turn on **Bluetooth**.
- Touch your device to make it visible or invisible.

### **To pair/connect your tablet with a Bluetooth device**


To exchange data with another device, you need to turn Bluetooth on and pair your tablet with the Bluetooth device with which you want to exchange data.

- Drag down notification panel, and touch  to switch to Quick

settings panel, then touch  to access **Settings**.

- Turn on **Bluetooth**, your tablet will searching the available devices automatically.
- Touch a Bluetooth device you want to be paired with in the list.
- A dialogue will popup, touch **PAIR** to confirm.
- If the pairing is successful, your tablet connects to the device.

#### **To disconnect/unpair from a Bluetooth device**

- Touch the Settings icon  beside the device you want to unpair.
- Touch **FORGET** to confirm.

## **8.3 Connecting to a computer**

With the USB cable, you can transfer media files and other files between microSD card/internal storage and computer.

Before using MTP or PTP you should firstly mark **USB debugging**.

- To access this function, touch **Settings>About tablet**, then touch **Build number** 7 times. Now you may touch **Settings\Developer options\USB debugging**.

#### **To connect/disconnect your tablet to/from the computer:**

- Use the USB cable that came with your tablet to connect the tablet to a USB port on your computer. You will receive a notification that the USB is connected as a media device.
- Drag down status bar to open the **Notification** panel and touch “USB for charging“, then select **Charging only**, **Transfer files(MTP)**, or **Transfer photos(PTP)**.

To disconnect (from mass storage):


- Unmount the microSD card on your computer.



For the operating system Windows XP or lower, you should download and install Windows Media Player 11 on your computer from the following link: <http://windows.microsoft.com/zh-CN/windows/download-windows-media-player>.

To locate the data you have transferred or downloaded in the internal storage, touch **File Manager**, all data you have downloaded is stored in **File Manager**, where you can view media files (videos, photos, music and others), rename files, install applications into your tablet, etc.



## To format a microSD card

- Drag down status bar to open quick settings panel and touch  to access **Settings**.
- Touch **Storage&USB**.
- Touch **Erase SD card**. On the screen a popup warns you that formatting the micro SD card will lose all data on the card, touch **Erase SD card**.

## 8.4 Connecting to virtual private networks

Virtual private networks (VPNs) allow you to connect to the resources inside a secured local network from outside that network. VPNs are commonly deployed by corporations, schools, and other institutions so that their users can access local network resources when not inside that network, or when connected to a wireless network.

### To add a VPN

- Touch **Apps**  from the home screen, then touch **Settings**.
- Touch **More...\VPN** and then touch .
- In the screen that opens, follow the instructions from your network administrator to configure each component of the VPN settings.
- Touch **Save**.


The VPN is added to the list on the VPN settings screen.



Before adding a VPN, you should set a lock screen pattern, PIN code or password for your tablet.

### To connect/disconnect to a VPN

To connect to a VPN:

- Touch **Apps**  from the home screen, then touch **Settings**.
- Touch **More...\VPN**.
- VPNs you have added are listed; touch the VPN you want to connect with.
- In the dialogue that opens, enter any requested credentials and touch **Connect**.

To disconnect:

- Open the Notification panel and touch the resulting notification for the VPN disconnection.

## To edit/delete a VPN

To edit a VPN:

- Touch the **Menu** key from the home screen, then touch **Settings**.
- Touch **More...\VPN**.
- VPNs you have added are listed; touch & hold the VPN you want to edit.
- Touch **Edit profile**.
- After finished, touch **Save**.



To delete:

- Long press the VPN you want to delete, in the dialogue that opens, touch **Delete profile**.

## 9 Play Store <sup>(1)</sup>

Play Store is an online software store, where you can download and install applications and games to your Android Powered Tablet.


To open Play Store:

- Touch **Apps**  from home screen, then touch  **Play Store**.
- For the first time you access **Play Store**, a screen with terms of service pops up for your attention, touch **Accept** to continue.

Touch , then select **Help & Feedback** to enter Play Store help page for more information about this function.

### 9.1 Locate the item you want to download and install

Play Store provides two kinds applications. It shows **APPS&GAMES**, **ENTERTAINMENT** in the home page.



Touch to search in **Google Play store**.

Slide up and down to see all categories.



Touch **CATEGORIES** on Play Store screen to browse all categories. Within each category you can select to view items sorted by TOP FREE, TOP PAID, TOP GROSSING, TOP NEW PAID, etc.

(1) Depending on your country and operator.

Touch Back key to return to the previous screen.

## 9.2 Download and install

### To download & install:

- Navigate to the item you want to download, and select to enter the details screen from which you can read its description, overall rating or comments, view developer's information, etc.
- Touch **INSTALL** to preview the functions and data the application can access on your tablet if you install it.
- Touch **ACCEPT**.
- The progress of the download will show on the details screen, touch  to stop downloading the item. You can also access this screen through Notification panel.
- After download and installation have finished, you will see a notification icon  on the status bar.



Be especially cautious with applications that have access to many functions or to a significant amount of your data. Once you accept, you are responsible for results of using this item on your tablet.

### To open the application you have downloaded:

- On Play Store screen, touch  and select **My apps & games**.
- Touch the installed application in the list, then touch **OPEN**.

### To buy an application<sup>(1)</sup>

On **Play Store**, some applications are labelled as free, while some of them are to be paid for before downloading and installing.

- Touch the application you want to buy.
- Touch the price on the up-right of the screen to preview the functions and data the application can access on your tablet if you install it.
- Touch **Continue** to confirm.
- When making your first purchase, you are required to input your credit card information and to log into Google payment and billing service.
- If your account has multiple credit card accounts, select one to proceed.
- Select the Terms of service link and read the document. When finished,

<sup>(1)</sup> Google Paid applications may not be available to users in some countries.


touch **Back** key.

- Mark the checkbox if you agree with the terms of service.
- Touch **Buy now** at the bottom of the screen.

When finished, Android downloads the application.

### **To request a refund**

If you are not satisfied with the application, you can ask for a refund within 15 minutes of the purchase. Your credit card will not be charged and the application will be removed. If you change your mind, you can install the application again, but you will not be able to request a refund.

- Touch  and select **My apps & games** from Play Store screen.
- Touch the application that you want to uninstall and refund.
- Touch **Refund** to uninstall the application and refund. If the button becomes **Uninstall**, your trial period has expired.
- In the survey form, select the answer that best matches your reason, and touch **OK**.


## **9.3 Manage your downloads**

After you downloaded and installed an application, the following further operations are available for your selection.


### **View**

On Play Store screen, touch  and select **My apps & games**.



### **Uninstall**

On Play Store screen, touch  and select **My apps & games**. Touch the application you want to uninstall to enter the details screen, touch **UNINSTALL** and finally touch **OK** to confirm.



### **Refund**

On Play Store screen, touch  and select **My apps & games**. Touch the application you want to uninstall for a refund, touch **Refund**, and finally touch **OK** to confirm.

### **Update notification**

On Play Store screen, touch  and select **My apps & games**. Touch  and select **Settings**, mark **App updates available** to enable update notification.

## Auto update

To auto update all installed applications, touch  and select **My apps & games** from Play Store screen. Touch  and select **Settings\Auto-update apps** to enable this function.

## Reviews

Open the details screen for an application, touch the stars  to award and input comments, touch **OK** to confirm.

## Flag

You can report an inappropriate application to Play Store by flagging it. Open the details screen for the application, scroll to the bottom and touch **Flag as inappropriate**, enter the reason and finally touch **Submit**.




# 10 Multimedia applications


## 10.1 Camera

Your tablet is fitted with a Camera for taking photos and shooting videos.



Before using the Camera, please be sure to open the protective lens cover to avoid it affecting your picture quality.




### To take a picture

The screen acts as the viewfinder. First position the object or landscape in the viewfinder, touch  icon to take the picture which will be automatically saved.

### To shoot a video

First position the object or landscape in the viewfinder, and touch  icon to start recording. Touch  to save the video.

### Further operations when viewing a picture/video you have taken

- Touch the icons below the screen to share or delete the photos/videos you have taken.
- Touch the photo icon  to access **Gallery**.

## **10.1.1 Settings in framing mode**

### **Rear camera shooting mode**


- Auto mode      Touch to switch to Auto mode.
- Polaroid        Touch to switch to Polaroid mode.
- HDR             Touch to turn on the HDR mode.
- Pano            Touch to switch to front camera.
- Manual mode    Touch to switch to Manual mode.
- Scanner        Touch to switch to scanner mode.
- Face beauty    Touch to switch to face beauty mode.

### **Front camera shooting mode**

- Auto mode      Touch to switch to Auto mode.
- Polaroid        Touch to switch to Polaroid mode.
- Face beauty    Touch to switch to face beauty mode.

## 10.2 Gallery

Gallery acts as a media player for you to view photos and playback videos. In addition, a set of further operations to pictures and videos are available for your choice.



Touch to select categories:  
Albums, Times, Locations,  
Videos.

### To view a picture/play a video

Pictures and videos are displayed by albums in **Gallery**.

- Touch an album and all pictures or videos will spread the screen.
- Touch the picture/video directly to view or play it.
- Slide left/right to view previous or next pictures/videos.




### Working with pictures

You can work with pictures by editing them, sharing them with friends, setting them as contact photo or wallpaper, etc.

Touch **Edit icon**  to enter the edit screen.






Edit tools

- Touch  to save the modified picture.
- Touch  to undo the previous modification.
- Touch  to redo the previous modification.

### **Batch operation**


Gallery provides a multi- select function, so that you can work with pictures/videos in batches.


Open the main Gallery window or Albums screen, touch  and select **Select item** to activate batch operation mode (you can also long press one picture), then touch pictures you want to work on. Touch  icon to delete the selected ones. Touch  to share selected ones.

# II Maps

## II.1 Get My Location

### II.1.1 Choose a data source to decide My Location

Drag down the status bar to open quick setting panel and touch  to access **Settings**, touch **Location**.


- Touch the switch  at the title bar to enable location services.
- Touch **Mode>Device only** to set GPS as My Location data source.

### II.1.2 Open Google Maps and view My Location

Touch Apps, then touch **Maps** to enter Google maps screen.

Touch  icon on the map to view **My Location**.

The map will then centre on a blue dot with a blue circle around. Your actual position is within the blue circle.



To move the map, drag the map with your finger.

To zoom in and out of a map, pinch or spread your fingers, or you can also zoom in by double-tapping a location on screen.


To clear the map history, touch  on top left of the maps screen, then select **Settings**, select **Maps history**, then touch .

## 11.2 Search for a location

While viewing a map, touch the Google search bar to activate search function.

In the search bar enter an address, a city or a local business.

Touch the search icon to search, and in a while your search results will appear on the map as red dots. You can touch one to show a label.



Touch to show more information

## 11.3 Star a location


Just like bookmarking a web address on the Internet, you can star any position on the map for later use.

### 11.3.1 How to star (or unstar) a location

Touch a location on a map.

Touch the address rectangle that opens.


Touch the blue star at the top of the screen to star the location. (Or touch a gold star to unstar that location.)



## 11.4 Get driving, public transportation or walking directions

### 11.4.1 Get suggested routes for your trip

Touch icon  from Maps screen.




To edit your start point by one of the following methods:

- Touch **Your location**, then enter an address as the start point.
- Choose destination directly by selecting a starred item saved before, selecting an address from your contacts, or using search history.

Do likewise for your end point. 

To reverse directions, touch .

A couple of suggested routes will appear in a list. Touch any routes to view their respective detailed directions.

To get reverse directions for a route you've already made, simply open that route's directions window and touch . No need to enter your start point and end point again.

### 11.4.2 Preview suggested routes and decide on a route more preferable or feasible to you

You can preview each turn in your route in Navigation, Satellite, and other views.

- Touch a left or right arrow to preview the next or previous leg of your route.

When selecting a more preferable or feasible route, distance and time will be the two most important factors for your evaluation. Distance



and estimated time will be displayed at the top of the directions screen.


### **11.4.3 Search for locations along your route**

Please refer to "**9.3 Search for a location**" for detailed information.

## **11.5 Arrangement of Layers**

Layers allow you to view locations and additional information overlaid on the map. You can add multiple layers or remove only certain layers so you control exactly what information you want visible on the map at one time.

### **11.5.1 To view multiple layers**

Touch icon  from Maps screen. All available layers are listed (like Traffic, Satellite, etc.), select one to view.

### **11.5.2 To clear the maps history**

After you get directions or search on a map, you can clear the markers/ layers that have been drawn: touch  and **Settings**, select **Maps history**, then touch .

# I2 Others

## I2.1 File Manager



To access this function, touch Apps , and then touch .

**File Manager** works with both external SD card and internal storage.

**File Manager** displays all data stored on both microSD card and internal storage, including applications, media files; videos, pictures or audios you have captured; other data transferred via Bluetooth, USB cable, etc.

When you download an application from PC to microSD card, you can locate the application on File Manager, then touch it to install it in your tablet.



File Manager allows you to perform and be really efficient with the following common operations: create (sub) folder, open folder/file, view, rename, move, copy, delete, play, share, etc.

## I2.2 Other applications <sup>(1)</sup>

The previous applications in this section are preinstalled on your tablet. To read a brief introduction of the preinstalled 3rd party applications, please refer to the leaflet provided with the tablet. You can also download thousands of 3rd party applications by going to Google Play Store on your tablet.

<sup>(1)</sup> Application availability depends on country and operator.

# 13 Settings

To access this function, touch  from Home screen and touch  to access **Settings**.

## 13.1 Wireless & networks

### 13.1.1 Wi-Fi

Using Wi-Fi you can now surf the Internet whenever you are in range of a wireless network. The only thing you have to do is to enter the **Wi-Fi** screen and configure an access point to connect your tablet to the wireless network.


### 13.1.2 Bluetooth

Bluetooth allows your tablet to exchange data (videos, images, music, etc.) in a small range with another Bluetooth supported device (tablet, computer, printer, headset, car kit, etc.).


### 13.1.3 Data usage

You can choose a data usage cycle to view the statistics and related applications of used data by your tablet.

### 13.1.4 Aeroplane mode

Slide the switch  to turn off **Aeroplane mode** in "more..." menu to simultaneously disable all wireless connections including Wi-Fi, Bluetooth and more.

### 13.1.5 Tethering & portable hotspot

Slide the switch  to turn off **Aeroplane mode** in "more..." menu to simultaneously disable all wireless connections including Wi-Fi, Bluetooth and more.

## 13.1.6 VPN settings

A mobile virtual private network (mobile VPN or mVPN) provides mobile devices with access to network resources and software applications on their home network, when they connect via other wireless or wired networks. Mobile VPNs are used in environments where workers need to keep application sessions open at all times, throughout the working day, as the user connects via various wireless networks, encounters gaps in coverage, or suspend-and-resumes their devices to preserve battery life. A conventional VPN cannot survive such events because the network tunnel is disrupted, causing applications to disconnect, time out, fail, or even the computing device itself to crash.

## 13.2 Device

### 13.2.1 Gestures

Your device can be configured in ALARM mode so that turning it over will start the snooze function, or you can mark a check box to change music tracks when you shake your device.

When the “Double tap screen” feature is enable, you can wake up the lock screen on by double touching the sleeping screen.

### 13.2.2 Display



- **Brightness level** Touch to adjust the brightness of the screen.
- **Wallpaper** Touch to set the wallpaper.
- **Sleep** Touch to set screen time out.
- **Daydream** Select an animation effect which shows in standby status.
- **Font size** Touch to set the font size.
- **When device is rotated** Touch to set when the screen will be rotated.

## 13.2.3 Sound & notification

Use the Sound settings to configure volume and ringtones for different events and environments.

### Sound & Notification Settings Overview

The sound settings menu allows you to configure the following options:

- **Sound** Set volume for ringtones, alarms, system features, etc.
- **Headset mode** Slide the  to turn on/off the Headset mode.
- **Silent mode** Slide the  to turn on/off the Silent mode.
- **Do not disturb** Set interruption allows and automatic rules for your tablet.
- **Phone ringtone** Set your tablet's ringtone.
- **Default notification ringtone** Set a tone for default tablet notifications.
- **Other sounds** Set a tone for dial pad, screen lock, etc.

### Notification

- **When device is locked** When device is locked, set to show or not show notification content.
- **App notifications** Tap to see all app notifications.
- **Notification access** Tap to check notification access.

## **13.2.4 Apps**

You use the Apps settings to view details about the applications installed on your tablet, to manage their data and force them to stop, and to set whether you want to permit installation of applications that you obtain from web sites and emails.

## **13.2.5 Storage & USB**

Use these settings to monitor the total and available space on your tablet and on your microSD card; to manage your microSD card.



If a warning message comes up saying that tablet memory is limited, you are required to free up space by deleting some unwanted applications, downloaded files, etc.

## **13.2.6 Battery**

In battery management screen you can view the battery usage data since you last connected the tablet to a power source. The screen also shows your battery status and how long it has been used since last charging. Touch one category, then you can learn its specific power consumption.

## **13.2.7 Memory**

You can check the memory status in Memory screen.

## **13.2.8 Users**

You can add user or profile in User setting screen, and also you can switch the users mode here.


# **13.3 Personal**

## **13.3.1 Location**

**Use GPS to determine your location**

Check to use your tablet's global positioning system (GPS) satellite receiver to pinpoint your location within an accuracy as close as several

meters (“street level”). To use Location-Based Services, you must first enable location services on your device:

- Select Settings > Location, touch the switch  at the title bar to enable/disable location services.
- Touch Mode > Device only to enable the GPS satellite.

The process of satellite and setting your tablet’s precise location will require up to 5 minutes. You will need to stand clear view of the sky and avoid moving. After this, 20-40 seconds to identify your precise location.

## 13.3.2 Security

### Func

Slide  to display shortcuts on your lock screen.

### Screen lock

Touch to set a method to unlock screen.

### Make pattern visible

Slide  to make pattern visible or not.

### Automatically lock

Set the time for automatically lock.

### Power button instantly locks

Slide  to enable the Power key to lock screen.

### Owner info

Touch to set the owner information on lock screen.

### Smart Lock

Touch to set smart lock.


### Make passwords visible

Slide  to show passwords as you type.

### Device administrators

Touch to view or deactivate device administrators.

### Unknown sources

Slide  to permit installation of applications that you obtain from web sites, emails, or other locations other than Google Play Store.

To protect your tablet and personal data, download applications only from trusted sources, such as Google Play Store.

## **Storage type**

Touch to choose a storage type.

## **Trusted credentials**

Touch to display trusted CA certificates.

## **Install from SD card**

Touch to install certificates from SD card.

## **Clear credentials**

Touch to remove all certificates.

## **Trust agents**

View or deactivate trust agents.

## **Screen pinning**

Turn on/off the screen pinning feature.

## **Apps with usage access**

Turn Engineering Mode on to access the information of the apps usage.

# **13.4 Accounts**

Use the settings to add, remove, and manage your Email and other supported accounts. You can also use these settings to control how and whether all applications send, receive, and synchronise data on their own schedules, and whether all applications can synchronise user data automatically.

## **13.4.1 Google**

Use the **Google** settings to find various options to set your google account or google service.

## **13.4.2 Language & input**

Use the Language & input settings to select the language for the text on your tablet and for configuring the onscreen keyboard. You can also configure voice input settings and the pointer speed.

### **Language**

Touch to set the system language.



## **Spell checker**

Mark the checkbox to enable the system to show suggested words.

## **Personal dictionary**

Touch to open a list of the words you've added to the dictionary.

Touch a word to edit or delete it.

Touch the add button + to add a word.

## **Current Keyboard**


Touch to select a current input method.

## **Android keyboard**

The Android keyboard settings apply to the onscreen keyboard that is included with your tablet. The correction and capitalisation features affect only the English version of the keyboard. Available options are as follows:

### **Text-to-speech output**

- **Preferred engine**

Touch to choose a preferred text-to-speech engine, touch the settings icon  to show more choices for each engine.

- **Speech rate**


Touch to open a dialogue where you can select how quickly you want the synthesizer to speak.

- **Listen to an example**

Touch to play a brief sample of the speech synthesizer, using your current settings.

## **13.4.3 Backup and reset**

### **Back up my data**


Slide  to back up your tablet's settings and other application data to Google Servers with your Google Account. If you replace your tablet, the settings and data you've backed up are restored onto the new tablet for the first time you sign in your Google Account. If you mark this option, a wide variety of settings and data are backed up, including your Wi-Fi

passwords, bookmarks, a list of the applications you've installed, the words you've added to the dictionary used by the onscreen keyboard, and most of the settings that you configure with the Settings application. If you unmark this option, you stop backing up your settings, and any existing backups are deleted from Google Servers.

### **Back up account**

Touch to set your backup account.

### **Automatic restore**

Slide  to restore your backed up settings or other data when reinstalling an application.

### **Network settings reset**

Touch to reset settings for network.

### **Factory data reset**

Tablet reset will erase all of your personal data from internal storage, including information about your Google Account, any other accounts, your system and application settings, and any downloaded applications. Resetting the tablet does not erase any system software updates you've downloaded or any files on your micro SD card, such as music or photos.

When you can't power on your tablet, there is another way to perform a factory data reset by using hardware keys. Press the **Volume up** key and the **power** key at same time until the screen lights up.

## **13.5 System**

### **13.5.1 Date & time**

Use Date & Time settings to customise your preferences for how date and time are displayed.

#### **Automatic date & time**

Touch to select **Use network/GPS provided time** or **Off**.

#### **Automatic time zone**

Slide  to turn on **Use network-provided time zone** or **Off**.

### **Set date**

Touch to open a dialogue where allows you to set the tablet's date manually.

### **Set time**

Touch to open a dialogue where you can manually set the tablet's time.

### **Select time zone**

Touch to open a dialogue where you can set the tablet's time zone.

### **Use 24-hour format**

Mark the checkbox to display the time using 24-hour format.

### **Choose date format**

Touch to open a dialogue where allows you to select the format for displaying dates.

## **13.5.2 Scheduled power on & off**

Touch to set the schedule power on or off for your tablet.

## **13.5.3 Accessibility**

You use the Accessibility settings to configure any accessibility plug-ins you have installed on your tablet.

## **13.5.4 Regulatory & Safety**

Touch to display the information about Regulatory and Safety.

## **13.5.5 Developer options**

To access this function, touch **Settings\About tablet**, then touch **Build number** 7 times. Now **Developer options** is available.

The Developer options screen contains settings that are useful for developing Android applications. For full information, including documentation of the Android applications and development tools, see the Android developer web site (<http://developer.android.com>).

**Note:** Mark the checkbox to enable “USB debugging”, which permit debugging tools on a computer to communicate with your tablet via a USB connection.

## **I3.5.6 About tablet**

This contains information about things ranging from Legal information, Model number, Firmware version, Baseband version, Kernel version, Build number to those listed below:

### **Updates**

Touch to check for system updates.

### **Status**

Touch to display the status of the battery, network, serial number and other information.

### **Legal information**

Touch to view legal information.

# I 4 Making the most of your tablet

You can download software upgrade for free from the website :  
([www.alcatel-mobile.com](http://www.alcatel-mobile.com)).

## I 5 Accessories

The latest generation of alcatel tablets offers a built-in handsfree feature that allows you to use the tablet from a distance, placed on a table for example. For those who prefer to keep their conversations confidential, an earpiece is also available known as the headset.

1. Charger

2. USB cable



Only use your tablet with the alcatel, charger and accessories in your box.

# 16 Troubleshooting

**Before contacting the service centre, you are advised to follow the instructions below:**

- You are advised to fully charge (🔋) the battery for optimal operation.
- Avoid storing large amounts of data in your tablet as this may affect its performance.
- Use Factory data reset and the upgrade tool to perform tablet formatting or software upgrading. All user tablet data: contacts, photos, and files, downloaded applications will be lost permanently. It is strongly advised to fully back up the tablet data and profile before doing formatting and upgrading.

## **My tablet cannot be switched on or is frozen**

- When the tablet cannot be switched on, charge for at least 20 minutes to ensure the minimum battery power needed, then try to switch on again.
- When the tablet falls into a loop during power on-off animation and the user interface cannot be accessed, press the Power key to Pop up the options, then long press “Power Off” to enter Safe Mode. This eliminates any abnormal OS booting issues caused by 3rd party APKs.

## **My tablet has not responded for several minutes**

- Restart your tablet by long pressing the Power key for about 10 seconds.

## **My tablet turns off by itself**

- Check that your screen is locked when you are not using your tablet, and make sure the Power key is not mis-contacted due to unlocked screen.
- Check the battery charge level.

## **My tablet can't charge properly**

- Make sure that your battery is not completely discharged; if the battery power is empty for a long time, it may take around 20 minutes to display the battery charger indicator on the screen.
- Make sure charging is carried out under normal conditions (0°C to +40°C).
- When abroad, check that the voltage input is compatible.

## **My tablet can't connect to the Internet**

- Check your tablet's Internet connection settings.

- Make sure you are in a place with network coverage.
- Try connecting at a later time or another location.

### **I am unable to use the features described in the manual**

- Check with your operator to make sure that your subscription includes this service.
- Make sure this feature does not require an alcatel accessory.

### **I am unable to connect my tablet to my computer**

- Install alcatel Centre.
- Check that your USB driver is installed properly.
- Check that you have marked the checkbox of USB debugging. To access this function, touch Settings\About tablet, then touch Build number for 7 times. Now you may touch Settings\Developer options\USB debugging.
- Check that your computer meets the requirements for alcatel Centre Installation.
- Make sure that you're using the right cable from the box.

### **I am unable to download new files**

- Make sure there is sufficient tablet memory for your download.
- Check your subscription status with your operator.

### **The tablet cannot be detected by others via Bluetooth**



- Make sure that Bluetooth is turned on and your tablet is visible to other users.
- Make sure that the two tablets are within Bluetooth's detection range.

### **How to make your battery last longer**

- Make sure you follow the complete charge time (minimum 2.5 hours).
- After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain an exact indication.
- Adjust the brightness of screen as appropriate.
- Extend the email auto-check interval for as long as possible.
- Update news and weather information on manual demand, or increase their auto-check interval.

- Exit background-running applications if they are not being used for a long time.
- Deactivate Bluetooth, Wi-Fi, or GPS when not in use.

**The tablet will become warm following prolonged game playing, internet surfing or running other complex applications.**

- This heating is a normal consequence of the CPU handling excessive data such as game playing, internet surfing or running other complex applications. Ending above actions will make your tablet return to normal temperature.
1. Please pay attention that after Factory data reset is performed you may be requested to enter Google account credentials<sup>(1)</sup> that were used on this device before Factory reset. Otherwise you will not be able to use the device. If you don't remember your Google account credentials please complete Google account recovery procedure. In case you don't succeed in it
    - Please apply to authorized repair center, but remember that it will not be regarded as warranty case.
  2. After Factory reset is performed my device asks to enter Google account credentials and I can't use it avoiding this action<sup>(1)</sup>.
    - After Factory reset is performed you need to enter the original Google account credentials that were used on this device before Factory data reset. Otherwise you will not be able to use the device. If you don't remember your Google account credentials please complete Google account recovery procedure. In case you don't succeed in it - please apply to authorized repair center, but remember that it will not be regarded as warranty case.
  3. I don't hear when somebody calls/message me, I just see missed calls/messages notifications on display.
    - Please check if Interruptions/Do not disturb mode is activated on your device. If it is activated you can see a "Star" symbol  (for Android OS 5.X version) or  icon (for Android OS 6.X version) displayed on notification panel. In this case you need deactivate Interruptions/Do not disturb mode. To do it just press volume up or down key and select "All" (on Android 5.X) → or modify → it in Settings "Sound & notifications" Interruptions ( for Android 5.X)

<sup>(1)</sup> Applicable for Android OS versions starting from 5.1.



or Do not disturb ( for Android 6.X).

4. My device asks me to enter some password/code/key that I don't remember or don't know due to this device has been used by another person before and I can't get this password/code/key from him/her.
- Password/code/key request could be caused by same security feature activated on this device. You can try to perform Factory data reset, but remember that if it doesn't help you need to apply authorized repair center and it will not be regarded as warranty case.

alcatel is a trademark of Alcatel-Lucent  
and is used under license by  
TCL Communication Ltd.

© Copyright 2016 TCL Communication Ltd..  
All rights reserved

TCL Communication Ltd. reserves  
the right to alter material  
or technical specification  
without prior notice.