

Start Guide



myTouch^Q

Welcome

to Android™ Basics



Phone Navigation

Move around your touch-screen



Tap

to select an item or an open application.

or

Touch & hold

to drag an item or to add widgets, shortcuts, and applications to your Home screen.




Swipe left & right

to see more of your Home screen.


Touch & drag down

the top bar to open Notifications screen.



Hardkeys

Are always there to help you out



Menu key

Tap to display a list of options.



Home key

Tap to go back to your home screen.



Back key

Tap to return to the previous screen.




Genius button™

Tap to speak commands for calling friends, sending text messages, searching the Web, or finding a business.

Dialer

Make calls and stay in touch




To **answer** a call,
tap .

To **decline** a call,
tap .




To **place** a call,
tap the Phone icon to
open the Dialer screen...



...then
enter a phone number
or select a contact and
tap .

To **end** a call,
tap .



Search

Find anything, anytime, and virtually anywhere



Google™ Search

Access the world's information to find what you are looking for.



Android Market™

Explore the world of games and apps on your phone.



Browser

Surf the Web while on the go.



TeleNav GPS Navigator™

Find your way around and never be lost again.

Additional Features



Visual Voicemail

Tap for Visual Voicemail.



Messaging

Tap for messages.



Contacts

Tap to view your contacts.

Want to know more?

For more detailed information please see the rest of this guide for more information.



TABLE OF CONTENTS

Support.....	1	Contacts	17
Service.....	2	E-mail Setup.....	18
Phone Overview	3	Messaging.....	20
SIM Card	5	Wi-Fi	21
Memory Card	7	Wi-Fi Calling	22
Battery	8	Bluetooth®	25
Power.....	9	Battery & Memory Management	26
Home Screen	9	Caring For Your Phone	28
Ringtones	13	Accessories	30
Volume.....	13	Emergency Dialing	31
Motion Sensor	14	Additional Information	31
Voice mail	15		


SUPPORT

This guide provides you with the information you need to get started.

For more information and additional support, please visit www.t-mobile.com/support where you can:

- Register at **My.T-Mobile.com** to check your minutes, pay your bill, upgrade your phone, and change your rate plan.
- Review your phone's User Manual and troubleshooting FAQs.
- View the latest troubleshooting solutions in the Support Forums or ask a question of your own.

You can also access account and device information from your phone.

1. From any Home screen, tap the **Applications**  icon.
2. Under the Applications section, scroll to and tap **My Account** or **My Device**.

SERVICE

If you are a new T-Mobile® customer and your service has not yet been activated, call Customer Care at **1-800-937-8997** and a T-Mobile Activations representative will assist you.

You will need the following information when activating service:

- Service Agreement and agent code on your Agreement
- Your name, home address, home phone number, and billing address
Note: For business and government accounts, please provide the name of your company or government agency, address, and tax ID.
- Your Social Security number, current driver's license number, and date of birth for credit check purposes
- Your choice of T-Mobile rate plan and services (see www.T-Mobile.com for latest plan information)
- SIM serial number and IMEI number (located on the box barcode label)

By activating service, you acknowledge that you have read, understand, and agree to be bound by each of T-Mobile's Terms and Conditions, and your Service Agreement.

PHONE OVERVIEW




SIM CARD

Your SIM (Subscriber Identity Module) card identifies your phone to the wireless network. You cannot make or receive calls or browse the Internet without the SIM card.

Insert the SIM card

1. Detach the SIM card from its packaging.



2. Use the notch on the bottom of the phone to detach and pull the back cover away.



3. Remove the battery and insert the SIM card, as shown.



4. Align the golden contacts on the battery with the golden contacts in the battery compartment and replace the back cover.



MEMORY CARD

Your phone comes with a 2 GB microSD memory card.

Install or remove the memory card

1. Use the notch on the bottom of the phone to detach and pull the back cover away.
2. Gently insert the memory card into the slot, as shown. To remove, gently slide the memory card from the slot.



BATTERY

Your phone is shipped with the battery partially charged. Please charge it fully before use.

For more information on how to conserve battery life, see the **Battery & Memory Management** section on page 26 of this guide.

Charge the battery

1. Insert the small end of the charger cable into the charger/USB port, as shown.
2. Plug the other end into an electrical wall outlet or a USB port on a computer.



POWER



To turn the power on,
press and hold the
Power/Lock key.

To turn the power
off, press and hold
the **Power/Lock** key
and tap **Power Off**.

HOME SCREEN

Swipe your finger left or right to view
more of your Home screen.



You can customize each screen with widgets
or shortcuts to your favorite applications.

Status bar


The Status bar appears at the top of
every Home screen. Icons indicating
the phone's status and new notification
alerts appear on the Status bar.

Notification screen

To open the Notification screen, touch
and drag the **Status** bar down.

Status bar


Touch and
drag down
to open



Quick
Setting
icons

Notification
icons

Applications screen

To access the Applications screen, from any Home screen, tap the **Applications**  icon to view the following:

- **Recent** to view applications you have opened recently.
- **Downloads** to view applications you have downloaded.
- **Applications** to view all applications on your phone.

Unlock the screen

Swipe up to unlock.

Add items to the Home screen

1. Swipe left or right to the desired Home screen.
2. Touch and hold an empty spot on the screen.
3. Tap **Widgets**, **Shortcuts**, or **Folders** on the bottom of the screen.
4. Tap the desired item to add.

Move and delete items


Touch and hold the item you want to move or delete and drag it to another location or to the **Trash Can** icon at the bottom of the screen.

Change Home screen wallpaper


1. Touch and hold an empty spot on the Home screen.
2. Tap **Wallpapers** on the bottom of the screen.
3. Tap **Gallery**, **Live wallpaper**, or **Downloaded Wallpaper**.
4. Tap the desired image.
5. Adjust the crop box, if necessary and tap **Set wallpaper** or **Save**.

RINGTONES

Set call and notification ringtone

1. From any Home screen, tap the **Menu**  key.
2. Tap **Settings**.
3. Tap **Sound**.
4. Tap **Phone ringtone** or **Notification ringtone**.
5. Tap the desired ringtone.
6. Tap **OK**.

Set other sounds


1. From any Home screen, tap the **Menu**  key.
2. Tap **Settings**.
3. Tap **Sound**.
4. Scroll to and tap the following items to turn the sound on or off:
 - **Audible touch tones**
 - **Audible selection**
 - **Screen lock sounds**
 - **Haptic feedback**
 - **Vibrate**

VOLUME

Set call volume

While on a call, press the **Volume** key up or down.

Set other volume

1. From any Home screen, tap the **Menu**  key.
2. Tap **Settings**.
3. Tap **Sound**.
4. Tap **Volume**.
5. Touch and drag the **Ringtone**, **Media**, and **Alarm** sliders to the desired level.
6. Tap to select the **Use incoming call volume for notifications** check box to set the notifications volume to match the ringtone volume.
7. Tap **OK**.

Silence ringer volume


From any Home screen, press the **Volume** key down until you see the **Silent mode** icon.

MOTION SENSOR

When the motion sensor is activated, you can:

- Mute the incoming call ringer by flipping over the phone
- Mute the alarm sound by flipping over the phone
- View items in the Gallery by tapping left and right side of the phone
- Pause the video player by flipping over the phone


To turn on/off motion sensor:

1. From any Home screen, tap the **Menu**  key.
2. Tap **Settings**.
3. Tap **Gesture**.
4. Tap the desired check boxes to turn the features on or off.



VOICEMAIL

Use voicemail

To call and set up voicemail:

1. From any Home screen, tap the **Phone**  icon.
2. Touch and hold **1** to call voicemail.
3. Follow the instructions to set up your voicemail account.


To reset the voicemail password to the last four digits of your phone number:

1. From any Home screen, tap the **Phone**  icon.
2. Tap **#793#**.
3. Tap the green **Phone**  icon.
4. Tap **OK**.



Use Visual Voicemail

With Visual Voicemail, you can view a list of your voicemail messages and play them in any order.



To set up Visual Voicemail:

1. From any Home screen, tap the **Applications**  icon.
2. Tap **Visual Voicemail**.
3. Tap **Next**.
4. Tap the blue **Record** icon to begin recording your custom greeting.
5. Tap the red **Stop** icon when done recording.
6. Tap **Next**.
7. Enter a name for the greeting.
8. Tap **Next**.
9. Tap **Done**.

To check Visual Voicemail messages:


1. From any Home screen, tap the **Applications**  icon.
2. Tap **Visual Voicemail**.
3. Tap the voicemail message you want to play.
4. Tap the **Play**  icon.

To delete Visual Voicemail messages:


1. From any Home screen, tap the **Applications**  icon.
2. Tap **Visual Voicemail**.
3. Tap the voicemail message you want to delete.
4. Tap the **Delete**  icon.
5. Tap **OK**.

CONTACTS

Add new contact

1. From any Home screen, tap the **Phone**  icon.
2. Tap the **Contacts** tab near the top of the screen.
3. Tap the green **New Contact** icon next to the **Search** box.
4. Enter the contact's information.
5. Tap **Save**.

Call contact from the contacts list


1. From any Home screen, tap the **Phone**  icon.
2. Enter the name or phone number of the desired contact and select from the list of potential matches. If the contact is not saved in your phone book, enter the complete phone number.

Note: You can also tap the **Contacts** tab near the top of the screen to view and select from contacts saved in your phone book.


3. Tap the green **Phone**  icon to call.

E-MAIL SETUP

Set up Gmail™

1. From any Home screen, tap the **Applications**  icon.
2. Tap **Gmail**.
Note: If you have already set up at least one other Google account, tap the **Menu** key > **Accounts** > **Add account** to set up additional Google accounts.
3. Tap **Next**.
4. Tap **Create** or **Sign in**.
5. Follow the on-screen instructions.

Set up personal email

1. From any Home screen, tap the **Envelope**  icon.
2. Tap **Yahoo!**, **Windows Live**, **Hotmail**, **AOL (or other)**.
Note: If you have already set up an email account, tap the **Menu** key > **More** > **Accounts** > **Menu** key > **Add account**.
3. Enter your email address and password.
4. Tap **Next**.
5. Enter a display name for the email account (optional) and the name you want to display on your outgoing emails.
6. Tap **Done**.

Set up corporate email

1. From any Home screen, tap the **Applications**  icon.

2. Tap **E-mail**.


Note: If you have already set up an email account, tap the **Menu** key > **More** > **Accounts** > **Menu** key > **Add account**.

3. Tap **MS Exchange**.
4. Enter your email address and password.
5. Tap **Next**.
6. Enter the server address and domain name.
7. Tap **Next**.
8. Tap **Activate**. Your phone syncs with the email server.
9. Enter a display name for the email account (optional) and the name you want to display on your outgoing emails.
10. Tap **Done**.


Contact your company's IT department if you need more help.

MESSAGING


Send a text message

1. From any Home screen, tap the **Messaging**  icon.
2. Tap **New Message**.
3. At **To**, enter the name or phone number of the desired contact and select from the list of potential matches. If the contact is not saved in your phone book, enter the complete phone number.
4. Enter your message.
5. Tap **Send**.

Read text messages

When you receive a new message, tap **View** or tap the **Messaging**  icon to view your inbox.

Delete text messages

1. From any Home screen, tap the **Messaging**  icon.
2. Touch and hold the message you want to delete.
3. Tap **Delete thread**.
4. Tap **OK**.


WI-FI

Your phone can connect to the Internet using Wi-Fi.

Turn on Wi-Fi

1. Touch and drag the **Status** bar down to open the Notification screen.
2. Tap the **Wi-Fi**  icon.

Connect to Wi-Fi networks

1. From any Home screen, tap the **Menu**  key.
2. Tap **Settings**.
3. Tap **Wireless & networks**.
4. Tap to select the **Wi-Fi** check box and turn on Wi-Fi, if necessary.
5. Tap **Wi-Fi settings** to view a list of available networks.
6. Tap the network you want to use.
7. If necessary, enter the network password and tap **Connect**.

WI-FI CALLING


IMPORTANT:

Wi-Fi Calling requires that you use the SIM card that is shipped with your phone.

Also, you must register your address for 9-1-1. Wi-Fi Calling will not work until you have registered for 9-1-1 by logging into your account at www.T-Mobile.com. Go to your profile and click **Customer Info** and continue on to enter your address.

About Wi-Fi Calling

Wi-Fi Calling can improve your coverage and allows you to make phone calls and send messages over a Wi-Fi network (when a Wi-Fi network is available). Unless your rate plan provides otherwise, Wi-Fi Calling minutes count the same as T-Mobile cellular calling minutes on your phone bill.

- To use Wi-Fi Calling, you must first turn on Wi-Fi, connect to a Wi-Fi network, and then turn on Wi-Fi Calling.
- When the Wi-Fi Calling feature is on, your phone displays the **Wi-Fi Calling**  icon on the **Status** bar.


- To stay on a Wi-Fi call, you must remain within range of the Wi-Fi network. Your call will drop as you leave the Wi-Fi range. When your Wi-Fi signal weakens, your phone will beep and display a warning message alerting you that your call will drop if the signal gets weaker.


Wi-Fi Calling offers three connection options:

- **Wi-Fi Preferred:** All calls are made over an available Wi-Fi network. If there are no available Wi-Fi networks calls are made over the cellular network.
- **Cellular Preferred:** All calls are made over the cellular network unless the cellular network is not available, then calls are made over an available Wi-Fi network.
- **Wi-Fi Only:** All calls are made over an available Wi-Fi network. If there are no available Wi-Fi networks, your calls will not connect.

Turn on Wi-Fi Calling

Note: Wi-Fi must be turned on before Wi-Fi Calling can be turned on.


1. From any Home screen, tap the **Menu**  key.
2. Tap **Settings**.
3. Tap **Wireless & networks**.
4. Tap to select or clear the **Wi-Fi Calling** check box to turn it on or off.

When you see the **Wi-Fi Calling**  icon on your **Status** bar, you are ready to make phone calls and send messages over the Wi-Fi network.

If you choose to turn off Wi-Fi Calling, you can still stay connected to Wi-Fi for data usage.

Set connection preferences

Note: Wi-Fi Calling must be turned on to change connection preferences.

1. From any Home screen, tap the **Menu**  key.
2. Tap **Settings**.
3. Tap **Wireless & networks**.
4. Tap to select the **Wi-Fi Calling** icon to turn it on, if necessary.
5. Tap **Wi-Fi Calling Settings**.
6. Tap **Connection Preferences**.
7. Tap **Wi-Fi Preferred**, **Wi-Fi Only**, or **Cellular Preferred**.
8. Tap **OK**.


BLUETOOTH®

Your phone comes with Bluetooth connectivity, a wireless technology that enables a data connection between your phone and a Bluetooth headset or other Bluetooth device (sold separately).

Prepare Bluetooth headset

Make sure that your headset is fully charged and in pairing mode. Refer to the headset's user manual for more information.

Turn on Bluetooth and pair with headset


1. From any Home screen, tap the **Menu**  key.
2. Tap **Settings**.
3. Tap **Wireless & networks**.
4. Tap **Bluetooth settings**.
5. Tap to select the **Bluetooth** check box to turn it on, if necessary.
6. Tap **Scan for devices** to view a list of available Bluetooth devices.
7. From the list, tap the headset you want to pair with your phone.
8. If necessary, enter the PIN or passcode.
9. Tap **OK**.

BATTERY & MEMORY MANAGEMENT

Optimize battery life

There are some things that you can do to help optimize your phone's battery life.


1. Touch and drag the **Status** bar down to open the Notification screen.
2. Tap the **Wi-Fi**, **Bluetooth**, and **GPS** icons to turn off these features and conserve battery life.



Optimize memory



Use Application Manager

Use the Application Manager to free up memory space.



1. From any Home screen, tap the **Applications**  icon.
2. Tap **Application Manager**.
3. Tap the following:
 - At the **Running applications** tab, tap **Stop all** to stop running applications.
 - Tap the **Installed applications** tab and tap **Uninstall** to remove unused applications that you have downloaded.

Clear browser cache



Get more storage space by clearing out your browser caches.

1. From any Home screen, tap the **Globe**  icon.
2. Tap the **Menu**  key.
3. Tap **More**.
4. Tap **Settings**.
5. Tap **Clear cache**, **Clear history**, and **Clear all cookie data**.
6. Tap **OK**.

Delete old text messages

1. From any Home screen, tap the **Messaging**  icon.
2. Tap the **Menu**  key.
3. Tap **Settings**.
4. Tap to select the **Delete old messages** check box to automatically delete text messages when the limit is reached.

Reduce text message limit

1. From any Home screen, tap the **Messaging**  icon.
2. Tap the **Menu**  key.
3. Tap **Settings**.
4. Tap Text message limit.
5. Tap the **+** or **-** icons to set the desired limit.
6. Tap **Set**.

CARING FOR YOUR PHONE

Make it last

Your phone is a complex electronic device; think of it as a mini-computer. Here are some tips to help you extend the life of your new phone.

Do not get your phone wet. Water will damage your phone and accessories. Even a small amount of moisture can cause damage.

Protect your phone's touch screen. Your phone's touch screen is delicate. Guard against scratches by using a screen protector or by keeping it in a protective case.

Use the original manufacturer's batteries and accessories. Non-approved batteries and accessories can harm you and damage your phone.

Do not use damaged accessories. If your charger or any other accessory is damaged, replace it or take it to a qualified service dealer. Do not attempt to charge your phone if the charger has received a sharp blow, been dropped, or is otherwise damaged; doing so may damage your phone.

ACCESSORIES

Whether you want a charger, a fashionable carrying case, or you just want to browse for fun extras, T-Mobile is the place to shop for all your phone accessories. Here are a few examples...



**Screen
Protector**



Holster

To purchase accessories for your phone, visit T-Mobile.com, call 1.800.204.2449, or visit your nearest T-Mobile store.

Accessory selection subject to change and may vary by location.

SAFETY TIPS

Consider device compatibility

If you have a pacemaker or hearing aid, check with your doctor to make sure it is safe for you to use a cell phone. In some cases, cellular radio frequencies can disrupt the performance of other electronic equipment. If you have questions about the interaction between your phone and any other piece of electronic equipment, ask the equipment manufacturer.

Drive safely

When you are driving, T-Mobile encourages you to use your phone in a safe and sensible manner. Here are a few tips:

- Assess road conditions before answering your phone. Your safety is more important than any call.
- Prepare your hands-free headset, if you have one, or turn on your speakerphone, before you start moving.
- Keep your phone close. If it rings and you discover it's in the back seat, do NOT crawl over the seat to answer it while driving.
- Pre-program frequently used numbers into your phone for easy, one-touch dialing.
- Remember that laws prohibiting or restricting the use of a cell phone while driving may apply in your area.

EMERGENCY DIALING

Although all phones are equipped with 9-1-1 emergency calling, this phone may or may not permit its location to be approximated during a 9-1-1 call.*

* Availability of this feature depends on upgrades to the (a) wireless network and (b) 9-1-1 calling system that are required to be installed by the local 9-1-1 response agency or public safety answering point (PSAP); these upgrades may not be available everywhere within our wireless coverage area or your roaming area. This approximation of the phone's location and the transmittal of location information are subject to emergency situations, transmission limits, network problems/limitations, interconnecting carrier problems, your phone, buildings/tunnels, signal strength and atmospheric/topographical conditions, and may be curtailed, interrupted, dropped or refused. The phone's approximate location is transmitted to the local 9-1-1 response agency or PSAP while the call is in progress; this approximation is intended solely to aid the PSAP in dispatching emergency assistance or to limit the search area for emergency services personnel. You should not rely solely on a phone for essential communications (such as a medical or other emergency). Please see T-Mobile's Terms and Conditions and Privacy Policy for additional service restrictions and details.

ADDITIONAL INFORMATION

Use of some features or services may incur separate, additional charges and/or require a qualifying data plan.

Wi-Fi: Device will not transition between Wi-Fi and the cellular network. Devices using wireless connections may be vulnerable to unauthorized attempts to access data and software stored on the device.

Messaging/Data: You will be charged for all data sent by or to you through the network, regardless of whether or not data is received. Character length/file size of messages/attachments may be limited. T-Mobile is not liable for content of messages/attachments or for any failures, delays or errors in any T-Mobile generated alerts or notifications. **Your data session, plan, or service may be slowed, suspended, terminated, or restricted** if you use your service in a way that interferes with or impacts our network or ability to provide quality service to other users, if you roam for a significant portion of your usage, or if you use a disproportionate amount of bandwidth during a billing cycle. You may not use your plan or device for prohibited uses.

Downloads/Applications: T-Mobile is not responsible for any third party content or Web site you may be able to access using your phone. Additional charges may apply; not all downloads available on all phones. You obtain no rights in downloads; duration of use may be limited and downloads may be stored solely for use with your phone. T-Mobile is not responsible for any download lost due to your error. T-Mobile is not responsible for Apps, including download, installation, use, transmission failure, interruption or delay, third party advertisements you may encounter while using an App, alterations any App may make to the functionality of your device, **including any changes that may affect your T-Mobile plan, service,**

or billing, or any content or website you may be able to access through an App.

Hearing Aid Compatibility: This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

See brochures and the **Terms and Conditions (including arbitration provision)** at T-Mobile.com, for rate plan information, charges for features and services, and restrictions and details, **including important limitations on availability and reliability of 9-1-1 emergency service when using Wi-Fi calling.**

The Bluetooth® word mark and logo are owned by the Bluetooth SIG, Inc. and are used by T-Mobile under license. T-Mobile and the magenta color are registered trademarks of Deutsche Telekom AG. Gmail is a trademark of Google Inc. ©2011 T-Mobile USA, Inc.

