



alcatel 1T 10

Wi-Fi Tablet

For more information on how to use the tablet, please go to www.alcatelmobile.com and download the complete user manual. Moreover, on the website, you can also find answers to frequently asked questions, upgrade the software via Mobile Upgrade, and so much more.

Table of Contents

Safety and use	4
Radio Waves.....	7
General information	11
I Your device	13
1.1 Keys and connectors.....	13
1.2 Getting started	16
1.3 Home screen.....	17
2 Text input	25
2.1 Using the Onscreen Keyboard.....	25
2.2 Text editing.....	25
3 Contacts & Gmail.....	26
3.1 Contacts.....	26
3.2 Gmail.....	28
4 Calendar & Clock & Calculator.....	33
4.1 Calendar	33
4.2 Clock	34
4.3 Calculator.....	36
5 Getting connected	38
5.1 Connecting to the Internet.....	38
5.2 Chrome.....	39
5.3 Connecting to Bluetooth devices	43
5.4 Connecting to a computer.....	44
5.5 Sharing your device's Wi-Fi connection.....	44
5.6 Connecting to virtual private networks	45
6 Multimedia applications.....	46
6.1 Camera/Camcorder.....	46
6.2 Photos	49
6.3 Parental Center	50

7 Others.....	53
7.1 File Manager	53
7.2 Other applications	53
8 Google applications	54
8.1 Gmail.....	54
8.2 Maps Go	54
8.3 YouTube.....	54
8.4 Play Store.....	55
8.5 Play Music	55
9 Settings.....	56
9.1 Network & Internet.....	56
9.2 Connected devices	56
9.3 Apps & notifications	57
9.4 Battery.....	57
9.5 Display.....	57
9.6 Sound.....	58
9.7 Storage	58
9.8 Security & Location.....	59
9.9 User & accounts.....	61
9.10 Accessibility.....	61
9.11 Google	62
9.12 System.....	62
10 Upgrade	66
10.1 Mobile Upgrade	66
10.2 FOTA Upgrade.....	66
11 Accessories	67
12 Warranty	68
13 Troubleshooting.....	70
14 Specifications	73



www.sar-tick.com

alcatel



PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.

This product meets applicable national SAR limits of 1.6 W/kg. The specific maximum SAR values can be found on **Radio waves** section.

When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 0 mm from the body to ensure compliance with RF exposure requirements.

Safety and use

We recommend that you read this chapter carefully before using your device. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein.

TRAFFIC SAFETY:

Given that studies show that using a device while driving a vehicle constitutes a real risk, drivers are requested to refrain from using their device when the vehicle is not parked. Check the laws and regulations on the use of wireless devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas.

CONDITIONS OF USE:

- You are advised to switch off the device from time to time to optimize its performance;
- Remember to abide by local authority rules of mobile device use on aircrafts;
- If your device is a unibody device, where the back cover and battery are not removable, disassembling the device will void your warranty. Disassembling the device can cause bodily injury if the battery is punctured;
- Always handle your device with care and keep it in a clean and dust-free place;
- Do not allow your device to be exposed to adverse weather or environmental conditions, such as moisture, humidity, rain, infiltration of liquids, dust, sea air, etc. The manufacturer's recommended operating temperature range is -10°C (14°F) to +55°C (131°F). At over 55°C (131°F), the legibility of the device's display may be impaired, though this is temporary and not serious;
- Do not open, dismantle, or attempt to repair your device yourself;
- Do not drop, throw, or bend your device;
- Use only batteries, battery chargers, and accessories which are recommended by TCL Communication Ltd. and its affiliates and are compatible with your device model. TCL Communication Ltd. and its affiliates disclaim any liability for damage caused by the use of other chargers or batteries;
- Your device should not be disposed of in a municipal waste. Please check local regulations for disposal of electronic products;
- Remember to make backup copies or keep a written record of all important information stored on your device;

- Some people may suffer epileptic seizures or blackouts when exposed to flashing lights, or when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your device or enabling a flashing-lights feature on your device;
- Parents should monitor their children's use of video games or other features that incorporate flashing lights on the devices. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, orientation, or movements.

PRIVACY:

Please note that you must respect the laws and regulations in force in your jurisdiction or other jurisdiction(s) where you will use your device regarding taking photographs and recording sounds with your device. Pursuant to such laws and regulations, it may be strictly forbidden to take photographs and/or to record the voices of other people or any of their personal attributes, and reproduce or distribute them, as this may be considered to be an invasion of privacy. It is the user's sole responsibility to ensure that prior authorization has been obtained, if necessary, in order to record private or confidential conversations or take a photograph of another person; the manufacturer, the seller or vendor of your device (including the carrier) disclaim any liability which may result from improper use of the device.

BATTERY:

For a non-unibody device:

Observe the following precautions:

- Do not attempt to open the battery (due to the risk of toxic fumes and burns);
- Do not puncture, disassemble, or cause a short circuit in a battery;
- Do not burn or dispose of a used battery in household rubbish or store it at temperatures above 60°C (140°F).

Batteries must be disposed of in accordance with locally applicable environmental regulations. Only use the battery for the purpose for which it was designed. Never use damaged batteries or those not recommended by TCL Communication Ltd. and/or its affiliates.

For a non-unibody device with a non-removable battery:

Observe the following precautions:

- Do not attempt to eject, replace or open the battery;
- Do not puncture, disassemble, or cause a short circuit in the battery;

- Do not burn or dispose of your device in household rubbish or store it at temperature above 60°C (140°F).

Device and battery must be disposed of in accordance with locally applicable environmental regulations.

For a unibody device:

Observe the following precautions:

- Do not attempt to open the back cover;
- Do not attempt to eject, replace, or open battery;
- Do not puncture the back cover of your device;
- Do not burn or dispose of your device in household rubbish or store it at temperature above 60°C (140°F);

Device and battery as a unibody device must be disposed of in accordance with locally applicable environmental regulations.



This symbol on your device, the battery, and the accessories means that these products must be taken to collection points at the end of their life:

- Municipal waste disposal centers with specific bins for these items of equipment;
- Collection bins at points of sale.

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

In European Union countries:

These collection points are accessible free of charge.

All products with this sign must be brought to these collection points.

In non-European Union jurisdictions:

Items of equipment with this symbol are not to be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled.

In the United States you may learn more about CTIA's Recycling Program at <http://www.gowirelessgogreen.org/>

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

CHARGERS:

Home A.C./Travel chargers will operate within the temperature range of: 0°C (32°F) to 40°C (104°F).

The chargers designed for your device meet the standard for safety of information technology equipment and office equipment use. Due to different applicable electrical specifications, a charger you purchased in one jurisdiction may not work in another jurisdiction. They should be used for this purpose only. Characteristics of power supply (depending on the country):

Travel charger: Input: 100-240 V, 50/60 Hz, 0.2A
Output: 5V, 1A

Battery:Lithium 4000 mAh

Radio Waves.....

THIS Device MEETS THE GOVERNMENT’S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Your device is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio-frequency (RF) energy. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. These guidelines include a substantial safety margin designed to ensure the safety of all persons, regardless of age and health.

The exposure standard for devices employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by public authorities such as the Federal Communications Commission of the US Government (FCC) is 1.6 W/kg averaged over 1 gram of body tissue. Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands.

This device is complied with SAR for general population /uncontrolled exposure limits in ANSI/IEEE C95.1-1992 and had been tested in accordance with the measurement methods and procedures specified in IEEE1528.

The FCC has granted an Equipment Authorization for this model device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model device is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on FCC ID: 2ACCJBT11

Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output of the device. Before a device model is available for sale to the public, compliance with national regulations and standards must be shown.

The highest SAR value for this model device when tested is 1.13 W/Kg for use close to the body.

While there may be differences between the SAR levels of various devices and at various positions, they all meet the government requirement for RF exposure.

For body-worn operation, the device meets FCC RF exposure guidelines provided that it is used with a non-metallic accessory with the handset at least 0 mm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

Additional information on SAR can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site: <http://www.ctia.org/>

Note: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna;
- Increase the separation between the equipment and receiver;
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected;
- Consult the dealer or an experienced radio/ TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

For the receiver devices associated with the operation of a licensed radio service (e.g. FM broadcast), they bear the following statement:

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- This device may not cause harmful interference;
- This device must accept any interference received, including interference that may cause undesired operation.

Your device is equipped with a built-in antenna. For optimal operation, you should avoid touching it or degrading it.

As mobile devices offer a range of functions, they can be used in positions other than against your ear. In such circumstances the device will be compliant with the guidelines when used with a headset or USB data cable.

If you are using another accessory ensure that whatever product is used is free of any metal and that it positions the device at least 15 mm away from the body.

Please note by using the device some of your personal data may be shared with the main device. It is under your own responsibility to protect your own personal data, not to share with it with any unauthorized devices or third party devices connected to yours. For products with Wi-Fi features, only connect to trusted Wi-Fi networks. Also when using your product as a hotspot (where available), use network security. These precautions will help prevent unauthorized access to your device. Your product can store personal information in various locations, memory card, and built-in memory. Be sure to remove or clear all personal information before you recycle, return, or give away your product. Choose your apps and updates carefully, and install from trusted sources only. Some apps can impact your product's performance and/or have access to private information including account details, call data, location details and network resources.

Note that any data shared with TCL Communication Ltd. is stored in accordance with applicable data protection legislation. For these purposes TCL Communication Ltd. implements and maintains appropriate technical and organizational measures to protect all personal data, for example against unauthorized or unlawful processing and accidental loss or destruction of or damage to such personal data whereby the measures shall provide a level of security that is appropriate having regard to

- The technical possibilities available;
- The costs for implementing the measures;
- The risks involved with the processing of the personal data, and;
- The sensitivity of the personal data processed.

You can access, review and edit your personal information at any time by logging into your user account, visiting your user profile or by contacting us directly. Should you require us to edit or delete your personal data, we may ask you to provide us with evidence of your identity before we can act on your request.

Licenses.....



microSD logo is a trademark.



The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by TCL Communication Ltd. and its affiliates is under licence. Other trademarks and trade names are those of their respective owners.

Alcatel 8082 Bluetooth Declaration ID D030189



The Wi-Fi Logo is a certification mark of the Wi-Fi Alliance.

Google, the Google logo, Android, the Android logo, Google Search TM, Google Maps TM, Gmail TM, YouTube, Google Play Store, Google Latitude TM, and Hangouts TM are trademarks of Google Inc.

The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License (the text will show when you touch **Google legal in Settings > System > About tablet > Legal information**) ⁽¹⁾.

You have purchased a product which uses the open source (<http://opensource.org/>) programs mtd, msdosfs, netfilter/iptables and initrd in object code and other open source programs licensed under the GNU General Public Licence and Apache Licence.

We will provide you with a complete copy of the corresponding source codes upon request within a period of three years from the distribution of the product by TCL Communication Ltd.

You may download the source codes from <http://sourceforge.net/projects/alcatel/files/>. The provision of the source code is free of charge from the internet.

⁽¹⁾ May not be available in all countries.

General information

- **Website (USA):** <https://us.alcatelmobile.com>
- **Website (Canada):** <https://ca.alcatelmobile.com>
- **Facebook (USA):** <https://www.facebook.com/alcatelmobileus>
- **Facebook (Canada):** <https://www.facebook.com/alcatelmobileca>
- **Twitter (USA):** <https://twitter.com/alcatelmobileus>
- **Twitter (Canada):** <https://twitter.com/alcatelotcanada>
- **Instagram (USA):** <https://www.instagram.com/alcatelmobileus>
- **Instagram (Canada):** <https://www.instagram.com/alcatelmobileca>
- **Hotline:** In the United States, call 855-368-0829 for technical support.
- **Manufacturer:** TCL Communication Ltd.
- **Address:** 5/F, Building 22E, 22 Science Park East Avenue, Hong Kong Science Park, Shatin, NT, Hong Kong
- **Electronic labeling path:** Touch **Settings** > **System** > **Regulatory & Safety**, you can find more information about labeling ⁽²⁾, such as FCC ID.

On our website, you will find our FAQ (Frequently Asked Questions) section. You can also contact us by email to ask any questions you may have.

Disclaimer

There may be certain differences between the user manual description and the device's operation, depending on the software release of your device or specific carrier services.

TCL Communication Ltd. shall not be held legally responsible for such differences, if any, nor for their potential consequences, which responsibility shall be borne by the carrier exclusively.

Warranty

For information on warranty of your device, visit USA website at <https://us.alcatelmobile.com/warranty/> and <https://ca.alcatelmobile.com/warranty/>

Electronic Recycling

For more information on Electronic Recycling, please Visit **Alcatel** Electronic Recycling Program website at (USA) <https://us.alcatelmobile.com/accessibility-compliance/electronic-recycling-program/> and (Canada) <https://ca.alcatelmobile.com/accessibility-compliance/electronic-recycling-program/>

Battery Recycling


Alcatel partners with Call2Recycle® to offer a safe and convenient battery recycling program.

For more information on our Battery Recycling Program, please visit the USA and Canada at <https://us.alcatelmobile.com/accessibility-compliance/battery-recycling/> and <https://ca.alcatelmobile.com/accessibility-compliance/battery-recycling/>

⁽²⁾ It depends on countries.

Your device

1.1 Keys and connectors





Recents key

- Touch to switch between individual app activities and documents.



Home key

- From any application or screen, touch to return to the Home screen.



Back key

- Touch to go back to the previous screen, or close a dialog box, options menu, the notification panel, etc.



Power key

- Press: Lock the screen/Light up the screen.
- Press and hold: Show the popup menu to select from Power off/Restart.
- Press and hold the **Power** key and **Volume down** key to make a screenshot.
- Press and hold the **Power** key for at least 10 seconds to force reboot.



Volume Keys


- In Music/Video/Streaming mode, adjusts the media volume.
- In general mode, adjusts the ringtone volume.
- In camera preview mode, press **Volume up** or **down** key to take a photo or press and hold to make burst shoot.

1.2 Getting started


1.2.1 Set up

Inserting or removing the SD card

Your device only supports SD cards. Do not attempt to insert SIM types like micro SIM and standard cards; otherwise this may cause damage to your device.




Charging the battery

You are advised to fully charge the battery (). Charging status is indicated by a percentage displayed on screen while the device is powered off. The percentage increases as the device is charged.



To reduce power consumption and energy waste when the battery is fully charged, disconnect your charger from the plug; switch off Wi-Fi, GPS, Bluetooth or background-running applications when not in use; reduce the backlight time, etc.



1.2.2 Power on your device


Hold down the **Power** key until the device powers on, unlock your device (Swipe, PIN, Password, Pattern) if necessary and confirm. The Home screen is displayed.


If you do not know your PIN code or forget it, contact your network carrier . Be sure to keep your PIN code well.

1.2.3 Power off your device

Hold down the **Power** key until options appear, select **Power off**.


1.3 Home screen


You can bring all the items (applications, shortcuts, folders and widgets) you love or use most frequently to your Home screen for quick access. Touch the **Home** key  to switch to the Home screen.




The Home screen is provided in an extended format to allow more space for adding applications, shortcuts etc. Slide the Home screen horizontally left and right to get a complete view.

1.3.1 Using the touchscreen

Touch 
To access an application, touch it with your finger.

Long press 
To enter the available options for an item, long press the item. For example, select a contact in Contacts, long press this contact, an options list will appear.

Drag 
Place your finger on the screen to drag an object to another location.

Slide/Swipe



Slide the screen to scroll up and down the applications, images, and web pages. You can slide the screen horizontally too.

The device also supports one finger zooming in the Camera and Gallery functions. Double touch the screen to zoom in/out.

Flick




Similar to swiping, but flicking makes it move quicker.

Pinch/Spread



Place two fingers on the screen surface and draw them apart or together to scale an element on the screen.

Rotate



Automatically change the screen orientation from portrait to landscape by turning the device sideways to have a better screen view.

1.3.2 Status bar

From the status bar, you can view both device status (on the right side) and notification information (on the left side).

Drag down the status bar to view notifications and drag again to enter the quick settings panel.

Touch and drag up to close it. When there are notifications, you can touch them to access notifications.

Notification panel

When there are notifications, touch and drag down the Status bar to open the Notification panel to read more detailed information.



Touch to access device settings, where you can make changes to more functions.

Touch to clear all event-based notifications (other ongoing notifications will remain).

Quick settings panel

Touch and drag down the Notification panel or touch the down-sided arrow to open the Quick settings panel. You can enable or disable functions or change modes by touching the icons. Touch the EDIT button to customize your Quick settings panel.



Touch to access **Settings**, where you can set more items.


Touch to enter user screen to edit and save owner's name, device number, and other information.

1.3.3 Search bar


The device provides a Search function which can be used to locate information within applications, the device or the web.



① Search by text

- Touch the Search bar from the Home screen.
- Enter the text/phrase you want to search for.
- Touch the  icon on the keyboard if you want to search on the web.


② Search by voice

- Touch  from the Search bar to display a dialog screen.
- Speak the word/phrase you want to search for. A list of search results will display for you to select from.

1.3.4 Lock/Unlock your screen

To protect your device and privacy, you can lock the device screen by choosing slide or creating a pattern, PIN or password, etc.

To create a screen unlock pattern

- From the Home screen, touch  to open the applications list, then touch **Settings>Security & Location >Screen lock>Pattern**.
- Draw your own pattern.

To lock device screen

Press the **Power** key once to lock the screen.

To unlock the device screen

Press the **Power** key once to light up the screen, slide to draw the unlock pattern you have created or enter your PIN or password, etc. to unlock the screen.

If you have chosen **Swipe** as the screen lock, you can press the **Power** key to light up the screen, then swipe up to unlock the screen, double touch the camera icon to enter Camera or double touch the Voice search icon to enter Voice search.



Swipe up to unlock the screen

Touch twice to take a selfie

Touch twice to open Calculator

1.3.5 Personalize your Home screen

Add

You can long press a folder, an application or a widget to activate the Move mode, and drag the item to your preferred Home screen.

Reposition

Long press the item to be repositioned to activate the Move mode, drag the item to the desired position and then release. You can move items both on the Home screen and the Favorite tray. Hold the icon on the left or right edge of the screen to drag the item to another Home screen.

Remove

Long press the item then touch the  icon, and enter into **App info**, then disable/FORCE STOP this function.

Create folders

To improve the organization of items (shortcuts or applications) on the Home screen and the Favorite tray, you can add them to a folder by stacking one item on top of another. To rename a folder, open it and touch the folder's title bar to input the new name.

Wallpaper customisation

Long press the empty area in the Home screen, then touch **WALLPAPERS** to customize wallpaper.

1.3.6 Widgets and recently-used applications


Consult widgets

Long press the empty area in the Home screen, then touch **WIDGETS** to display all widgets.

Touch the selected widget and slide it to move to your preferred screen.

Consult recently-used applications

To consult recently-used applications, touch the **Overview** key. Touch a thumbnail in the window to open the application.



Touch one thumbnail and slide it right/left or touch  to close the application.

Touch clear icon at the middle bottom of the screen to close all the running applications.

1.3.7 Volume adjustment

Using the volume key

Press the **Volume** key to adjust the volume. To activate the vibrate mode, press the **Volume down** key until the device vibrates.

Using the settings menu

From the Home screen, touch **Settings>Sound** to set the volume of media, ringtone, alarm, etc. to your preference.


2 Text input

2.1 Using the Onscreen Keyboard

Onscreen Keyboard settings

Touch **Settings>System>Language & input**, touch the keyboard you want to set up and a series of settings will become available.

2.1.1 Virtual keyboard



2.2 Text editing

You can edit the texts you entered.

- Long press or double touch within the texts you want to edit.
- Drag the tabs to change the checked texts.
- The following options will show: **CUT**, **COPY** and **SHARE**.



You can also insert new texts if preferred

- Touch where you want to type, or long press the blank, the cursor will blink and the tab will show. Drag the tab to move the cursor.
- If you have cut or copied any text, touch the tab to show the **PASTE** icon which allows you to complete pasting immediately.

3 Contacts & Gmail


3.1 Contacts

Contacts enables quick and easy access to the contact you want to reach.

You can view and create contacts on your device and synchronize these with your Gmail contacts or other applications on the web or on your device.

3.1.1 Consult your Contacts

To see your contacts, touch **Contacts** icon  in the homescreen.




Delete a contact

To delete a contact, long press the contact you want to delete, then touch .




The contact you have deleted will also be removed from other applications on the device or web the next time you synchronize your device.


Touch  to display the contacts list option menu, following actions are enabled:

- **Select** Touch to select one contact that you want
- **Select all** Touch to select all contacts
- **Customize view** Touch to set the contact display, like All contacts or Cutomise which you can set for different groups.

3.1.2 Adding a contact

Touch  in the contact list to create a new contact.

You are required to enter the contact's name and other contact information. By scrolling up and down the screen, you can move from one field to another.




3.1.3 Editing your contacts


To edit contact information, touch  in the contact details screen to edit.

When finished, touch SAVE to save.

3.1.4 Importing, exporting and sharing contacts


This device enables you to import or export contacts between your device, SIM card and device storage.

From the Contacts screen, touch  to open the options menu, touch **Settings> Import/Export**.

To share a contact, long press the contact you want to share, then touch . You can share a single contact or contacts with others by sending the contact's vCard to them via Bluetooth, Gmail, etc.

3.1.5 Accounts

Contacts, data or other information can be synchronized from multiple accounts, depending on the applications installed on your device.

To add an account, touch  from the home screen, then **Settings\Users & accounts\ Add account**.

You are required to select the kind of account you are adding, like Google, Corporate, etc.

As with other account setup, you need to enter detailed information, like username, password, etc.

You can remove an account to delete it and all associated information from the device. Touch the account you want to delete, touch **REMOVE ACCOUNTS**, then confirm.

Turn on/off the auto-sync

In the **Accounts** screen, mark the **Automatically-sync data** checkbox. When activated, all changes to information on the device or online will be automatically synchronized with each other.




3.2 Gmail





As Google's web-based email service, Gmail is configured when you first set up your device. Gmail on your device can be automatically synchronized with your Gmail account on the web.


3.2.1 To access Gmail

From the Home screen, touch **Gmail**.


3.2.2 To create and send emails

- Touch the icon  from the Inbox screen.
- Enter recipient(s)'s email address in **To** field, and if necessary, touch  the downward arrow to add a copy (Cc) or a blind copy (Bcc) to the message.
- Enter the subject and the content of the message.
- Touch  to add an attachment.

- Finally, touch the  icon to send.
- If you do not want to send the mail out right away, you can touch  and **Save draft** or touch the **Back** key to save a copy. To view the draft, touch the icon , then select **Drafts**.
- If you do not want to send or save the mail, you can touch  and then touch **Discard**.



To add a signature to emails, touch  and **Settings** from inbox screen, choose an account, then touch **Signature**.

3.2.3 To receive and read your emails






When a new email arrives, you will be notified by a ringtone or vibration, and an  icon will appear on the Status bar.

Touch and drag down the Status bar to display the Notification panel and touch the new email to view it. You can also access the Gmail Inbox label and touch the new mail to read it.

You can search for an email by sender, subject, label, etc.

- Touch the  icon from Inbox screen.
- Enter the keyword you want to search for in the search box and touch .


3.2.4 To reply or forward emails

- **Reply** When viewing an email, touch  to reply to the sender of this mail.
- **Reply all** Touch  and select “**Reply all**” to send the message to all people in a mail loop.
- **Forward** Touch  and select “**Forward**” to forward the received mail to other people.
- **Add star** Touch  and select “**Add star**” to add a star for the mail.
- **Print** Touch  and select “**Print**” to print the mail.




3.2.5 Managing Gmails by Labels

To conveniently manage conversations and messages, you can organize them using a Label.

To label a conversation when reading a conversation's messages, touch  and then choose **Move to**.

To view conversations by labels when viewing your inbox or another conversation list, touch the icon , then touch a label to view a list of conversations with that label.


Long press an email to activate batch mode and produce the following options:

-  Touch to archive the email message. To display the archived messages, you can touch in Inbox screen then touch **All mail**.
-  Touch to delete the email message.
-  Touch to mark an email message as read or unread.

Touch  to access the following options.

- **Move to** Touch to move the mail to other labels.
- **Change labels** Touch to change the label of the email message or conversation.
- **Add star** Touch to remark in star for the mail
- **Mark as important** To Mark the email as important or not important.
- **Mute** Touch to hide the mail and the mail could be found by touching **All mail**.
- **Report spam** To report the email message/conversation as spam.

3.2.6 Gmail settings

To access Gmail settings, touch the icon  and select **Settings**.

General settings

- **Gmail default action** Touch to set the default action: archive or delete.
- **Manage notifications** Touch to set the notifications' action
- **Conversation view** Mark the checkbox to group emails in the same conversation for IMAP, POP3 and Exchange accounts.
- **Swipe actions** Mark the checkbox to enable a Swipe to archive messages within the conversation list.
- **Sender image** Mark the checkbox to show the sender's image beside their name in the conversation list.
- **Default reply action** Touch to choose your default reply action for Reply/Reply all
- **Auto-fit messages** Mark the checkbox to shrink messages to fit the screen and allow zooming.

- **Open web links in Gmail** Mark the checkbox to turn on for faster browsing.
- **Confirm before deleting** Mark the checkbox to receive a request to confirm your action before deleting emails.
- **Confirm before archiving** Mark the checkbox to receive a request to confirm your action before archiving emails.
- **Confirm before sending** Mark the checkbox to receive a request to confirm your action before sending emails.

Touch an account to view the following settings:

- **Inbox type** To set this inbox as the default or priority Inbox.
- **Inbox categories** Mark the checkbox to enable the folder to appear under the Inbox folder.

- **Notifications** Mark the checkbox to activate a notification when a new email arrives.

- **Manage notifications** Touch to set the notifications' action

- **Default reply action** Touch to set the default reply action: Reply or Reply to all.
- **Mobile signature** To add a signature text to the end of each mail you send.
- **Smart Reply** Mark the checkbox to show suggested replies when available

- **Out of Office AutoReply** Touch to set the AutoReply when out of office

- **Sync Gmail** Mark the checkbox to turn on/off Gmail sync.
- **Days of mail to sync** Touch to set the duration of days for mail sync.
- **Download attachments** Mark the checkbox to auto download attachments to recent messages via Wi-Fi.
- **Images** Touch to set whether images are always shown or if you will be prompted to show them.

4 Calendar & Clock & Calculator


4.1 Calendar

Use the Calendar to keep track of important meetings, appointments, etc.

To view the calendar and create events, touch **Calendar** from the Home screen.


4.1.1 Multimode view

You can display the Calendar by Schedule, Day, Week, or Month.




4.1.2 To create new events



You can add new events from any Calendar view.

- Touch  to access a new event edit screen.
- Fill in all required information for this new event. If it is a whole-day event, you can select **All-day**.


- Invite guests to the event. Enter the email addresses of the guests you want to invite with commas to separate. The guests will receive an invitation from Calendar and Email.
- When finished, touch **SAVE** from the top of the screen.

To quickly create an event from the Week view screens, touch an empty spot to select a target area which will then turn , and touch the icon to create the new event.

4.1.3 To delete or edit an event

To delete or edit an event, touch the event to enter its details screen, touch the  icon to edit the event, and touch  **Delete** to delete.

4.1.4 Event reminder

If a reminder is set for an event, the upcoming event icon  will appear on the Status bar as a notification when the reminder time arrives.

Touch and drag down the status bar to open the notification panel, touch an event name to view the Calendar notification list.

Touch the **Back** key to keep the reminders pending in the status bar and the notification panel.


4.2 Clock

Your device has a built-in clock.

To view the current time, touch  from the Home screen, then touch **Clock**.

4.2.1 World clock


To view the world clock, touch  on the Time screen.

Touch the  icon to add a time zone.

4.2.2 Alarm



From the Time screen, touch  to enter the **Alarm** screen.

Touch the switch  to enable the alarm.

Touch  to add a new alarm, the following options will appear:



- **Time** Touch to set the alarm time.
- **Repeat** Touch to select the days when you want the alarm to work.
- **Ringtone** Touch to select a ringtone for the alarm.
- **Label** Touch to set a name for the alarm.
- **Delete** Touch to delete the alarm

Touch a currently existing alarm to enter the alarm editing screen.

Touch  then touch  to delete the selected alarm.




4.2.3 Countdown

From the Time screen, touch  to enter the **Countdown** screen.


- Enter the time. The time should be typed in second, minute and hour number sequence.
- Touch  icon to activate Countdown.
- Touch **ADD TIMER** to set the countdown time in panel.
- Touch  icon to deactivate Countdown.
- Touch **DELETE** to delete current countdown label.

4.2.4 Timer

From the Time screen, touch  to enter the **Timer** screen.

- Touch  to activate the timer.
- Touch **LAP** to show a list of records according to the updated time.
- Touch  to halt the total and lap times. These will only restart after  is touched.
- Touch **RESET** to reset the record.

4.2.5 Adjust Clock settings

Touch the  icon and then **Settings**, the following options can now be adjusted:

- **Style** Touch to set the clock style to Analogue or Digital.
- **Automatic home clock** Mark the checkbox to enable the function when travelling in an area where the time is different, add a clock for home.
- **Home time zone** Touch to set Home time zone.
- **Silence after** Touch to set a temporary turn off time for an alarm.
- **Snooze length** Touch to set the duration of alarms.
- **Alarm volume** Touch to set alarm volume.
- **Gradually increase volume** Touch to choose the time to gradually increase volume
- **Volume buttons** Touch to set side **Volume up/down** key behaviors when alarm sounds: **Snooze**, **Dismiss** or **Do nothing**.
- **Start week on** Touch to choose which day as the one to start week on

4.3 Calculator


With the Calculator, you can solve many mathematical problems.

To use the calculator, touch  from the Home screen, then touch **Calculator**.

There are two panels available: Basic panel and Advanced panel.

To switch between panels, turn the device to the landscape mode from the basic panel or swipe left to open the Advanced panel⁽³⁾.

⁽³⁾ If Settings\Display\When device is rotated\Rotate the contents of the screen is enabled, this item will display.



Enter a number and the arithmetic operation to be performed, enter the second number, then touch “=” to display the result. Touch **DEL** to delete digits one by one, long press **DEL** to delete all at one time.

5 Getting connected


To connect to the internet with this device, you can use Wi-Fi.

5.1 Connecting to the Internet

5.1.1 Wi-Fi

Using Wi-Fi, you can connect to the Internet when your device is within range of a wireless network.

To turn Wi-Fi on and connect to a wireless network

- Touch **Settings> Network & Internet>Wi-Fi**.
- Touch the switch  to turn on/off Wi-Fi.
- Once Wi-Fi is on, the detailed information of detected Wi-Fi networks is displayed.
- Touch a Wi-Fi network to connect to it. If the network you selected is secured, you are required to enter a password or other credentials (you may contact the network carrier for details). When finished, touch **Connect**.

To activate notification when a new network is detected

When Wi-Fi is on and the network notification is activated, the Wi-Fi icon will appear on the status bar whenever the device detects an available wireless network within range. The following steps activate the notification function when Wi-Fi is on:

- Touch **Settings**.
- Touch **Wi-Fi**, scroll to the bottom, then touch **Wi-Fi preferences**.
- Switch the toggle **Open network notification** to activate/deactivate this function.

To add a Wi-Fi network

When Wi-Fi is on, you may add new Wi-Fi networks according to your preference.

- Touch **Settings**.
- Touch **Wi-Fi**, scroll to the bottom and touch **Add network**.
- Enter the name of the network and any required network information.
- Touch **SAVE**.

To forget a Wi-Fi network

The following steps prevent automatic connections to networks which you no longer wish to use.

- Turn on Wi-Fi, if it's not already on.
- In the Wi-Fi screen, touch the name of the saved network.
- Touch **FORGET** in the dialog that opens.


5.2 Chrome

Using Chrome, you can enjoy surfing the Web.


To surf the web, touch from **Chrome** the Home screen.

To go to a web page

On the Chrome screen, touch the URL bar at the top, enter the address of the web page, then confirm.




To set a homepage

- Touch the  icon from Chrome screen to display option menu, touch **Settings\Homepage**.
- Touch the switch on to set this website as your homepage.

Viewing web pages


When opening a website, you can navigate on web pages by sliding your finger on the screen in any direction to locate the information you want to view.

To find text on a web page




- Touch the  icon from Chrome screen to display option menu, and touch **Find in page**.
- Enter the text or phrase you want to find.
- Words with matching characters will be highlighted on the screen.
- Touch the up or down arrow to switch to the previous or next matching items.
- When finished, you can touch the **Back** key to close the search bar.

Further operations for the text on a web page





You can copy, share or search the text from a web page:

- Long press the text to highlight the text.
- Move two tabs to select the text.
- Touch the  icon to show further actions, including search on the web.
- When finished, touch the **Back** key to deactivate the mode.

To open new window/switch between windows

- Touch  to open a new window.
- Touch  icon and **New incognito tab** to open a window without any trace.
- To close a window, touch  on the window you want to close or slide it sideways.

Other options:

-  To add the current website page as a bookmark.
-  To see details about the current website.
-  Touch to download the current website.
-  To refresh the current page.
- **New tab** Touch to open a new web
- **New incognito tab** Touch to open the incognito web
- **Bookmarks** To see the bookmarks.
- **Recent tabs** To see the tabs you have recently closed.
- **History** To view your browsing history.
- **Downloads** To check the downloaded web
- **Share...** To share via Gmail, Meassageing, Bluetooth...
- **Find in page** To enter the information looking, then find in the website
- **Add to Home screen** Touch to add the web page opened to homescreen.
- **Desktop site** To set the web screen to desktop mode.
- **Settings** To access detailed Chrome settings.
- **Help & feedback** To get help tips and send feedback about Chrome.


5.2.1 Manage links, history, downloads

To manage a link, device number or address displayed on a web page

- **Link** Touch the link to open the web page.
Long press the link to open options for further operation, like open in new window, download link, share link, copy link address, copy link text, etc.
- **Device number** Touch to call the device number.
- **Address** Touch to open Google Maps and locate the address.


To download a web application/view your downloads

To download an item, touch the item or the link you want to download.


To cancel a download, touch the downloaded item from the Notification panel, select the item to be canceled, and touch  to confirm.

5.2.2 Manage bookmarks





To bookmark a web page

- Open the web page you want to bookmark.
- Touch the  icon in the web page .

To open a bookmark

- Touch the  icon and **Bookmarks**.
- Touch the bookmark you want to open.

To edit a bookmark


- Touch the  icon and **Bookmarks**.
- Long press the bookmark you want to edit.
- Touch , and enter your changes.
- Touch  to move the bookmark to a folder.
- Touch  to delete a bookmark.

5.3 Connecting to Bluetooth devices⁽⁴⁾

Bluetooth is a short-range wireless communication technology that you can use to exchange data, or connect to other Bluetooth devices for various uses.

To exchange data, touch **Settings>Connected devices >Bluetooth**, your device and other available ones will show on the screen.

To turn on Bluetooth

- Touch **Settings>Connected devices >Bluetooth**.
- Touch  to activate/deactivate this function.

To make your device more recognisable, you can change your device's name which is visible to others.


- Touch **Settings>Connected devices >Bluetooth**.
- Touch **Device name**, enter a name, then touch **RENAME** to confirm.

To pair/connect your device with a Bluetooth device

To exchange data with another device, you need to turn Bluetooth on and pair your device with the Bluetooth device with which you want to exchange data.

- Touch **Settings>Connected devices >Bluetooth**.
- Touch **Pair new device**.
- Touch a Bluetooth device you want to be paired with in the list.
- A dialog will pop up, touch **PAIR** to confirm.
- If the pairing is successful, your device connects to the device.

To disconnect/unpair from a Bluetooth device

- Touch the Settings icon  beside the device you want to unpair.
- Touch **FORGET** to confirm.

⁽⁴⁾ You are recommended to use Alcatel Bluetooth headsets, which have been tested and proved compatible with your device. You can go to www.alcatelmobile.com for more information about the alcatel Bluetooth headset.

5.4 Connecting to a computer

With the USB cable, you can transfer media files and other files between your internal storage and a computer.

To connect your device to the computer

Use the USB cable that came with your device to connect the device to a USB port on your computer. You will receive a notification that the USB is connected.

Open the Notification panel and choose for three different modes below:

- Charge this device
- Transfer files
- Transfer photos(PTP)
- Use device as MIDI

5.5 Sharing your device's Wi-Fi connection

You can share your device's Wi-Fi connection with a single computer via a USB cable (USB tethering) or with up to eight devices at once by turning your device into a portable Wi-Fi hotspot.

To share your device's data connection via USB

Use the USB cable that come with your device to connect the device to a USB port on your computer.

- Touch **Settings\Network & Internet\Tethering**.
- Touch the switch beside **USB tethering** to activate/deactivate this function.

To share your device's data connection via Bluetooth


Use the bluetooth that come with your device to connect the device to a bluetooth port on your computer.

- Touch **Settings\Network & Internet\Tethering**.
- Touch the switch beside **Bluetooth tethering** to activate/deactivate this function.
-

5.6 Connecting to virtual private networks

Virtual private networks (VPNs) allow you to connect to the resources inside a secured local network from outside that network. VPNs are commonly deployed by corporations, schools, and other institutions so that their users can access local network resources when not inside that network, or when connected to a wireless network.

To add a VPN

- Touch **Settings**>**Network & Internet**>**VPN** and then touch .
- In the screen that opens, follow the instructions from your network administrator to configure each component of the VPN settings.
- Touch **SAVE**.

The VPN is added to the list on the VPN settings screen.



Before adding a VPN, you should set a PIN code or password for your device.

To connect/disconnect VPN

To connect to a VPN:


- Touch **Settings**>**Network & Internet**>**VPN**.
- VPNs you have added are listed; touch the VPN you want to connect with.
- In the dialog that opens, enter any requested credentials and touch **CONNECT**.

To disconnect:


- Open the Notification panel and touch the notification for the VPN disconnection.

To edit/delete a VPN

To edit a VPN:

- Touch **Settings**>**Network & Internet**>**VPN**.
- VPNs you have added are listed; touch the  icon beside the VPN you want to edit.
- After editing, touch **SAVE**.

To delete:

- Touch the  icon beside the VPN you want to delete, then touch **FORGET**.


6 Multimedia applications

6.1 Camera/Camcorder


Your device is fitted with a Camera and a Camcorder for taking photos and shooting videos.

Before using the Camera or Camcorder, be sure to remove the protective lens cover to avoid it affecting your picture quality.



To take a photo or video, touch **Camera** from the Home screen.





To take a picture

The screen acts as the viewfinder. First, position the object or landscape in the viewfinder, touch the screen to focus if necessary and touch the  icon to take the picture which will be automatically saved.

To shoot a video




Switch to the video mode by touching VIDEO icon besides, position the object or landscape in the viewfinder and touch the  icon to start recording. Touch the  icon to stop recording. The video will be automatically saved.

Further operations when viewing a picture/video you have taken



- Touch the circle in the lower left part to view the photos or videos you have taken.
- Touch the  icon then Gmail, Bluetooth, etc to share the photo or video.
- Touch the  back icon to return to Camera.

6.1.1 Modes and settings

Back camera shooting mode

-  Take a picture in the HDR mode.
-  Set the countdown before taking a photo.
-  Set for night mode.

Settings

Touch  to choose different mode for Auto, Pano, Social, and enter for setting  to set under options:


- **Picture size** Touch to select picture size.
- **Video quality** Set the the quality of the video captured.
- **Grid** Set the grid mode when take picture
- **Volume function** **button** Use this function to enable the volume buttons to capture a photo, zoom in or out, or adjust the volume.
- **Storage** Set the storage location in your device or SD card.

- **Save location information** Switch the toggle to activate/deactivate the function of tagging photos and videos with your location.
- **Shutter sound** Switch the toggle to enable/disable shutter sound when taking a photo.
- **One hand mode** Switch the toggle to enable/disable the function to use one hand when take a photo.
- **Reset settings** Touch and confirm to reset the camera settings.



6.2 Photos


Photos act as a media player for you to view photos and play videos. In addition, a set of further operations to pictures and videos are available for your choice.

To view the photos you have taken, touch **Photo** icon  in the home screen.






Working with pictures

Touch a picture you want to work on, touch the  icon to delete a selected one. Touch  to share selected ones.

Touch the  icon>Use as to set them as contact photo or wallpaper, etc.

Batch operation

The **Photos** provide a multi-select function, so that you can work with pictures/videos in batches.

Open the **Photos** window, long press one picture, touch the  icon to delete photos, move the selected files to trash. Touch  to share selected files, touch  to **Delete from device**, **Back up now**, or **Archive**.

6.3 Parental Center

Parental Center provide you a kid-friendly and parent-friendly mode.

Parent can set usage time and select which apps are available to use for kids, authorise or not for kid accessing to the web.


Kid can also enjoy the pre-approved apps and pre-loaded popular games, and personalize their own interface and take picture to change avatar.

Touch **Parental Center** icon  in the home screen to view it.


6.3.1 Parental Password

When opening the app for the first time the parent is prompted to enter the password.

Parent can change his PSW from the Main Interface of Parental Center



As soon as password is set the parent will land on the page of Main Interface of Parental Center



6.3.2 Parental Center Main Interface

Enter kid name or pseudo and gender: two avatars are included, the background and the theme will be adjusted according to the gender


Get access to application management to control which apps the kid can use

Establish the time zone when the kid can use the tablet

Autorise or not accessing the web

The parent can also change his password

Once all settings are done, press « **switch to kid profile** » icon to convert the tablet to the kid profile



6.3.3 Application Management

Get access to application management menu to control which apps the kid can use

Click on the icon to authorise or not the app

Once done get back to the main interface of Parental Center



6.3.4 Kid interface

The kid interface background and Setting « icons theme» will adjust to the gender per default

All applications authorized by the parent via Application management screen will be accessible from this page

Exit the kids interface by press change user icon In the upper right corner



7 Others

7.1 File Manager

To manage the files in your device, touch  from the Home screen, then touch **Files Go**.

Files Go work with both external SD card and internal storage.

Files Go display all data stored on the device, including applications, media files downloaded from Google Play Store, YouTube or other locations; videos, pictures or audios you have captured; other data transferred via Bluetooth, USB cable, etc.

When you download an application from PC to device, you can locate the application using Files, then touch it to install it in your device.

Files Go allow you to perform and is really efficient with the following common operations: create (sub) folder, open folder/file, view, rename, move, copy, delete, play, share, etc.

7.2 Other applications⁽⁵⁾

The previous applications in this section are preinstalled on your device. To read a brief introduction of the preinstalled 3rd party applications, refer to the leaflet provided with the device. You can also download thousands of 3rd party applications by going to Google Play Store on your device.

⁽⁵⁾ Application availability depends on country and carrier .

8 Google applications

Google apps are preinstalled on your device to improve work efficiency and help you enjoy life.

This manual briefly introduces the apps. For detailed features and user guides, refer to related websites or the introduction provided in the apps.

You are recommended to register with a Google account to enjoy all the functions.

8.1 Gmail

As the Google's web-based email service, Gmail is configured when you first set up your device. With this application, you can receive and send mails, manage mails by labels, and archive mails, etc. Mails can be automatically synchronized with your Gmail account.

8.2 Maps Go

Google Maps offers satellite imagery, street maps, 360° panoramic views of streets, real-time traffic conditions, and route planning for traveling by foot, car, or public transportation. By using this application, you can get your own location, search for a place, and get suggested route planning for your trips.

8.3 YouTube

YouTube is an online video-sharing application where users can upload, view, and share videos. Available content includes video clips, TV clips, music videos, and other content such as video blogging, short original videos, and educational videos. It supports a streaming function that allows you to start watching videos almost as soon as they begin downloading from the Internet.

8.4 Play Store

Serves as the official app store for the Android operating system, allowing users to browse and download applications and games. Applications are either free of charge or at a cost.

In Play Store, search for the app you need, download it and then follow the installation guide to install the app. You can also uninstall, update an app, and manage your downloads.

8.5 Play Music

A music streaming service and online music locker operated by Google.

You can upload and listen to a large number of songs for free. In addition to offering music streaming for Internet-connected devices, the Google Play Music app allows music to be stored and listened to offline. Songs purchased through the Play Music are automatically added to the user's account.

9 Settings

To go to Settings, touch  from the Home screen, then touch **Settings**.

9.1 Network & Internet

9.1.1 Wi-Fi

Using Wi-Fi you can now surf the Internet without using your SIM card whenever you are in range of a wireless network. The only thing you have to do is to enter the **Wi-Fi** screen and configure an access point to connect your device to the wireless network.

For detailed instructions on using Wi-Fi, refer to “5.1.1 Wi-Fi”.

9.1.2 Tethering

This function allows you to share your device's Wi-Fi connection via USB or as a portable Wi-Fi access point (refer to “5.5 Sharing your device's Wi-Fi connection”).

9.1.3 VPN

A mobile virtual private network (mobile VPN or mVPN) provides devices with access to network resources and software applications on their home network, when they connect via other wireless or wired networks. Mobile VPNs are used in environments where workers need to keep application sessions open at all times, throughout the working day, as the user connects via various wireless networks, encounters gaps in coverage, or suspends-and-resumes their devices to preserve battery life. A conventional VPN can't survive such events because the network tunnel is disrupted, causing applications to disconnect, time out, fail, or even the computing device itself to crash.

For more information on VPN, refer to “5.6 Connecting to virtual private networks”.

9.2 Connected devices

This function allows you to use Bluetooth to connect your device to other devices. (refer to “5.3 connecting to Bluetooth devices”)

9.3 Apps & notifications

Touch to view details about the applications installed on your device, to manage their data usage and force them to stop.

In the App permissions menu of an application, you can grant permissions for the app, such as allowing the app to access your Camera, Contacts, Location, etc.

9.4 Battery

Touch any category in the battery management screen to view its power consumption.

You can adjust power use via the screen brightness or screen timeout settings in the Display screen.

9.5 Display

In this menu, you can adjust your screen brightness level, wallpaper, font size, etc.

MiraVision™

A Set of engines to enhance display picture quality

Brightness level

Touch to set the brightness of the screen or enable the automatic brightness mode.

Eye care

Touch to activate/disactivate eye care automatically.

Wallpaper

You choose the wallpaper of your screen from Gallery, Photos, or Wallpapers.

Sleep

Set your device to enter the sleep mode after a specified period of time, such as 1 minute or 30 seconds.

Auto-rotate screen

Set your device to rotate the screen contents or stay in portrait view when the device is rotated.

Font size

Touch to set the size of the fonts displayed on your screen.

Display size

This function makes the items on your screen smaller or larger. Some apps may change position.

Double tap screen

Touch to enable/disable it. If enabled, double tap to light up when screen is off.

9.6 Sound

- **Sound** Set volume for media, ringtone, notifications, and alarms.
- **Do not disturb preferences** Touch to allow alarms, reminders, calls, etc. when Do not disturb mode is enabled.
- **Default notification sound** Touch to set the default sound for notifications.
- **Default alarm sound** Touch to set the default sound for alarms.
- **Power on ringtone** Touch to disable the Power on ringtone.
- **Other sounds** Touch to set dial pad tones, screen locking sounds, touch sounds, power on & off ringtone..

9.7 Storage

Use these settings to monitor the total and available space on your device and touch to view the total memory and the memory used by applications.

9.8 Security & Location

Security status

-Google Play Protect

Touch to enable/disable Google Play Protect which can regularly checks your apps and device for harmful behavior when turns on.

-Find My Device

Check this function to remotely locate this device, or allow remote lock and erase.

-Security update

Check if your system is up to date, if not, touch **Check for update** to upgrade.

You can specify a maximum of five app shortcuts displayed on the lock screen.

Screen lock

Touch to set your screen unlock method. For example, you can unlock your device by sliding the screen, entering a password, or drawing a pattern, etc.

Lock screen preferences


Touch set the status show on the lock screen & Lock screen message, or add users from lock screen.

Smart Lock

Touch to set your device to automatically unlocked as long as it's in motion, like when you're holding or carrying your device. Your device will lock when it detects that it's been set down.

Location

-On

Touch the  switch to enable the use of information from Wi-Fi and mobile networks to determine your approximate location, for use in Google Maps, when you search, and so on. When you select this option, you're asked whether you consent to share your location anonymously with Google's location service.

-Mode

Touch to select High accuracy, Battery saving or Device only mode.

- **High accuracy:** Use GPS, Wi-Fi and mobile network to determine location.
- **Battery saving:** Use Wi-Fi to determine location.
- **Device only:** Use GPS to determine location.

-Recent location requests

This list shows the recent location requests.

Show passwords

Switch the toggle to show passwords as you type

Device admin apps

Touch to view or deactivate device administrators.

Encrypt & credentials

-Encryption

Requires a numeric PIN, pattern, or password to decrypt your device each time you power it on.

- Credential storage

- **Storage type:** Touch to check the hardware-backed
- **Trusted credentials:** Touch to display trusted CA certificates
- **User credentials:** Touch to view and modify stored credentials
- **Install from SD card:** Touch to install encrypted certificates from internal storage or SD card.

Trusted agents

View or deactivate trust agents.

Screen pinning

When this function is enabled, you can always keep a window in view by touching the **Overview** button and then the pin icon. In this case, the user cannot go to any other window or open any other app.

To stop pinning a window in view, long press both the **Back** and **Overview** keys together, then entering your screen unlock password or drawing your unlock pattern.

Apps with usage access

Touch to display the apps which can track what apps you are using, and the using frequency. You can switch the toggle to turn on/off the permission.

9.9 User & accounts

This feature allows you to add another user account. When a friend need to use your device, switch to the guest account so that information in the main account cannot be accessed.

9.10 Accessibility

Use the Accessibility settings to configure any accessibility plug-ins you have installed on your device.

Volume key shortcut

Touch to enable/disable quick activating for accessibility features.

Text-to-speech output

Touch to update the settings for text-to-speech output, such as the speech rate.

Font size

Touch to set the size of the fonts displayed on your screen.

Display size

This function makes the items on your screen smaller or larger. Some apps may change position.

Magnification

Touch to turn on/off to activate/deactivate zoom in/out function by triple-tapping the screen.

Color correction

Touch to turn on/off color correction.

Color inversion

Touch the switch to turn on/off color inversion.

Large mouse cursor

Touch the switch to activate large mouse cursor.

Click after cursor stops moving

Touch to activate/deactivate this function.

Auto-rotate screen

Touch the switch to activate auto-rotate screen. Content on the screen or the keyboard will be automatically rotated when you rotate your device.

Touch & hold delay

Touch to adjust the duration of touch and hold delay. This function enables your device to differ touch and touch & hold, which may avoid incorrect operations.

Mono audio

Touch to activate/deactivate combining channels when playing audio.

Captions

Touch to activate/deactivate captions for device screen.

High contrast text

Touch the switch to activate high contrast text.

9.11 Google

Touch to check Google services & preferences.

9.12 System

9.12.1 Language & input

Use the Language & input settings to select the language for the text on your device and for configuring the onscreen keyboard. You can also configure voice input settings and the pointer speed.

Language

Touch to select the language and the region you want.

Virtual keyboard

Touch to manage virtual keyboard.

Physical keyboard

Touch to set the physical keyboard.

Spell checker

Switch the toggle to enable the system to show suggested words.

Auto-fill service

Touch to set Auto-fill service for None or Auto-fill with Google


Personal dictionary

Touch to open a list of the words you've added to the dictionary. Touch a word to edit or delete it. Touch the add button (+) to add a word.

Pointer speed

Touch to open a dialog where you can change the pointer speed, touch **OK** to confirm.

Text-to-speech output

- **Preferred engine:** Touch to choose a Preferred text-to-speech engine, touch the settings icon  to show more choices for each engine.
- **Language:** Touch to choose language preferred.
- **Speech rate:** Touch to open a dialog where you can select how quickly you want the synthesizer to speak.
- **Pitch:** Touch to set the pitch you want the synthesizer to speak.

9.12.2 Date & time

Use Date & time settings to customize your preferences for how date and time are displayed.

Automatic date & time

Touch the switch to use the network-provided date and time.

Set date

Touch to open a dialog where you can manually set the device's date.

Set time

Touch to open a dialog where you can manually set the device's time.

Select time zone

Touch to open a dialog where you can set the device's time zone.

Use 24-hour format

Touch the switch to display the time using the 24-hour clock format.

9.12.3 Backup

Touch the switch to back up your device's settings and other application data to Google servers. If you replace your device, the settings and data you've backed up will be restored onto the new device for the first time you sign in with your Google account. If you mark this option, a wide variety of settings and data are backed up, including your Wi-Fi passwords, bookmarks, a list of the applications you've installed, the words you've added to the dictionary used by the onscreen keyboard, and most of the settings that you configure in the Settings application. If you unmark this option, you stop backing up your settings, and any existing backups are deleted from Google servers.

Backup account

Touch to set your backup account.

9.12.4 Reset options

Touch to reset your device.

DRM reset

Touch to delete all DRM licenses.

Reset Wi-Fi, Bluetooth

Touch to reset all network settings.

Reset app preferences

Touch to reset all preference for:

- Disabled apps
- Disabled app notificaitons
- Default applications for actions
- Background data restrictions for apps
- Any permission restrictions

Erase all data(factory reset)

Erase all of your personal data from internal device storage, including information about your Google account, any other accounts, your system and application settings, and any downloaded applications. Resetting the device does not erase any system software updates you've downloaded.

If you reset the device in this way, you're prompted to re-enter the same kind of information as when you first started Android.

When you are unable to power on your device, there is another way to perform a factory data reset by using hardware keys. Press the **Volume up** key and the **Power** key at same time until the screen lights up.

9.12.5 Regulatory & safety

Touch to view product information like Product model, Manufacture name/address, IMEI, Bluetooth Declaration ID, and some certification logo or text.

9.12.6 About tablet

This contains information ranging from Legal information, Model number, Firmware version, Baseband version, Kernel version, Build number to those listed below:

Status

This contains the status of the Battery status, Battery level, IP address, Wi-Fi MAC address, Bluetooth address, SN etc.

10 Upgrade

You can use the Mobile Upgrade tool or FOTA Upgrade tool to update your device's software.

10.1 Mobile Upgrade




Download Mobile Upgrade from alcatel website (www.alcatelmobile.com) and install it on your PC. Launch the tool and update your device by following the step by step instructions (refer to the User Guide provided together with the tool). Your device's software will now have the latest software.



All personal information will be permanently lost following the update process. We recommend you back up your personal data using Smart Suite before upgrading.

10.2 FOTA Upgrade

Use the FOTA (Firmware Over The Air) Upgrade tool to update your device's software. To access **Updates**, touch the Application tab from the Home screen, then select **Updates** or touch **Settings>System>System updates**.

Touch  and the device will search for the latest software. If you want to update the system, touch the  button, and when that's finished, touch  to complete the upgrade. Now your device will have the latest version of the software. You should turn on data connection or Wi-Fi before searching for updates. Settings for auto-check frequency are also available once you restart the device. If you have chosen auto-check, when the system discovers the new version, a dialog will pop up to choose download or ignore, the notification will also appear in status bar.

During FOTA downloading or updating, to avoid errors in locating the correct update packages, do not change your default storage location.

Accessories

The latest generation of Alcatel mobile devices offers a built-in handsfree feature that allows you to use the teledevice from a distance, placed on a table for example. For those who prefer to keep their conversations confidential, an earpiece is also available known as the headset.

1. Charger

2. USB cable



Only use the Alcatel chargers and accessories included along with your device.

2 Warranty

Your device is warranted against any defect or malfunctioning which may occur in conditions of normal use during the warranty period of twelve (12) months from the date of purchase as shown on your original invoice.

Batteries and accessories sold with your device are also warranted against any defect which may occur during the first six (6) months(1) from the date of purchase as shown on your original invoice.

In case of any defect of your device which prevents you from normal use thereof, you must immediately inform your vendor and present your device with your proof of purchase.

If the defect is confirmed, your device or part thereof will be either replaced or repaired, as appropriate. Repaired device and accessories are entitled to a one (1) month warranty for the same defect. Repair or replacement may be carried out using reconditioned components offering equivalent functionality.

This warranty covers the cost of parts and labor but excludes any other costs.

This warranty shall not apply to defects to your device and/or accessory due to (without any limitation):

- Non-compliance with the instructions for use or installation, or with technical and safety standards applicable in the geographical area where your device is used;
- Connection to any equipment not supplied or not recommended by TCL Communication Ltd.;
- Modification or repair performed by individuals not authorized by TCL Communication Ltd. or its affiliates or your vendor;
- Modification, adjustment or alteration of software or hardware performed by individuals not authorized by TCL Communication Ltd.;
- Inclement weather, lightning, fire, humidity, infiltration of liquids or foods, chemical products, download of files, crash, high voltage, corrosion, oxidation...

Your device will not be repaired in case labels or serial numbers (IMEI) have been removed or altered.

There are no express warranties, whether written, oral or implied, other than this

printed limited warranty or the mandatory warranty provided by your country or jurisdiction.

In no event shall TCL Communication Ltd. or any of its affiliates be liable for indirect, incidental or consequential damages of any nature whatsoever, including but not limited to commercial or financial loss or damage, loss of data or loss of image to the full extent those damages can be disclaimed by law.

Some countries/states do not allow the exclusion or limitation of indirect, incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

3 Troubleshooting

Before contacting the service center, here are some instructions to help you troubleshoot your device:

- To have optimal operation, fully charge the battery.
- To improve the device's performance, remove unnecessary files or apps on your device.
- To update your system software, use the System Updates command in your device's settings.
- To set your device to factory default, use the Backup & Reset in the device's settings, All your device data will be lost permanently. It is strongly advised to fully back up your device before resetting.

My device can't be switched on

- When the device can't be switched on, charge for at least 20 minutes to ensure the minimum battery power needed. Then switch it on again.

My device has not responded for several minutes

- If your device doesn't respond, turn off your device by pressing and holding the Power key until it turns off and then restart it again.
- If your device has a removable battery, remove the battery and reinsert it, then restart the device.

My device turns off by itself

- When your device turns off by itself, make sure that the Power key is not accidentally pressed.
- Check the battery charge level.
- Check your device's settings for turning off the device at a certain time.
- If it still doesn't work, Factory reset the device via the Backup & reset in the device's Settings. Make sure you have backed up your data.

My device can't charge properly

- Make sure that you are using the proper charger that comes with the device.
- If your device has a removable battery, make sure that your battery is inserted properly and the battery terminal makes a good contact with the device. It must be inserted before plugging in the charger.
- Make sure that your battery is not completely discharged; if the battery power has been discharged for a long time, it may take around 20 minutes to display the battery charging indicator on the screen.

- Make sure that charging is carried out under normal conditions (0°C (32°F) to 40°C (104°F)).
- When abroad, check that the voltage input is compatible.
- Check that the charging port is secured or it's not damaged.

My device can't connect to a network or "No service" is displayed

- Try connecting to the network by moving to another physical location.
- Make sure your device's setting is not in airplane mode.
- If you are away from your carrier's network, you may need to enable roaming in the device's settings to connect to other network. Roaming charges may apply.

My device can't connect to the internet

- Make sure that Cellular Data internet service is available in your wireless service plan.
- Check your device's settings. Make sure Cellular Data is enabled or Wi-Fi connected.
- Make sure that you are in a place with network coverage for cellular data or Wi-Fi internet connection.
- Try connecting at a later time or another location.

I can't use the features described in the manual

- Check with your carrier to make sure that your subscription includes this service.
- Make sure that this feature doesn't require any additional accessory.

I can't connect my device to my computer

- Install Smart Suite.
- Check that your USB driver is installed properly.
- Open the Notification panel to check if the Smart Suite Agent has been activated.
- Check that you have marked the USB debugging checkbox.
- Check that your computer meets the requirements for Smart Suite installation.
- Make sure that you're using the right cable from the box.

I can't download new files

- Make sure that there is sufficient device storage space for your download.
- Select the microSD card as the location to store downloaded files.
- Check your subscription status with your carrier.

The device can't be detected by others via Bluetooth

- Make sure that Bluetooth is turned on and your device is visible to other users.
- Make sure that the two devices are within Bluetooth's detection range.

The battery drains too fast

- Make sure that you follow the complete charge time (minimum 135 minutes).
- After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain an exact indication.
- Adjust the brightness of screen as appropriate.
- Extend the email auto-check interval for as long as possible.
- Update news and weather information on manual demand, or increase their auto-check interval.
- Exit background-running applications if they are not being used for extended periods of time.
- Deactivate Bluetooth, Wi-Fi, or GPS when not in use.

After Factory data reset is performed, I can't use my device without entering Google account credentials

- After reset is performed, you must enter the original Google account credentials that were used on this device.
- If you don't remember your Google account credentials, complete Google account recovery procedures.
- If you still cannot access your device, apply to the authorized repair center, but remember that it will not be regarded as warranty case.

I forget some passwords/codes/keys on device

- Perform Factory data reset.
- If you still cannot access your device, apply to the authorized repair center, but remember that it will not be regarded as warranty case.

I 4 Specifications

Processor	MT8321 Quad core 1.3GHz
Platform	Android 8.1(GO Edition)
Memory	1GB ROM + 16GB RAM
Dimensions (LxWxT)	255.9*155.4*9.35mm
Weight	415 g
Display	10.1 inch 800 X 1280 IPS
GPS	GPS
Network	Wi-Fi
Connectivity	<ul style="list-style-type: none"> • Bluetooth V4.2 • Wi-Fi 2.4GHz • 3.5 mm audio jack • micro-USB
Camera	<ul style="list-style-type: none"> • 5M+5M
Audio supported formats	<ul style="list-style-type: none"> • AAC LC, HE-AACv1 (AAC+), HE-AACv2 (enhanced AAC+), AAC ELD (enhanced low delay AAC), AMR-NB, AMR-WB, FLAC, MP3, MIDI, Vorbis, PCM/WAVE

Video supported formats	H.263, H.264 AVC, H.265 HEVC, MPEG-4 SP, VP8, VP9
Battery ⁽¹⁾	<ul style="list-style-type: none"> • Rechargeable Lithium-ion battery • Capacity: 4000 mAh (Typical)
Expansion Slot	microSD™ memory card, support up to 128GB microSD card (Availability of microSD card depends on market)
Special Features	<ul style="list-style-type: none"> • GPS • G-sensor • Parental Center

Note: Specifications are subject to change without prior notice. ⁽⁶⁾

⁽⁶⁾ The original battery has undergone rigorous safety inspections to meet qualification standards, the use of non-original batteries may be dangerous.